

Linear Sigma Series

Setup Manual





Linear Sigma Series, Setup Manual

Responsible Section: Motor Tech. Dept., Linear Mechatronics Tech. Section

This manual describes the setup procedure to operating properly when Linear series motor and the driver are combined.

Refer to the following manuals and specification manuals for other matters (Connection with host controller, Adjustment etc.).

- **Linear Sigma series SGL___/SGDD User's Manual**
- **Design and Maintenance: SIZ-S800-39.1**
- **Linear - Sigma -II series SGL___/SGDH User's Manual**
- **Design and Maintenance: SIZ-S800-39.2**
- **Sigma -II series SGM_H/SGDH User's Manual**
- **Servo Selection & Data Sheet: SI-S800-32.1**
- **Design and Maintenance: SI-S800-32.2**
- **AC servo packing SGDH-___EY213 Manufacture Specifications: DE0401783**



Contents

LINEAR SIGMA SERIES, SETUP MANUAL	2
1.1 FOR LINEAR MOTOR WITH POLE SENSOR	4
1.1.1 <i>Installation and Wiring of Motor and Linear Scale</i>	4
1.1.2 <i>Scale Pitch Parameter Setting</i>	5
1.1.3 <i>Feedback Signal Verification</i>	6
1.1.4 <i>Trial Operation by Panel Operator (Jog Mode Operation)</i>	9
1.1.5 <i>Torque Limit Parameter Setting</i>	10
1.2 FOR LINEAR MOTOR WITHOUT POLE SENSOR	11
1.2.1 <i>Installation and Wiring of Motor and Linear Scale</i>	11
1.2.2 <i>Scale Pitch Parameter Setting</i>	12
1.2.3 <i>Setting of Pole Sensor Unused</i>	12
1.2.4 <i>Feedback Signal Verification</i>	13
1.2.5 <i>Magnetic Pole Detection Start Signal/P-DET Setting of Input Allocation</i>	15
1.2.6 <i>Mass Ratio Setting</i>	15
1.2.7 <i>Over Travel Signal Setting</i>	16
1.2.8 <i>Torque Limit Parameter Setting</i>	16
1.2.9 <i>Verification of Magnetic Pole Detecting Operation</i>	16
1.2.10 <i>Trial Operation by Panel Operator (JOG Mode Operation)</i>	17
2 SGDD TYPE SERVO AMPLIFIER SETUP PROCEDURE	18
2.1 MOTOR AND LINEAR SCALE INSTALLATION AND WIRING	18
2.2 LINEAR ENCODER RESOLUTION (BEFORE QUADRATURE) SETTING	19
2.3 FEEDBACK SIGNAL VERIFICATION	20
2.4 SETTING OF MAGNETIC POLE DETECTION BEGINNING TIMING	22
2.5 MASS RATIO SETTING	22
2.6 OVER TRAVEL SIGNAL SETTING	22
2.7 VERIFICATION OF MAGNETIC POLE DETECTION	23
2.8 TRIAL OPERATION BY PANEL OPERATOR	24
2.9 TRIAL OPERATION BY POSITIONING CONTROL	24
3 DIFFERENCE FROM SGDH- EY213	25
3.1 MOTOR PEAK SPEED SETTING	25
3.2 CURRENT COMMUTATION DIRECTION SETTING OF MOTOR WITH POLE SENSOR (NOTE 1)	25
3.3 ERROR DETECTION OF FREQUENCY DIVIDING OUTPUT SETTING (NOTE 1)	25
3.4 POLE SENSOR SIGNAL MONITOR (NOTE 1)	25



SGDH Type Servo Amplifier Setup Procedure

As for the SGDH type servo amplifier, the setup method is different when linear motor with a pole sensor, and linear motor without a pole sensor. Refer to the suitable setup procedure for the system.

1.1 For Linear Motor with Pole Sensor

1.1.1 Installation and Wiring of Motor and Linear Scale


Install a moving coil and linear scale to make the motor forward direction, and the linear scale count-up be in the same direction.

(Note)

When a forward direction of a motor and linear scale count are not in the same direction, and when a motor is moved under such a condition, the motor might not move or might run away.

Motor forward direction is on a cable drawing side for the linear series motor (moving coil direction, when electric current flows into the phase in order of UVW).

An analog 1Vp-p voltage input, which is input from the linear scale to a serial exchange unit, is counted up at A-phase (cos signal) progress.





[When the motor forward direction, and the linear scale count-up direction are not the same]

When the motor forward direction and the linear scale count direction become opposite direction by the reason such as wirings etc., it is possible to move the motor only with SGDH-___EY213 by setting the user parameter. (Restrictions can apply to a software version. Refer to (Note1) in chapter 3.

When it is possible to handle by the parameter, set it to Parameter Pn080 1=1 and then, cycle power. By the procedure, the servo amplifier considers the direction of the linear scale countdown to be a motor forward direction, and controls the electric current phase.

When other servo amplifiers are used, a hardware countermeasure is needed. Refer to (2) "Verification of the **conformance** for the motor forward direction and scale count direction" in 1.1.3 "Feedback Signal Verification" for details.

(Note)

There is the first digit of Pn080 setting on the SGDH-___E. This setting is for pole sensor using only. The first digit setting of Pn080 should not be changed when pole sensor is used.

Do wiring for the servo amplifier after the installation is completed. Refer to "Linear - Sigma - Series SGL_/SGDH User' s Manual Design & Maintenance in Chapter 2 (Wiring)"

1.1.2 Scale Pitch Parameter Setting


Turn the servo amplifier power supply on (only a control source is preferable), and set the scale pitch. Set with user parameter Pn280 [unit: μm]. After the setting is completed, cycle power to activate the parameter.

(Note)

When Pn280 is not correctly input, motor control cannot be done. Set to the proper value before the motor operation. For the first time use only, "Alarm A.08" occurs, but this is just a reminder for the parameter Pn280 setting. The alarm will be cleared once the correct value is set, and cycled power.

Scale pitch (Pn280)

= Distance for analog voltage feedback signal one cycle



The distance 1/256 of the scale pitch is controlled as a minimum feedback pulse in the servo amplifier (counting with 1/256 of the scale pitch in the serial conversion unit).



1.1.3 Feedback Signal Verification

Verify whether the signal from the linear scale is properly received, and the motor forward direction and linear scale count direction are the same at the installation of 1.1.

(Note)

Make sure to verify the feedback signal before the motor operation. Otherwise motor might not move, and runaway.

(1) Verify whether the Scale Signal is Read Properly

First of all, turn the servo amplifier power supply on (only a control source is preferable) and then, make the servo to Off state. Second, display the monitor Un00D (Feedback pulse monitor, Hex display) with a digital operator or built-in panel operator in the state. Third, move the motor only the distance of the arbitrary by hand. Finally, verify whether the only correct feedback pulse number is returned.

(Example):

Assume that the linear scale of scale pitch 20µm is used. When the motor is moved in the direction of 1cm count up by hand. The feedback pulse is $1\text{cm}/(20\mu\text{m}/256) = 128000$ pulse (1F400Hex pulse). So the display of Un00D should just be "H.0001", "L.F400" (H: Upper 16 bit data, L: Lower 16 bit data).

(Note):

It is OK when the value is close to the above-mentioned value, since an actual display is shifted by the error of travel distance.




Illustration of the above-mentioned example
When a motor is moved 1cm by hand, it is OK, if Un00D counts only the portion.



[Value of Un00D is Incorrect]

The following situations can be considered.

Linear scale pitch is not suitable

The feedback pulse same as the assumed value is not returned when a set scale pitch with Pn280, and an actual scale pitch are different. Verify the scale specification.

The linear scale is not adjusted

When the scale is not adjusted, the output signal level goes down and proper countdown cannot be done. Verify whether the adjustment is proper.


The wiring between the scale serial conversion units is incorrect

When the wiring is incorrect, proper count cannot be done. Review the wiring.

(2) Conformance verification of motor forward direction and scale count direction

Verify whether the monitor Un00D is counted up when the monitor-moving coil is moved by hand to the lead drawing side.

(The upper 16 bit data must increase as 1,2,3... When it is changed as FFFF, FFFE, FFFD, it means the value is counted down.)



[Value of UN00D is counted down]

When Un00D is counted down, reverse the count direction by using one of the following methods

- Reverse the installation direction of the moving coil (Reverse the direction of the moving coil with lead drawing exit).
- Reverse the scanning direction of the scale head.
- Replace the scale signal of the B phase + (sin) signal and B phase -(/sin) signal.




(3) Verify whether the feedback with entire stroke is normal

Move the moving coil of two magnets of magnet track by hand and then, verify whether the value of monitor Un004 (Motor electrical angle monitor, Unit [°]) is returned to the original value. Also verify whether it becomes in the same condition with entire stroke.

(Example)

Assume that the position of Un004 value before the moving coil is moved is 30. It is OK when the monitor value returns to 0 after the monitor value is counted up to 360, and it counts up to 30 again at the place where two magnets is completed moving in the case of the moving coil is moved to the motor forward direction.



[Value of Un004 is not returned to the original value]

The following situations can be considered

❑ **Linear scale pitch is not suitable**

The feedback pulse same as the assumed value is not returned when a set scale pitch with Pn280, and an actual scale pitch are different. Verify the scale specification.

❑ **The linear scale is not adjusted**

When the scale is not adjusted, the output signal level goes down and proper countdown cannot be done. Verify whether the adjustment is proper.

❑ **The wiring between the scale serial conversion units is incorrect**

When the wiring is incorrect, proper count cannot be done. Review the wiring.



1.1.4 Trial Operation by Panel Operator (Jog Mode Operation)

(Note)

The trial run should be done in non-load condition as much as possible. Set the mass ratio (parameter Pn103) before the operation when the load is put on. Measure the mass by pulling the moving coil with the load by spring scale etc. (All the motor lines must be unconnected). Pn103 is obtained from the following formula.

$$\text{Mass Ratio (Pn103)} = \left[\frac{\text{Load Mass (Including Motor Moving Coil Mass)}}{\text{Motor Moving Mass}} - 1 \right] \times 100[\%]$$

After the verification of 1.1.2 and 1.1.3, do trial operation with the following procedure.

- (1) Turn the control power and main circuit power supply on.
- (2) Move the motor by operating a digital operator in the JOG mode.
 Refer to the "Sigma - Series SGM_H/SGDH User's Manual Design/Maintenance - Chapter 7.2.2 "Operation by digital operator" for the operation method.

(Note)

Stay away from the motor, since the motor might run away at the time of Servo ON in the beginning.

- (3) Verify whether the motor moves properly from the edge to the edge of the stroke.

[Trial operation is not done well]

The following situations can be considered

- Torque reference is saturated because the load is too heavy or JOG speed is too fast.**
 Try the torque limit parameter setting. Refer to 1.1.5. If the torque reference is still saturated, lighten the load or slow down the Jog speed.
- Motor stops moving, after a moment movement. (1)**
 Motor is in a reverse moving when the motor moves in reverse direction by pressing © key on the panel operator, or when the motor moves in forward direction by pressing ™ key on the panel operator in the Jog operation mode. Verify the motor wiring, and "Feedback Signal"(1.1.3).
- Motor stops moving, after a moment movement. (2)**
 The scale pitch is not set correctly or scale signal is not read correctly when the motor moves in forward direction by pressing © key on the panel operator, or when the motor moves in reverse direction by pressing ™ key on the panel operator in the Jog operation mode. Verify "Scale Pitch Parameter Setting" (1.1.2) and "Feedback Signal"(1.1.3).
- When the motor is moved, alarm A.C2 occurs**
 There are possibilities that the scale signal count direction is incorrect or counting is incorrect. Verify "Feedback Signal"(1.1.3). When the counting is correctly done, it might malfunction by noise. Verify the wiring and grounding condition of the Servo amplifier, serial conversion unit, and linear motor.



1.1.5 Torque Limit Parameter Setting

The factory setting of the torque limit parameter (Pn483, Pn484 Unit: [%/Rated Torque]) of SGDh is decreased for hazard prevention for motor set up (Factory Setting: 30[%]).

When the motor moves in forward direction by pressing © key on the panel operator in the Jog operation mode, increase the parameter value up to the used torque. (Increase up to the maximum value when there is no condition)

The setup is completed when the all above-mentioned is verified.



1.2 For Linear Motor without Pole Sensor

1.2.1 Installation and Wiring of Motor and Linear Scale


Install a moving coil and linear scale to make the motor forward direction, and the linear scale count-up be in the same direction.

(Note)

When a forward direction of a motor and linear scale count are not in the same direction, and when a motor is moved under such a condition, the motor might not move or might run away.

Motor forward direction is on a cable drawing side for the linear Sigma series motor (moving coil direction, when electric current flows into the phase in order of UVW).

An analog 1Vp-p voltage input, which is input from the linear scale to a serial exchange unit, is counted up at A-phase (cos signal) progress



[When the direction of the motor forward, and the linear scale count-up are not in the same]

- ❑ When the motor forward direction and linear scale count direction become opposite direction because of the reason such as wirings etc., it is possible to move the motor by changing user parameter setting.
- ❑ Refer to (2) “Verification of the conformance for the motor forward direction and scale count direction” in the chapter 1.2.4 “Feedback Signal” for details.
- ❑ Do the wiring for the servo amplifier after the installation is completed. Refer to “Linear Sigma - Series SGL_/SGDH User’ s Manual Design & Maintenance-Chapter 2 Wiring”




1.2.2 Scale Pitch Parameter Setting

Turn the servo amplifier power supply on (only a control source is preferable), and set the scale pitch. Set with the user parameter Pn280 [unit: μm]. After the setting is completed, cycle power to activate parameter. When Pn280 is not correctly input, motor control cannot be done.

(Note)

For the first time use only, "Alarm A.08" occurs, but this is just a reminder for the parameter Pn280 setting. The alarm will be cleared once the correct value is set and cycled power.

Scale pitch (Pn280)
= Distance for analog voltage feedback signal one cycle



The distance $1/256$ of the scale pitch is controlled as a minimum feedback pulse in the servo amplifier (counting with $1/256$ of the scale pitch in the serial conversion unit).

1.2.3 Setting of Pole Sensor Unused

Set the pole sensor unused, following the 1.2.2. Set with the 0th digit (The rightmost digit of the digital operator: (Described as Pn080.0)of user parameter to Pn080. Change the setting from the factory setting 0 (with pole sensor) to 1 (without pole sensor).When the setting is completed, cycle power to activate the parameter.

(Note)

Alarm A.04 occurs when the power is turned on in the case of the pole sensor is not connected with the setting of Pn080.0=0, or the pole sensor is connected with the setting of Pn080.0=1.



1.2.4 Feedback Signal Verification

Verify whether the signal from the linear scale is properly received, and motor forward direction and linear scale count direction are the same at the installation of 1.1.

(1) Scale Signal Verification


First of all, turn the servo amplifier power supply on (only a control source is preferable) and then, make the servo to Off state. Second, display the monitor Un00D (Feedback pulse monitor, Hex display) with a digital operator or built-in panel operator in the state. Third, move the motor only the distance of the arbitrary by hand. Finally, verify whether the only correct feedback pulse number is returned.

(Example)

Assume that the linear scale of scale pitch $20\mu\text{m}$ is used. When the motor is moved in the direction of 1cm count up by hand, the feedback pulse is $1\text{cm}/(20\mu\text{m}/256) = 128000$ pulse (1F400Hex pulse). So the display of Un00D should just be "H.0001", "L.F400" (H: Upper 16 bit data, L: Lower 16 bit data).

(Note)

It is OK when the value is close to the above-mentioned value, since an actual display is shifted by the error of travel distance.



❑ Linear scale pitch is not suitable

The feedback pulse same as the assumed value is not returned when a set scale pitch with Pn280, and an actual scale pitch are different. Verify the scale specification.

❑ The linear scale is not adjusted

When the scale is not adjusted, the output signal level goes down and proper countdown cannot be done. Verify whether the adjustment is proper.

❑ The wiring between the scale serial conversion units is incorrect


When the wiring is incorrect, proper count cannot be done. Review the wiring.



(2) Conformance verification of motor forward direction and scale count direction

Verify whether the monitor Un00D is counted up when the monitor-moving coil is moved by hand to the lead drawing side.

(The upper 16 bit data must increase as 1,2,3... When it is changed as FFFF, FFFE, FFFD, it means the value is counted down.).



[Value of Un00D is counted down]


When the value of Un00D is counted down, change the setting of user parameter Pn080.1. To activate the setting, change the factory setting Pn080.1=0 to 1, and then cycle control power. In this case, servo amplifier considers the direction of the linear scale countdown to be a motor forward direction and controls the electric current.

(3) Verify whether the feedback with the entire stroke is normal

Move the moving coil of two magnets of magnet track by hand and then verify whether the value of monitor Un004 (Motor electrical angle monitor, Unit [°]) goes back to the original value. Also verify whether it becomes in the same condition with entire stroke.

(Example)

Assume that the value of Un004 at the position before the moving coil is moved is 30. It is OK when the monitor value returns to 0 after the monitor value is counted up to 360 and it counts up to 30 again in the place which it completed moving by two magnets in the case of the moving coil is moved to the motor forward direction.





[Value of Un004 is not returned to the original value]

The following situations can be considered

Linear scale pitch is not suitable

The feedback pulse the same as the assumed value is not returned when a scale pitch set with Pn280 and an actual scale pitch are different. Verify the scale specification.

The linear scale is not adjusted

When the sale is not adjusted, the output signal level goes down and proper countdown cannot be done. Verify whether the adjustment is proper.

The wiring between the scale cereal conversion units is incorrect

When the wiring is incorrect, a proper count cannot be done. Review the wiring.

1.2.5 Magnetic Pole Detection Start Signal/P-DET Setting of Input Allocation

For the linear motor without a pole sensor, it is necessary to detect the magnetic pole after the power supply is turned on.

When the input signal allocation mode is a factory setting (SGDB compatible mode, Pn50A.0=0), the magnetic pole detection is begun synchronizing with the servo ON (/S-ON) signal and the servo ready (/S-RDY) signal is turned on at the same time with detection's ending.

When the servo ready signal is observed and the sequence of the servo on signal output is united by the host controller or to detect the magnetic pole according to timing different from the servo on signal, it is necessary to allocate the magnetic pole detection start signal (/P-DET) to the arbitrary input terminal.

After it is set as user parameter Pn50A.0=1(input signal allocation is freely settable), allocate /P-DET signal to the arbitrary input terminal by Pn50D.3. After completing the allocation, cycle power to activate the parameter.

1.2.6 Mass Ratio Setting

Set the mass ratio (parameter Pn103) before the magnetic pole detecting operation. Measure the mass by pulling the moving coil with the load by spring scale etc. (all motor lines must be unconnected).

Pn103 is obtained from the following formula.

$$\text{Mass Ratio (Pn 103)} = \left[\frac{\text{Load Mass (Including Motor Moving Coil Mass)}}{\text{Motor Moving Mass}} - 1 \right] \times 100[\%]$$



1.2.7 Over Travel Signal Setting

When it is in over-travel state, the magnetic pole detection cannot be begun. Connect the signal conductor and put it into the base block state when the over-travel function is used. Set the user parameter to Pn50A.3=8, Pn50B.0=8(OT signal is invalid) when the over-travel function is not used. Then cycle power.

1.2.8 Torque Limit Parameter Setting

The factory setting of the torque limit parameter (Pn483, Pn484 Unit: [%/Rated Torque]) for SGDH is reduced for hazard prevention for motor set up (Factory Setting: 30[%]).

The motor does not runaway after the setting completion of the scale pitch parameter and the verification completion of the feedback signal. So increase the parameter value up to the used torque. (Increase up to the maximum value when there is no condition) The magnetic pole detection might not operate properly when the limitation is too much.

1.2.9 Verification of Magnetic Pole Detecting Operation

Verify whether the magnetic pole detection is done properly.

After inputting both control sources and main circuit power supply, input /S-ON signal (When the magnetic pole detection start signal is used: /P-DET signal) and then detect the magnetic pole.

When the operator display is “bb” at power supply is turned on, it displays “Pdt” while detecting the magnetic pole and it returns to “bb” when the detection is completed.

(Note)

While detecting the magnetic pole, current flows to the motor. Be careful with an electric shock.

Moreover, stay away from the motor since the motor might move greatly while detecting.

After the detection is completed, verify the electrical angle with monitor Un004 by pressing the motor against the stroke end. After the verification, separate the motor from the stroke end some degree (It is preferable to separate by 10mm or more). Then detect the magnetic pole gain after cycling power.

As for the magnetic pole detection, if the gap of the electrical angle is within $\pm 10^\circ$, in a repeated operation of three times or more, this detection is appropriate.

[Magnetic pole detection is not performed properly]

The following situation can be considered.

Magnetic pole detection speed loop gain parameter (Pn481) is small.

Enlarge Pn481 setting when the electrical angle is greatly different every time and when it is hard to tell whether the detected motor is moving in the performance of the magnetic pole detection.

Used scale resolution is too rough.

It is effective to increase the used scale resolution when alarm A.C5 occurs while the magnetic pole detection. The minimum pulse resolution should be $5\mu\text{m}$ or less (scale pitch is 1.28mm or less) for SGDH. The magnetic pole can surely be detected when the minimum resolution is $1\mu\text{m}$ or less. Consult a technical engineer when a scale is larger than above-mentioned since the adjustment of the magnetic pole detection is needed.

The linear scale signal cannot be read properly

Go through the set up procedure of 1.2.2, 1.2.3, and 1.2.4. Then verify whether the scale and parameter are set properly.

It is necessary to adjust the parameter for the magnetic pole detection when the magnetic pole detection is not performed properly even if the above-mentioned countermeasure is done. Because the parameter for the magnetic pole detection is being kept in the system parameter excluding the speed loop gain and



the speed loop integral time constant for SGDh, the user cannot adjust the parameter. Consult a technical engineer when adjustment is needed.

1.2.10 Trial Operation by Panel Operator (JOG Mode Operation)

After the verification from 1.2.1 through 1.2.9, do trial operation using the following procedures.

(Note)

Do the Trial Operation with Non-Load as Much as Possible.

- (1) Turn the control power and main circuit power supply on.
- (2) Move the motor by operating a digital operator in the JOG mode.

Refer to the “Σ-II Series SGM_H/SGDH User's Manual Design & Maintenance-Chapter 7.2.2 Operation by digital operator” for the operation method.

(Note)

Stay away from the motor, since the motor might run away at the time of Servo ON in the beginning.

- (3) Verify whether the motor moves properly from the edge to the edge of the stroke.

[Trial operation is not done well]

The following situations can be considered

- ❑ **Torque reference is saturated because the load is too heavy or JOG speed is too fast.**

Lighten the load or slow down the Jog speed.

- ❑ **Motor stops moving, after a moment movement. (1)**

Motor is in a reverse moving when the motor moves in reverse direction by pressing \odot key on the panel operator, or when the motor moves in forward direction by pressing TM key on the panel operator in the Jog operation mode. Verify the motor wiring and “Feedback Signal Verification”(1.2.4).

- ❑ **Motor stops moving, after a moment movement. (2)**

The scale pitch is not set correctly or scale signal is not read correctly when the motor moves in forward direction by pressing \odot key on the panel operator, or when the motor moves in reverse direction by pressing TM key on the panel operator in the Jog operation mode. Verify “Scale Pitch Parameter Setting” (1.2.2) and “Feedback Signal” (1.2.4).

- ❑ **When the motor is moved, alarm A.C2 occurs**

There is a possibility that the Feedback count is incorrect. Verify “Feedback Signal” (1.2.4). When the counting is done correctly, it might malfunction by noise. Verify the wiring and grounding condition of the Servo amplifier, serial conversion unit, and linear motor.

The setup is completed when the all above-mentioned is verified.



2 SGDD Type Servo Amplifier Setup Procedure

2.1 Motor and Linear Scale Installation and Wiring


Install a moving coil and linear scale to make the motor forward direction, and the linear scale count-up be in the same direction.

(Note)

When a forward direction of a motor and linear scale count are not in the same direction, and when a motor is moved under such a condition, the motor might not move or might run away.

Motor forward direction is on a cable drawing side for the linear Σ series motor (moving coil direction, when electric current flows into the phase in order of UVW).

The 90° phase differential two-phase pulse train input, which is input from the linear scale to the servo amplifier is counted up at B phase progress.



[When the direction of the motor forward, and the linear scale count-up are not in the same]

When the motor forward direction and linear scale count direction become opposite direction because of the reason such as wirings etc., it is possible to move the motor by changing user parameter setting.

Refer to (2) “Verification of the conformance for the motor forward direction and scale count direction” in the chapter 1.2.3 “Feedback Signal” for details.

Do the wiring for the servo amplifier after the installation is completed. Refer to “Linear Σ -II Series SGL_/_/SGDH User’s Manual Design & Maintenance-Chapter 2 Wiring”



2.2 Linear Encoder Resolution (before quadrature) Setting

Turn the servo amplifier power supply on (only a control source is preferable), and set the linear encoder resolution (before quadrature). Set with the user parameter Pn280 [unit: 0.01 μ m]. After the setting is completed, cycle power to activate the parameter. When Pn209 is not correctly input, motor control cannot be done.

(Note)


For the first time use only, "Alarm A.08" occurs, but this is just a reminder for the parameter Pn209 setting. The alarm will be cleared once the correct value is set and cycled power.

Scale pitch (Pn280)

= Distance for analog voltage feedback signal one cycle

Setting Procedure:

Set the distance between rising edges of the phase in the one side of 90° phase differential two-phase pulse train feedback signal.



The distance 1/4 of the linear encoder resolution (Pn209) is controlled as a minimum feedback pulse in the servo amplifier.



2.3 Feedback Signal Verification

Verify whether the signal from the linear scale is properly received, and motor forward direction and linear scale count direction are the same at the installation of 1.1.

(1) Scale Signal Verification

First of all, turn the servo amplifier power supply on (only a control source is preferable) and then, make the servo to Off state. Second, display the monitor Un00D (Feedback pulse monitor, Hex display) with a digital operator or built-in panel operator in the state. Third, move the motor only the distance of the arbitrary by hand. Finally, verify whether the only correct feedback pulse number is returned.


(Example)

Assume that the linear scale of 1 μ m liner encoder resolution (Assume that the setting is parameter Pn209 = 400: resolution after quadrature) is used.

When the motor is moved in the direction of 1cm count up by hand, the feedback pulse is 1cm/1 μ m=10000 pulse (2710 Hex pulse). So the display of Un00D should just be "H.0000", "L.2710" (H: Upper 16 bit data, L: Lower 16 bit data)

(Note)

It is OK when the value is close to the above-mentioned value, since an actual display is shifted by the error of travel distance.



[Value of Un00D is incorrect]

The following situations can be considered

Linear scale resolution setting is not suitable

When the linear encoder resolution and the actual scale resolution set by Pn209 are different, the assumed feedback pulse value is not returned. Verify the scale specification.

The linear scale is not adjusted

When the scale is not adjusted, the output signal level goes down and proper countdown cannot be done. Verify whether the adjustment is proper.

The wirings between the scale servo amplifier are incorrect


When the wiring is incorrect, a proper count cannot be done. Review the wiring.



(2) Conformance verification of motor forward direction and scale count direction

Verify whether the monitor Un00D is counted up when the monitor-moving coil is moved by hand to the lead drawing side.

(The upper 16 bit data must increase as 1,2,3... When it is changed as FFFF, FFFE, FFFD, it means the value is counted down.).



[Value of Un00D is counted down]


When the value of Un00D is counted down, change the setting of the user parameter Pn007.2. To activate the setting, change the factory setting Pn007.2=0 to 1, and then cycle control power. In this case, servo amplifier considers the direction of the linear scale countdown to be a motor forward direction and controls the electric current.

(3) Verity whether the feedback with the entire stroke is normal

Move the moving coil of two magnets of magnet track by hand and then verify whether the value of monitor Un004 (Motor electrical angle monitor, Unit [°]) goes back to the original value. Also verify whether it becomes in the same condition with entire stroke.

(Example)

Assume that the value of Un004 at the position before the moving coil is moved is 30. It is OK when the monitor value returns to 0 after the monitor value is counted up to 360 and it counts up to 30 again in the place which it completed moving by two magnets in the case of the moving coil is moved to the motor forward direction.





[Value of Un004 is not returned to the original value]

The following situations can be considered

Linear scale resolution setting is not suitable

When the linear encoder resolution and the actual scale resolution set by Pn209 is different, the assumed feedback pulse value is not returned. Verify the scale specification.

The linear scale is not adjusted

When the scale is not adjusted, the output signal level goes down and proper countdown cannot be done. Verify whether the adjustment is proper.

The wiring between the scale cereal conversion units is incorrect

When the wiring is incorrect, a proper count cannot be done. Review the wiring.

2.4 Setting of Magnetic Pole Detection Beginning Timing

For linear motor without the pole sensor, it is necessary to detect the magnetic pole after the power supply is turned on.

For the SGDD type servo amplifier, magnetic pole detection start signal /M is allocated to I1 (CN1-41) at shipping. /M-SET signal needs to be provided to use as it is.

When /M-SET signal is not used, set the user parameter to Pn007.0=1 and then, cycle power. As a result, the magnetic pole detection is done synchronizing with the servo on signal (/S-ON).

2.5 Mass Ratio Setting

Set the mass ratio (parameter Pn103) before the magnetic pole detecting operation. Measure the mass by pulling the moving coil with the load by spring scale etc. (all motor lines must be unconnected).

Pn103 is obtained from the following formula.

$$\text{Mass Ratio (Pn103)} = \left[\frac{\text{Load Mass (Including Motor Moving Coil Mass)}}{\text{Motor Moving Mass}} - 1 \right] \times 100[\%]$$

2.6 Over Travel Signal Setting

When it is in over-travel state, the magnetic pole detection cannot be begun. Connect the signal conductor and put it into the base block state when the over-travel function is used. Set the user parameter to Pn50A.3=8, Pn50B.0=8(OT signal is invalid) when the over-travel function is not used. Then cycle power.

Moreover, detecting the magnetic pole regardless of the over travel signal state, set to Pn007.3=1 (Before completing the magnetic pole detection, the OT mask should be done) and then, cycle power.



2.7 Verification of Magnetic Pole Detection

Verify whether the magnetic pole detection is done properly. After inputting both control source and main circuit power supply, input /MSET signal (/S-ON when the setting is Pn007.0=1) and then detect the magnetic pole.

(Note)

While detecting the magnetic pole, current flows to the motor. Be careful with an electric shock. Moreover, stay away from the motor since the motor might move greatly while detecting.

After the detection is completed, verify the electrical angle with monitor Un004 by pressing the motor against the stroke end. After the verification, separate the motor from the stroke end some degree (It is preferable to separate by 10mm or more). Then detect the magnetic pole gain after cycling power.

As for the magnetic pole detection, if the gap of the electrical angle is within $\pm 10^\circ$, in a repeated operation of three times or more, this detection is appropriate.

[Magnetic pole detection is not performed properly]

The following situation can be considered.

Magnetic pole detection speed loop gain parameter (Pn413) is small.

Enlarge Pn413 setting when the electrical angle is greatly different every time and when it is hard to tell whether the detected motor is moving in the performance of the magnetic pole detection.

Used scale resolution is too rough.

It is effective to increase the used scale resolution when alarm A.C5 occurs while the magnetic pole detection. The minimum pulse resolution should be 5 μ m or less (Pn209=2000 or less) for SGDD. The magnetic pole can surely be detected when the minimum resolution is 1 μ m or less. Consult a technical engineer when a scale is larger than above-mentioned since the adjustment of the magnetic pole detection is needed.

The linear scale signal cannot be read properly

Go through the set up procedure of 2.2, 2.3. Then verify whether the scale and parameter are set properly.

It is necessary to adjust the parameter for the magnetic pole detection when the magnetic pole detection is not performed properly even if the above-mentioned countermeasure is done. Consult the technical engineer when the adjustment is needed.



2.8 2Trial Operation by Panel Operator

After the verification from 2.1 through 2.7, do trial operation by using the following procedures.

(Note)

Do the Trial Operation with No-Load as Much as Possible.

- (1) Turn the control power and main circuit power supply on.
- (2) Move the motor by operating a digital operator in the JOG mode.

Refer to the “Σ-II Series SGM_H/SGDH User’s Manual Design & Maintenance-Chapter 7.2.2 Operation by digital operator” for the operation method.

(Note)

Stay away from the motor, since the motor might run away at the time of Servo ON in the beginning.

- (3) Verify whether the motor moves properly from the edge to the edge of the stroke.

[Trial operation is not done well]

The following situation can be considered

- ❑ **Torque reference is saturated because the load is too heavy or JOG speed is too fast.**

Slow down Jog speed or lighten the load.

- ❑ **Motor stops moving, after a moment movement. (1)**

Motor is in a reverse moving when the motor moves in reverse direction by pressing © key on the panel operator, or when the motor moves in forward direction by pressing ™ key on the panel operator in the Jog operation mode. Verify the motor wiring and “Feedback Signal Verification”(2.3.)

- ❑ **Motor stops moving, after a moment movement. (2)**

The linear encoder resolution is not set correctly or scale signal is not read correctly when the motor moves in forward direction by pressing © key on the panel operator, or when the motor moves in reverse direction by pressing ™ key on the panel operator in the Jog operation mode. Verify (2.2) and (2.3).

2.9 Trial Operation by Positioning Control

When the trial run by JOG is completed, repeat positioning between arbitrary two points by position control of the servo amplifier or the host controller. Then verify whether any changes have been made with the operation in about one hour.

[Trial operation is not done well]

The following situations are considered when there is a change in operation.

- ❑ **The position shifts. Or, the torque reference gradually grows.**

There is a possibility that feedback count is not appropriate. Verify 2.3 “Feedback Signal Verification”. When the counting is appropriate, it might be malfunctioned by noise. Verify the wiring and the ground condition of the servo amplifier and linear motor.

The setup is completed when all the above-mentioned is verified.



3 Difference from SGDH-___EY213

SGDH-___EY213 is a servo amplifier dedicated for the linear, which has improved features and performances of SGDH-___E. The following features are different from SGDH-___E.

3.1 Motor Peak Speed Setting

Motor peak speed can be set by user parameter for Y213. Pn384: Motor Peak Speed [Unit: 100mm/s]

It is possible to increase the speed control resolution by decreasing the parameter value. The speed ripple and stop accuracy performance might be improved by increasing the speed control resolution.

3.2 Current Commutation Direction Setting of Motor with Pole Sensor (Note 1)

Set the user parameter to Pn080.1=1 when a motor forward direction and linear scale count up direction with pole sensor are opposite for Y213. The change in the direction of the motor current commutation and the pole sensor signal matched to it are processed.

With the setting change, it is possible to control the motor properly even though the motor forward direction with pole sensor and scale count up direction are opposite.

3.3 Error Detection of Frequency Dividing Output Setting (Note 1)

Alarm A.09 occurs for Y213 when the setting for frequency dividing output exceeds the limit (Max.12.8MHz).

Also, the setting value that the frequency does not exceed the limit is displayed in the monitor mode Un010. Since the frequency of the frequency dividing output is adjusted by either parameter in the PG dividing ratio (Pn281) or motor peak speed (Pn384), limit value display can be chosen by user parameter Pn080.3 on the monitor Un010.

3.4 Pole Sensor Signal Monitor (Note 1)

Pole sensor signal is monitored in the monitor mode Un011 in Y213 It is effective for the trouble shooting at the setup.

(Note)

Applied to the software of base version 14 or later version, and revised version 9 of base version 13.



4 Electric Gear Ratio Setting Method

4.1 For the SGDH Type Servo Amplifier

Electric gear ratio for the SGDH type servo amplifier can be obtained from the following formula.

$$\text{Reference Pulse [}\hat{\text{i m/pulse}}] = \frac{\text{Pn280}}{256} \times \frac{\text{Pn202}}{\text{Pn203}}$$

(Example)

Making the travel distance per 1 pulse reference to 1μm, when the linear scale of scale pitch 20μm is used.

$$\frac{20[\hat{\text{i m}}]}{256} \times \frac{\text{Pn202}}{\text{Pn203}} = 1[\hat{\text{i m/pulse}}]$$

$$\therefore \frac{\text{Pn202}}{\text{Pn203}} = \frac{256}{20} = \frac{64}{5}$$

Therefore, set as Pn202=64, Pn203=5.

4.2 For the SGDD Type Servo Amplifier

Electric gear ratio for the SGDD type servo amplifier can be obtained from the following formula.

$$\text{Reference Pulse [}\hat{\text{i m/pulse}}] = \frac{\text{Pn209}}{400} \times \frac{\text{Pn202}}{\text{Pn203}}$$

(Example)

Making the travel distance per 1 pulse reference to 10μm, when the linear scale of scale resolution 0.5μm is used.

$$\frac{200}{400} \times \frac{\text{Pn202}}{\text{Pn203}} = 10[\hat{\text{i m/pulse}}]$$

$$\therefore \frac{\text{Pn202}}{\text{Pn203}} = \frac{400 \times 10}{200} = 20$$

Therefore, set as Pn202=20, Pn203=1.