

**SCARA Robots
XG Series**

R6Y - XGC/XGP series

INSTALLATION MANUAL

OMRON

Safety Instructions

1. Safety Information	S-1
2. Signal words used in this manual	S-2
3. Warning labels	S-3
3.1 Warning labels	S-3
3.1.1 Warning label messages on robot and controller	S-3
3.1.2 Supplied warning labels	S-6
3.2 Warning symbols	S-7
4. Major precautions for each stage of use	S-8
4.1 Precautions for using robots and controllers	S-8
4.2 Design	S-9
4.2.1 Precautions for robots	S-9
4.2.2 Precautions for robot controllers	S-9
4.3 Moving and installation	S-10
4.3.1 Precautions for robots	S-10
4.3.2 Precautions for robot controllers	S-11
4.4 Safety measures	S-13
4.4.1 Safety measures	S-13
4.4.2 Installing a safety enclosure	S-14
4.5 Operation	S-15
4.5.1 Trial operation	S-15
4.5.2 Automatic operation	S-17
4.5.3 Precautions during operation	S-17
4.6 Inspection and maintenance	S-19
4.6.1 Before inspection and maintenance work	S-19
4.6.2 Precautions during service work	S-20
4.7 Disposal	S-21
5. Emergency action when a person is caught by robot	S-22
6. Cautions regarding strong magnetic fields	S-22
7. Using the robot safely	S-23
7.1 Movement range	S-23
7.2 Robot protective functions	S-24
7.3 Residual risk	S-25
7.4 Special training for industrial robot operation	S-25

Warranty

Introduction

Before using the robot (Be sure to read the following notes.)	i
--	----------

Introduction	iii
---------------------	------------

Chapter 1 Functions

1. Robot manipulator	1-1
-----------------------------	------------

1.1 Manipulator movement	1-1
--------------------------	-----

1.2 Part names	1-2
----------------	-----

2. Robot initialization number list	1-4
--	------------

Chapter 2 Installation

1. Robot installation conditions	2-1
---	------------

1.1 Sucking from the base rear side of the clean room model	2-1
---	-----

1.2 Protection ratings for moisture and dust on dust/drip proof models	2-2
--	-----

1.2.1 Plug	2-2
------------	-----

1.2.2 Air purge piping	2-3
------------------------	-----

1.2.3 Exhaust port	2-4
--------------------	-----

2. Installation	2-5
------------------------	------------

2.1 Checking the product	2-5
--------------------------	-----

2.2 Moving the robot	2-7
----------------------	-----

2.2.1 R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600	2-7
---	-----

2.2.2 R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000	2-8
---	-----

3. User wiring and user tubing	2-9
---------------------------------------	------------

4. Limiting the movement range with X- and Y-axis mechanical stoppers	2-13
--	-------------

4.1 Installing the X-axis/Y-axis additional mechanical stoppers	2-16
---	------

4.1.1 R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600	2-16
---	------

4.1.2 R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000	2-18
---	------

5. Limiting the movement range with Z-axis mechanical stopper	2-19
--	-------------

6. Working envelope and mechanical stopper positions for maximum working envelope	2-19
--	-------------

7. Installing the user wiring and tubing newly	2-20
---	-------------

8. Passing the user wiring and tubing through the spline	2-21
---	-------------

9. Detaching or attaching the covers	2-22
9.1 R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, 6YXGLC(P)600	2-22
9.2 R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000	2-27

10. Installing the tool flange	2-29
---------------------------------------	-------------

11. Permissible spline load	2-30
------------------------------------	-------------

Chapter 3 Robot settings	
1. Overview	3-1

2. Adjusting the origin	3-2
--------------------------------	------------

3. Standard coordinate setting using a standard coordinate setup jig	3-3
3.1 R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600	3-3
3.2 R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000	3-4

Chapter 4 Periodic inspection	
1. List of inspection items	4-1

Chapter 5 Harmonic drive replacement period	
1. Overview	5-1

2. Replacement period	5-2
------------------------------	------------

Chapter 6 Torque limit designated Z-axis pushing action	
1. Torque limit designated Z-axis pushing action	6-1

Chapter 7 Specifications	
1. Manipulator	7-1
1.1 Basic specification	7-1
1.2 External view and dimensions	7-4
1.2.1 R6YXGLC(P)250	7-4
1.2.2 R6YXGLC(P)350	7-6
1.2.3 R6YXGLC(P)400	7-8
1.2.4 R6YXGLC(P)500	7-10
1.2.5 R6YXGLC(P)600	7-12
1.2.6 R6YXGP500	7-14
1.2.7 R6YXGP600	7-16
1.2.8 R6YXGHP600	7-18

CONTENTS

XGC/XGP
Installation Manual

1.2.9	R6YXGP700	7-20
1.2.10	R6YXGP800	7-22
1.2.11	R6YXGP900	7-24
1.2.12	R6YXGP1000	7-26

Safety Instructions

Contents

1. Safety Information	S-1
2. Signal words used in this manual	S-2
3. Warning labels	S-3
3.1 Warning labels	S-3
3.1.1 Warning label messages on robot and controller	S-3
3.1.2 Supplied warning labels	S-6
3.2 Warning symbols	S-7
4. Major precautions for each stage of use	S-8
4.1 Precautions for using robots and controllers	S-8
4.2 Design	S-9
4.2.1 Precautions for robots	S-9
4.2.2 Precautions for robot controllers	S-9
4.3 Moving and installation	S-10
4.3.1 Precautions for robots	S-10
4.3.2 Precautions for robot controllers	S-11
4.4 Safety measures	S-13
4.4.1 Safety measures	S-13
4.4.2 Installing a safety enclosure	S-14
4.5 Operation	S-15
4.5.1 Trial operation	S-15
4.5.2 Automatic operation	S-17
4.5.3 Precautions during operation	S-17
4.6 Inspection and maintenance	S-19
4.6.1 Before inspection and maintenance work	S-19
4.6.2 Precautions during service work	S-20
4.7 Disposal	S-21
5. Emergency action when a person is caught by robot	S-22
6. Cautions regarding strong magnetic fields	S-22
7. Using the robot safely	S-23
7.1 Movement range	S-23
7.2 Robot protective functions	S-24
7.3 Residual risk	S-25
7.4 Special training for industrial robot operation	S-25

1. Safety Information

Industrial robots are highly programmable, mechanical devices that provide a large degree of freedom when performing various manipulative tasks. To ensure safe and correct use of OMRON industrial robots and controllers, carefully read and comply with the safety instructions and precautions in this "Safety Instructions" guide. Failure to take necessary safety measures or incorrect handling may result in trouble or damage to the robot and controller, and also may cause personal injury (to installation personnel, robot operator or service personnel) including fatal accidents.

Before using this product, read this manual and related manuals and take safety precautions to ensure correct handling. The precautions listed in this manual relate to this product. To ensure safety of the user's final system that includes OMRON robots, please take appropriate safety measures as required by the user's individual system.

To use OMRON robots and controllers safely and correctly, always comply with the safety rules and instructions:

- For specific safety information and standards, refer to the applicable local regulations and comply with the instructions.
- Warning labels attached to the robots are written in English, Japanese, Chinese and Korean. This manual is available in English or Japanese (or some parts in Chinese). Unless the robot operators or service personnel understand these languages, do not permit them to handle the robot.
- Cautions regarding the official language of EU countries:
For equipment that will be installed in EU countries, the language used for the manuals, warning labels, operation screen characters, and CE declarations is English only.
Warning labels only have pictograms or else include warning messages in English. In the latter case, messages in Japanese or other languages might be added.

It is not possible to list all safety items in detail within the limited space of this manual. So please note that it is essential that the user have a full knowledge of safety and also make correct judgments on safety procedures.

2. Signal words used in this manual

This manual uses the following safety alert symbols and signal words to provide safety instructions that must be observed and to describe handling precautions, prohibited actions, and compulsory actions. Make sure you understand the meaning of each symbol and signal word and then read this manual.



DANGER

THIS INDICATES AN IMMEDIATELY HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, WILL RESULT IN DEATH OR SERIOUS INJURY.



WARNING

THIS INDICATES A POTENTIALLY HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, COULD RESULT IN DEATH OR SERIOUS INJURY.



CAUTION

This indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury, or damage to the equipment.



NOTE

Explains the key point in the operation in a simple and clear manner.

3. Warning labels

Warning labels shown below are attached to the robot body and controller to alert the operator to potential hazards. To ensure correct use, read the warning labels and comply with the instructions.

3.1 Warning labels



WARNING

IF WARNING LABELS ARE REMOVED OR DIFFICULT TO SEE, THEN THE NECESSARY PRECAUTIONS MAY NOT BE TAKEN, RESULTING IN AN ACCIDENT.

- DO NOT REMOVE, ALTER OR STAIN THE WARNING LABELS ON THE ROBOT BODY.
- DO NOT ALLOW WARNING LABELS TO BE HIDDEN BY DEVICES INSTALLED ON THE ROBOT BY THE USER.
- PROVIDE PROPER LIGHTING SO THAT THE SYMBOLS AND INSTRUCTIONS ON THE WARNING LABELS CAN BE CLEARLY SEEN FROM OUTSIDE THE SAFETY ENCLOSURE.

3.1.1 Warning label messages on robot and controller

Word messages on the danger, warning and caution labels are concise and brief instructions. For more specific instructions, read and follow the "Instructions on this label" described on the right of each label shown below. See "7.1 Movement range" in "Safety instructions" for details on the robot's movement range.

1. Warning label 1 (SCARA robots)



DANGER

SERIOUS INJURY MAY RESULT FROM CONTACT WITH A MOVING ROBOT.

- KEEP OUTSIDE OF THE ROBOT SAFETY ENCLOSURE DURING OPERATION.
- PRESS THE EMERGENCY STOP BUTTON BEFORE ENTERING THE SAFETY ENCLOSURE.

Instructions on this label	
	<ul style="list-style-type: none"> • Always install a safety enclosure to keep all persons away from the robot movement range and prevent injury from contacting the moving part of the robot. • Install an interlock that triggers emergency stop when the door or gate of the safety enclosure is opened. • The safety enclosure should be designed so that no one can enter inside except from the door or gate equipped with an interlock device. • Warning label 1 that comes supplied with a robot should be affixed to an easy-to-see location on the door or gate of the safety enclosure.
Potential hazard to human body	Serious injury may result from contact with a moving robot.
To avoid hazard	<ul style="list-style-type: none"> • Keep outside of the robot safety enclosure during operation. • Press the emergency stop button before entering the safety enclosure.

2. Warning label 2 (SCARA robots)



WARNING

MOVING PARTS CAN PINCH OR CRUSH HANDS.
KEEP HANDS AWAY FROM THE MOVABLE PARTS OF THE ROBOT.

Instructions on this label	
	<p>Use caution to prevent hands and fingers from being pinched or crushed by the movable parts of the robot when transporting or moving the robot or during teaching.</p>
Potential hazard to human body	Moving parts can pinch or crush hands.
To avoid hazard	Keep hands away from the movable parts of the robot.

3. Warning label 3 (SCARA robots)



WARNING

IMPROPER INSTALLATION OR OPERATION MAY CAUSE SERIOUS INJURY.
BEFORE INSTALLING OR OPERATING THE ROBOT, READ THE MANUAL AND INSTRUCTIONS ON THE WARNING LABELS AND UNDERSTAND THE CONTENTS.

Instructions on this label	
	<ul style="list-style-type: none"> • Be sure to read the warning label and this manual carefully to make you completely understand the contents before attempting installation and operation of the robot. • Before starting the robot operation, even after you have read through this manual, read again the corresponding procedures and "Safety instructions" in this manual. • Never install, adjust, inspect or service the robot in any manner that does not comply with the instructions in this manual.
Potential hazard to human body	Improper installation or operation may cause serious injury.
To avoid hazard	Before installing or operating the robot, read the manual and instructions on the warning labels and understand the contents.

4. Warning label 4 (SCARA robots)



CAUTION

Do not remove the parts on which Warning label 4 is attached.
Doing so may damage the ball screw.

Instructions on this label	
	<p>The Z-axis ball screw will be damaged if the upper end mechanical stopper on the Z-axis spline is removed or moved. Never attempt to remove or move it.</p>

5. Warning label 5 (Controller)



WARNING

GROUND THE CONTROLLER TO PREVENT ELECTRICAL SHOCK.
GROUND TERMINAL IS LOCATED INSIDE THIS COVER.
READ THE MANUAL FOR DETAILS.

Instructions on this label	
	<ul style="list-style-type: none"> • High voltage section inside • To prevent electrical shock, always ground the robot using the ground terminal located inside the cover.
Potential hazard to human body	Electrical shock
To avoid hazard	Ground the controller.


6. "Read instruction manual" label (Controller)*

* This label is attached to the front panel.



CAUTION

Refer to the manual.

	Instructions on this label
	<p>This indicates important information that you must know and is described in the manual.</p> <p>Before using the controller, be sure to read the manual thoroughly.</p> <p>When adding external safety circuits or connecting a power supply to the controller, read the manual carefully and make checks before beginning the work.</p> <p>Connectors have an orientation. Insert each connector in the correct direction.</p>

3.1.2 Supplied warning labels

Some warning labels are not affixed to robots but included in the packing box. These warning labels should be affixed to an easy-to-see location.

- Warning label is attached to the robot body.
- Warning label comes supplied with the robot and should be affixed to an easy-to-see location on the door or gate of the safety enclosure.
- ◎ Warning label comes supplied with the robot and should be affixed to an easy-to-see location.

		SCARA robots
Warning label 1		<ul style="list-style-type: none"> ● *1 ○
Warning label 2		<ul style="list-style-type: none"> ● *1
Warning label 3		<ul style="list-style-type: none"> ● *1

*1: See "Part names" in each SCARA robot manual for label positions.

3.2 Warning symbols


Warning symbols shown below are indicated on the robots and controllers to alert the operator to potential hazards. To use the OMRON robot safely and correctly always follow the instructions and cautions indicated by the symbols.

1. Electrical shock hazard symbol



WARNING

TOUCHING THE TERMINAL BLOCK OR CONNECTOR MAY CAUSE ELECTRICAL SHOCK, SO USE CAUTION.


	Instructions by this symbol
	<p>This indicates a high voltage is present. Touching the terminal block or connector may cause electrical shock.</p>

2. High temperature hazard symbol



WARNING

MOTORS, HEATSINKS, AND REGENERATIVE UNITS BECOME HOT, SO DO NOT TOUCH THEM.


	Instructions by this symbol
	<p>This indicates the area around this symbol may become very hot. Motors, heatsinks, and regenerative units become hot during and shortly after operation. To avoid burns be careful not to touch those sections.</p>

3. Caution symbol



CAUTION

Always read the manual carefully before using the controller.

	Instructions by this symbol
	<p>This indicates important information that you must know and is described in the manual. Before using the controller, be sure to read the manual thoroughly. When adding external safety circuits or connecting a power supply to the controller, read the manual carefully and make checks before beginning the work. Connectors must be attached while facing a certain direction, so insert each connector in the correct direction.</p>

4. Major precautions for each stage of use

This section describes major precautions that must be observed when using robots and controllers. Be sure to carefully read and comply with all of these precautions even if there is no alert symbol shown.

4.1 Precautions for using robots and controllers

General precautions for using robots and controllers are described below.

1. Applications where robots cannot be used

OMRON robots and robot controllers are designed as general-purpose industrial equipment and cannot be used for the following applications.



DANGER

OMRON ROBOT CONTROLLERS AND ROBOTS ARE DESIGNED AS GENERAL-PURPOSE INDUSTRIAL EQUIPMENT AND CANNOT BE USED FOR THE FOLLOWING APPLICATIONS.

- IN MEDICAL EQUIPMENT SYSTEMS WHICH ARE CRITICAL TO HUMAN LIFE
- IN SYSTEMS THAT SIGNIFICANTLY AFFECT SOCIETY AND THE GENERAL PUBLIC
- IN EQUIPMENT INTENDED TO CARRY OR TRANSPORT PEOPLE
- IN ENVIRONMENTS WHICH ARE SUBJECT TO VIBRATION SUCH AS ONBOARD SHIPS AND VEHICLES.

2. Qualification of operators/workers

Operators or persons who handle the robot such as for teaching, programming, movement check, inspection, adjustment, and repair must receive appropriate training and also have the skills needed to perform the job correctly and safely. They must read the manual carefully to understand its contents before attempting the robot operation or maintenance.

Tasks related to industrial robots (teaching, programming, movement check, inspection, adjustment, repair, etc.) must be performed by qualified persons who meet requirements established by local regulations and standards for industrial robots.



WARNING

- THE ROBOT MUST BE OPERATED ONLY BY PERSONS WHO HAVE RECEIVED SAFETY AND OPERATION TRAINING. OPERATION BY AN UNTRAINED PERSON IS EXTREMELY HAZARDOUS.
- ADJUSTMENT AND MAINTENANCE BY REMOVING A COVER REQUIRE SPECIALIZED TECHNICAL KNOWLEDGE AND SKILLS, AND MAY ALSO INVOLVE HAZARDS IF ATTEMPTED BY AN UNSKILLED PERSON. THESE TASKS MUST BE PERFORMED ONLY BY PERSONS WHO HAVE ENOUGH ABILITY AND QUALIFICATIONS IN ACCORDANCE WITH LOCAL LAWS AND REGULATIONS. FOR DETAILED INFORMATION, PLEASE CONTACT YOUR DISTRIBUTOR WHERE YOU PURCHASED THE PRODUCT.

4.2 Design

4.2.1 Precautions for robots

1. Restricting the robot moving speed

**WARNING**

RESTRICTION ON THE ROBOT MOVING SPEED IS NOT A SAFETY-RELATED FUNCTION. TO REDUCE THE RISK OF COLLISION BETWEEN THE ROBOT AND WORKERS, THE USER MUST TAKE THE NECESSARY PROTECTIVE MEASURES SUCH AS ENABLE DEVICES ACCORDING TO RISK ASSESSMENT BY THE USER.

2. Restricting the movement range

See “7.1 Movement range” in “Safety instructions” for details on the robot’s movement range.

**WARNING**

SOFT LIMIT FUNCTION IS NOT A SAFETY-RELATED FUNCTION INTENDED TO PROTECT THE HUMAN BODY. TO RESTRICT THE ROBOT MOVEMENT RANGE TO PROTECT THE HUMAN BODY, USE THE MECHANICAL STOPPERS INSTALLED IN THE ROBOT (OR AVAILABLE AS OPTIONS).

**CAUTION**

If the robot moving at high speed collides with a mechanical stopper installed in the robot (or available as option), the robot may be damaged.

3. Provide safety measures for end effector (gripper, etc.)

**WARNING**

- END EFFECTORS MUST BE DESIGNED AND MANUFACTURED SO THAT THEY CAUSE NO HAZARDS (SUCH AS A LOOSE WORKPIECE OR LOAD) EVEN IF POWER (ELECTRICITY, AIR PRESSURE, ETC.) IS SHUT OFF OR POWER FLUCTUATIONS OCCUR.
- IF THE OBJECT GRIPPED BY THE END EFFECTOR MIGHT POSSIBLY FLY OFF OR DROP, THEN PROVIDE APPROPRIATE SAFETY PROTECTION TAKING INTO ACCOUNT THE OBJECT SIZE, WEIGHT, TEMPERATURE, AND CHEMICAL PROPERTIES.

4. Provide adequate lighting

Provide enough lighting to ensure safety during work.

5. Install an operation status light

**WARNING**

INSTALL A SIGNAL LIGHT (SIGNAL TOWER) AT AN EASY-TO-SEE POSITION SO THAT THE OPERATOR WILL BE AWARE OF THE ROBOT STOP STATUS (TEMPORARILY STOPPED, EMERGENCY STOP, ERROR STOP, ETC.).

4.2.2 Precautions for robot controllers

1. Emergency stop input terminal

**DANGER**

EACH ROBOT CONTROLLER HAS AN EMERGENCY STOP INPUT TERMINAL TO TRIGGER EMERGENCY STOP. USING THIS TERMINAL, INSTALL A SAFETY CIRCUIT SO THAT THE SYSTEM INCLUDING THE ROBOT CONTROLLER WILL WORK SAFELY.

2. Maintain clearance

**CAUTION**

Do not bundle control lines or communication cables together or in close to the main power supply or power lines. Usually separate these by at least 100mm. Failure to follow this instruction may cause malfunction due to noise.

4.3 Moving and installation

4.3.1 Precautions for robots

■ Installation environment

1. Do not use in strong magnetic fields



WARNING

DO NOT USE THE ROBOT NEAR EQUIPMENT OR IN LOCATIONS THAT GENERATE STRONG MAGNETIC FIELDS. THE ROBOT MAY BREAK DOWN OR MALFUNCTION IF USED IN SUCH LOCATIONS.

2. Do not use in locations subject to possible electromagnetic interference, etc.



WARNING

DO NOT USE THE ROBOT IN LOCATIONS SUBJECT TO ELECTROMAGNETIC INTERFERENCE, ELECTROSTATIC DISCHARGE OR RADIO FREQUENCY INTERFERENCE. THE ROBOT MAY MALFUNCTION IF USED IN SUCH LOCATIONS CREATING HAZARDOUS SITUATIONS.

3. Do not use in locations exposed to flammable gases



WARNING

- OMRON ROBOTS ARE NOT DESIGNED TO BE EXPLOSION-PROOF.
- DO NOT USE THE ROBOTS IN LOCATIONS EXPOSED TO EXPLOSIVE OR INFLAMMABLE GASES, DUST PARTICLES OR LIQUID. FAILURE TO FOLLOW THIS INSTRUCTION MAY CAUSE SERIOUS ACCIDENTS INVOLVING INJURY OR DEATH, OR LEAD TO FIRE.

■ Moving

1. Use caution to prevent pinching or crushing of hands or fingers



WARNING

MOVING PARTS CAN PINCH OR CRUSH HANDS OR FINGERS.
KEEP HANDS AWAY FROM THE MOVABLE PARTS OF THE ROBOT.

As instructed in Warning label 2, use caution to prevent hands or fingers from being pinched or crushed by movable parts when transporting or moving the robot. For details on warning labels, see "3. Warning labels" in "Safety instructions."

2. Take safety measures when moving the robot

To ensure safety when moving a SCARA robot with an arm length of 500mm or more, use the eyebolts that come supplied with the robot.

Refer to the Robot Manual for details.

■ Installation

1. Protect electrical wiring and hydraulic/pneumatic hoses

Install a cover or similar item to protect the electrical wiring and hydraulic/pneumatic hoses from possible damage.

■ Wiring

1. Protective measures against electrical shock



WARNING

ALWAYS GROUND THE ROBOT TO PREVENT ELECTRICAL SHOCK.

■ Adjustment

1. Adjustment that requires removing a cover



WARNING

ADJUSTMENT BY REMOVING A COVER REQUIRE SPECIALIZED TECHNICAL KNOWLEDGE AND SKILLS, AND MAY ALSO INVOLVE HAZARDS IF ATEMPTED BY AN UNSKILLED PERSON. THESE TASKS MUST BE PERFORMED ONLY BY PERSONS WHO HAVE ENOUGH ABILITY AND QUALIFICATIONS IN ACORDANCE WITH LOCAL LAWS AND REGULATIONS. FOR DETAILED INFORMATION, PLEASE CONTACT YOUR DISTRIBUTOR WHERE YOU PURCHASED THE PRODUCT.

4.3.2 Precautions for robot controllers

■ Installation environment

1. Installation environment



WARNING

OMRON ROBOTS ARE NOT DESIGNED TO BE EXPLOSION-PROOF. DO NOT USE THE ROBOTS AND CONTROLLERS IN LOCATIONS EXPOSED TO EXPLOSIVE OR INFLAMMABLE GASES, DUST PARTICLES OR LIQUID SUCH AS GASOLINE AND SOLVENTS. FAILURE TO FOLLOW THIS INSTRUCTION MAY CAUSE SERIOUS ACCIDENTS INVOLVING INJURY OR DEATH, AND LEAD TO FIRE.



WARNING

- USE THE ROBOT CONTROLLER IN LOCATIONS THAT SUPPORT THE ENVIRONMENTAL CONDITIONS SPECIFIED IN THIS MANUAL. OPERATION OUTSIDE THE SPECIFIED ENVIRONMENTAL RANGE MAY CAUSE ELECTRICAL SHOCK, FIRE, MALFUNCTION OR PRODUCT DAMAGE OR DETERIORATION.
- THE ROBOT CONTROLLER AND PROGRAMMING BOX MUST BE INSTALLED AT A LOCATION THAT IS OUTSIDE THE ROBOT SAFETY ENCLOSURE YET WHERE IT IS EASY TO OPERATE AND VIEW ROBOT MOVEMENT.
- INSTALL THE ROBOT CONTROLLER IN LOCATIONS WITH ENOUGH SPACE TO PERFORM WORK (TEACHING, INSPECTION, ETC.) SAFELY. LIMITED SPACE NOT ONLY MAKES IT DIFFICULT TO PERFORM WORK BUT CAN ALSO CAUSE INJURY.
- INSTALL THE ROBOT CONTROLLER IN A STABLE, LEVEL LOCATION AND SECURE IT FIRMLY. AVOID INSTALLING THE CONTROLLER UPSIDE DOWN OR IN A TILTED POSITION.
- PROVIDE SUFFICIENT CLEARANCE AROUND THE ROBOT CONTROLLER FOR GOOD VENTILATION. INSUFFICIENT CLEARANCE MAY CAUSE MALFUNCTION, BREAKDOWN OR FIRE.

■ Installation

To install the robot controller, observe the installation conditions and method described in the manual.

1. Installation



WARNING

SECURELY TIGHTEN THE SCREWS FOR THE L-SHAPED BRACKETS USED TO INSTALL THE ROBOT CONTROLLER. IF NOT SECURELY TIGHTENED, THE SCREWS MAY COME LOOSE CAUSING THE CONTROLLER TO DROP.

2. Connections



WARNING

- ALWAYS SHUT OFF ALL PHASES OF THE POWER SUPPLY EXTERNALLY BEFORE STARTING INSTALLATION OR WIRING WORK. FAILURE TO DO THIS MAY CAUSE ELECTRICAL SHOCK OR PRODUCT DAMAGE.
- NEVER DIRECTLY TOUCH CONDUCTIVE SECTIONS AND ELECTRONIC PARTS OTHER THAN THE CONNECTORS, ROTARY SWITCHES, AND DIP SWITCHES ON THE OUTSIDE PANEL OF THE ROBOT CONTROLLER. TOUCHING THEM MAY CAUSE ELECTRICAL SHOCK OR BREAKDOWN.
- SECURELY INSTALL EACH CABLE CONNECTOR INTO THE RECEPTACLES OR SOCKETS. POOR CONNECTIONS MAY CAUSE THE CONTROLLER OR ROBOT TO MALFUNCTION.

■ Wiring

1. Connection to robot controller

The controller parameters are preset at the factory before shipping to match the robot model. Check the specified robot and controller combination, and connect them in the correct combination.

Since the software detects abnormal operation such as motor overloads, the controller parameters must be set correctly to match the motor type used in the robot connected to the controller.

2. Wiring safety points



WARNING

ALWAYS SHUT OFF ALL PHASES OF THE POWER SUPPLY EXTERNALLY BEFORE STARTING INSTALLATION OR WIRING WORK. FAILURE TO DO THIS MAY CAUSE ELECTRICAL SHOCK OR PRODUCT DAMAGE.



CAUTION

- Make sure that no foreign matter such as cutting chips or wire scraps get into the robot controller. Malfunction, breakdown or fire may result if these penetrate inside.
- Do not apply excessive impacts or loads to the connectors when making cable connections. This might bend the connector pins or damage the internal PC board.
- When using ferrite cores for noise elimination, be sure to fit them onto the power cable as close to the robot controller and/or the robot as possible, to prevent malfunction caused by noise.

3. Wiring method



WARNING

SECURELY INSTALL THE CONNECTORS INTO THE ROBOT CONTROLLER AND, WHEN WIRING THE CONNECTORS, MAKE THE CRIMP, PRESS-CONTACT OR SOLDER CONNECTIONS CORRECTLY USING THE TOOL SPECIFIED BY THE CONNECTOR MANUFACTURER.



CAUTION

When disconnecting the cable from the robot controller, detach by gripping the connector itself and not by tugging on the cable. Loosen the screws on the connector (if fastened with the screws), and then disconnect the cable. Trying to detach by pulling on the cable itself may damage the connector or cables, and poor cable contact will cause the controller or robot to malfunction.

4. Precautions for cable routing and installation



CAUTION

- Always store the cables connected to the robot controller in a conduit or clamp them securely in place. If the cables are not stored in a conduit or properly clamped, excessive play or movement or mistakenly pulling on the cable may damage the connector or cables, and poor cable contact will cause the controller or robot to malfunction.
- Do not modify the cables and do not place any heavy objects on them. Handle them carefully to avoid damage. Damaged cables may cause malfunction or electrical shock.
- If the cables connected to the robot controller may possibly become damaged, then protect them with a cover, etc.
- Check that the control lines and communication cables are routed at a gap sufficiently away from main power supply circuits and power lines, etc. Bundling them together with power lines or close to power lines may cause faulty operation due to noise.

5. Protective measures against electrical shock



WARNING

BE SURE TO GROUND THE CONTROLLER USING THE GROUND TERMINAL ON THE POWER TERMINAL BLOCK. POOR GROUNDING MAY CAUSE ELECTRICAL SHOCK.

4.4 Safety measures

4.4.1 Safety measures

1. Referring to warning labels and manual



WARNING

- BEFORE STARTING INSTALLATION OR OPERATION OF THE ROBOT, BE SURE TO READ THE WARNING LABELS AND THIS MANUAL, AND COMPLY WITH THE INSTRUCTIONS.
- NEVER ATTEMPT ANY REPAIR, PARTS REPLACEMENT AND MODIFICATION UNLESS DESCRIBED IN THIS MANUAL. THESE TASKS REQUIRE SPECIALIZED TECHNICAL KNOWLEDGE AND SKILLS AND MAY ALSO INVOLVE HAZARDS. PLEASE CONTACT YOUR DISTRIBUTOR FOR ADVICE.



NOTE

For details on warning labels, see "3. Warning labels" in "Safety instructions."

2. Draw up "work instructions" and make the operators/workers understand them



WARNING

DECIDE ON "WORK INSTRUCTIONS" IN CASES WHERE PERSONNEL MUST WORK WITHIN THE ROBOT SAFETY ENCLOSURE TO PERFORM STARTUP OR MAINTENANCE WORK. MAKE SURE THE WORKERS COMPLETELY UNDERSTAND THESE "WORK INSTRUCTIONS".

Decide on "work instructions" for the following items in cases where personnel must work within the robot safety enclosure to perform teaching, maintenance or inspection tasks. Make sure the workers completely understand these "work instructions".

1. Robot operating procedures needed for tasks such as startup procedures and handling switches
2. Robot speeds used during tasks such as teaching
3. Methods for workers to signal each other when two or more workers perform tasks
4. Steps that the worker should take when a problem or emergency occurs
5. Steps to take after the robot has come to a stop when the emergency stop device was triggered, including checks for cancelling the problem or error state and safety checks in order to restart the robot.
6. In cases other than above, the following actions should be taken as needed to prevent hazardous situations due to sudden or unexpected robot operation or faulty robot operation as listed below.
 - Place a display sign on the operator panel
 - Ensure the safety of workers performing tasks within the robot safety enclosure
 - Clearly specify position and posture during work
 - Specify a position and posture where worker can constantly check robot movements and immediately move to avoid trouble if an error/problem occurs
 - Take noise prevention measures
 - Use methods for signaling operators of related equipment
 - Use methods to decide that an error has occurred and identify the type of error

Implement the "work instructions" according to the type of robot, installation location, and type of work task.

When drawing up the "work instructions", make an effort to include opinions from the workers involved, equipment manufacturer technicians, and workplace safety consultants, etc.

3. Take safety measures



DANGER

- NEVER ENTER THE ROBOT MOVEMENT RANGE WHILE THE ROBOT IS OPERATING OR THE MAIN POWER IS TURNED ON. FAILURE TO FOLLOW THIS WARNING MAY CAUSE SERIOUS ACCIDENTS INVOLVING INJURY OR DEATH. INSTALL A SAFETY ENCLOSURE OR A GATE INTERLOCK WITH AN AREA SENSOR TO KEEP ALL PERSONS AWAY FROM THE ROBOT MOVEMENT RANGE.
- WHEN IT IS NECESSARY TO OPERATE THE ROBOT WHILE YOU ARE WITHIN THE ROBOT MOVEMENT RANGE SUCH AS FOR TEACHING OR MAINTENANCE/INSPECTION TASKS, ALWAYS CARRY THE PROGRAMMING BOX WITH YOU SO THAT YOU CAN IMMEDIATELY STOP THE ROBOT OPERATION IN CASE OF AN ABNORMAL OR HAZARDOUS CONDITION. INSTALL AN ENABLE DEVICE IN THE EXTERNAL SAFETY CIRCUIT AS NEEDED. ALSO SET THE ROBOT MOVING SPEED TO 3% OR LESS. FAILURE TO FOLLOW THESE INSTRUCTIONS MAY CAUSE SERIOUS ACCIDENTS INVOLVING INJURY OR DEATH.

**WARNING**

- DURING STARTUP OR MAINTENANCE TASKS, DISPLAY A SIGN "WORK IN PROGRESS" ON THE PROGRAMMING BOX AND OPERATION PANEL IN ORDER TO PREVENT ANYONE OTHER THAN THE PERSON FOR THAT TASK FROM MISTAKENLY OPERATING THE START OR SELECTOR SWITCH. IF NEEDED, TAKE OTHER MEASURES SUCH AS LOCKING THE COVER ON THE OPERATION PANEL.
- ALWAYS CONNECT THE ROBOT AND ROBOT CONTROLLER IN THE CORRECT COMBINATION. USING THEM IN AN INCORRECT COMBINATION MAY CAUSE FIRE OR BREAKDOWN.

4. Install system

When configuring an automated system using a robot, hazardous situations are more likely to occur from the automated system than the robot itself. So the system manufacturer should install the necessary safety measures required for the individual system. The system manufacturer should provide a proper manual for safe, correct operation and servicing of the system.

**WARNING**

TO CHECK THE ROBOT CONTROLLER OPERATING STATUS, REFER TO THIS MANUAL AND TO RELATED MANUALS. DESIGN AND INSTALL THE SYSTEM INCLUDING THE ROBOT CONTROLLER SO THAT IT WILL ALWAYS WORK SAFELY.

5. Precautions for operation**WARNING**

- DO NOT TOUCH ANY ELECTRICAL TERMINAL. DIRECTLY TOUCHING THESE TERMINALS MAY CAUSE ELECTRICAL SHOCK, EQUIPMENT DAMAGE, AND MALFUNCTION.
- DO NOT TOUCH OR OPERATE THE ROBOT CONTROLLER OR PROGRAMMING BOX WITH WET HANDS. TOUCHING OR OPERATING THEM WITH WET HANDS MAY RESULT IN ELECTRICAL SHOCK OR BREAKDOWN.

6. Do not disassemble and modify**WARNING**

NEVER DISASSEMBLE AND MODIFY ANY PART IN THE ROBOT, CONTROLLER, AND PROGRAMMING BOX. DO NOT OPEN ANY COVER. DOING SO MAY CAUSE ELECTRICAL SHOCK, BREAKDOWN, MALFUNCTION, INJURY, OR FIRE.

4.4.2 Installing a safety enclosure

Be sure to install a safety enclosure to keep anyone from entering within the movement range of the robot. The safety enclosure will prevent the operator and other persons from coming in contact with moving parts of the robot and suffering injury.

See "7.1 Movement range" in "Safety instructions" for details on the robot's movement range.

**DANGER**

SERIOUS INJURY MAY RESULT FROM CONTACT WITH A MOVING ROBOT.

- KEEP OUTSIDE OF THE ROBOT SAFETY ENCLOSURE DURING OPERATION.
- PRESS THE EMERGENCY STOP BUTTON BEFORE ENTERING THE SAFETY ENCLOSURE.

**WARNING**

- INSTALL AN INTERLOCK THAT TRIGGERS EMERGENCY STOP WHEN THE DOOR OR GATE OF THE SAFETY ENCLOSURE IS OPENED.
- THE SAFETY ENCLOSURE SHOULD BE DESIGNED SO THAT NO ONE CAN ENTER INSIDE EXCEPT FROM THE DOOR OR GATE EQUIPPED WITH AN INTERLOCK DEVICE.
- WARNING LABEL 1 (SEE "3. WARNING LABELS" IN "SAFETY INSTRUCTIONS") THAT COMES SUPPLIED WITH A ROBOT SHOULD BE AFFIXED TO AN EASY-TO-SEE LOCATION ON THE DOOR OR GATE OF THE SAFETY ENCLOSURE.

4.5 Operation

When operating a robot, ignoring safety measures and checks may lead to serious accidents. Always take the following safety measures and checks to ensure safe operation.



DANGER

CHECK THE FOLLOWING POINTS BEFORE STARTING ROBOT OPERATION.

- NO ONE IS WITHIN THE ROBOT SAFETY ENCLOSURE.
- THE PROGRAMMING UNIT IS IN THE SPECIFIED LOCATION.
- THE ROBOT AND PERIPHERAL EQUIPMENT ARE IN GOOD CONDITION.

4.5.1 Trial operation

After installing, adjusting, inspecting, maintaining or repairing the robot, perform trial operation using the following procedures.

1. If a safety enclosure has not yet been provided right after installing the robot:

Then rope off or chain off the movement range around the robot in place of the safety enclosure and observe the following points. See “7.1 Movement range” in “Safety instructions” for details on the robot’s movement range.



DANGER

PLACE A "ROBOT IS MOVING - KEEP AWAY!" SIGN TO KEEP THE OPERATOR OR OTHER PERSONNEL FROM ENTERING WITHIN THE MOVEMENT RANGE OF THE ROBOT.



WARNING

- USE STURDY, STABLE POSTS WHICH WILL NOT FALL OVER EASILY.
- THE ROPE OR CHAIN SHOULD BE EASILY VISIBLE TO EVERYONE AROUND THE ROBOT.

2. Check the following points before turning on the controller.

- Is the robot securely and correctly installed?
- Are the electrical connections to the robot wired correctly?
- Are items such as air pressure correctly supplied?
- Is the robot correctly connected to peripheral equipment?
- Have safety measures (safety enclosure, etc.) been taken?
- Does the installation environment meet the specified standards?

3. After the controller is turned on, check the following points from outside the safety enclosure.

- Does the robot start, stop and enter the selected operation mode as intended?
- Does each axis move as intended within the soft limits?
- Does the end effector move as intended?
- Are the correct signals being sent to the end effector and peripheral equipment?
- Does emergency stop function?
- Are teaching and playback functions normal?
- Are the safety enclosure and interlocks functioning as intended?

4. Working inside safety enclosures

Before starting work within the safety enclosure, **always confirm from outside the enclosure that each protective function is operating correctly (see the previous section 2.3).**



DANGER

NEVER ENTER WITHIN THE MOVEMENT RANGE WHILE WITHIN THE SAFETY ENCLOSURE.

See “7.1 Movement range” in “Safety instructions” for details on the robot’s movement range.



WARNING

WHEN WORK IS REQUIRED WITHIN THE SAFETY ENCLOSURE, PLACE A SIGN "WORK IN PROGRESS" IN ORDER TO KEEP OTHER PERSONS FROM OPERATING THE CONTROLLER SWITCH OR OPERATION PANEL.



WARNING

WHEN WORK WITHIN THE SAFETY ENCLOSURE IS REQUIRED, ALWAYS TURN OFF THE CONTROLLER POWER EXCEPT FOR THE FOLLOWING CASES:

Exception

Work with power turned on, but robot in emergency stop

Origin position setting	SCARA robots	Follow the precautions and procedure described in "2. Adjusting the origin" in Chapter 3.
Standard coordinate setting	SCARA robots	Follow the precautions and procedure described in "4. Setting the standard coordinates" in Chapter 3.
Soft limit settings	SCARA robots	Follow the precautions and procedure described in "3. Setting the soft limits" in Chapter 3.

Work with power turned on

Teaching	SCARA robots	Refer to "5. Teaching within safety enclosure" described below.
----------	--------------	---

5. Teaching within the safety enclosure

When performing teaching within the safety enclosure, check or perform the following points **from outside the safety enclosure.**



DANGER

NEVER ENTER WITHIN THE MOVEMENT RANGE WHILE WITHIN THE SAFETY ENCLOSURE.

See “7.1 Movement range” in “Safety instructions” for details on the robot’s movement range.



WARNING

- MAKE A VISUAL CHECK TO ENSURE THAT NO HAZARDS ARE PRESENT WITHIN THE SAFETY ENCLOSURE.
- CHECK THAT THE PROGRAMMING BOX OR HANDY TERMINAL OPERATES CORRECTLY.
- CHECK THAT NO FAILURES ARE FOUND IN THE ROBOT.
- CHECK THAT EMERGENCY STOP WORKS CORRECTLY.
- SELECT TEACHING MODE AND DISABLE AUTOMATIC OPERATION.

4.5.2 Automatic operation

Check the following points when operating the robot in AUTO mode. Observe the instructions below in cases where an error occurs during automatic operation. Automatic operation described here includes all operations in AUTO mode.

1. Checkpoints before starting automatic operation

Check the following points before starting automatic operation



DANGER

- CHECK THAT NO ONE IS WITHIN THE SAFETY ENCLOSURE.
- CHECK THE SAFETY ENCLOSURE IS SECURELY INSTALLED WITH INTERLOCKS FUNCTIONAL.



WARNING

- CHECK THAT THE PROGRAMMING BOX / HANDY TERMINAL AND TOOLS ARE IN THEIR SPECIFIED LOCATIONS.
- CHECK THAT THE SIGNAL TOWER LAMPS OR OTHER ALARM DISPLAYS INSTALLED FOR THE SYSTEM ARE NOT LIT OR FLASHING, INDICATING NO ERROR IS OCCURRING ON THE ROBOT AND PERIPHERAL DEVICES.

2. During automatic operation and when errors occur

After automatic operation starts, check the operation status and the signal tower to ensure that the robot is in automatic operation.



DANGER

NEVER ENTER THE SAFETY ENCLOSURE DURING AUTOMATIC OPERATION.



WARNING

IF AN ERROR OCCURS IN THE ROBOT OR PERIPHERAL EQUIPMENT, OBSERVE THE FOLLOWING PROCEDURE BEFORE ENTERING THE SAFETY ENCLOSURE.

- 1) PRESS THE EMERGENCY STOP BUTTON TO SET THE ROBOT TO EMERGENCY STOP.
- 2) PLACE A SIGN ON THE START SWITCH, INDICATING THAT THE ROBOT IS BEING INSPECTED IN ORDER TO KEEP OTHER PERSONS FROM RESTARTING THE ROBOT.

4.5.3 Precautions during operation

1. When the robot is damaged or an abnormal condition occurs



WARNING

- IF UNUSUAL ODORS, NOISE OR SMOKE OCCUR DURING OPERATION, IMMEDIATELY TURN OFF POWER TO PREVENT POSSIBLE ELECTRICAL SHOCK, FIRE OR BREAKDOWN. STOP USING THE ROBOT AND CONTACT YOUR DISTRIBUTOR.
- IF ANY OF THE FOLLOWING DAMAGE OR ABNORMAL CONDITIONS OCCURS THE ROBOT, THEN CONTINUING TO OPERATE THE ROBOT IS DANGEROUS. IMMEDIATELY STOP USING THE ROBOT AND CONTACT YOUR DISTRIBUTOR.

Damage or abnormal condition	Type of danger
Damage to machine harness or robot cable	Electrical shock, robot malfunction
Damage to robot exterior	Damaged parts fly off during robot operation
Abnormal robot operation (position deviation, vibration, etc.)	Robot malfunction
Z-axis (vertical axis) or brake malfunction	Loads fall off

2. High temperature hazard



WARNING

- DO NOT TOUCH THE ROBOT CONTROLLER AND ROBOT DURING OPERATION. THE ROBOT CONTROLLER AND ROBOT BODY ARE VERY HOT DURING OPERATION, SO BURNS MAY OCCUR IF THESE SECTIONS ARE TOUCHED.
- THE MOTOR AND SPEED REDUCTION GEAR CASING ARE VERY HOT SHORTLY AFTER OPERATION, SO BURNS MAY OCCUR IF THESE ARE TOUCHED. BEFORE TOUCHING THOSE PARTS FOR INSPECTIONS OR SERVICING, TURN OFF THE CONTROLLER, WAIT FOR A WHILE AND CHECK THAT THEIR TEMPERATURE HAS COOLED.

3. Use caution when releasing the Z-axis (vertical axis) brake



WARNING

THE VERTICAL AXIS WILL SLIDE DOWNWARD WHEN THE BRAKE IS RELEASED, CAUSING A HAZARDOUS SITUATION. TAKE ADEQUATE SAFETY MEASURES IN CONSIDERATION BY TAKING THE WEIGHT AND SHAPE INTO ACCOUNT.

- BEFORE RELEASING THE BRAKE AFTER PRESSING THE EMERGENCY STOP BUTTON, PLACE A SUPPORT UNDER THE VERTICAL AXIS SO THAT IT WILL NOT SLIDE DOWN.
- BE CAREFUL NOT TO LET YOUR BODY GET CAUGHT BETWEEN THE VERTICAL AXIS AND THE INSTALLATION BASE WHEN PERFORMING TASKS (DIRECT TEACHING, ETC.) WITH THE BRAKE RELEASED.

4. Be careful of Z-axis movement when the controller is turned off or emergency stop is triggered (air-driven Z-axis)



WARNING

THE Z-AXIS STARTS MOVING UPWARD WHEN POWER TO THE CONTROLLER OR PLC IS TURNED OFF, THE PROGRAM IS RESET, EMERGENCY STOP IS TRIGGERED, OR AIR IS SUPPLIED TO THE SOLENOID VALVE FOR THE Z-AXIS AIR CYLINDER.

- DO NOT LET HANDS OR FINGERS GET CAUGHT AND SQUEEZED BY ROBOT PARTS MOVING ALONG THE Z-AXIS.
- KEEP THE USUAL ROBOT POSITION IN MIND SO AS TO PREVENT THE Z-AXIS FROM HANGING UP OR BINDING ON OBSTACLES DURING RAISING OF THE Z-AXIS EXCEPT IN CASE OF EMERGENCY STOP.

5. Take protective measures when the Z-axis interferes with peripheral equipment (air-driven Z-axis)



WARNING

WHEN THE Z-AXIS COMES TO A STOP DUE TO OBSTRUCTION FROM PERIPHERAL EQUIPMENT, THE Z-AXIS MAY MOVE SUDDENLY AFTER THE OBSTRUCTION IS REMOVED, CAUSING INJURY SUCH AS PINCHED OR CRUSHED HANDS.

- TURN OFF THE CONTROLLER AND REDUCE THE AIR PRESSURE BEFORE ATTEMPTING TO REMOVE THE OBSTRUCTION.
- BEFORE REDUCING THE AIR PRESSURE, PLACE A SUPPORT UNDER THE Z-AXIS BECAUSE THE Z-AXIS WILL DROP UNDER ITS OWN WEIGHT.

6. Be careful of Z-axis movement when air supply is stopped (air-driven Z-axis)



WARNING

THE Z-AXIS WILL SLIDE DOWNWARD WHEN THE AIR PRESSURE TO THE Z-AXIS AIR CYLINDER SOLENOID VALVE IS REDUCED, CREATING A HAZARDOUS SITUATION.
TURN OFF THE CONTROLLER AND PLACE A SUPPORT UNDER THE Z-AXIS BEFORE CUTTING OFF THE AIR SUPPLY.

7. Make correct parameter settings



CAUTION

The robot must be operated with the correct tolerable moment of inertia and acceleration coefficients that match the manipulator tip mass and moment of inertia. Failure to follow this instruction will lead to a premature end to the drive unit service life, damage to robot parts, or cause residual vibration during positioning.

8. If the X-axis, Y-axis or R-axis rotation angle is small



CAUTION

If the X-axis, Y-axis or R-axis rotation angle is set smaller than 5 degrees, then it will always move within the same position. This restricted position makes it difficult for an oil film to form on the joint support bearing, and so may possibly damage the bearing. In this type of operation, add a range of motion so that the joint moves through 90 degrees or more, about 5 times a day.

4.6 Inspection and maintenance

Always perform daily and periodic inspections and make a pre-operation check to ensure there are no problems with the robot and related equipment. If a problem or abnormality is found, then promptly repair it or take other measures as necessary.

Keep a record of periodic inspections or repairs and store this record for at least 3 years.

4.6.1 Before inspection and maintenance work

1. Do not attempt any work or operation unless described in this manual.

Never attempt any work or operation unless described in this manual.

If an abnormal condition occurs, please be sure to contact your distributor. Our service personnel will take appropriate action.



WARNING

NEVER ATTEMPT INSPECTION, MAINTENANCE, REPAIR, AND PART REPLACEMENT UNLESS DESCRIBED IN THIS MANUAL. THESE TASKS REQUIRE SPECIALIZED TECHNICAL KNOWLEDGE AND SKILLS AND MAY ALSO INVOLVE HAZARDS. PLEASE BE SURE TO CONTACT YOUR DISTRIBUTOR FOR ADVICE.

2. Precautions during repair and parts replacement



WARNING

WHEN IT IS NECESSARY TO REPAIR OR REPLACE PARTS OF THE ROBOT OR CONTROLLER, PLEASE BE SURE TO CONTACT YOUR DISTRIBUTOR AND FOLLOW THE INSTRUCTIONS THEY PROVIDE. INSPECTION AND MAINTENANCE OF THE ROBOT OR CONTROLLER BY AN UNSKILLED, UNTRAINED PERSON IS EXTREMELY HAZARDOUS.

Adjustment, maintenance and parts replacement require specialized technical knowledge and skills, and also may involve hazards. These tasks must be performed only by persons who have enough ability and qualifications required by local laws and regulations.



WARNING

ADJUSTMENT AND MAINTENANCE BY REMOVING A COVER REQUIRE SPECIALIZED TECHNICAL KNOWLEDGE AND SKILLS, AND MAY ALSO INVOLVE HAZARDS IF ATTEMPTED BY AN UNSKILLED PERSON. FOR DETAILED INFORMATION, PLEASE CONTACT YOUR DISTRIBUTOR WHERE YOU PURCHASED THE PRODUCT.

3. Shut off all phases of power supply



WARNING

ALWAYS SHUT OFF ALL PHASES OF THE POWER SUPPLY EXTERNALLY BEFORE CLEANING THE ROBOT AND CONTROLLER OR SECURELY TIGHTENING THE TERMINAL SCREWS ETC. FAILURE TO DO THIS MAY CAUSE ELECTRICAL SHOCK OR PRODUCT DAMAGE OR MALFUNCTION.

4. Allow a waiting time after power is shut off (Allow time for temperature and voltage to drop)



WARNING

- WHEN PERFORMING MAINTENANCE OR INSPECTION OF THE ROBOT CONTROLLER UNDER YOUR DISTRIBUTOR'S INSTRUCTIONS, WAIT AT LEAST 30 MINUTES FOR THE YRC SERIES AFTER TURNING THE POWER OFF. SOME COMPONENTS IN THE ROBOT CONTROLLER ARE VERY HOT OR STILL RETAIN A HIGH VOLTAGE SHORTLY AFTER OPERATION, SO BURNS OR ELECTRICAL SHOCK MAY OCCUR IF THOSE PARTS ARE TOUCHED.
- THE MOTOR AND SPEED REDUCTION GEAR CASING ARE VERY HOT SHORTLY AFTER OPERATION, SO BURNS MAY OCCUR IF THEY ARE TOUCHED. BEFORE TOUCHING THOSE PARTS FOR INSPECTIONS OR SERVICING, TURN OFF THE CONTROLLER, WAIT FOR A WHILE AND CHECK THAT THE TEMPERATURE HAS COOLED.

5. Precautions during inspection of controller



WARNING

- WHEN YOU NEED TO TOUCH THE TERMINALS OR CONNECTORS ON THE OUTSIDE OF THE CONTROLLER DURING INSPECTION, ALWAYS FIRST TURN OFF THE CONTROLLER POWER SWITCH AND ALSO THE POWER SOURCE IN ORDER TO PREVENT POSSIBLE ELECTRICAL SHOCK.
- DO NOT DISASSEMBLE THE CONTROLLER. NEVER TOUCH ANY INTERNAL PARTS OF THE CONTROLLER. DOING SO MAY CAUSE BREAKDOWN, MALFUNCTION, INJURY, OR FIRE.

4.6.2 Precautions during service work

1. Be careful when removing the Z-axis motor (SCARA robots)



WARNING

- THE Z-AXIS WILL SLIDE DOWNWARD WHEN THE Z-AXIS MOTOR IS REMOVED, CAUSING A HAZARDOUS SITUATION.
- TURN OFF THE CONTROLLER AND PLACE A SUPPORT UNDER THE Z-AXIS BEFORE REMOVING THE Z-AXIS MOTOR.
 - BE CAREFUL NOT TO LET YOUR BODY GET CAUGHT BY THE DRIVING UNIT OF THE Z-AXIS OR BETWEEN THE Z-AXIS DRIVE UNIT AND THE INSTALLATION BASE.
-

2. Do not remove the Z-axis upper limit mechanical stopper



CAUTION

- Warning label 4 is attached to each SCARA robot. (For details on warning labels, see "3. Warning labels" in "Safety instructions.") Removing the upper limit mechanical stopper installed to the Z-axis spline or shifting its position will damage the Z-axis ball screw. Never attempt to remove it.
-

3. Use caution when handling a robot that contains powerful magnets



WARNING

- POWERFUL MAGNETS ARE INSTALLED INSIDE THE ROBOT. DO NOT DISASSEMBLE THE ROBOT SINCE THIS MAY CAUSE INJURY. DEVICES THAT MAY MALFUNCTION DUE TO MAGNETIC FIELDS MUST BE KEPT AWAY FROM THIS ROBOT.
-

See "6. Cautions regarding strong magnetic fields" in "Safety instructions" for detailed information on strong magnetic fields.

4. Use the following caution items when disassembling or replacing the pneumatic equipment.



WARNING

- AIR OR PARTS MAY FLY OUTWARD IF PNEUMATIC EQUIPMENT IS DISASSEMBLED OR PARTS REPLACED WHILE AIR IS STILL SUPPLIED.
- DO SERVICE WORK AFTER TURNING OFF THE CONTROLLER, REDUCING THE AIR PRESSURE, AND EXHAUSTING THE RESIDUAL AIR FROM THE PNEUMATIC EQUIPMENT.
 - BEFORE REDUCING THE AIR PRESSURE, PLACE A SUPPORT STAND UNDER THE Z-AXIS SINCE IT WILL DROP UNDER ITS OWN WEIGHT.
-

5. Use caution to avoid contact with the controller cooling fan



WARNING

- TOUCHING THE ROTATING FAN MAY CAUSE INJURY.
 - IF REMOVING THE FAN COVER, FIRST TURN OFF THE CONTROLLER AND MAKE SURE THE FAN HAS STOPPED.
-

6. Precautions for robot controllers



CAUTION

- Back up the robot controller internal data on an external storage device. The robot controller internal data (programs, point data, etc.) may be lost or deleted for unexpected reasons. Always make a backup of this data.
 - Do not use thinner, benzene, or alcohol to wipe off the surface of the programming box. The surface sheet may be damaged or printed letters or marks erased. Use a soft, dry cloth and gently wipe the surface.
 - Do not use a hard or pointed object to press the keys on the programming box. Malfunction or breakdown may result if the keys are damaged. Use your fingers to operate the keys.
 - Do not insert any SD memory card other than specified into the SD memory card slot in the programming box. Malfunction or breakdown may result if the wrong memory card is inserted.
-

4.7 Disposal

When disposing of robots and related items, handle them carefully as industrial wastes. Use the correct disposal method in compliance with your local regulations, or entrust disposal to a licensed industrial waste disposal company.

1. Disposal of lithium batteries

When disposing of lithium batteries, use the correct disposal method in compliance with your local regulations, or entrust disposal to a licensed industrial waste disposal company. We do not collect and dispose of the used batteries.

2. Disposal of packing boxes and materials

When disposing of packing boxes and materials, use the correct disposal method in compliance with your local regulations. We do not collect and dispose of the used packing boxes and materials.

3. Strong magnet



WARNING

STRONG MAGNETS ARE INSTALLED IN THE ROBOT. BE CAREFUL WHEN DISPOSING OF THE ROBOT.

See "6. Cautions regarding strong magnetic fields" in "Safety instructions" for detailed information on strong magnetic fields.

5. Emergency action when a person is caught by robot

If a person should get caught between the robot and a mechanical part such as the installation base, then release the axis.

■ Emergency action

Release the axis while referring to the following section in the manual for the robot controller.

Controller	Refer to:
YRC	Section 1, "Freeing a person caught by the robot" in Chapter 1



NOTE

Make a printout of the relevant page in the manual and post it a conspicuous location near the controller.

6. Cautions regarding strong magnetic fields

Some OMRON robots contain parts generating strong magnetic fields which may cause bodily injury, death, or device malfunction. Always comply with the following instructions.

- Persons wearing ID cards, purses, or wristwatches must keep away from the robot.
- Do not bring tools close to the magnet inside the robot.

7. Using the robot safely

7.1 Movement range

When a tool or workpiece is attached to the robot manipulator tip, the actual movement range enlarges from the movement range of the robot itself (Figure A) to include the areas taken up by movement of the tool and workpiece attached to the manipulator tip (Figure B).

The actual movement range expands even further if the tool or workpiece is offset from the manipulator tip. The movement range here is defined as the range of robot motion including all areas through which the robot arms, the tool and workpiece attached to the manipulator tip, and the solenoid valves attached to the robot arms move.

To make the robot motion easier to understand, the figures below only show the movement ranges of the tool attachment section, tool, and workpiece.

Please note that during actual operation, the movement range includes all areas where the robot arms and any other parts move along with the robot.

Movement range




Figure A: Movement range of robot itself

Figure B: Movement range when tool and workpiece are attached to manipulator tip



CAUTION

To make the robot motion easier to understand, the above figures only show the movement ranges of the tool attachment section, tool, and workpiece. In actual operation, the movement range includes all areas where the robot arms and any other parts move along with the robot.

7.2 Robot protective functions

Protective functions for OMRON robots are described below.

1. Overload detection

This function detects an overload applied to the motor and turns off the servo.

If an overload error occurs, take the following measures to avoid such errors:

1. Insert a timer in the program.
2. Reduce the acceleration.

2. Overheat detection

This function detects an abnormal temperature rise in the driver inside the controller and turns off the servo.

If an overheat error occurs, take the following measures to avoid the error:

1. Insert a timer in the program.
2. Reduce the acceleration.

3. Soft limits

Soft limits can be set on each axis to limit the working envelope in manual operation after return-to-origin and during automatic operation. The working envelope is the area limited by soft limits.



WARNING

SOFT LIMIT FUNCTION IS NOT A SAFETY-RELATED FUNCTION INTENDED TO PROTECT THE HUMAN BODY. TO RESTRICT THE ROBOT MOVEMENT RANGE TO PROTECT THE HUMAN BODY, USE THE MECHANICAL STOPPERS INSTALLED IN THE ROBOT (OR AVAILABLE AS OPTIONS).

4. Mechanical stoppers

If the servo is turned off by emergency stop operation or protective function while the robot is moving, then these mechanical stoppers prevent the axis from exceeding the movement range. The movement range is the area limited by the mechanical stoppers.

SCARA robots	<ul style="list-style-type: none">• The X and Y axes have mechanical stoppers that are installed at both ends of the maximum movement range. Some robot models have a standard feature that allows changing the mechanical stopper positions. On some other models, the mechanical stopper positions can also be changed by using option parts.• The Z-axis has a mechanical stopper at the upper end and lower end. The stopper positions can be changed by using option parts.• No mechanical stopper is provided on the R-axis.
---------------------	--



WARNING

AXIS MOVEMENT DOES NOT STOP IMMEDIATELY AFTER THE SERVO IS TURNED OFF BY EMERGENCY STOP OR OTHER PROTECTIVE FUNCTIONS, SO USE CAUTION.



CAUTION

If the robot moving at high speed collides with a mechanical stopper installed in the robot (or available as option), the robot may be damaged.

5. Z-axis (vertical axis) brake

An electromagnetic brake is installed on the Z-axis to prevent the Z-axis from sliding downward when the servo is OFF. This brake is working when the controller is OFF or the Z-axis servo power is OFF even when the controller is ON. The Z-axis brake can be released by the programming unit / handy terminal or by a command in the program when the controller is ON.



WARNING

THE VERTICAL AXIS WILL SLIDE DOWNWARD WHEN THE BRAKE IS RELEASED, CAUSING A HAZARDOUS SITUATION. TAKE ADEQUATE SAFETY MEASURES IN CONSIDERATION BY TAKING THE WEIGHT AND SHAPE INTO ACCOUNT.

- BEFORE RELEASING THE BRAKE AFTER PRESSING THE EMERGENCY STOP BUTTON, PLACE A SUPPORT UNDER THE VERTICAL AXIS SO THAT IT WILL NOT SLIDE DOWN.
- BE CAREFUL NOT TO LET YOUR BODY GET CAUGHT BETWEEN THE VERTICAL AXIS AND THE INSTALLATION BASE WHEN PERFORMING TASKS (DIRECT TEACHING, ETC.) WITH THE BRAKE RELEASED.

7.3 Residual risk

To ensure safe and correct use of OMRON robots and controllers, System integrators and/or end users implement machinery safety design that conforms to ISO12100.

Residual risks for OMRON robots and controllers are described in the DANGER or WARNING instructions provided in each chapter and section. Read them carefully.

7.4 Special training for industrial robot operation

Operators or persons who handle the robot for tasks such as for teaching, programming, movement checks, inspections, adjustments, and repairs must receive appropriate training and also have the skills needed to perform the job correctly and safely. They must also read the manual carefully to understand its contents before attempting the robot operation or maintenance.

Tasks related to industrial robots (teaching, programming, movement check, inspection, adjustment, repair, etc.) must be performed by qualified persons who meet requirements established by local regulations and safety standards for industrial robots.

Comparison of terms used in this manual with ISO

This manual	ISO 10218-1	Note
Maximum movement range	maximum space	Area limited by mechanical stoppers.
Movement range	restricted space	Area limited by movable mechanical stoppers.
Working envelope	operational space	Area limited by software limits.
Within safety enclosure	safeguarded space	

See “7.1 Movement range” in “Safety instructions” for details on the robot’s movement range.

Warranty

The OMRON robot and/or related product you have purchased are warranted against the defects or malfunctions as described below.

■ Warranty description

If a failure or breakdown occurs due to defects in materials or workmanship in the genuine parts constituting this OMRON robot and/or related product within the warranty period, then OMRON shall supply free of charge the necessary replacement/repair parts.

■ Warranty period

The warranty period ends 24 months after the date of manufacturing as shown on the products.

■ Exceptions to the warranty

This warranty will not apply in the following cases:

1. Fatigue arising due to the passage of time, natural wear and tear occurring during operation (natural fading of painted or plated surfaces, deterioration of parts subject to wear, etc.)
2. Minor natural phenomena that do not affect the capabilities of the robot and/or related product (noise from computers, motors, etc.)
3. Programs, point data and other internal data were changed or created by the user.

Failures resulting from the following causes are not covered by warranty.

1. Damage due to earthquakes, storms, floods, thunderbolt, fire or any other natural or man-made disaster.
2. Troubles caused by procedures prohibited in this manual.
3. Modifications to the robot and/or related product not approved by OMRON or OMRON sales representative.
4. Use of any other than genuine parts and specified grease and lubricant.
5. Incorrect or inadequate maintenance and inspection.
6. Repairs by other than authorized dealers.

WARRANTY

OMRON's exclusive warranty is that the products are free from defects in materials and workmanship for a period of one year (or other period if specified) from date of sale by OMRON.

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, REGARDING NONINFRINGEMENT, MERCHANTABILITY, OR FITNESS FOR PARTICULAR PURPOSE OF THE PRODUCTS. ANY BUYER OR USER ACKNOWLEDGES THAT THE BUYER OR USER ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. OMRON DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED.

LIMITATIONS OF LIABILITY

OMRON SHALL NOT BE RESPONSIBLE FOR SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED ON CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

In no event shall the responsibility of OMRON for any act exceed the individual price of the product on which liability is asserted.

IN NO EVENT SHALL OMRON BE RESPONSIBLE FOR WARRANTY, REPAIR OR OTHER CLAIMS REGARDING THE PRODUCTS UNLESS OMRON'S ANALYSIS CONFIRMS THAT THE PRODUCTS WERE PROPERLY HANDLED, STORED, INSTALLED AND MAINTAINED AND NOT SUBJECT TO CONTAMINATION, ABUSE, MISUSE OR INAPPROPRIATE MODIFICATION OR REPAIR.



Introduction

Contents

Before using the robot (Be sure to read the following notes.)	i
---	---


Introduction	iii
--------------	-----

3. Put timer during Z-axis operation.

If the tip load attached to the spline tip of the R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500 or R6YXGLC(P)600 exceeds 2kg, the Z-axis may be overloaded depending on the operation pattern.

In this case, put a timer during operation as shown in the Fig. below to prevent overload of the Z-axis. The reference timer values are shown below. Furthermore, the maximum payload is 4kg. If the tip load exceeds this maximum payload, the Z-axis may be overloaded easily. So, do not operate the robot with a tip load exceeding 4kg.

Putting timer during Z-axis operation



4. Z-axis additional mechanical stopper

The Z-axis additional mechanical stopper cannot be installed in the R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500 and R6YXGLC(P)600 as they are equipped with bellows.

The following models have mechanical stoppers only for the "minus" direction (no "plus" direction stopper):

R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000

5. Detach or attach the Y-axis arm cover.

On the R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600 models, the Y-axis arm cover can be detached/attached only when the Z-axis is at its DOWN end position. For details, see Chapter 2 "9. Detaching or attaching the covers".

Introduction

This manual describes OMRON industrial robots XGC series clean room models (R6YXGLC250 to R6YXGLC600) and XGP series dust/drip proof models (R6YXLGP250 to R6YXGP1000).

This manual describes the safety measures, handling, adjustment and maintenance of XGC/XGP series robots for correct, safe and effective use. Be sure to read this manual carefully before installing the robot. Even after you have read this manual, keep it in a safe and convenient place for future reference. This manual should be used with the robot and considered an integral part of it. When the robot is moved, transferred or sold, send this manual to the new user along with the robot. Be sure to explain to the new user the need to read through this manual.

For explanations not described in this manual, see the Installation Manual and Maintenance Manual for XG series. Additionally, for details about safety instructions, see also these manuals. If you have any questions, contact your distributor.

For details about actual robot operation and programming, refer to the "OMRON Robot Controller User's Manual".



WARNING

THE ADJUSTMENT AND MAINTENANCE WORK WITH THE COVER REMOVED NEEDS THE SPECIAL KNOWLEDGE AND SKILL. IF UNSKILLED WORK PERSON PERFORMS SUCH WORK, THIS MAY INVOLVE RISK. THESE TASKS MUST BE PERFORMED ONLY BY PERSONS WHO HAVE ENOUGH ABILITY AND QUALIFICATIONS IN ACCORDANCE WITH LOCAL LAWS AND REGULATIONS, BY REFERRING TO THE SEPARATE MAINTENANCE MANUAL. FOR DETAILED INFORMATION, PLEASE CONTACT YOUR DISTRIBUTOR WHERE YOU PURCHASED THE PRODUCT.

Chapter 1 **Functions**

Contents

1. Robot manipulator	1-1
1.1 Manipulator movement	1-1
1.2 Part names	1-2
2. Robot initialization number list	1-4


1. Robot manipulator

This chapter describes only the points that are different from the standard models.
For details about other explanations, see the Installation Manual for XG series standard models.

1.1 Manipulator movement


The XG series robots are available in 4-axis models having an X/Y-axis arm (equivalent to human arm) and a Z/R-axis (equivalent to human wrist). With these 4 axes, the XG series robots can move as shown in the Fig. below. By attaching different types of end effector (gripper) to the end of the arm, a wide range of tasks can be performed with high precision at high speeds. The (+) and (-) signs show the direction of axis movement when the jog keys on the programming box are pressed (standard setting at the factory).


Manipulator movement



1.2 Part names

R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600





2. Robot initialization number list

The XGC/XGP series robots are initialized for optimum setting (default setting) according to the robot model prior to shipping. The robot controllers do not have to be reinitialized during normal operation. However, if for some reason the controller must be reinitialized, proceed while referring to the list below.



CAUTION

- Absolute reset must be performed after reinitializing the controller. Before reinitializing the controller, read the descriptions stated in "2. Adjusting the origin" in Chapter 3 of the Installation Manual for XG series standard models and make sure you thoroughly understand the procedure.
- When the controller is initialized, the "ARM LENGTH" and "OFFSET PULSE" settings in the axis parameters will be erased, making the standard coordinate settings invalid. (For details about standard coordinates, see "4. Setting the standard coordinates" in Chapter 3 of the Installation Manual for XG series standard models.) If you do not want to change the origin position by initializing, make a note of the "ARM LENGTH" and "OFFSET PULSE" settings before initializing, and re-enter their settings after initialization is complete.

Robot initialization number	Model name
2300	R6YXGLC250, R6YXGLP250
2301	R6YXGLC350, R6YXGLP350
2302	R6YXGLC400, R6YXGLP400
2303	R6YXGLC500, R6YXGLP500
2304	R6YXGLC600, R6YXGLP600
2400	R6YXGP500 200
2401	R6YXGP500 300
2402	R6YXGP600 200
2403	R6YXGP600 300
2404	R6YXGHP600 200
2405	R6YXGHP600 400
2406	R6YXGP700 200
2407	R6YXGP700 400
2408	R6YXGP800 200
2409	R6YXGP800 400
2410	R6YXGP900 200
2411	R6YXGP900 400
2412	R6YXGP1000 200
2413	R6YXGP1000 400

Chapter 2 Installation

Contents

1. Robot installation conditions	2-1
1.1 Sucking from the base rear side of the clean room model	2-1
1.2 Protection ratings for moisture and dust on dust/drip proof models	2-2
1.2.1 Plug	2-2
1.2.2 Air purge piping	2-3
1.2.3 Exhaust port	2-4
2. Installation	2-5
2.1 Checking the product	2-5
2.2 Moving the robot	2-7
2.2.1 R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600	2-7
2.2.2 R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000	2-8
3. User wiring and user tubing	2-9
4. Limiting the movement range with X- and Y-axis mechanical stoppers	2-13
4.1 Installing the X-axis/Y-axis additional mechanical stoppers	2-16
4.1.1 R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600	2-16
4.1.2 R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000	2-18
5. Limiting the movement range with Z-axis mechanical stopper	2-19
6. Working envelope and mechanical stopper positions for maximum working envelope	2-19
7. Installing the user wiring and tubing newly	2-20
8. Passing the user wiring and tubing through the spline	2-21
9. Detaching or attaching the covers	2-22
9.1 R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600	2-22
9.2 R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000	2-27
10. Installing the tool flange	2-29
11. Permissible spline load	2-30

1. Robot installation conditions

The installation conditions for the clean room models are identical to the standard models.

The installation conditions for the dust/drip proof models are identical to the standard models except for the moisture and dust conditions.



NOTE


This chapter describes only the points that are different from the standard models.

For details about other explanations, see the Installation Manual for XG series standard models.

1.1 Sucking from the base rear side of the clean room model

Suck from the suction air joint on the base rear side at a suction air flow of 30N ϕ /min. as shown in the Fig. below.
If the Z-axis bellows become dented when sucking, reduce the suction air flow.

- Suction air joint
- Clean room model



1.2 Protection ratings for moisture and dust on dust/drip proof models

The protection ratings for moisture and dust on the R6YXGLP250, R6YXGLP350, R6YXGLP400, R6YXGLP500, R6YXGLP600, R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900 and R6YXGP1000 dust/drip proof models are equivalent to IP65.



WARNING

- DO NOT IMMERSE AND USE THE ROBOT OR ANY PART OF THE ROBOT IN WATER. OTHERWISE, WATER MAY PENETRATE INSIDE THE ROBOT.
- DO NOT USE THE ROBOT IN AN ENVIRONMENT EXCEEDING THE LISTED LEVELS OF PROTECTION FOR DUST AND MOISTURE. OTHERWISE, WATER OR DUST MAY PENETRATE INSIDE THE ROBOT.
- DO NOT SPLASH THE JET FLOW ONTO THE BELLOWS DIRECTLY. FOR DETAILS ABOUT DRIP PROOF PERFORMANCE FOR FLUID OTHER THAN WATER, CONTACT YOUR DISTRIBUTOR.

IP 6 5

Degree of protection versus water penetration : 5

At level 5, water injected from an optional angle does not exert a harmful effect.

Water injection pressure per the standards is 30kPa (30kN/m², 0.3kgf/cm²)

Injection speed is 12.5 liters per minute, at a time interval of 3 minutes.

Water may penetrate inside the robot if the water pressure is higher than this level.

Degree of protection versus solid debris : 6

1.2.1 Plug

On the R6YXGLP250, R6YXGLP350, R6YXGLP400, R6YXGLP500, R6YXGLP600 models, the accessory plug must be used at base's rear-side $\phi 12$ joint. (See the Fig. below.)




CAUTION

Install the accessory plug when the joint is not used. Failing to plug this hole can result in dust, etc., collecting there.

Using the plug

R6YXGLP250, R6YXGLP350, R6YXGLP400, R6YXGLP500, R6YXGLP600



1.2.2 Air purge piping



WARNING

BE SURE TO TURN THE CONTROLLER POWER AND THE AIR SUPPLY OFF BEFORE PERFORMING PIPING WORK.

The R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000 models are equipped with an air supply port (for air purging) at the X and Y axis joint areas on the rear face of the base. This air purging keeps dust out of the joint areas. The specifications are given below.

Maximum pressure	0.58MPa (6Kgf/cm ²)
Outer diameter × inner diameter	∅6mm × ∅4mm
Fluid	Dry clean air not containing deteriorated compressor oil; filtration 40μm or less

Be sure to connect the air supply and use the air purge function. Failing to do so may allow water and dust to enter the joint areas in some environments. Adjust the air to a pressure which suitable for keeping out water and dust. Use the air flow controller on the base's rear face to adjust the air flowrate.



WARNING

INSTALL THE AIR PURGE TUBING SO IT WILL NOT BECOME AN OBSTRUCTION THAT MIGHT CAUSE INJURIES IF PEOPLE STUMBLE ON IT AND FALL.




CAUTION

Install the air purge tubing so it will not obstruct robot movement.

Air purge piping

R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000



1.2.3 Exhaust port



WARNING

BE SURE TO TURN THE CONTROLLER POWER OFF BEFORE PERFORMING PIPING WORK.

The R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000 models are equipped with a $\phi 38$ exhaust port on rear face of the base. This provides the air path for the Z-axis bellows action. A blocked exhaust port will prevent proper bellows action, possibly damaging the bellows.

When installed in an area where there is a risk of water and dust entering the exhaust port, install a pipe which extends from the exhaust port to an area which is free of water and dust.



WARNING

INSTALL THE EXHAUST TUBING SO THEY WILL NOT BECOME AN OBSTRUCTION THAT MIGHT CAUSE INJURIES IF PEOPLE STUMBLE ON IT AND FALL.




CAUTION

Install the exhaust tubing so they will not obstruct robot movement.

Exhaust port

R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000



2. Installation

2.1 Checking the product

After unpacking, check the product configuration and conditions.

The following configurations are typical examples, so please check that the product is as specified in your order.




CAUTION

If there is any damage due to transportation or insufficient parts, please notify your distributor immediately.









- Controller : YRC
- Robot : R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600

Product configurations



- Controller : YRC
- Robot : R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000

Product configurations

Standard	
<p>Robot manipulator</p> 	<p>CD-ROM User's Manual or User's Manual</p> 
	<p>Warning label (×1)</p> 
	<p>Connector for user wiring (×2)</p> 
	<p>Origin position stickers</p> 
<p>YRC controller</p> 	<p>Standard coordinate setting jig (option)</p> 
Option	
<p>PB programming box</p> 	

2.2 Moving the robot



WARNING

SERIOUS INJURY MAY OCCUR IF THE ROBOT FALLS AND PINS SOMEONE UNDER IT.


- DO NOT ALLOW ANY PART OF YOUR BODY TO ENTER THE AREA BENEATH THE ROBOT DURING WORK.
- ALWAYS WEAR A HELMET, SAFETY SHOES AND GLOVES DURING WORK.

2.2.1 R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600

To check the mass of each robot, refer to "1.1 Basic specifications" in Chapter 7.

- 1 ***Fold the arms while referring to the Fig. below.***

Moving the robot



- 2 ***Place the robot on the base.***
One work person holds the support of the robot main body with both hands and other work person holds the robot cable to place the robot on the base.
- 3 ***Temporarily secure the robot by tightening the bolts.***

4

Secure the robot main body firmly.

Secure the robot main body firmly with the four hex socket head bolts as shown in the Fig. below.



WARNING

WHEN INSTALLING THE ROBOT, BE SURE TO USE THE SPECIFIED SIZE AND QUANTITY OF BOLTS THAT MATCH THE DEPTH OF TAPPED HOLES IN THE INSTALLATION BASE, AND SECURELY TIGHTEN THE BOLTS TO THE CORRECT TORQUE. IF THE BOLTS ARE NOT TIGHTENED CORRECTLY, THE ROBOT MIGHT FALL OVER DURING OPERATION CAUSING A SERIOUS ACCIDENT.


Tightening torque

Robot Model	Bolts Used	Tightening torque
R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600	M8	37Nm (380kgfcm)

Depth of tapped holes in installation base:

- Iron installation base : Bolt diameter × 1.5 or more
- Aluminum installation base : Bolt diameter × 3.0 or more
- Recommended bolt : JIS B 1176 hex socket head bolt, or equivalent
Strength class JIS B 1051 12.9, or equivalent

Installing the robot



2.2.2 R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000

For details regarding the transport (moving) and installation of the R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000 models, refer to the standard specification XG Installation Manual, Chapter 2 "2. Installation".

3. User wiring and user tubing



WARNING

ALWAYS TURN OFF THE CONTROLLER AND SHUT OFF AIR SUPPLY BEFORE ATTEMPTING WIRING AND PIPING WORK. IF AIR OR POWER IS SUPPLIED DURING THIS WORK, THE MANIPULATOR MAY MOVE ERRONEOUSLY CAUSING A HAZARDOUS SITUATION.

The XGC/XGP series robots are equipped with user wires and air tubes in the machine harness. The table below shows the number of wires and air tubes available for each robot model.

Robot Model	User wiring	User tubing
R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600	10 wires	Ø4, 4 tubes
R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000	20 wires	Ø6, 3 tubes

* Robot models for custom specifications may have different wiring or tubing.

The specifications of the user wires and air tubes are shown below. Always observe the specifications.

User Wiring

Rated voltage	30V
Allowable current	1.5A
Nominal cross-section area of conductor	0.2mm ²
Shield	Yes


User Tubing

Maximum pressure	0.58MPa (6Kgf/cm ²)
Outer diameter × inner diameter	Ø4mm × Ø2.5mm Ø6mm × Ø4mm
Fluid	Dry clean air not containing deteriorated compressor oil; filtration 40µm or less

Connector for the user wiring and joint for the user tubing are provided on each of the arm and base sides. For details about locations, see "1.2 External view and dimensions" in Chapter 7.

If the connector for the user wiring and the joint for the user tubing of the R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600, R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900 or R6YXGP1000 are not used, attach the cap and plug, respectively. Otherwise, moisture or dust may penetrate inside the robot. (See the Fig. below.)

Plug and cap



Y-axis arm side

Base side

■ Signal wiring connections in the machine harness

- R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600

Connector pins 1 to 10 can be used.

Signal	Connector	No.	Connection	No.	Connector	Color
User signal line	I O (Arm side)	1		1	I O (Base side)	Brown
		2		2		Red
		3		3		Orange
		4		4		Blue
		5		5		Violet
		6		6		Grey
		7		7		White
		8		8		Brown
		9		9		Red
		10		10		Orange
		11		11		
		12		12		
		13		13		
		14		14		
		15		15		Grey
Flame Ground				1	FG	Grey

* Robots models with non-standard specifications may have different wiring colors.

- R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000


Connectors 1 to 20 can be used for user signal wires. A shielded cable is connected to connector 24, and it cannot be used as a signal wire.

Signal	Connector	No.	Connection	No.	Connector	Color
User signal line	I O (Arm side)	1		1	I O (Base side)	Blue
		2		2		Orange
		3		3		Green
		4		4		Brown
		5		5		Gray
		6		6		Red
		7		7		Black
		8		8		Yellow
		9		9		Pink
		10		10		Violet
		11		11		White
		12		12		Blue/Red
		13		13		Orange/White
		14		14		Green/White
		15		15		Brown/White
		16		16		Gray/White
		17		17		Red/White
		18		18		Black/White
		19		19		Yellow/Black
		20		20		Pink/Black
Flame Ground		24		24		Orange/White
Flame Ground				1	FG	Green

The following describes how to make the wiring to the connector supplied with the robot.

Solder the user signal wires to the connector as shown in Fig. below and assemble the connector. Then, connect it to the user wiring connector. Tighten each connector screw to its specified torque. If the outer diameter of the cable is small, use tape or an equivalent item to thicken the cable clamp. Otherwise, moisture and dust may penetrate inside the robot.

Wiring



• Screw tightening torque

Position	Torque value (kgf • cm)
End hood	10 to 15
Clamp nut	15 to 20
Setscrews A and B	2 to 3

• Cable outer diameter

Model	Cable outer diameter (mm)
R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600	φ13.1 to 15.0
R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000	φ16.1 to 18.0



WARNING


- SECURE THE CONNECTOR FOR THE USER WIRING (SUPPLIED) FIRMLY WITH THE MOUNTING BRACKET (SUPPLIED). IF THIS CONNECTOR COMES OFF, THIS MAY CAUSE THE ROBOT TO MALFUNCTION. (SEE THE FIG. BELOW.)
- TAKE APPROPRIATE MEASURES SO THAT THE WIRING OR TUBING PREPARED BY THE USER THAT HAS BEEN INSTALLED USING THE CONNECTOR FOR THE USER WIRING OR THE JOINT FOR THE USER TUBING DOES NOT INTERFERE WITH THE ROBOT, ENTANGLE AROUND THE ROBOT, OR FLAP AROUND DURING ROBOT OPERATION. OTHERWISE, THE WIRING OR TUBING IS DAMAGED, CAUSING MALFUNCTION.
- LAY OUT THE WIRING OR TUBING PREPARED BY THE USER THAT HAS BEEN INSTALLED USING THE CONNECTOR FOR THE USER WIRING OR THE JOINT FOR THE USER TUBING SO THAT IT DOES NOT HINDER THE MOVEMENT OF WORK PERSONNEL. OTHERWISE, WORK PERSONNEL MAY STUMBLE OVER THE WIRING OR TUBING, CAUSING FALLING OR PERSONAL INJURY.




CAUTION

- For the connector for the user wiring supplied with the robot, pin contacts are connected to the connector on the arm side while socket contacts are connected to the connector on the base side. Pay special attention to this instruction when performing the soldering.
- Be sure to use the connector for the user wiring supplied with the robot. If other connector is used, contact fault may occur.

Connector for user wiring (Y-axis arm side)



Connector for user wiring (base side)



- Connector for user wiring supplied with the robot at shipment

R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600

Part Name	OMRON Model No.	Model No.	Quantity
User wiring connector at base side	KDM-M4872-000	NJW-24-16-PF-15 (Nanaboshi Electric Mfg.Co.,Ltd.)	1
User wiring connector at arm side	KDM-M4871-000	NJW-24-16-PM-15 (Nanaboshi Electric Mfg.Co.,Ltd.)	1
Cap	KDM-M4839-000	NJW-24-RCA (Nanaboshi Electric Mfg.Co.,Ltd.)	2

R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000

Part Name	OMRON Model No.	Model No.	Quantity
User wiring connector at base side	KDP-M4872-000	NJW-28-24-PF-18 (Nanaboshi Electric Mfg.Co.,Ltd.)	1
Arm side D-sub connector	KDP-M4871-000	NJW-28-24-PM-18 (Nanaboshi Electric Mfg.Co.,Ltd.)	1

To check the operation and signal transmission between the end effector and the controller or peripheral equipment after making connections, refer to the section "4.5.1 Trial Operation" in Chapter "Safety Instructions" of this manual.

4. Limiting the movement range with X- and Y-axis mechanical stoppers



WARNING

ALWAYS TURN OFF THE CONTROLLER BEFORE CHANGING THE MOVEMENT RANGE WITH MECHANICAL STOPPERS.



CAUTION

When the mechanical stopper positions are changed, the soft limits must be set to a point inside the mechanical stopper positions. For details about soft limits, see "3. Setting the soft limits" in Chapter 3 of the Installation Manual for XG standard model.


If the working envelope during robot work is smaller than the maximum working envelope range or if the robot interferes with peripheral units, the movement range is limited. (When the robot is shipped from factory, the movement range is set to the maximum level.)

The movement range can be limited by shifting the X-axis and Y-axis mechanical stopper positions. Follow the steps below to limit the movement range.


The following shows the mechanical stopper positions and movement range.

Mechanical stopper position and maximum movement position


R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600




X-axis standard stopper position




X-axis additional stopper position




Y-axis standard stopper position
(R6YXGLC(P)250, R6YXGLC(P)350)



Y-axis additional stopper position
(R6YXGLC(P)250, R6YXGLC(P)350)




Y-axis standard stopper position
(R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600)



Y-axis additional stopper position
(R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600)


Stopper position in plus direction

R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000



Stopper position in minus direction

R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000



As option parts are ordered, and then they are installed, the movement ranges of the X-axis and Y-axis can be narrowed. The movement range of the X-axis can be narrowed by moving only the existing stopper.



NOTE

Note that the stopper position may slightly deviate due to the part machining accuracy and mounting position.

After changing the mechanical stopper positions, set the soft limits to the values shown below.

■ Soft limits

• R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600

	Standard stopper	Additional stopper
Stopper position in X-axis plus or minus direction	131°	119°
Maximum movement position in X-axis plus or minus direction	129°	117°
Stopper position in Y-axis plus or minus direction	136° (R6YXGLC(P)250, R6YXGLC(P)350) 146° (R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600)	108°
Maximum movement position in Y-axis plus or minus direction	134° (R6YXGLC(P)250, R6YXGLC(P)350) 144° (R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600)	106°

• R6YXGP500, R6YXGP600

X-axis stopper position	Soft limit (pulses)	Working envelope
±12°	±32768	±9°
±36°	±120150	±33°
±92°	±324040	±89°
±132° (maximum working envelope position)	±473315	±130°

• R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000

X-axis stopper position	Soft limit (pulses)	Working envelope
±12°	±32768	±9°
±43°	±145635	±40°
±87°	±305834	±84°
±132° (maximum working envelope position)	±473315	±130°

• R6YXGP500, R6YXGP600

Y-axis stopper position	Soft limit (pulses)	Working envelope
±147° (maximum working envelope position)	±527928	±145°
+112°	+396857	+109°
-102°	-360448	-99°

• R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000

Y-axis stopper position	Soft limit (pulses)	Working envelope
±152° (maximum working envelope position)	±546133	±150°
+121°	+429264	+118°
-114°	-415061	-111°

■ Soft limits after setting additional stopper

• R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600

	Soft limit (pulses)	Working envelope
Working envelope in X-axis plus direction	425984	117°
Working envelope in X-axis minus direction	-425984	-117°
Working envelope in Y-axis plus direction	385934	106°
Working envelope in Y-axis minus direction	-385934	-106°

4.1 Installing the X-axis/Y-axis additional mechanical stoppers

4.1.1 R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600

Follow the steps below to install the X-axis/Y-axis additional mechanical stoppers.

Install the X-axis additional mechanical stopper by moving only the existing stopper.

Use the optional bolts and nuts listed below to install the Y-axis additional mechanical stopper.

	No.	Part No.	Q'ty	Remarks
Additional mechanical stopper parts in either one direction of Y-axis plus or minus direction or both directions (*1)	1	KCY-M2197-000	1	Stopper damper
	2	90990-01J067	1	Bolt
	3	90189-00J106	1	Nut
	4	90990-36J010	3	Seal washer

*1 : Only one set of parts shown above is used even when the stopper is added in either plus or minus direction or both directions. (When adding the stopper in both directions, the existing stopper is also used after moving it.)

■ Torque wrench, etc.



CAUTION

Use torque screwdrivers and torque wrenches which have been accurately calibrated.

	Name	Model No.	Manufacturer	Remarks
A	Torque wrench	N670SPK 17	KANON Nakamura Mfg. Co., Ltd.	Width across flats: 17mm. Tightening torque: 42Nm (428kgf/cm)

The X-axis and Y-axis mechanical stoppers can be individually installed in the X-axis and Y-axis plus and minus directions.

The following describes how to install the mechanical stopper using the stopper in the X-axis and Y-axis plus direction as an example. (The stopper in the minus direction can also be installed in the same manner.)




CAUTION


When adding the stopper in one direction of the Y-axis, do not remove the standard stopper. If this stopper is removed, the stopper on the opposite side is lost.

- 1 **Turn off the controller.**
- 2 **Place a sign indicating the robot is being adjusted.**
Place a sign indicating the robot is being adjusted, to keep others from touching the controller switch.
- 3 **Enter the safety enclosure.**
- 4 **Remove the bolts, seal washers, and washers.**
Remove the tapped-hole plug bolts, seal washers, and washers. Additionally, remove the stopper from the plus side of the X-axis.
- 5 **Sandwich the damper among the bolt, nut, and seal washer, and secure the parts.**
 1. Sandwich the damper (1) among the bolt (2), nut (3), and seal washer (4). At this time, use the bolt and nut listed in the Table on the previous page.
 2. Secure the parts to the arm by tightening the nut to the specified torque (42Nm (428kgfcm)).

▶ Step 4 Removing the tapped-hole plug bolts and seal washer



▶ Step 5 Installing the damper



**CAUTION**

When adding the stopper in one direction of the Y-axis, do not remove the standard stopper. If this stopper is removed, the stopper on the opposite side is lost.

6

Install the bolt and washer in the blank tapped hole in the standard stopper.

To protect the blank tapered hole in the standard stopper, tighten the bolt and washer to the specified torque (16Nm (163kgfcm)).

**CAUTION**

Be sure to put the seal washer (4). Otherwise, the dust/drip proof performance or the degree of cleanliness may lower.

7

Check that the movement range is limited.

8

Go out of the safety enclosure.

9

Turn on the controller.

Check that no one is inside the safety enclosure, and then turn on the controller.

10

Set the soft limits in the X-axis and Y-axis plus directions.

When the stopper is installed in the minus direction, set the soft limits in the minus direction.

**CAUTION**

Whether or not the X-axis stops at a position before the stopper limited by the soft limit must be checked from the outside of the safety enclosure.

11


Check that the X-axis and Y-axis stop firmly.

Whether or not the X-axis stops at a position before the stopper limited by the maximum soft limit must be checked from the outside of the safety enclosure.

**NOTE**

The X-axis may not stop at a position before the stopper due to the stopper part accuracy or position. If this happens, decrease the value while referring to the Table "n Soft limits" described previously.


▶ Step 6

Installing the bolt in the standard stopper

■ Installing the additional stoppers in both the plus and minus directions

Install the additional stoppers in both the plus and minus directions while referring to the Fig. below.

Installing the additional stoppers in both the plus and minus directions



4.1.2 R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000

For the R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900 and R6YXGP1000 models, refer to the standard specification XG Installation Manual, Chapter 2 "7. Limiting the movement range with X-axis and Y-axis mechanical stoppers".

5. Limiting the movement range with Z-axis mechanical stopper

The Z-axis additional mechanical stopper cannot be installed in the R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500 and R6YXGLC(P)600 as they are equipped with bellows.

Because the R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900 and R6YXGP1000 models are equipped with bellows, they have a Z-axis additional mechanical stopper for the "minus" direction only (no stopper for the "plus" direction).

For the installation procedure, refer to the standard specification XG Installation Manual, Chapter 2 "8. Limiting the movement range with Z-axis mechanical stopper".

6. Working envelope and mechanical stopper positions for maximum working envelope

The movement ranges for each robot, and the mechanical stopper positions which allow the maximum movement range are shown in Chapter 7 "1.2 External view and dimensions". For cautionary information, refer to the standard specification XG Installation Manual.

For the R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600, R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900 and R6YXGP1000, operate the robot carefully since there are positions where the base flange or robot cable interferes with the spline, bellows, or tool flange even within the working envelope.

7. Installing the user wiring and tubing newly


Use the user wiring and tubing in the machine harness as much as possible by considering the durability of the machine harness.

If the user wiring and tubing incorporated into the machine are insufficient, add new user wiring and tubing using cable ties.

The following shows the outside diameters and quantities that can be added by considering the durability of the machine harness.

Installing the user wiring and tubing newly

Clamp the user wiring and tubing with minimal cable tie quantity so that the additional signal lines and tubes do not deviate.
If the clamp is too strong, the machine harness may have faulty wiring.



Robot model	Signal line outside diameter $\varnothing D$ (mm) × quantity	Tube outside diameter $\varnothing d$ (mm) × quantity
R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600	$\varnothing 6 \times 1$ pc.	$\varnothing 4 \times 3$ pcs.
R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000	$\varnothing 10 \times 1$ pc.	$\varnothing 6 \times 3$ pcs.


8. Passing the user wiring and tubing through the spline

In the R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500 and R6YXGLC(P)600, the user wiring and tubing can be passed through the spline.

The following Fig. shows a reference example.

The wiring at the top end of the spline can be detached or attached easily when replacing the spline, R-axis speed reduction unit or R-axis motor. Use an appropriate connector that passes through the spline with an inside diameter of $\phi 11$.

Example of how to pass the wiring and tubing



9. Detaching or attaching the covers

9.1 R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600

To detach the covers, remove the bolts and screws.

It is recommended to replace the O-rings and seals shown below with new ones.

No.	Part name	Part number	Q'ty
1	O-ring	90200-01J350	2
2	O-ring	90990-17J025	1
3	Seal washer	90990-36J008	4
4	Seal	KDM-M1328-000	1
5	Seal	KDM-M1329-000	1
6	Seal	KDM-M1567-000 (R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400)	1
		KDM-M1567-100 (R6YXGLC(P)500, R6YXGLC(P)600)	
7	Seal	KDM-M1568-000 (R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400)	1
		KDM-M1568-100 (R6YXGLC(P)500, R6YXGLC(P)600)	
8	Seal washer	90990-36J008	4
9	Seal	KDM-M1315-000	2



WARNING

WHEN THE COVERS HAVE BEEN REMOVED FOR THE MAINTENANCE WORK, BE SURE TO RETURN THE COVERS TO THEIR ORIGINAL POSITIONS USING THE SCREWS AND BOLTS THAT HAVE SECURED THEM. IF ANY SCREW IS LOST, BE SURE TO SECURE THE COVERS USING THE SPECIFIED SCREWS AND QUANTITIES WHILE REFERRING TO THE FIG. BELOW.

IF THE COVERS ARE NOT SECURED FIRMLY, NOISE MAY OCCUR, THE COVER MAY DROP AND FLY OUT, YOUR HAND MAY BE ENTANGLED IN THE DRIVE UNIT DURING TEACHING, OR YOUR HAND MAY BE IN CONTACT THE HOT DRIVE UNIT, CAUSING BURN. TO PREVENT SUCH TROUBLES, STRICTLY OBSERVE THIS INSTRUCTION.



CAUTION

- The Y-axis arm cover cannot be detached or attached unless the Z-axis is moved down to its lower end.
- If any seal loses its strength when detaching the cover, it is recommended to replace it with a new one. If not replaced with a new one, the dust/drip proof performance or the degree of cleanliness may lower.
- Some seals are affixed. When removing such seal, peel off the adhesive agent and replace the seal with a new one.

■ Y-axis arm cover


- 1 Turn on the controller.**
Check that no one is inside the safety enclosure, and then turn on the controller.
- 2 Press the emergency stop button.**
Press the emergency stop button on the PB to put the robot in the emergency stop status.
- 3 Place a sign indicating the robot is being adjusted.**
Place a sign indicating the robot is being adjusted, to keep others from operating the controller or operation panel.

- 4 **Enter the safety enclosure while holding the PB.**
- 5 **Disconnect the user wiring and tubing from the spline.**
Disconnect all of the user wiring and tubing that have passed through the spline from the spline.
- 6 **Loosen the screw of the clamp.**
- 7 **Remove the bellows and remove the O-ring.**
- 8 **Remove the rolling mechanism part and O-ring.**
- 9 **To prevent the Z-axis from dropping, be sure to prop the spline or end effector with a support stand.**
- 10 **Release the Z-axis brake.**
Make sure that dropping of the Z-axis is prevented. Then, carefully move down the Z-axis to a position close to the lower end of the Z-axis.


**NOTE**

For details about how to release the Z-axis brake, see the "OMRON Robot Controller User's Manual".


▶ **Step 5-6** **Disconnecting the user wiring and tubing**




▶ **Step 7** **Removing the bellows**



▶ **Step 8** **Removing the rolling mechanism part**






▶ **Step 10** **Releasing the Z-axis brake**



- 11 *Turn off the controller.*
- 12 *Remove the mounting bracket, disconnect the connector for the user wiring, and remove the plate, seal (4) (5), and seal washer (3).*

- 13 *Remove the cover, seal (6), and seal (7).*
 Since the seal (7) is affixed to the Y-axis arm, peel off the adhesive agent completely.

CAUTION  When detaching or attaching the cover, it may be in contact with the boss inside the cover or the stay. So, install the cover while widening it slightly or shifting it.




14 *Place the cover on the base side.*

15 ***Reattach the cover in the reverse order of detachment.***


It is recommended to replace the O-rings and seals with new ones. If these parts are not replaced or reattached, the dust/drip proof performance or the degree of cleanliness may lower.

For details about the bellows clamp position, see the Fig. on the right.


▶ **Step 14** **Placing the cover**



▶ **Step 15** **Clamp**




* Install the bellows and clamp at the positions shown in the Fig. above (Tolerance: ± 0.5 mm)




■ Base cover

It is recommended to replace the seals with new ones. If these parts are not replaced or reattached, the dust/drip proof performance or the degree of cleanliness may lower.

Removing the base front cover



Removing the base rear cover



9.2 R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000

To detach the covers, remove the bolts and screws shown in the Fig. below.



WARNING

WHEN THE COVERS HAVE BEEN REMOVED FOR THE MAINTENANCE WORK, BE SURE TO RETURN THE COVERS TO THEIR ORIGINAL POSITIONS USING THE SCREWS AND BOLTS THAT HAVE SECURED THEM.

IF ANY SCREW IS LOST, USE THE SPECIFIED SCREWS AND QUANTITIES TO SECURE THE COVERS WHILE REFERRING TO THE FIG. BELOW.


IF THE COVERS ARE NOT SECURED FIRMLY, NOISE MAY OCUR, THE COVER MAY DROP AND FLY OUT, YOUR HAND MAY BE ENTANGLED IN THE DRIVE UNIT DURING TEACHING, OR YOUR HAND MAY BE IN CONTACT THE HOT DRIVE UNIT, CAUSING BURN. TO PREVENT SUCH TROUBLES, STRICTLY OBSERVE THIS CAUTION.




CAUTION

- The Y-axis arm cover cannot be detached or attached unless the Z-axis is moved down to its lower end.
- If any seal loses its strength when detaching the cover, it is recommended to replace it with a new one. If not replaced with a new one, the dust/drip proof performance or the degree of cleanliness may lower.
- Some seals are affixed. When removing such seal, peel off the adhesive agent and replace the seal with a new one.

R6YXGP500, R6YXGP600



R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000



10. Installing the tool flange


A tool flange can be installed later on the R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500 and R6YXGLC(P)600 models.

The following option parts are needed.

No.	Part No.	Q'ty	Remarks
1	KCY-M1790-000	1	Tool flange
2	91312-05014	2	Bolt
3	92A08-05308	1	Set screw

- 1 Turn off the controller.**
- 2 Place a sign indicating the robot is being adjusted.**
Place a sign indicating the robot is being adjusted, to keep others from operating the controller and operation panel.
- 3 Enter the safety enclosure.**
- 4 Install the tool flange.**
Align the orientation of the tapped hole for the tool flange set screw with that of the width across flat part of the spline, and then insert the tool flange all the way inside.
- 5 Install the tool flange with the bolt (2).**
Secure the tool flange after it has been inserted all the way inside.
 - Tightening torque: 9Nm (92kgfcm)Apply the grease to the bolt thinly to make the tightening torque stable.
- 6 Tighten the set screw (3).**
 - Tightening torque: 3.5Nm (36kgfcm)Apply Loctite 262 (Henkel Japan) to the set screw.
- 7 Go out of the safety enclosure.**







▶ Step 4-6 Installing the tool flange





11. Permissible spline load




Due to the strength factors of the spline, and the X, Y, Z, R axes, do not apply loads which exceed those shown below during an all-axis servo hold status, or during ultra-slow-speed operations. "F₂" includes the load of the tip load's weight.

Permissible spline loads












* The vertical distance from the Z-axis origin position to the load must not exceed 150mm.



* The vertical distance from the Z-axis origin position to the load must not exceed 300mm.



* The vertical distance from the Z-axis origin position to the load must not exceed 400mm.



* The vertical distance from the Z-axis origin position to the load must not exceed 400mm.

Chapter 3 Robot settings

Contents

1. Overview	3-1
2. Adjusting the origin	3-2
3. Standard coordinate setting using a standard coordinate setup jig	3-3
3.1 R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600	3-3
3.2 R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000	3-4

1. Overview

Various settings have been completely made at the factory or by your distributor before shipment, including the origin position setting. If the operating conditions are changed and the robot needs to be set again, then follow the procedures described in this chapter.

The following describes the safety precautions to be observed when making various settings.



CAUTION

- Read and understand the contents of this chapter completely before attempting to set the robot.
 - Place a conspicuous sign indicating the robot is being adjusted, to prevent others from touching the controller switch, programming box or operation panel.
 - If a safety enclosure has not yet been provided right after installation of the robot, rope off or chain off the movement area around the manipulator in place of a safety enclosure, and observe the following points.
 1. Use stable posts which will not fall over easily.
 2. The rope or chain should be easily visible by everyone around the robot.
 3. Place a conspicuous sign prohibiting the operator or other personnel from entering the movement area of the manipulator.
 - To check the operation after the settings have been made, refer to the section "4.5.1 Trial Operation" in Chapter "Safety Instructions" of this manual.
-

This chapter describes only the points that are different from the standard models.

For details about other explanations, see the Installation Manual for XG series standard models.


2. Adjusting the origin

This section describes only the origin adjustment points that are different from the standard models. For details about other explanations, see the Installation Manual for XG series standard models.

■ Adjusting the origin of the R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, or R6YXGLC(P)600

- Since the joints of the X-, Y-, and R-axis are covered, it is difficult to understand the clearance between the sensor and dog. After the return-to-origin has performed in the same manner as the standard model, carefully adjust the machine reference so that the origin does not deviate even when you touch the arm, etc. accidentally during work. After the machine reference has been adjusted, turn the joint to check that the sensor does not collide with the dog.
- Since the joints are covered, the origin positions of the X-axis and Y-axis cannot be changed.
- The R-axis sensor uses a compact sensor. So, carefully check that the tightening torque of the hex nut is as small as 1Nm (10kgfcm). If tightened to a torque larger than this level, the sensor may break.

R-axis origin sensor and hex nut



* KANON (Nakamura Mfg. Co., Ltd.), torque wrench N30SPK 8
Tightening torque 1Nm (10kgfcm)

3. Standard coordinate setting using a standard coordinate setup jig

Use a standard coordinate setup jig (option) to set the standard coordinates more accurately. The following describes how to set the standard coordinates using the standard coordinate setup jig.

3.1 R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600

Standard coordinate setup jig (option)

	Part No.	Name	Q'ty
1	KDM-M1577-000	Pin	1
2	91317-03065	Bolt	1

- 1 **Turn on the controller.**
Check that no one is inside the safety enclosure, and then turn on the controller.
- 2 **Put the robot in the emergency stop status.**
Press the emergency stop button on the PB to put the robot in the emergency stop status.




NOTE


For details about emergency stop and how to cancel the emergency stop, see the "OMRON Robot Controller User's Manual".

- 3 **Place a sign indicating the robot is being adjusted.**
Place a sign indicating the robot is being adjusted, to keep others from operating the controller or operation panel.
- 4 **Enter the safety enclosure while holding the PB.**
- 5 **Remove the plug bolt and seal washer.**
Put the robot in the posture with the positional relationship between the Y-axis arm and the X-axis arm as shown in the Fig. on the right, and then remove the plug bolt and seal washer.
- 6 **Insert the pin (1).**
 1. Put the robot in the arm posture allowing insertion of the pin, and make the X-axis arm almost aligned with the Y-axis.
 2. Adjust the arm positions so that the pin can be inserted into the enlarged hole in the Y-axis arm and the hole in the X-axis arm without jamming, and then insert the pin into the holes.
- 7 **Secure the pin (1) with the bolt (2).**
Lightly tighten the bolt so that the pin does not move.

Step 5 Removing the plug bolt



Step 6-8 Y-axis position pulse value




8 **Make a note of the Y-axis position pulse value.**

1. Enter "MANUAL>POINT" mode.
2. Lightly apply a clockwise torque to the Y-axis while holding the X-axis arm.
3. Make a note of the Y-axis position pulse value displayed on [POS] when the torque is unloaded.
4. Lightly apply a counterclockwise torque to the Y-axis while holding the X-axis arm.
5. Make a note of the Y-axis position pulse value displayed on [POS] when the torque is unloaded.

9 **Determine the + direction of the X-axis.**

Move the X-axis arm in the direction that you want to set as the + direction of the X-axis. At this time, make a note of the X-axis position pulse value displayed on [POS].

▶ Step 9 **X-axis + direction**



10 **Enter the "11. Arm length [mm]" values.**

Enter the following values in M1 and M2 for "11. Arm length [mm]" of axis parameters.

	M1 (X-axis arm length)	M2 (Y-axis arm length)
R6YXGLC(P)250	100.00	150.00
R6YXGLC(P)350	200.00	150.00
R6YXGLC(P)400	250.00	150.00
R6YXGLC(P)500	250.00	250.00
R6YXGLC(P)600	350.00	250.00

11 **Enter the "12. Offset pulse" values.**

Enter the values shown on the right in "12. Offset pulse" of axis parameters.

▶ Step 11 **Entering the "12. Offset pulse" values**

M1= X-axis position pulse value you have made a note of in step 9

$$M2 = \frac{\text{Y-axis position pulse value you have made a note of in step 8 (clockwise)} + \text{Y-axis position pulse value you have made a note of in step 8 (counterclockwise)}}{2}$$

Note: Round off the decimal part of the M2 value.

12 **Reattach the plug bolt and seal washer.**

1. Remove the pin and bolt.
2. Reattach the plug bolt and seal washer.

3.2 **R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000**

Regarding the R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000 models, refer to the standard specification XG Installation Manual, Chapter 3 "4. Setting the standard coordinates".

Chapter 4 Periodic inspection

Contents

1. List of inspection items	4-1
-----------------------------	-----

1. List of inspection items



WARNING

ONLY QUALIFIED ENGINEERS WHO HAVE RECEIVED THE ROBOT TRAINING COURSE CONDUCTED BY YOUR DISTRIBUTOR ARE ALLOWED TO INSPECT THE ITEMS NEEDING THE COVER REMOVAL WORK WHILE REFERRING TO THE SEPARATE MAINTENANCE MANUAL FOR XG SERIES.

●: Conduct. ○: Conduct if trouble is found as a result of inspection. △: Contact your distributor.

Location	Contents	Daily	6-month	Cleaning	Adjustment	Replacement
■ Inspection with the controller turned off						
Machine harness Robot cable	• Check for scratch, dent, or excessive bend.	●			○	
	• Check for damage.	●				△
Bellows	• Check for breakage.		●			○
Cables prepared by user	• Check for scratch, dent, or excessive bend.	●			○	○
Regulator Joint Air tube Solenoid valve Air cylinder	• Check that the air pressure level is correct.	●			○	
	• Check for air leak.	●			○	
	• Check that the drain is discharged.	●			○	
	• Check the air filter for contamination or damage.	●		○		○
Exterior of robot	• Check for damage.	●				△
Major bolts and screws of robot main body (those exposed to the outside)	• Check for looseness. (*1)		●		○	
Controller	• Check the terminal on the outside of the controller for looseness.		●		○	
	• Check the connection connector for looseness. (*2)		●		○	
Application of grease to Z-axis spline and Z-axis ball screw (*3) R6YXG(L)C: LG2(NSK) R6YXG(L)P: Alvania grease S2 (Showa Shell)	• Remove the old grease with a cloth rag and apply the grease.		●			
Z-axis ball screw and ball spline	• Check for play.		●		○	△
■ Inspection with the controller turned on						
Safeguard enclosure	• Check that the safeguard enclosure is located at its specified position.	●			○	
	• Check that the emergency stop turns on when the safeguard enclosure is open.	●			○	
	• Check that the warning label is affixed to the entrance.	●			○	
Emergency stop switch	• Check that the emergency stop turns on when pressed.	●			○	
Robot operation	• Check for unusual operation, vibration, or noise.	●				△
Functional check of Z-axis brake (*4)	• Drop amount from the Z-axis rest state is 3mm or less.	●				△
Air cooling fan on the rear of the controller	• Check that the fan rotates.		●		○	
	• Check for object blocking the fan.		●		○	
	• Check for noise during rotation. (*5)		●		○	△
	• Check the fan cover for contamination.		●		○	△

*1: If any bolt or screw is loose, retighten it. (For details about tightening torque, see the table below.)

*2: For details, see "4. Robot cable connection" in Chapter 2.

*3: For detail about how to apply the grease, see the separate Maintenance Manual.

*4: When the emergency stop switch is pressed outside the safeguard enclosure or when the controller power is turned off, visually inspect the Z-axis brake.

*5: If any object is found through the visual inspection, remove it. If noise is heard even when no object is found, contact your distributor.

Bolt tightening torque

Bolt size	Tightening torque (kgfcm)	Tightening torque (Nm)
M3 button head bolt	14	1.4
M4 set screw	20	2.0
M3	20	2.0
M4	46	4.5
M5	92	9.0
M6	156	15.3
M8	380	37
M10	459	45.0
M12	1310	128
M14	2090	205

Chapter 5 Harmonic drive replacement period

Contents

1. Overview	5-1
2. Replacement period	5-2

1. Overview

The XG series robots listed below use a harmonic drive as the speed reduction gear for the X, Y and R axes. Harmonic drives need to be replaced after specified operation hours have elapsed. Use the guideline explained below to determine the replacement period and replace the harmonic drive periodically. Since the XG series robots listed below use long-life harmonic grease, it is not necessary to replace the harmonic grease.



WARNING

ONLY AUTHORIZED ENGINEERS WHO RECEIVED THE ROBOT TRAINING COURSE CONDUCTED BY YOUR DISTRIBUTOR MUST REPLACE THE HARMONIC DRIVE WHILE REFERRING TO THE SEPARATE XG SERIES MAINTENANCE MANUAL.

Applicable models: R6YXGLC250, R6YXGLC350, R6YXGLC400, R6YXGLC500, R6YXGLC600
R6YXGLP250, R6YXGLP350, R6YXGLP400, R6YXGLP500, R6YXGLP600
R6YXGP500, R6YXGP600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900,
R6YXGP1000

2. Replacement period

The harmonic drive replacement period is determined by the total number of turns of the wave generator used in the harmonic drive. It is recommended to replace the harmonic drive when the total number of turns has reached 8.4×10^8 (at ambient operating temperatures of 0°C to $+40^\circ\text{C}$). This means that the replacement period will differ depending on the following operating conditions. If the robot operation duty ratio is high or the robot is operated in environments at higher temperatures, the harmonic drive should be replaced earlier.

$$\text{Replacement period} = 8.4 \times 10^8 / (n \times 60 \times h \times D \times N \times \theta) \text{ years}$$

where

- n : Number of axis movements per minute
- θ : Average turn per axis movement
- N : Speed reduction ratio
- h : Operation time per day
- D : Operation days per year

For example, when the robot is used under the following conditions, the replacement period for the X-axis harmonic drive of the R6YXG500 can be calculated as follows.

- n : 10
- θ : 0.25
- N : 80
- h : 24 hours per day
- D : 240 days per year

$$\begin{aligned} \text{Replacement period} &= 8.4 \times 10^8 / (n \times 60 \times h \times D \times N \times \theta) \\ &= 8.4 \times 10^8 / (10 \times 60 \times 24 \times 240 \times 80 \times 0.25) \\ &= 12.2 \text{ years} \end{aligned}$$

Harmonic drive speed reduction ratio

Robot model	X-axis	Y-axis	R-axis
R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600, R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000	80	80	50
R6YXGP500, R6YXGP600	80	80	30

Chapter 6

Torque limit designated Z-axis pushing action

Contents

1. Torque limit designated Z-axis pushing action

6-1

1. Torque limit designated Z-axis pushing action

Z-axis pushing action can be executed from the program by using the DRIVE statement's torque limit setting. The table below shows the various tip load weights and the corresponding recommended torque limit (%), torque offset (gravity offset for tip load weight), and speed limit (%) values relative to the motor's rated torque. Be sure to operate the robot within these limit values.

Failing to observe these limits could shorten the life of the Z-axis drive area and the arm joints.

For programming specifics, refer to the separate "YRC series programming manual".

R6YXGLC(P)250, R6YXGLC(P)350, R6YXGLC(P)400, R6YXGLC(P)500, R6YXGLC(P)600

Tip Load Weight (kg)	Torque Limit Value (%)	Pushing Force (N)	Torque Offset	Speed Limit Value (%)		
				R6YXGLC(P)250 R6YXGLC(P)350 R6YXGLC(P)400	R6YXGLC(P)500	R6YXGLC(P)600
4kg	55% to 100%	45 to 81	-33	50	40	33
3kg	55% to 100%	45 to 81	-26	50	40	33
2kg	50% to 100%	41 to 81	-20	50	40	33
1kg	40% to 100%	32 to 81	-14	50	40	33
0kg	30% to 100%	24 to 81	-10	50	40	33

R6YXGP500, R6YXGP600 Z200mm stroke specifications

Tip Load Weight (kg)	Torque Limit Value (%)	Pushing Force (N)	Torque Offset	Speed Limit Value (%)
8kg	60% to 100%	120 to 200	-19	15
7kg	50% to 100%	100 to 200	-17	15
6kg	50% to 100%	100 to 200	-15	14
5kg	40% to 100%	80 to 200	-14	14
4kg	40% to 100%	80 to 200	-12	13
3kg	30% to 100%	60 to 200	-10	12
2kg	30% to 100%	60 to 200	-8	12
1kg	30% to 100%	60 to 200	-8	11
0kg	30% to 100%	60 to 200	-8	10

R6YXGP500, R6YXGP600 Z300mm stroke specifications

Tip Load Weight (kg)	Torque Limit Value (%)	Pushing Force (N)	Torque Offset	Speed Limit Value (%)
8kg	60% to 100%	120 to 200	-21	21
7kg	50% to 100%	100 to 200	-19	19
6kg	50% to 100%	100 to 200	-17	18
5kg	40% to 100%	80 to 200	-15	16
4kg	40% to 100%	80 to 200	-14	15
3kg	30% to 100%	60 to 200	-12	14
2kg	30% to 100%	60 to 200	-10	13
1kg	30% to 100%	60 to 200	-9	13
0kg	30% to 100%	60 to 200	-9	12

R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000 Z200mm stroke specifications

Tip Load Weight (kg)	Torque Limit Value (%)	Pushing Force (N)	Torque Offset	Speed Limit Value (%)			
				R6YXGHP600, R6YXGP700	R6YXGP800	R6YXGP900	R6YXGP1000
18kg	50 to 100%	200 to 400	-21	34	30	26	24
17kg	50 to 100%	200 to 400	-21	33	29	26	23
16kg	50 to 100%	200 to 400	-20	33	29	26	23
15kg	50 to 100%	200 to 400	-19	32	28	25	23
14kg	50 to 100%	200 to 400	-18	32	28	25	22
13kg	50 to 100%	200 to 400	-18	31	27	24	22
12kg	40 to 100%	160 to 400	-16	30	27	24	21
11kg	40 to 100%	160 to 400	-15	30	26	23	21
10kg	40 to 100%	160 to 400	-14	29	26	23	20
9kg	40 to 100%	160 to 400	-13	29	25	22	20
8kg	40 to 100%	160 to 400	-12	28	25	22	20
7kg	30 to 100%	120 to 400	-11	27	24	21	19
6kg	30 to 100%	120 to 400	-10	27	23	21	19
5kg	30 to 100%	120 to 400	-9	26	23	20	18
4kg	20 to 100%	80 to 400	-8	25	22	20	18
3kg	20 to 100%	80 to 400	-7	25	22	19	17
2kg	20 to 100%	80 to 400	-6	24	21	19	17
1kg	20 to 100%	80 to 400	-5	23	20	18	16
0kg	10 to 100%	40 to 400	-4	23	20	18	16

R6YXGHP600, R6YXGP700, R6YXGP800, R6YXGP900, R6YXGP1000 Z400mm stroke specifications

Tip Load Weight (kg)	Torque Limit Value (%)	Pushing Force (N)	Torque Offset	Speed Limit Value (%)			
				R6YXGHP600, R6YXGP700	R6YXGP800	R6YXGP900	R6YXGP1000
18kg	60 to 100%	240 to 400	-22	34	30	26	24
17kg	50 to 100%	200 to 400	-21	33	29	26	23
16kg	50 to 100%	200 to 400	-21	33	29	26	23
15kg	50 to 100%	200 to 400	-20	32	28	25	23
14kg	50 to 100%	200 to 400	-19	32	28	25	22
13kg	50 to 100%	200 to 400	-18	31	27	24	22
12kg	40 to 100%	160 to 400	-16	30	27	24	21
11kg	40 to 100%	160 to 400	-15	30	26	23	21
10kg	40 to 100%	160 to 400	-15	29	26	23	20
9kg	40 to 100%	160 to 400	-13	29	25	22	20
8kg	40 to 100%	160 to 400	-13	28	25	22	20
7kg	30 to 100%	120 to 400	-11	27	24	21	19
6kg	30 to 100%	120 to 400	-10	27	23	21	19
5kg	30 to 100%	120 to 400	-9	26	23	20	18
4kg	30 to 100%	120 to 400	-9	25	22	20	18
3kg	20 to 100%	80 to 400	-8	25	22	19	17
2kg	20 to 100%	80 to 400	-6	24	21	19	17
1kg	20 to 100%	80 to 400	-5	23	20	18	16
0kg	10 to 100%	40 to 400	-4	23	20	18	16

Chapter 7 Specifications

Contents

1. Manipulator	7-1
1.1 Basic specification	7-1
1.2 External view and dimensions	7-4
1.2.1 R6YXGLC(P)250	7-4
1.2.2 R6YXGLC(P)350	7-6
1.2.3 R6YXGLC(P)400	7-8
1.2.4 R6YXGLC(P)500	7-10
1.2.5 R6YXGLC(P)600	7-12
1.2.6 R6YXGP500	7-14
1.2.7 R6YXGP600	7-16
1.2.8 R6YXGHP600	7-18
1.2.9 R6YXGP700	7-20
1.2.10 R6YXGP800	7-22
1.2.11 R6YXGP900	7-24
1.2.12 R6YXGP1000	7-26

1. Manipulator

1.1 Basic specification

Robot model		R6YXGLC(P)250	R6YXGLC(P)350	R6YXGLC(P)400	R6YXGLC(P)500	R6YXGLC(P)600	
Axis specifications	X-axis	Arm length	100mm	200mm	250mm	250mm	350mm
		Rotation angle	±129°				
	Y-axis	Arm length	150mm			250mm	
		Rotation angle	±134°		±144°		
	Z-axis	Stroke	150mm				
	R-axis	Rotation angle	±360°				
Motor	X-axis	200W					
	Y-axis	150W					
	Z-axis	50W					
	R-axis	100W					
Maximum speed	XY resultant	4.5m/s	5.6m/s	6.1m/s	5.1m/s	4.9m/s	
	Z-axis	1.1m/s					
	R-axis	1020°/s					
Repeatability (*1)	XY-axes	±0.01mm					
	Z-axis	±0.01mm					
	R-axis	±0.004°					
Payload		4kg					
R-axis tolerable moment of inertia (*2)		0.05kgm ² (0.5kgfcm ²)					
User wiring		10 cables					
User tubing		∅4×4					
Travel limit		1.Soft limit 2.Mechanical stopper (XYZ-axes)					
Robot cable		3.5m (option: 5m, 10m)					
Weight		21.5kg	22kg	22.5kg	25kg	26kg	
Degree of cleanliness (R6YXG(L)C)		Class ISO 3 (ISO14644-1), Suction air flow 30Nℓ/min. (*3)					
Dust/drip proof protection rating (R6YXG(L)P)		IP65 (IEC60529) or its equivalent (*4)					

*1: At constant ambient temperature (XY)

*2: There are limits to acceleration coefficient settings.

*3: Class 10 (0.1μm) FED-STD-209D or its equivalent

The required suction air flow may vary depending on the operating conditions or environment.

*4: Do not splash the jet flow onto the bellows directly. For details about drip proof performance for fluid other than water, contact your distributor.

* The Z-axis spline may vibrate in a Z-axis operation speed range of 20% to 40% depending on the arm position or Z-axis position. If the Z-axis spline vibrates, operate it beyond this operation speed range.

Noise level

Equivalent sound level of robot, Laeq (A) (when there is 10dB or larger difference from the back ground sound pressure level)	Position where the noise level is measured
75.1dB	1.25m apart from the back of the robot, 1.6m height from the floor surface.

Note: The noise level can be higher when the robot is set nearby the objects that cause sound reflection.

Robot model		R6YXGP500	R6YXGP600
Axis specifications	X-axis	Arm length	200mm
		Rotation angle	±130°
	Y-axis	Arm length	300mm
		Rotation angle	±145°
	Z-axis	Stroke	200mm/300mm
R-axis	Rotation angle	±360°	
Motor	X-axis	400W	
	Y-axis	200W	
	Z-axis	200W	
	R-axis	200W	
Maximum speed	XY resultant	7.6m/sec	8.4m/sec
	Z-axis	2.3m/sec(200st), 1.7m/sec(300st)	
	R-axis	1700°/sec	
Repeatability (*1)	XY-axes	±0.01mm	
	Z-axis	±0.01mm	
	R-axis	±0.004°	
Payload		8kg	
R-axis tolerable moment of inertia (*2)		0.30kgm ²	
User wiring		20 cables	
User tubing		∅6×3	
Travel limit		1.Soft limit 2.Mechanical stopper (XYZ-axes)	
Robot cable		3.5m (option: 5m, 10m)	
Weight		33kg	34kg
Dust/drip proof protection rating (R6YXG(L)P)		IP65 (IEC60529) or its equivalent (*3)	

*1: At constant ambient temperature (XY-axes)

*2: There are limits to acceleration coefficient settings.

*3: Do not splash the jet flow onto the bellows directly.

For details about drip proof performance for fluid other than water, contact your distributor.

Noise level

Equivalent sound level of robot, Laeq (A) (when there is 10dB or larger difference from the back ground sound pressure level)	Position where the noise level is measured
76.2dB	1.25m apart from the back of the robot, 1.6m height from the floor surface.

Robot model		R6YXGHP600	R6YXGP700	R6YXGP800	R6YXGP900	R6YXGP1000	
Axis specifications	X-axis	Arm length	200mm	300mm	400mm	500mm	600mm
		Rotation angle	±130°				
	Y-axis	Arm length	400mm				
		Rotation angle	±150°				
	Z-axis	Stroke	200mm/400mm				
R-axis	Rotation angle	±360°					
Motor	X-axis	750W					
	Y-axis	400W					
	Z-axis	400W					
	R-axis	200W					
Maximum speed	XY resultant	7.7m/sec	8.4m/sec	9.2m/sec	9.9m/sec	10.6m/sec	
	Z-axis	2.3m/sec(200st), 1.7m/sec(400st)					
	R-axis	920°/sec					
Repeatability (*1)	XY-axes	±0.02mm					
	Z-axis	±0.01mm					
	R-axis	±0.004°					
Payload		18kg					
R-axis tolerable moment of inertia (*2)		1.0kgm ²					
User wiring		20 cables					
User tubing		∅6×3					
Travel limit		1.Soft limit 2.Mechanical stopper (XYZ-axes)					
Robot cable		3.5m (option: 5m, 10m)					
Weight		52kg, 54kg	54kg, 56kg	56kg, 58kg	58kg, 60kg	60kg, 62kg	
Dust/drip proof protection rating (R6YXG(L)P)		IP65 (IEC60529) or its equivalent (*3)					

*1: At constant ambient temperature (XY-axes)

*2: There are limits to acceleration coefficient settings.

*3: Do not splash the jet flow onto the bellows directly.


For details about drip proof performance for fluid other than water, contact your distributor.

Noise level

Equivalent sound level of robot, Laeq (A) (when there is 10dB or larger difference from the back ground sound pressure level)	Position where the noise level is measured
78.4dB	1.0m apart from the back of the robot, 1.6m height from the floor surface.


1.2 External view and dimensions

1.2.1 R6YXGLC(P)250




R6YXGLC250, R6YXGLP250

Tool flange mount type



R6YXGLC250, R6YXGLP250

Working envelope






Option :

- X-axis additional stopper: X-axis mechanical stopper position can be changed to 119°-position (working envelope, 117°).
- Y-axis additional stopper: Y-axis mechanical stopper position can be changed to 108°-position (working envelope, 106°).




Other option: Standard coordinate setting jig

- Note that the robot cannot be used at a position where the base flange, robot cable, spline, bellows, and tool flange interfere with each other in the working envelope shown above.
- X-axis mechanical stopper position : 131°
- Y-axis mechanical stopper position : 136°

1.2.2 R6YXGLC(P)350




Standard clean room model, dust/drip proof model



R6YXGLC350, R6YXGLP350

Tool flange mount type




Clean room model, dust/drip proof model with tool flange

Detailed drawing D
Scale 1 : 1

View of E

R6YXGLC350, R6YXGLP350

Working envelope



Option :


- X-axis additional stopper: X-axis mechanical stopper position can be changed to 119°-position (working envelope, 117°).
- Y-axis additional stopper: Y-axis mechanical stopper position can be changed to 108°-position (working envelope, 106°).

Other option: Standard coordinate setting jig

- Note that the robot cannot be used at a position where the base flange, robot cable, spline, bellows, and tool flange interfere with each other in the working envelope shown above.
- X-axis mechanical stopper position : 131°
- Y-axis mechanical stopper position : 136°


R6YXGLC400, R6YXGLP400

Tool flange mount type



R6YXGLC400, R6YXGLP400

Working envelope



Option :

- X-axis additional stopper: X-axis mechanical stopper position can be changed to 119°-position (working envelope, 117°).
- Y-axis additional stopper: Y-axis mechanical stopper position can be changed to 108°-position (working envelope, 116°).

Other option: Standard coordinate setting jig

- Note that the robot cannot be used at a position where the base flange, robot cable, spline, bellows, and tool flange interfere with each other in the working envelope shown above.
- X-axis mechanical stopper position : 131°
- Y-axis mechanical stopper position : 146°

1.2.4 R6YXGLC(P)500

Connector for user wiring
(No. 1 to 10 usable. Cable clamp size,
 $\Phi 13.1$ to 15)

If not used, cover the connectors with
the caps supplied with the robot.

User tubing 1 ($\Phi 4$ black)

If the user tubing is not used,
attach the plug supplied with the robot.

User tubing 2 ($\Phi 4$ red)




User tubing 3 ($\Phi 4$ blue)

User tubing 4 ($\Phi 4$ white)



4-M3 \times 0.5 Depth 5

(There is no phase relationship with the R-axis origin.)


Since this tapped hole is used for the wiring or tubing
clamp, do not apply a large load.



Standard clean room model, dust/drip proof model




Cross section A-A
Scale 1:1



Z-axis tip shape
Scale 1:1


R6YXGLC500, R6YXGLP500

Tool flange mount type



R6YXGLC500, R6YXGLP500

Working envelope



- Note that the robot cannot be used at a position where the base flange, robot cable, spline, bellows, and tool flange interfere with each other in the working envelope shown above.
- X-axis mechanical stopper position : 131°
- Y-axis mechanical stopper position : 146°

Option :

- X-axis additional stopper: X-axis mechanical stopper position can be changed to 119°-position (working envelope, 117°).
- Y-axis additional stopper: Y-axis mechanical stopper position can be changed to 108°-position (working envelope, 116°).

Other option: Standard coordinate setting jig

1.2.5 R6YXGLC(P)600

Connector for user wiring
(No. 1 to 10 usable. Cable clamp size,
Ø13.1 to 15)

If not used, cover the connectors with
the caps supplied with the robot.



User tubing 1 (Ø4 black)

If the user tubing is not used,
attach the plug supplied with the robot.




User tubing 2 (Ø4 red)

User tubing 3 (Ø4 blue)

User tubing 4 (Ø4 white)




Standard clean room model, dust/drip proof model




R6YXGLC600, R6YXGLP600

Tool flange mount type



R6YXGLC600, R6YXGLP600

Working envelope



Option :

- X-axis additional stopper: X-axis mechanical stopper position can be changed to 119°-position (working envelope, 117°).
- Y-axis additional stopper: Y-axis mechanical stopper position can be changed to 108°-position (working envelope, 116°).

Other option: Standard coordinate setting jig






- Note that the robot cannot be used at a position where the base flange, robot cable, spline, bellows, and tool flange interfere with each other in the working envelope shown above.
- X-axis mechanical stopper position : 131°
- Y-axis mechanical stopper position : 146°

1.2.6 R6YXGP500

Connector for user wiring
(No.1 to 20 usable, cable clamp size: $\Phi 16$ to 18)

Cover with the caps provided when not used.

Note. Insert the plug provided when not used.




* There is no phase relation between each position of M5 tapped holes and R-axis origin position.


Z axis tip shape

R6YXGP500

Working envelope



Working envelope of left-handed system



Working envelope of right-handed system






- Note that the robot cannot be used at a position where the base flange, robot cable, spline, and bellows interfere with each other in the working envelope shown above.
- X-axis mechanical stopper position : 132°
- Y-axis mechanical stopper position : 147°

1.2.7 R6YXGP600

Connector for user wiring

(No.1 to 20 usable, cable clamp size: $\Phi 16$ to 18)

Cover with the caps provided when not used.




* There is no phase relation between each position of M5 tapped holes and R-axis origin position.


Z axis tip shape

R6YXGP600

Working envelope



Working envelope of left-handed system








Working envelope of right-handed system

- Note that the robot cannot be used at a position where the base flange, robot cable, spline, and bellows interfere with each other in the working envelope shown above.
- X-axis mechanical stopper position : 132°
- Y-axis mechanical stopper position : 147°

1.2.8 R6YXGHP600

Connector for user wiring
(No.1 to 20 usable, cable clamp size: $\phi 16$ to 18)
Cover with the caps provided when not used.




* There is no phase relation between each position of M5 tapped holes and R-axis origin position.


Z axis tip shape

R6YXGHP600

Working envelope



Working envelope of left-handed system








Working envelope of right-handed system

- Note that the robot cannot be used at a position where the base flange, robot cable, spline, and bellows interfere with each other in the working envelope shown above.
- X-axis mechanical stopper position : 132°
- Y-axis mechanical stopper position : 152°

1.2.9 R6YXGP700

Connector for user wiring
(No.1 to 20 usable, cable clamp size: $\varnothing 16$ to 18)

Cover with the caps provided when not used.




* There is no phase relation between each position of M5 tapped holes and R-axis origin position.


Z axis tip shape

R6YXGP700

Working envelope



Working envelope of left-handed system








Working envelope of right-handed system

- Note that the robot cannot be used at a position where the base flange, robot cable, spline, and bellows interfere with each other in the working envelope shown above.
- X-axis mechanical stopper position : 132°
- Y-axis mechanical stopper position : 152°

1.2.10 R6YXGP800

Connector for user wiring
(No.1 to 20 usable, cable clamp size: $\phi 16$ to 18)
Cover with the caps provided when not used.




* There is no phase relation between each position of M5 tapped holes and R-axis origin position.


Z axis tip shape

R6YXGP800

Working envelope



Working envelope of left-handed system




Working envelope of right-handed system




- Note that the robot cannot be used at a position where the base flange, robot cable, spline, and bellows interfere with each other in the working envelope shown above.
- X-axis mechanical stopper position : 132°
- Y-axis mechanical stopper position : 152°

1.2.11 R6YXGP900

Connector for user wiring
(No.1 to 20 usable, cable clamp size: $\phi 16$ to 18)
Cover with the caps provided when not used.



Note. Insert the plug provided when not used.




* There is no phase relation between each position of M5 tapped holes and R-axis origin position.


Z axis tip shape

R6YXGP900

Working envelope




Working envelope of left-handed system




Working envelope of right-handed system

- Note that the robot cannot be used at a position where the base flange, robot cable, spline, and bellows interfere with each other in the working envelope shown above.
- X-axis mechanical stopper position : 132°
- Y-axis mechanical stopper position : 152°


1.2.12 R6YXGP1000



R6YXGP1000
Working envelope



Working envelope of left-handed system




Working envelope of right-handed system

- Note that the robot cannot be used at a position where the base flange, robot cable, spline, and bellows interfere with each other in the working envelope shown above.
- X-axis mechanical stopper position : 132°
- Y-axis mechanical stopper position : 152°

Revision history

A manual revision code appears as a suffix to the catalog number on the front cover manual.

Cat. No. I158E-EN-01



The following table outlines the changes made to the manual during each revision.

Revision code	Date	Description
01	October 2013	Original production

OMRON

Authorized Distributor: