OMRON

Machine Automation Controller

NJ/NX-series CPU Unit Motion Control

User's Manual

NX701-17 NX701-16 NJ501-15 NJ501-14 NJ501-13 NJ301-12 NJ301-11 NJ301-11 NJ101-10





W507-E1-11

NOTE -

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.

No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

Trademarks -

- · Sysmac and SYSMAC are trademarks or registered trademarks of OMRON Corporation in Japan and other countries for OMRON factory automation products.
- · Microsoft, Windows, Windows Vista, Excel, and Visual Basic are either registered trademarks or trademarks of Microsoft Corporation in the USA and other countries.
- EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.
- ODVA, CIP, CompoNet, DeviceNet, and EtherNet/IP are trademarks of ODVA.
- The SD and SDHC logos are trademarks of SD-3C, LLC.



Other company names and product names in this document are the trademarks or registered trademarks of their respective companies.

Copyrights

Microsoft product screen shots reprinted with permission from Microsoft Corporation.

Introduction

Thank you for purchasing an NJ/NX-series CPU Unit.

This manual contains information that is necessary to use the Motion Control Function Module of an NJ/NX-series CPU Unit. Please read this manual and make sure you understand the functionality and performance of the NJ/NX-series CPU Unit before you attempt to use it in a control system. Keep this manual in a safe place where it will be available for reference during operation.

Intended Audience

This manual is intended for the following personnel, who must also have knowledge of electrical systems (an electrical engineer or the equivalent).

- Personnel in charge of introducing FA systems.
- · Personnel in charge of designing FA systems.
- Personnel in charge of installing and maintaining FA systems.
- · Personnel in charge of managing FA systems and facilities.

For programming, this manual is intended for personnel who understand the programming language specifications in international standard IEC 61131-3 or Japanese standard JIS B 3503.

Applicable Products

This manual covers the following products.

- NX-series CPU Units
 - NX701-17□□
 - NX701-16□□
- NJ-series CPU Units
 - NJ501-15□□
 - NJ501-14□□
 - NJ501-13□□
 - NJ301-12
 - NJ301-11
 - NJ101-10

Part of the specifications and restrictions for the CPU Units are given in other manuals. Refer to *Relevant Manuals* on page 2 and *Related Manuals* on page 21.

Relevant Manuals

The following provides the relevant manuals for the NJ-series CPU Units.

Read all of the manuals that are relevant to your system configuration and application before you use the NJ-series CPU Unit.

Most operations are performed from the Sysmac Studio Automation Software. Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for information on the Sysmac Studio.


						Manual					
	В	Basic information									
Purpose of use	NX-series CPU Unit Hardware User's Manual	NJ-series CPU Unit Hardware User's Manual	NJ/NX-series CPU Unit Software User's Manual	NJ/NX-series Instructions Reference Manual	NJ/NX-series CPU Unit Motion Control User's Manual	NJ/NX-series Motion Control Instructions Reference Manual	NJ/NX-series CPU Unit Built-in EtherCAT Port User's Manual	NJ/NX-series CPU Unit Built-in EtherNet/IP Port User's Manual	NJ-series Database Connection CPU Unit User's Manual	NJ-series SECS/GEM CPU Units User's Manual	Manual
Introduction to NX-series Controllers	•										
Introduction to NJ-series Controllers		•									
Setting devices and hardware											
Using motion control		Ē			•						
Using EtherCAT							•				
Using EtherNet/IP	•	•						•			
Using the database connection service		-							•		
Using the GEM Services		-								•	
Software settings											
Using motion control			Ē		•						
Using EtherCAT			_				•				
Using EtherNet/IP			•					•			
Using the database connection service			Ē						•		
Using the GEM Services			Ē							•	
Writing the user program											
Using motion control					•	•					
Using EtherCAT							•				
Using EtherNet/IP			•	•				•			
Using the database connection service									•		
Using the GEM Services										•	
Programming error processing											•
Testing operation and debugging											
Using motion control			ŀ		•						
Using EtherCAT			-				•				
Using EtherNet/IP			•					•			
Using the database connection service			ŀ						•		
Using the GEM Services			ŀ							•	
Learning about error management and corrections ^{*1}											•
Maintenance											
Using motion control	_				•						
Using EtherCAT	•	•					•				
Using EtherNet/IP		ŀ						•			

*1 Refer to the *NJ/NX-series Troubleshooting Manual* (Cat. No. W503) for the error management concepts and an overview of the error items. Refer to the manuals that are indicated with triangles for details on errors for the corresponding Units.

Manual Structure

Page Structure

The following page structure is used in this manual.



This illustration is provided only as a sample. It may not literally appear in this manual.

Special Information

Special information in this manual is classified as follows:

Precautions for Safe Use

Precautions on what to do and what not to do to ensure safe usage of the product.

Precautions for Correct Use

Precautions on what to do and what not to do to ensure proper operation and performance.

L			
I	_		75
	_	_	7.0
	_		N
	-	_	

Additional Information

Additional information to read as required. This information is provided to increase understanding or make operation easier.

Note References are provided to more detailed or related information.



Version Information


Information on differences in specifications and functionality for CPU Units with different unit versions and for different versions of the Sysmac Studio are given.

Precaution on Terminology

In this manual, "download" refers to transferring data from the Sysmac Studio to the physical Controller and "upload" refers to transferring data from the physical Controller to the Sysmac Studio.

For the Sysmac Studio, synchronization is used to both upload and download data. Here, "synchronize" means to automatically compare the data for the Sysmac Studio on the computer with the data in the physical Controller and transfer the data in the direction that is specified by the user.

Sections in this Manual



CONTENTS

Introduction	1
Relevant Manuals	2
Manual Structure	3
Sections in this Manual	5
Terms and Conditions Agreement	11
Safety Precautions	13
Precautions for Safe Use	14
Precautions for Correct Use	15
Regulations and Standards	16
Versions	18
Related Manuals	21
Revision History	24

Section 1 Introduction to the Motion Control Function Module

1-1	Featu	res	
1-2	Syste	m Configuration	1-3
1-3	Applic	cation Procedure	
1-4	Specif	fications	
	1-4-1	General Specifications	
	1-4-2	Performance Specifications	
	1-4-3	Function Specifications	

Section 2 Motion Control Configuration and Principles

2-1	Interna	I Configuration of the CPU Unit	2-2
2-2	Motion	Control Configuration	2-3
2-3	Motion	Control Principles	2-4
	2-3-1	CPU Unit Tasks	2-4
	2-3-2	Example of Task Operations for Motion Control	2-11
2-4	EtherC	AT Communications and Motion Control	2-18
	2-4-1	CAN Application Protocol over EtherCAT (CoE)	2-18
	2-4-2	Relationship between EtherCAT Master Function Module and MC Function Module	2-19
	2-4-3	Relationship between Process Data Communications Cycle and Motion Control Period	2-21

Section 3 Configuring Axes and Axes Groups

3-1	Axes		3-2
	3-1-1	Introduction to Axes	3-2

	3-1-2	Introduction to Axis Parameters	
	3-1-3	Introduction to Axis Variables	
	3-1-4	Synchronizing Axis Variables	
	3-1-5	Specifying an Axis in the User Program	
3-2	Axis S	Setting Procedure	
	3-2-1	Axis Configuration Procedure	
	3-2-2	Setting Procedure	
3-3	Axes	Groups	
	3-3-1	Introduction to Axes Groups	
	3-3-2	Introduction to Axes Group Parameters	
	3-3-3	Introduction to Axes Group Variables	
	3-3-4	Specifying an Axes Group in the User Program	
3-4	Settin	g Procedures for Axes Groups	
	3-4-1	Setting Procedure for an Axes Group	
	3-4-2	Setting Procedure	
		0	

Section 4 Checking Wiring from the Sysmac Studio

4-1	Functi	ons of the Sysmac Studio	4-2
	4-1-1	MC Test Run Function	
	4-1-2	Application Procedure	
	4-1-3	Axis Parameter Setting Example	
	4-1-4	Starting the MC Test Run Function	4-6
4-2	Monito	oring Sensor Signals	4-7
4-3	Check	ing Motor Operation	4-8
4-3	Check 4-3-1	ing Motor Operation Turning ON the Servo	
4-3		Turning ON the Servo	4-8
4-3	4-3-1	Turning ON the Servo Jogging Homing	4-8 4-8 4-9
4-3	4-3-1 4-3-2	Turning ON the Servo Jogging Homing Absolute Positioning	4-8 4-8 4-9 4-10
4-3	4-3-1 4-3-2 4-3-3	Turning ON the Servo Jogging Homing	4-8 4-8 4-9 4-10

Section 5 Motion Control Parameters

5-1	Introdu	iction	
5-2	Axis Pa	arameters	
	5-2-1	Axis Parameters	
	5-2-2	Axis Basic Settings	
	5-2-3	Unit Conversion Settings	
	5-2-4	Operation Settings	
	5-2-5	Other Operation Settings	5-17
	5-2-6	Limit Settings	
	5-2-7	Position Count Settings	
	5-2-8	Servo Drive Settings	
	5-2-9	Homing Settings	
	5-2-10	Axis Parameter Setting Example	
5-3	Axes G	roup Parameters	5-25
	5-3-1	Axes Group Parameters	
	5-3-2	Axes Group Basic Settings	
	5-3-3	Axes Group Operation Settings	
	5-3-4	Enabling an Axes Group	

Section 6 Motion Control Programming

6-1	Introdu	uction	. 6-2
6-2	Motior	Control Instructions	. 6-4
	6-2-1	Function Blocks for PLCopen® Motion Control	6-4

	6-2-2	Motion Control Instructions of the MC Function Module	6-4
6-3	State T 6-3-1 6-3-2 6-3-3	Transitions	6-5 6-6
6-4	Execut 6-4-1 6-4-2 6-4-3 6-4-4	tion and Status of Motion Control Instructions Basic Rules for Execution of Instructions Execution Timing Charts Timing Chart for Re-execution of Motion Control Instructions Timing Chart for Multi-execution of Motion Control Instructions	6-10 6-12 6-15
6-5	Positio 6-5-1 6-5-2	n s Types of Positions Valid Positions for Each Axis Type	6-17
6-6	Systen 6-6-1 6-6-2 6-6-3	n-defined Variables for Motion Control Overview of System-defined Variables for Motion Control System for System-defined Variables for Motion Control Tables of System-defined Variables for Motion Control	6-19 6-22
6-7	Cam Ta	ables and Cam Data Variables	6-35
6-8	Progra	mming Motion Controls	6-38
6-9	Creatir	ng Cam Tables	6-40

Section 7 Manual Operation

7-1	Outlin	ne	7-2
7-2	Turnin	ng ON the Servo	7-3
	7-2-1	Turning ON the Servo	
	7-2-2	Setting Axis Parameters	7-4
	7-2-3	Programming Example	
7-3	Joggiı	ng	7-5
	7-3-1	Jogging Procedure	
	7-3-2	Setting Axis Parameters	7-6
	7-3-3	Setting Example for Input Variables	7-6
	7-3-3		

Section 8 Homing

8-1	Outline8-					
8-2	Homin					
	8-2-1	Setting Homing Parameters				
	8-2-2	Monitoring the Homing Operation				
8-3 Homing Operation						
8-4	Homin	g with an Absolute Encoder				
	8-4-1	Outline of Function				
	8-4-2	Setting Procedure	8-16			
8-5	5 High-speed Homing8					

Section 9 Motion Control Functions

9-1	Single-	axis Position Control	9-3
		Outline of Operation	
		Absolute Positioning	
		Relative Positioning	
		Interrupt Feeding	

	9-1-5	Cyclic Synchronous Positioning	
	9-1-6	Stopping	
	9-1-7	Override Factors	
9-2	Sinale-	axis Synchronized Control	9-13
J -2	9-2-1	Overview of Synchronized Control	
	9-2-1	Gear Operation	
	9-2-2	Positioning Gear Operation	
	9-2-3 9-2-4	Cam Operation	
	9-2-4 9-2-5	Cam Tables	
	9-2-5 9-2-6	Synchronous Positioning	
	9-2-0 9-2-7		
	9-2-7 9-2-8	Combining Axes Master Axis Phase Shift	
	9-2-8 9-2-9		
		Slave Axis Position Compensation	
	9-2-10	Achieving Synchronized Control in Multi-motion	
9-3	Single-	axis Velocity Control	
	9-3-1	Velocity Control	
	9-3-2	Cyclic Synchronous Velocity Control	
9-4	Single-	axis Torque Control	9-31
-			
9-5		on Functions for Single-axis Control	
	9-5-1	Positions	
	9-5-2	Velocity	
	9-5-3	Acceleration and Deceleration	
	9-5-4	Jerk	
	9-5-5	Specifying the Operation Direction	
	9-5-6	Re-executing Motion Control Instructions	
	9-5-7	Multi-execution of Motion Control Instructions (Buffer Mode)	
9-6		xes Coordinated Control	
	9-6-1	Outline of Operation	
	9-6-2	Linear Interpolation	
	9-6-3	Circular Interpolation	
	9-6-4	Axes Group Cyclic Synchronous Positioning	
	9-6-5	Stopping Under Multi-axes Coordinated Control	
	9-6-6	Overrides for Multi-axes Coordinated Control	
9-7	Comm		0.61
		on Functions for Multi-axes Coordinated Control	
		on Functions for Multi-axes Coordinated Control	
	9-7-1	Velocity Under Multi-axes Coordinated Control	
		Velocity Under Multi-axes Coordinated Control Acceleration and Deceleration Under Multi-axes Coordinated Control	9-61 9-62
	9-7-1 9-7-2	Velocity Under Multi-axes Coordinated Control Acceleration and Deceleration Under Multi-axes Coordinated Control Jerk for Multi-axes Coordinated Control	
	9-7-1 9-7-2 9-7-3 9-7-4	Velocity Under Multi-axes Coordinated Control Acceleration and Deceleration Under Multi-axes Coordinated Control Jerk for Multi-axes Coordinated Control Re-executing Motion Control Instructions for Multi-axes Coordinated Control	
	9-7-1 9-7-2 9-7-3	Velocity Under Multi-axes Coordinated Control Acceleration and Deceleration Under Multi-axes Coordinated Control Jerk for Multi-axes Coordinated Control	9-61 9-62 9-63 9-64
9- 8	9-7-1 9-7-2 9-7-3 9-7-4 9-7-5	Velocity Under Multi-axes Coordinated Control Acceleration and Deceleration Under Multi-axes Coordinated Control Jerk for Multi-axes Coordinated Control Re-executing Motion Control Instructions for Multi-axes Coordinated Control Multi-execution (Buffer Mode) of Motion Control Instructions for Multi-axes Coordinated Control	9-61 9-62 9-63 9-63 9-64 9-65
9-8	9-7-1 9-7-2 9-7-3 9-7-4 9-7-5 Other F	Velocity Under Multi-axes Coordinated Control	9-61 9-62 9-63 9-64 9-65 9-65
9-8	9-7-1 9-7-2 9-7-3 9-7-4 9-7-5 Other F 9-8-1	Velocity Under Multi-axes Coordinated Control	9-61 9-62 9-63 9-64 9-65 9-65 9-73 9-73
9-8	9-7-1 9-7-2 9-7-3 9-7-4 9-7-5 Other F 9-8-1 9-8-2	Velocity Under Multi-axes Coordinated Control	9-61 9-62 9-63 9-64 9-65 9-65 9-73 9-73 9-74
9-8	9-7-1 9-7-2 9-7-3 9-7-4 9-7-5 Other F 9-8-1 9-8-2 9-8-3	Velocity Under Multi-axes Coordinated Control	9-61 9-62 9-63 9-64 9-65 9-65 9-73 9-73 9-74 9-74
9-8	9-7-1 9-7-2 9-7-3 9-7-4 9-7-5 Other F 9-8-1 9-8-2 9-8-3 9-8-3 9-8-4	Velocity Under Multi-axes Coordinated Control	9-61 9-62 9-63 9-64 9-65 9-65 9-73 9-73 9-74 9-74 9-75
9-8	9-7-1 9-7-2 9-7-3 9-7-4 9-7-5 Other F 9-8-1 9-8-2 9-8-3 9-8-3 9-8-4 9-8-5	Velocity Under Multi-axes Coordinated Control	9-61 9-62 9-63 9-64 9-65 9-65 9-73 9-73 9-73 9-74 9-74 9-75 9-76
9-8	9-7-1 9-7-2 9-7-3 9-7-4 9-7-5 Other F 9-8-1 9-8-2 9-8-3 9-8-4 9-8-5 9-8-6	Velocity Under Multi-axes Coordinated Control	9-61 9-63 9-63 9-65 9-65 9-65 9-73 9-73 9-73 9-74 9-74 9-75 9-76 9-77
9-8	9-7-1 9-7-2 9-7-3 9-7-4 9-7-5 Other F 9-8-1 9-8-2 9-8-3 9-8-4 9-8-5 9-8-6 9-8-7	Velocity Under Multi-axes Coordinated Control	9-61 9-62 9-63 9-64 9-65 9-73 9-73 9-74 9-74 9-74 9-75 9-76 9-77 9-78
9-8	9-7-1 9-7-2 9-7-3 9-7-4 9-7-5 Other F 9-8-1 9-8-2 9-8-3 9-8-4 9-8-5 9-8-6 9-8-7 9-8-8	Velocity Under Multi-axes Coordinated Control	9-61 9-62 9-63 9-64 9-65 9-73 9-73 9-74 9-74 9-74 9-75 9-76 9-77 9-78 9-78
9-8	9-7-1 9-7-2 9-7-3 9-7-4 9-7-5 Other F 9-8-1 9-8-2 9-8-3 9-8-4 9-8-5 9-8-6 9-8-7 9-8-8 9-8-9	Velocity Under Multi-axes Coordinated Control	9-61 9-62 9-63 9-64 9-65 9-73 9-73 9-73 9-74 9-74 9-75 9-76 9-77 9-78 9-78 9-78
9-8	9-7-1 9-7-2 9-7-3 9-7-4 9-7-5 Other F 9-8-1 9-8-2 9-8-3 9-8-3 9-8-4 9-8-5 9-8-6 9-8-7 9-8-8 9-8-7 9-8-8 9-8-9 9-8-10	Velocity Under Multi-axes Coordinated Control	9-61 9-62 9-63 9-64 9-65 9-73 9-73 9-73 9-74 9-74 9-75 9-76 9-77 9-78 9-78 9-78 9-79
9-8	9-7-1 9-7-2 9-7-3 9-7-4 9-7-5 Other F 9-8-1 9-8-2 9-8-3 9-8-4 9-8-5 9-8-6 9-8-7 9-8-8 9-8-9	Velocity Under Multi-axes Coordinated Control	9-61 9-62 9-63 9-64 9-65 9-73 9-73 9-73 9-74 9-74 9-75 9-76 9-77 9-78 9-78 9-78 9-79 9-81 9-81

Section 10 Sample Programming

10-1	1 Overview of Sample Programming ⁻				
		Devices			
		Installation and Wiring			

	10-1-3	Setup	10-2
10-2	Basic P	rogramming Samples	10-3
	10-2-1	Monitoring EtherCAT Communications and Turning ON Servos	
	10-2-2	Interlocking Axis Operation with Master Control Instructions	
	10-2-3	Error Monitoring and Error Resetting for	
		Single-axis Operation and Synchronized Operation	10-7
	10-2-4	Error Monitoring and Error Resetting for Multi-axes Coordinated Operation	
	10-2-5	Monitoring for Instruction Errors	
	10-2-6	Checking to See If Errors Are Reset	
	10-2-7	Stopping Axes during Single-axis Operation	10-19
	10-2-8	Stopping an Axes Group in Coordinated Motion	
	10-2-9	Homing and Absolute Positioning	
	10-2-10	Changing the Target Position by Re-execution of an Instruction	
	10-2-11	Interrupt Feeding	
	10-2-12	Changing the Cam Table by Re-execution of an Instruction	
	10-2-13	Using a Cam Profile Curve to Correct the Sync Position	
	10-2-14	Shifting the Phase of a Master Axis in Cam Motion	
	10-2-15	Changing the Actual Position during Velocity Control	
	10-2-16	Changing a Cam Data Variable and Saving the Cam Table	
	10-2-17	Temporarily Changing Axis Parameters	
	10-2-18	Updating the Cam Table End Point Index	10-89

Section 11 Troubleshooting

11-1	Overvie			
		How to Check for Errors Errors Related to the Motion Control Function Module		
		eshooting		
	11-2-1 11-2-2	Error Table Error Descriptions Error Causes and Remedies		

Appendices

A-1	Connecting the Servo DriveA-				
		Wiring the Servo Drive			
	A-1-2	Servo Drive Settings	A-2		
A-2	Connec	cting to Encoder Input Terminals	A-12		
	A-2-1	Wiring to Encoder Input Terminals	A-12		
	A-2-2	Settings for Encoder Input Terminals			
A-3	Connec	cting to NX Units	A-18		
A-4	PDS St	ate Transition	A-19		
	A-4-1	PDS State Control Method.			
	A-4-2	Main Circuit Power Supply OFF Detection			
A-5	Termin	ology	A-22		
	A-5-1	NJ/NX-series Controller	A-22		
	A-5-2	Motion Control	A-23		
	A-5-3	EtherCAT Communications			
A-6	Versior	n Information	A-26		

Index

Terms and Conditions Agreement

Warranty, Limitations of Liability

Warranties

Exclusive Warranty

Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.

Limitations

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right.

• Buyer Remedy

Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See http://www.omron.com/global/ or contact your Omron representative for published information.

Limitation on Liability; Etc

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CON-SEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

Application Considerations

Suitability of Use

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

Programmable Products

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

Disclaimers

Performance Data

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

Change in Specifications

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

Errors and Omissions

Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

Safety Precautions

Definition of Precautionary Information

Refer to the following manuals for safety precautions.

- NX-series CPU Unit Hardware User's Manual (Cat. No. W535)
- NJ-series CPU Unit Hardware User's Manual (Cat. No. W500)
- NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501)

Precautions for Safe Use

Refer to the following manuals for precautions for safe use.

- NX-series CPU Unit Hardware User's Manual (Cat. No. W535)
- NJ-series CPU Unit Hardware User's Manual (Cat. No. W500)
- NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501)

Precautions for Correct Use

Refer to the following manuals for precautions for correct use.

- NX-series CPU Unit Hardware User's Manual (Cat. No. W535)
- NJ-series CPU Unit Hardware User's Manual (Cat. No. W500)
- NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501)

Regulations and Standards

Conformance to EC Directives

Applicable Directives

- EMC Directives
- · Low Voltage Directive

Concepts

• EMC Directive

OMRON devices that comply with EC Directives also conform to the related EMC standards so that they can be more easily built into other devices or the overall machine. The actual products have been checked for conformity to EMC standards.*

Whether the products conform to the standards in the system used by the customer, however, must be checked by the customer. EMC-related performance of the OMRON devices that comply with EC Directives will vary depending on the configuration, wiring, and other conditions of the equipment or control panel on which the OMRON devices are installed. The customer must, therefore, perform the final check to confirm that devices and the overall machine conform to EMC standards.

* Applicable EMC (Electromagnetic Compatibility) standards are as follows:
 EMS (Electromagnetic Susceptibility): EN 61131-2 and EN 61000-6-2
 EMI (Electromagnetic Interference): EN 61131-2 and EN 61000-6-4 (Radiated emission: 10-m regulations)

• Low Voltage Directive

Always ensure that devices operating at voltages of 50 to 1,000 VAC and 75 to 1,500 VDC meet the required safety standards. The applicable directive is EN 61131-2.

• Conformance to EC Directives

The NJ/NX-series Controllers comply with EC Directives. To ensure that the machine or device in which the NJ-series Controller is used complies with EC Directives, the Controller must be installed as follows:

- The NJ/NX-series Controller must be installed within a control panel.
- You must use reinforced insulation or double insulation for the DC power supplies connected to DC Power Supply Units and I/O Units.
- NJ/NX-series Controllers that comply with EC Directives also conform to the Common Emission Standard (EN 61000-6-4). Radiated emission characteristics (10-m regulations) may vary depending on the configuration of the control panel used, other devices connected to the control panel, wiring, and other conditions.

You must therefore confirm that the overall machine or equipment complies with EC Directives.

Conformance to KC Standards

Observe the following precaution if you use NJ/NX-series Units in Korea.

A 급 기기 (업무용 방송통신기자재) 이 기기는 업무용(A 급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.

Class A Device (Broadcasting Communications Device for Office Use)

This device obtained EMC registration for office use (Class A), and it is intended to be used in places other than homes.

Sellers and/or users need to take note of this.

Conformance to Shipbuilding Standards

The NJ/NX-series Controllers comply with the following shipbuilding standards. Applicability to the shipbuilding standards is based on certain usage conditions. It may not be possible to use the product in some locations. Contact your OMRON representative before attempting to use a Controller on a ship.

Usage Conditions for NK and LR Shipbuilding Standards

- The NJ/NX-series Controller must be installed within a control panel.
- Gaps in the door to the control panel must be completely filled or covered with gaskets or other material.
- The following noise filter must be connected to the power supply line.

Noise Filter

Manufacturer	Model
Cosel Co., Ltd.	TAH-06-683

Software Licenses and Copyrights

This product incorporates certain third party software. The license and copyright information associated with this software is available at http://www.fa.omron.co.jp/nj_info_e/.

Versions


Unit versions are used to manage the hardware and software in NJ/NX-series Units and EtherCAT slaves. The unit version is updated each time there is a change in hardware or software specifications. Even when two Units or EtherCAT slaves have the same model number, they will have functional or performance differences if they have different unit versions.

Checking Versions


You can check versions on the ID information indications or with the Sysmac Studio.

Checking Unit Versions on ID Information Indications

The unit version is given on the ID information indication on the side of the product. The ID information on an NX-series NX701- \Box \Box \Box CPU Unit is shown below.



The ID information on an NJ-series NJ501-1500 CPU Unit is shown below.



Checking Unit Versions with the Sysmac Studio

You can use the Sysmac Studio to check unit versions. The procedure is different for Units and for EtherCAT slaves.

• Checking the Unit Version of an NX-series CPU Unit

You can use the Production Information while the Sysmac Studio is online to check the unit version of a Unit. You can check the unit version of only the CPU Unit.

1 Right-click CPU Rack under Configurations and Setup – CPU/Expansion Racks in the Multiview Explorer and select *Production Information*.

The Production Information Dialog Box is displayed.

• Checking the Unit Version of an NJ-series CPU Unit

You can use the Production Information while the Sysmac Studio is online to check the unit version of a Unit. You can do this for the CPU Unit, CJ-series Special I/O Units, and CJ-series CPU Bus Units. You cannot check the unit versions of CJ-series Basic I/O Units with the Sysmac Studio.

Use the following procedure to check the unit version.

1 Double-click CPU/Expansion Racks under Configurations and Setup in the Multiview Explorer. Or, right-click CPU/Expansion Racks under Configurations and Setup and select *Edit* from the menu.

The Unit Editor is displayed.


2 Right-click any open space in the Unit Editor and select **Production Information**.

The Production Information Dialog Box is displayed.

• Changing Information Displayed in Production Information Dialog Box

1 Click the **Show Detail** or **Show Outline** Button at the lower right of the Production Information Dialog Box.

The view will change between the production information details and outline.



Outline View

Detail View

The information that is displayed is different for the Outline View and Detail View. The Detail View displays the unit version, hardware version, and software versions. The Outline View displays only the unit version.

• Checking the Unit Version of an EtherCAT Slave

You can use the Production Information while the Sysmac Studio is online to check the unit version of an EtherCAT slave. Use the following procedure to check the unit version.

1 Double-click **EtherCAT** under **Configurations and Setup** in the Multiview Explorer. Or, rightclick **EtherCAT** under **Configurations and Setup** and select **Edit** from the menu.

The EtherCAT Tab Page is displayed.

2 Right-click the master on the EtherCAT Tab Page and select **Display Production Information**.

The Production Information Dialog Box is displayed. The unit version is displayed after "Rev."

Production Information						
Type information	Serial number					
Node10 R88D-KN01L-ECT Rev:2.1 (OMRON Corporation)	0x00000000					
Node9 R88D-KN01L-ECT Rev:2.1 (OMRON Corporation)	0x0000000					
Output file						
Close						

Unit Versions of CPU Units and Sysmac Studio Versions

The functions that are supported depend on the unit version of the NJ/NX-series CPU Unit. The version of Sysmac Studio that supports the functions that were added for an upgrade is also required to use those functions.

Refer to the *NJ/NX-series CPU Unit Software User's Manual* (Cat. No. W501) for the relationship between the unit versions of CPU Units and the Sysmac Studio versions.

Refer to A-6 Version Information for the functions that are supported by each unit version.

Related Manuals

The following are the manuals related to this manual. Use these manuals for reference.


Manual name	Cat. No.	Model numbers	Application	Description
NX-series CPU Unit Hardware User's Manual	W535	NX701-□□□	Learning the basic specifi- cations of the NX-series CPU Units, including intro- ductory information, design- ing, installation, and maintenance. Mainly hard- ware information is pro- vided.	 An introduction to the entire NX-series system is provided along with the following information on the CPU Unit. Features and system configuration Introduction Part names and functions General specifications Installation and wiring Maintenance and inspection Use this manual together with the <i>NJ/NX-series CPU Unit Software User's Manual</i> (Cat. No. W501).
NJ-series CPU Unit Hardware User's Manual	W500	NJ501-□□□ NJ301-□□□ NJ101-□□□	Learning the basic specifi- cations of the NJ-series CPU Units, including intro- ductory information, design- ing, installation, and maintenance. Mainly hard- ware information is pro- vided.	 An introduction to the entire NJ-series system is provided along with the following information on the CPU Unit. Features and system configuration Introduction Part names and functions General specifications Installation and wiring Maintenance and inspection Use this manual together with the <i>NJ-series CPU Unit Software User's Manual</i> (Cat. No. W501).
NJ/NX-series CPU Unit Software User's Manual	W501	NX701-□□□ NJ501-□□□ NJ301-□□□ NJ101-□□□	Learning how to program and set up an NJ/NX-series CPU Unit. Mainly software information is provided.	 The following information is provided on a Controller built with an NJ/NX-series CPU Unit. CPU Unit operation CPU Unit features Initial settings Programming based on IEC 61131-3 language specifications Use this manual together with the <i>NX-series CPU Unit Hardware User's Manual</i> (Cat. No. W535) or <i>NJ-series CPU Unit Hardware User's Manual</i> (Cat. No. W500).
NJ/NX-series Instruc- tions Reference Manual	W502	NX701-000 NJ501-000 NJ301-000 NJ101-000	Learning detailed specifica- tions on the basic instruc- tions of an NJ/NX-series CPU Unit.	The instructions in the instruction set (IEC 61131-3 specifications) are described. When program- ming, use this manual together with the <i>NX-series</i> <i>CPU Unit Hardware User's Manual</i> (Cat. No. W535) or <i>NJ-series CPU Unit Hardware User's</i> <i>Manual</i> (Cat. No. W500) and with the <i>NJ/NX-</i> <i>series CPU Unit Software User's Manual</i> (Cat. No. W501).
NJ/NX-series CPU Unit Motion Control User's Manual	W507	NX701-000 NJ501-000 NJ301-000 NJ101-000	Learning about motion con- trol settings and program- ming concepts.	The settings and operation of the CPU Unit and programming concepts for motion control are described. When programming, use this manual together with the <i>NX-series CPU Unit Hardware</i> <i>User's Manual</i> (Cat. No. W535) or <i>NJ-series CPU</i> <i>Unit Hardware User's Manual</i> (Cat. No. W500) and with the <i>NJ/NX-series CPU Unit Software User's</i> <i>Manual</i> (Cat. No. W501).

Manual name	Cat. No.	Model numbers	Application	Description
NJ/NX-series Motion Control Instructions Ref- erence Manual	W508	NX701-□□□□ NJ501-□□□□ NJ301-□□□□ NJ101-□□□□	Learning about the specifi- cations of the motion control instructions that are pro- vided by OMRON.	The motion control instructions are described. When programming, use this manual together with the <i>NX-series CPU Unit Hardware User's Manual</i> (Cat. No. W535) or <i>NJ-series CPU Unit Hardware</i> <i>User's Manual</i> (Cat. No. W500) and with the <i>NJ/NX-series CPU Unit Software User's Manual</i> (Cat. No. W501), and <i>NJ/NX-series CPU Unit</i> <i>Motion Control User's Manual</i> (Cat. No. W507).
NJ/NX-series CPU Unit Built-in EtherCAT® Port User's Manual	W505	NX701-0000 NJ501-0000 NJ301-0000 NJ101-0000	Using the built-in EtherCAT port on an NJ/NX-series CPU Unit.	Information on the built-in EtherCAT port is pro- vided. This manual provides an introduction and provides information on the configuration, features, and setup. Use this manual together with the <i>NX-series CPU</i> <i>Unit Hardware User's Manual</i> (Cat. No. W535) or <i>NJ-series CPU Unit Hardware User's Manual</i> (Cat. No. W500) and with the <i>NJ/NX-series CPU Unit</i> <i>Software User's Manual</i> (Cat. No. W501).
NJ/NX-series CPU Unit Built-in EtherNet/IP TM Port User's Manual	W506	NX701-0000 NJ501-0000 NJ301-0000 NJ101-0000	Using the built-in Ether- Net/IP port on an NJ/NX- series CPU Unit.	Information on the built-in EtherNet/IP port is pro- vided. Information is provided on the basic setup, tag data links, and other features. Use this manual together with the <i>NX-series CPU</i> <i>Unit Hardware User's Manual</i> (Cat. No. W535) or <i>NJ-series CPU Unit Hardware User's Manual</i> (Cat. No. W500) and with the <i>NJ/NX-series CPU Unit</i> <i>Software User's Manual</i> (Cat. No. W501).
NJ-series Database Con- nection CPU Units User's Manual	W527	NJ501-1□20	Using the database connec- tion service with NJ-series Controllers	Describes the database connection service.
NJ-series SECS/GEM CPU Unit User's Manual	W528	NJ501-1340	Using the GEM service with NJ-series Controllers.	Describes the GEM service.
NJ/NX-series Trouble- shooting Manual	W503	NX701-000 NJ501-000 NJ301-000 NJ101-000	Learning about the errors that may be detected in an NJ/NX-series Controller.	Concepts on managing errors that may be detected in an NJ/NX-series Controller and infor- mation on individual errors are described. Use this manual together with the <i>NX-series CPU</i> <i>Unit Hardware User's Manual</i> (Cat. No. W535) or <i>NJ-series CPU Unit Hardware User's Manual</i> (Cat. No. W500) and with the <i>NJ/NX-series CPU Unit</i> <i>Software User's Manual</i> (Cat. No. W501).
Sysmac Studio Version 1 Operation Manual	W504	SYSMAC- SE2	Learning about the operat- ing procedures and func- tions of the Sysmac Studio.	Describes the operating procedures of the Sysmac Studio.
NX-series EtherCAT® Coupler Unit User's Man- ual	W519	NX-ECC	Learning how to use an NX- series EtherCAT Coupler Unit and EtherCAT Slave Terminals	The system and configuration of EtherCAT Slave Terminals, which consist of an NX-series Ether- CAT Coupler Unit and NX Units, are described along with the hardware, setup, and functions of the EtherCAT Coupler Unit that are required to configure, control, and monitor NX Units through EtherCAT.
NX-series NX Units User's Manuals	W521	NX-ID	Learning how to use NX Units	Describes the hardware, setup methods, and func- tions of the NX Units. Manuals are available for the following Units. Digital I/O Units, Analog I/O Units, System Units, and Position Interface Units.
	W522	NX-AD		and Position Interface Units.
	W523	NX-PD1		
	W524	NX-EC0		
NX-series Data Reference Manual	W525	NX-000000	Referring to the list of data required for NX-series unit system configuration.	Provides the list of data required for system config- uration including the power consumption and weight of each NX-series unit.

Manual name	Cat. No.	Model numbers	Application	Description
GX-series EtherCAT	W488	GX-ID	Learning how to use the	Describes the hardware, setup methods and func-
Slave Units User's Man-		GX-OD	EtherCAT remote I/O	tions of the EtherCAT remote I/O terminals.
ual		GX-OC	terminals.	
		GX-MD		
		GX-AD		
		GX-DA		
		GX-EC□□□□		
		XWT-ID□□		
		XWT-OD□□		
G5-series AC Servomo-	1573	R88M-K□	Learning how to use the AC	Describes the hardware, setup methods and func-
tors/Servo Drives User's		R88D-KN□-ECT-	Servomotors/Servo Drives	tions of the AC Servomotors/Servo Drives with
Manuals		R	with built-in EtherCAT Com-	built-in EtherCAT Communications.
	1576	R88M-K□	munications.	The linear motor type model and the model dedi-
		R88D-KN□-ECT		cated for position controls are available in
	1577	R88L-EC-		G5-series.
	-	R88D-KN□-ECT-L		

Revision History

A manual revision code appears as a suffix to the catalog number on the front and back covers of the manual.



Revision code	Date	Revised content	
01	July 2011	Original production	
02	March 2012	Added information on the NJ301- $\Box\Box\Box$.	
		Made changes accompanying the upgrade to unit version 1.01.	
03	May 2012	Made changes accompanying the upgrade to unit version 1.02 and corrected mistakes.	
04	August 2012	Made changes accompanying release of unit version 1.03 of the CPU Unit.	
05	February 2013	Made changes accompanying release of unit version 1.04 of the CPU Unit.	
06	April 2013	Made changes accompanying release of unit version 1.05 of the CPU Unit and corrected mistakes.	
07	June 2013	Made changes accompanying release of unit version 1.06 of the CPU Unit and corrected mistakes.	
08	December 2013	Made changes accompanying release of unit version 1.08 of the CPU Unit and corrected mistakes.	
09	July 2014	Made changes accompanying release of unit version 1.09 of the CPU Unit and corrected mistakes.	
10	January 2015	Made changes accompanying release of unit version 1.10 of the CPU Unit and corrected mistakes.	
11	April 2015	Made changes accompanying release of the NX-series NX701-DDD CPU Unit and the NJ-series NJ101-10DD CPU Unit, and corrected mistakes.	

Introduction to the Motion Control Function Module

This section describes the features, system configuration, and application flow for the Motion Control Function Module.

1-1	Feature	es	1-2
1-2	System	n Configuration	1-3
1-3	Applica	ation Procedure	1-4
1-4	Specifi	cations	1-6
	1-4-1	General Specifications	.1-6
	1-4-2	Performance Specifications	.1-6
	1-4-3	Function Specifications	.1-9

1-1 Features

The Motion Control Function Module (sometimes abbreviated to "MC Function Module") is a software function module that is built into the CPU Unit. The MC Function Module can perform motion control for up to 256 axes through the EtherCAT port that is built into the CPU Unit. Cyclic communications are performed with Servo Drives and other devices that are connected to the EtherCAT port to enable high-speed, high-precision machine control.

Motion Control Instructions Based on PLCopen®

The motion control instructions of the MC Function Module are based on motion control function blocks that are standardized by PLCopen[®]. These instructions allow you to program single-axis PTP positioning, interpolation control, synchronized control (e.g., of electronic cams), velocity control, and torque control. You can set the velocity, acceleration rate, deceleration rate, and jerk each time a motion control instruction is executed to flexibly control operation according to the application.

Additional Information

PLCopen[®]

PLCopen[®] is an association that promotes IEC 61131-3. It has its headquarters in Europe and a world-wide membership. PLCopen[®] standardizes function blocks for motion control to define a program interface for the languages specified in IEC 61131-3 (JIS B 3503).

Jerk

Jerk is the rate of change in the acceleration rate or deceleration rate. If you specify the jerk, the velocity graph will form an S-curve for acceleration and deceleration.

Data Transmission Using EtherCAT Communications

The MC Function Module can be combined with OMRON G5-series Servo Drives with built-in EtherCAT communications to enable exchange of all control information with high-speed data communications. The various control commands are transmitted via data communications. That means that the Servo-motor's operational performance is maximized without being limited by interface specifications, such as the response frequency of the encoder feedback pulses. You can use the Servo Drive's various control parameters and monitor data on a host controller to unify management of system information.

Additional Information

What Is EtherCAT?

EtherCAT is an open high-speed industrial network system that conforms to Ethernet (IEEE 802.3). Each node achieves a short cycle time by transmitting Ethernet frames at high speed. A mechanism that allows sharing clock information enables high-precision synchronized control with low communications jitter.

1-2 System Configuration

1

1-2 System Configuration

The MC Function Module receives sensor signal status from devices and control panels. It receives commands from the motion control instructions that are executed in the user program. It uses both of these to perform motion control with the Servo Drives, Encoder Input Terminals, and NX-series Position Interface Units.

Motion Control Configuration


The EtherCAT network configuration, the Slave Terminal configurations for EtherCAT Coupler Units, and the Sysmac Studio are used for the MC Function Module.

EtherCAT Network Configuration

The MC Function Module performs control for Servo Drives and Encoder Input Terminals through the EtherCAT master port that is built into the CPU Unit. The EtherCAT network configuration is used to perform precise motion control in a fixed period with very little deviation.

- Slave Terminal Configurations of EtherCAT Coupler Units
 The MC Function Module uses the Position Interface Units that are mounted under an EtherCAT
 Coupler Unit to output motor control pulses and read encoder inputs. You can also use this config uration to perform precise motion control in a fixed period with very little deviation.
- Sysmac Studio

The Sysmac Studio is connected to the peripheral USB port on the CPU Unit with a commercially available USB cable. You can also connect it to the built-in EtherNet/IP port on the CPU Unit with Ethernet cable.



Version Information

A CPU Unit with unit version 1.05 or later and Sysmac Studio version 1.06 or higher are required to use the NX-series Position Interface Units.

Some of the functions of the MC Function Module are different when NX-series Position Interface Units are used. Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for details.

1-3 Application Procedure

This section provides the basic procedure to perform motion control with the MC Function Module.

	(START)	
Catura		Sysmac Studio Version 1 Operation Manual
Setup	Create a project.	(Cat. No. W504)
	Create the EtherCAT Network Configuration.*	<i>NJ/NX-series CPU Unit Software User's Manual</i> (Cat. No. W501)
	Add axes.	Section 3 Configuring Axes and Axes Groups
		_
	Assign the axes.	
	\downarrow	-
	Set the axis parameters.	
	\downarrow	
	Set the Controller Setup.	NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501)
	\checkmark	-
Transferring	Transfer the project to the Controller.	
]
Checking Wiring	Open the MC Test Run Tab Page.	Section 4 Checking Wiring from the Sysmac Studio
Checking Operation	Monitor input signals to check the wiring.	
		_
	Perform jogging.	
	<u> </u>	-
Continues	s to (A) on next page.	


The EtherCAT Network Configuration can be set online if you are connected to the physical network The EtherCAT Network Configuration can be selected offline if the hardware is not available yet.



Additional Information

Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for the procedures for the NX-series Position Interface Units.

*



1

1-4 Specifications

This section gives the specifications of the MC Function Module.



Precautions for Correct Use

The NJ101-90 Units do not provide the Motion Control Function Module.

1-4-1 General Specifications

General specifications conform to the general specifications of the CPU Unit.

Refer to the *NX-series CPU Unit Hardware User's Manual* (Cat. No. W535) or *NJ-series CPU Unit Hardware User's Manual* (Cat. No. W500) for details.

1-4-2 Performance Specifications

Item			NX701-		
	Iter		17🗆	16□□	
Number of	Maximum nun	nber of controlled axes ^{*1}	256 axes	128 axes	
controlled	Maximum nun	nber of used real axes *2	256 axes	128 axes	
axes	Maximum number of axes for single-axis control		256 axes	128 axes	
	Maximum nun interpolation a	nber of axes for linear xis control	4 axes per axes group		
	Number of axes for circular interpolation axis control		2 axes per axes group		
Maximum nu	mber of axes gro	ups	64 axes groups		
Override fact	ors		0.00% or 0.01% to 500.00%		
Motion contro	ol period		The same control period as that is used for the process data communications cycle for EtherCAT.		
Multi-motion			Supported.		
Cams	Number of cam data	Maximum points per cam table	65,535 points		
	points	Maximum points for all cam tables	1,048,560 points		
	Maximum nun	nber of cam tables	640 tables		

*1 This is the total for all axis types.

*2 This is the total number of axes whose axis type is set to Servo Axis or Encoder Axis and axis use is set to Used Axis.

Item			NJ501-			
			15□□	14□□	13□□	
Number of	Maximum nur	mber of controlled axes *1	64 axes	32 axes	16 axes	
controlled axes	Maximum nur	mber of used real axes *2 (*)	64 axes	32 axes	16 axes	
	Maximum nur control	Maximum number of axes for single-axis control		32 axes	16 axes	
		Maximum number of axes for linear inter- polation axis control		4 axes per axes group		
	Number of axes for circula axis control		2 axes per axes group			
Maximum nu	mber of axes gro	oups	32 axes groups			
Override fact	ors		0.00% or 0.01% to 500.00%			
Motion control period			The same control period as that is used for the process data communications cycle for EtherCAT.			
Multi-motion			Not supported.			
Cams	Number of cam data	Maximum points per cam table	65,535 points			
	points	Maximum points for all cam tables	1,048,560 points			
	Maximum nur	mber of cam tables	640 tables			

*1 This is the total for all axis types.

*2 This is the total number of axes whose axis type is set to Servo Axis or Encoder Axis and axis use is set to Used Axis.

Note Functions with asterisks were added for an upgraded version of the CPU Unit. Refer to *A-6 Version Information* for information on version upgrades.

1

Item			NJ301-		NJ101-	
			12□□	11□□	10□□	
Number of	Maximum nu	Maximum number of controlled axes *1		15 axes ^{*3} (*)	6 axes	
controlled axes	Maximum nu	mber of used real $axes^{*4}$ (*)	8 axes	4 axes	2 axes	
	Maximum nu control	Maximum number of axes for single-axis control		15 axes ^{*6} (*)	6 axes	
		Maximum number of axes for linear inter- polation axis control		4 axes per axes group		
	Number of ax axis control	Number of axes for circular interpolation axis control		2 axes per axes group		
Maximum nu	mber of axes gro	oups	32 axes groups			
Override fact	ors		0.00% or 0.01% to 500.00%			
Motion control period			The same control period as that is used for the process data communications cycle for EtherCAT.			
Multi-motion		Not supported.				
Cams	Number of cam data	Maximum points per cam table	65,535 points			
	points	Maximum points for all cam tables	262,140 points			
	Maximum nu	mber of cam tables	160 tables			

*1 This is the total for all axis types.

*2 This number of axes is achieved in a combination of a CPU Unit with unit version 1.06 or later and Sysmac Studio version 1.07 or higher. In other combinations, the maximum number of controlled axes is 8 axes.

- *3 This number of axes is achieved in a combination of a CPU Unit with unit version 1.06 or later and Sysmac Studio version 1.07 or higher. In other combinations, the maximum number of controlled axes is 4 axes.
- *4 This is the total number of axes whose axis type is set to Servo Axis or Encoder Axis and axis use is set to Used Axis.
- *5 This number of axes is achieved in a combination of a CPU Unit with unit version 1.06 or later and Sysmac Studio version 1.07 or higher. In other combinations, the maximum number of axes for single-axis control is 8 axes.
- *6 This number of axes is achieved in a combination of a CPU Unit with unit version 1.06 or later and Sysmac Studio version 1.07 or higher. In other combinations, the maximum number of axes for single-axis control is 4 axes.
- **Note** Functions with asterisks were added for an upgraded version of the CPU Unit. Refer to *A-6 Version Information* for information on version upgrades.

1-4-3 Function Specifications

The following table describes the functions that are supported for connections to OMRON control devices.

Item		Description	
Controllable Servo Drives		OMRON G5-series Servo Drives with built-in EtherCAT communications ^{*1} (*)	
Controllable encoder input terminals	3	OMRON GX-series GX-EC0211/EC0241 EtherCAT Remote I/O Terminals *2	
Controllable Position Interface Units *3 (*)		OMRON NX-EC0	
Control method		Control commands using EtherCAT communications	
Control modes		Position control, Velocity control, and Torque control	
Unit conversions	Position units	Pulse, mm, μ m, nm, degree, and inch	
	Electronic gear ratio	Pulse per motor rotation/travel distance per motor rotation	
Positions that can be managed		Command positions and actual positions	
Axis types		Servo axes, Virtual servo axes, Encoder axes, and Virtual encoder axes	
Position command values		Negative or positive long reals (LREAL) or 0 (command units ^{*4})	
Velocity command values		Negative or positive long reals (LREAL) or 0 (command units/s)	
Acceleration command values and deceleration command values		Positive long reals (LREAL) or 0 (command units/s ²)	
Jerk command values		Positive long reals (LREAL) or 0 (command units/s ³)	

1

Item			Description	
Single axes	Single-axis posi- tion control	Absolute positioning	Positioning is performed for a target position that is speci- fied with an absolute value.	
		Relative positioning	Positioning is performed for a specified travel distance from the command current position.	
		Interrupt feeding	Positioning is performed for a specified travel distance from the position where an interrupt input was received from an external input.	
		Cyclic synchronous abso- lute positioning (*)	A command position is output each control period in Position Control Mode.	
	Single-axis veloc-	Velocity control	Velocity control is performed in Position Control Mode.	
	ity control	Cyclic synchronous velocity control	A velocity command is output each control period in Veloc- ity Control Mode.	
	Single-axis torque control	Torque control	The torque of the motor is controlled.	
	Single-axis syn-	Starting cam operation	A cam motion is performed using the specified cam table.	
	chronized control	Ending cam operation	The cam motion for the axis that is specified with the input parameter is ended.	
		Starting gear operation	A gear motion with the specified gear ratio is performed between a master axis and slave axis.	
		Positioning gear opera- tion	A gear motion with the specified gear ratio and sync posi- tion is performed between a master axis and slave axis.	
		Ending gear operation	The specified gear motion or positioning gear motion is ended.	
		Synchronous positioning	Positioning is performed in sync with a specified master axis.	
		Master axis phase shift	The phase of a master axis in synchronized control is shifted.	
		Combining axes	The command positions of two axes are added or sub- tracted and the result is output as the command position.	
	Single-axis manual operation	Powering the Servo	The Servo in the Servo Drive is turned ON to enable axis motion.	
		Jogging	An axis is jogged at a specified target velocity.	

	Item		Description
Single axes	Auxiliary functions	Resetting axis errors	Axes errors are cleared.
	for single-axis con- trol	Homing	A motor is operated and the limit signals, home proximity signal, and home signal are used to define home.
		Homing with parameters (*)	The parameters are specified, the motor is operated, and the limit signals, home proximity signal, and home signal are used to define home.
		High-speed homing	Positioning is performed for an absolute target position of 0 to return to home.
		Stopping	An axis is decelerated to a stop.
		Immediately stopping	An axis is stopped immediately.
		Setting override factors	The target velocity of an axis can be changed.
		Changing the current position	The command current position or actual current position of an axis can be changed to any position.
		Enabling external latches	The position of an axis is recorded when a trigger occurs.
		Disabling external latches	The current latch is disabled.
		Zone monitoring	You can monitor the command position or actual position of an axis to see when it is within a specified range (zone).
		Enable Digital Cam Switch (*)	The digital outputs are turned ON or turned OFF depend- ing on the axis position.
		Monitoring axis following error	You can monitor whether the difference between the com- mand positions or actual positions of two specified axes exceeds a threshold value.
		Resetting the following error	The error between the command current position and actual current position is set to 0.
		Torque limit	The torque control function of the Servo Drive can be enabled or disabled and the torque limits can be set to control the output torque.
		Changing axis use (*)	The Axis Use axis parameter can be temporarily changed.
		Start velocity (*)	You can set the initial velocity when axis motion starts.
Axes groups	Multi-axes coordi- nated control	Absolute linear interpola- tion	Linear interpolation is performed to a specified absolute position.
		Relative linear interpola- tion	Linear interpolation is performed to a specified relative position.
		Circular 2D interpolation	Circular interpolation is performed for two axes.
		Axes group cyclic syn- chronous absolute posi- tioning (*)	A positioning command is output each control period in Position Control Mode.
	Auxiliary functions for multi-axes coor- dinated control	Resetting axes group errors	Axes group errors and axis errors are cleared.
		Enabling axes groups	Motion of an axes group is enabled.
		Disabling axes groups	Motion of an axes group is disabled.
		Changing the axes in an axes group (*)	The Composition Axes parameter in the axes group parameters can be overwritten temporarily.
		Stopping axes groups	All axes in interpolated motion are decelerated to a stop.
		Immediately stopping axes groups	All axes in interpolated motion are stopped immediately.
		Setting axes group over- ride factors	The blended target velocity is changed during interpolated motion.
		Reading axes group posi- tions (*)	The command current positions and actual current positions of an axes group can be read.

Item			Description	
Common items	Cams ^{*5}	Setting cam table proper- ties	The end point index of the cam table that is specified in the input parameter is changed.	
		Saving cam tables	The cam table that is specified with the input parameter is saved in non-volatile memory in the CPU Unit.	
		Generating cam tables (*)	The cam table that is specified with the input parameter is generated from the cam property and cam node.	
	Parameters	Writing MC settings	Some of the axis parameters or axes group parameters are overwritten temporarily.	
		Changing axis parame- ters (*)	You can access and change the axis parameters from the user program.	
Auxiliary functions	Count modes		You can select either Linear Mode (finite length) or Rotary Mode (infinite length).	
	Unit conversions		You can set the display unit for each axis according to the machine.	
	Acceleration/decel- eration control	Automatic accelera- tion/deceleration control	Jerk is set for the acceleration/deceleration curve for an axis motion or axes group motion.	
		Changing the accelera- tion and deceleration rates	You can change the acceleration or deceleration rate even during acceleration or deceleration.	
	In-position check		You can set an in-position range and in-position check time to confirm when positioning is completed.	
	Stop method		You can set the stop method to the immediate stop input signal or limit input signal.	
	Re-execution of mot	ion control instructions	You can change the input variables for a motion control instruction during execution and execute the instruction again to change the target values during operation.	
	Multi-execution of motion control instructions (Buffer Mode)		You can specify when to start execution and how to con- nect the velocities between operations when another motion control instruction is executed during operation.	
	Continuous axes group motions (Transition Mode)		You can specify the Transition Mode for multi-execution of instructions for axes group operation.	
	Monitoring func- tions	Software limits	The movement range of an axis is monitored.	
		Following error	The error between the command current value and the actual current value is monitored for an axis.	
		Velocity, acceleration rate, deceleration rate, torque, interpolation velocity, interpolation acceleration rate, and interpolation decelera- tion rate	You can set and monitor warning values for each axis and each axes group.	
	Absolute encoder support		You can use an OMRON G5-series Servomotor with an Absolute Encoder to eliminate the need to perform homing at startup. ^{*6}	
	Input signal logic inversion (*)		You can inverse the logic of immediate stop input signal, positive limit input signal, negative limit input signal, or home proximity input signal.	
External interface signals			The Servo Drive input signals listed on the right are used. Home signal, home proximity signal, positive limit signal, negative limit signal, immediate stop signal, and interrupt input signal	

- *1 Unit version 2.1 or later is recommended for Cylinder-type Servo Drives. Unit version 1.1 or later is recommended for Linear Motor Types.
- *2 The recommended unit version is 1.1 or later.

1

- *3 Some of the functions of the MC Function Module are different when NX-series Position Interface Units are used. Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for details.
- *4 Positions can be set within a 40-bit signed integer range when converted to pulses.
- *5 You can create the cam table with the Cam Editor in the Sysmac Studio or with the Generate Cam Table instruction in the user program. Specify the master axis phase and the slave axis displacement. You can change the phase pitch for each range. Cam data can be overwritten from the user program.
- *6 Application is possible when you use an absolute external scale for a G5-series Linear Motor Type.
- **Note** Functions with asterisks were added for an upgraded version of the CPU Unit. Refer to *A-6 Version Information* for information on version upgrades.

2

Motion Control Configuration and Principles

This section outlines the internal structure of the CPU Unit and describes the configuration and principles of the MC Function Module.

2-1	Interna	al Configuration of the CPU Unit	2-2
2-2	Motior	Control Configuration	2-3
2-3	Motior	Control Principles	2-4
	2-3-1	CPU Unit Tasks	
	2-3-2	Example of Task Operations for Motion Control	2-11
2-4	EtherC	CAT Communications and Motion Control	2-18
	2-4-1	CAN Application Protocol over EtherCAT (CoE)	
	2-4-2	Relationship between EtherCAT Master Function Module and MC Function Module	
	2-4-3	Relationship between Process Data Communications Cycle	
		and Motion Control Period	2-21

2-1 Internal Configuration of the CPU Unit

This section provides an overview of the internal mechanisms of the NJ/NX-series CPU Unit. The CPU Unit has the following software configuration. The Motion Control Function Module is a software module that performs motion control.

Motion Control Function	EtherCAT Master Function	Other Function
Module	Module	Modules*

PLC Function Module

OS * Refer to the *NJ/NX-series CPU Unit Software User's Manual* (Cat. No. W501) for details on other Function Modules.

The PLC Function Module runs on top of the OS. The other Function Modules run on top of the PLC Function Module. A description of each Function Module is given in the following table.

Function Module name	Abbreviation	Description
PLC Function Module	PLC	This module manages overall scheduling, executes the user program, sends commands to the Motion Control Function Module, and provides interfaces to USB and the SD Memory Card.
Motion Control Function Module	MC	This module performs motion control according to the commands from motion control instructions that are executed in the user program. It sends data to the EtherCAT Master Function Module.
EtherCAT Master Function Module	ECAT	This module communicates with the EtherCAT slaves as the EtherCAT master.


Note Refer to the *NJ/NX-series CPU Unit Software User's Manual* (Cat. No. W501) for details on other Function Modules.


This manual provides the specifications and operating procedures for the Motion Control Function Module (sometimes abbreviated to "MC Function Module"). Refer to the other NJ/NX-series user's manuals as required when using the MC Function Module in an application.

Motion Control Configuration 2-2

A control system built with Servo Drives generally controls motor operation with a semi-closed loop. The semi-closed loop uses an encoder attached to the motor to detect the amount of rotation that has been performed by the motor in response to the command value. This is provided as feedback of the machine's travel distance. The following error between the command value and actual motor rotation is calculated and control is performed to bring the following error to zero.

In a machine configuration that uses the MC Function Module, no feedback information is provided for the commands from the user program in the CPU Unit. A feedback system is built into the Servo Drive.





A feedback system is not configured.

A feedback system is configured.

- When motion control instructions are executed in the user program, the MC Function Module interprets the resulting commands.
- The MC Function Module then performs motion control processing at a fixed period based on the results of the command interpretation. It generates command values to send to the Servo Drive. The following command values are generated: target position, target velocity, and target torque.
- The command values are sent by using PDO communications during each process data communications cycle of EtherCAT communications.
- The Servo Drive performs position loop control, velocity loop control, and torque loop control based on the command values received during each process data communications cycle of EtherCAT communications.
- The encoder's current value and the Servo Drive status are sent to the CPU Unit during each process data communications cycle of EtherCAT communications.

Additional Information

- Motion control processing and process data communications in EtherCAT communications are performed during the same time period.
- The MC Function Module controls the Servo Drive, which contains the position control loop, velocity control loop, and torque control loop.
- Refer to the NX-series Position Interface Units User's Manual (Cat. No. W524) for information on the configuration of the NX-series Position Interface Units.

2-3 Motion Control Principles

This section provides information on the CPU Unit tasks and how they relate to motion control.

2-3-1 CPU Unit Tasks

Tasks are attributes of programs that determine the execution conditions and sequence of the programs. The NJ/NX-series CPU Units support the following tasks.

Type of task	Task name
Tasks that execute programs at a fixed period	Primary periodic task
	Priority-5 ^{*1} , -16, -17, and -18 periodic tasks
Tasks that execute programs only once when the exe- cution conditions for the tasks are met	Event task (execution priority: 8 and 48) *2

*1 You can use the priority-5 periodic task only with NX-series CPU Units. You cannot use it with NJ-series CPU Units.

*2 A CPU Unit with unit version 1.03 or later and Sysmac Studio version 1.04 or higher are required to use event tasks.

Refer to the *NJ/NX-series CPU Unit Software User's Manual* (Cat. No. W501) for details on programs, tasks, and setting methods.

Types of Tasks and Task Priority

The NJ/NX-series CPU Unit can execute the user program with a single task or multiple tasks. Tasks have an execution priority. Tasks with the highest execution priority are executed first. If the execution conditions are met for another task with a higher execution priority while a task is under execution, the task with the higher execution priority is given priority in execution. The following table lists the tasks in which you can use motion control instructions and the task priorities for the NJ/NX-series CPU Unit. You cannot use motion control instructions in event tasks.

Type of task	Number of tasks	Priority	Operation
Primary periodic task	1	4	This task executes I/O refreshing, programs, and motion control in the specified task period. This task has the highest execution priority of all tasks and can be executed quickly and precisely. Therefore, this task is best suited for situations when synchronized control or highly responsive control is required. Use the primary periodic task to execute all control with a single task.
Periodic tasks	0 or 1	5*1	These tasks execute I/O refreshing, programs, and motion control in the specified task period. The priority-5 periodic task has the second highest execution priority after the primary periodic task and can be executed quickly and precisely. The priority-5 periodic task is used when you want to divide functions configuring the deivce for separate control, those functions that need high-speed control with the primary periodic task and others with the priority-5 periodic task. The primary periodic task and priority-5 periodic task are used for the multi-task motion control.

Type of task	Number of tasks	Priority	Operation
Periodic tasks	0 or 1	16 ^{*2}	These tasks execute programs and I/O refreshing in the specified task period. The execution period for this priority-16 periodic task is longer than the execution period of the primary periodic task and priority-5 periodic task. Therefore, periodic tasks are used to execute programs. In the priority-16 periodic task, you can write the user program for some slaves and Units that refresh I/O in the primary periodic task.
			For example, synchronized control and control requiring a fast response time are placed in the primary periodic task or priority-5 periodic task. Overall device control is separately placed in a priority-16 periodic task.

- *1 You can use the priority-5 periodic task only with NX-series CPU Units. You cannot use it with NJ-series CPU Units.
- *2 The CPU Unit has some periodic tasks with an execution priority of 17 or 18. However, you cannot use motion control instructions in these tasks. These tasks also do not perform I/O refreshing.



Precautions for Correct Use

- Motion control instructions can be used in the primary periodic task and in a priority-5 or a priority-16 periodic task.
- If motion control instructions are used in any other tasks, an error will occur when the user program is built on the Sysmac Studio.

Additional Information

The NX-series CPU Unit allows you to execute the motion control in the primary periodic task and in the priority-5 periodic task. If these two motion controls need to be identified, the motion control in the primary periodic task is called motion control 1, while the motion control in the priority-5 periodic task is called motion control 2.

Task Assignment

Axes and axes groups can be assigned to either of the primary periodic task and the priority-5
periodic task. The I/O device task that is assigned to an axis must be the same type of task that is
assigned to the axis.

Assignment possible	I/O device	Assignment NOT possible	I/O device
	(Primary periodic task)		(Primary periodic task)
Axis 1: Primray periodic task	CH1	Axis 1: Primray periodic task	CH1
Axis 2: Primray periodic task	CH2	Axis 2: Priority-5 periodic task	CH2

• You can execute motion control instructions from the user program that is operated in the priority-16 periodic task for the axes and axes groups that are assigned to the primary periodic task.



Precautions for Correct Use

• Yon cannot execute motion control instructions from the user program that is operated in the priority-5 periodic task for the axes and axes groups that are assigned to the primary periodic task. If you perform the execution, an Execution ID Setting Out of Range (event code: 57490000 hex) occurs.

Similarly, you cannot execute motion control instructions from the user program that is operated in the primary periodic task for the axes and axes groups that are assigned to the priority-5 periodic task.

 You cannot execute motion control instructions from the user program that is operated in the priority-16 periodic task for the axes and axes groups that are assigned to the priority-5 periodic task. If you perform the execution, an Execution ID Setting Out of Range (event code: 57490000 hex) occurs.


Additional Information

Refer to Section 3 Configuring Axes and Axes Groups for details on axes and axes groups.


Basic Operation of Tasks

• Overall Task Operation

The primary periodic task and periodic tasks operate based on the task period of the primary periodic task (also known as the primary period). The primary periodic task and priority-5 periodic task include operations such as system common processing and motion control in addition to I/O refreshing and user program execution. Processing of motion control instructions in the programs is executed during the next motion control (MC) period after the END instruction is executed in the task.



Symbol	Description
10	I/O refreshing
UPG	User program execution
MC	Motion control
(A)	A dotted line represents a transition to another task.
(B)	A dashed-dotted line means that processing for that
	task has been interrupted.
(C)	A double line means that all processing for that task
	has been completed.



• Operation of the Primary Periodic Task

Processing	Processing Contents	
Output data processing	 Output refresh data is created for Output Units that execute I/O refreshing. If forced refreshing is set, the forced refreshing values are reflected in the output refresh data. 	
Refresh execution	This process exchanges data with I/O.	
Input data processing	• Whether the condition expression for event task execution is met or not is determined.	
	 Input refresh data is loaded from Input Units that execute I/O refreshing. If forced refreshing is set, the forced refreshing values are reflected in the input refresh data that was read. 	
System common processing 1	Processing for exclusive control of variables in tasks is performed when accessing tasks are set.	
	Motion input processing is performed. ^{*1}	
	Data tracing processing (sampling and trigger checking) is performed.	
User program execution	 Programs assigned to tasks are executed in the order that they are assigned. 	
Motion control 1 ^{*2}	• The motion control commands from the motion control instructions in the programs in the primary periodic task and priority-16 periodic task are executed.	
	 Motion output processing is performed.^{*3} 	
System common processing 2	• Processing for exclusive control of variables in tasks is performed when refreshing tasks are set.	
	• Processing for variables accessed from outside of the Controller is per- formed to maintain concurrency with task execution (executed for the vari- able access time that is set in the Task Settings).	
	• If there is processing for EtherNet/IP tag data links and refreshing tasks are set for the tags (i.e., variables with a Network Publish attribute), variable access processing is performed.	


*1 The Servo Drive status, axis current values, and other motion control system-defined variables are updated according to data received from the Servo Drives.

*2 For the system-defined variables of the axes that are assigned to Motion control 1, _MC_AX[0-255] or _MC1_AX[0-255] are used. Similarly, for the system-defined variables of the axes groups, _MC_GRP[0-63] or _MC1_GRP[0-63] are used.

Refer to 3-1-3 Introduction to Axis Variables for the system-defined variables of axes and 3-3-3 Introduction to Axes Group Variables for the system-defined variables of axes groups.

*3 Data is sent to the Servo Drives during I/O refreshing in the next primary periodic task.

• Operation of a Priority-5 Periodic Task



Processing	Processing contents
Output data processing	Output refresh data is created for Output Units that execute I/O refreshing.
	• If forced refreshing is set, the forced refreshing values are reflected in the output refresh data.
Refresh execution	This process exchanges data with I/O.
Input data processing	 Input refresh data is loaded from Input Units that execute I/O refreshing.
	 If forced refreshing is set, the forced refreshing values are reflected in the input refresh data that was read.
System common processing 1	 Processing for exclusive control of variables in tasks is performed when accessing tasks are set.
	 Motion input processing is performed.^{*1}
	Data tracing processing (sampling and trigger checking) is performed.
User program execution	Programs assigned to tasks are executed in the order that they are assigned.
Motion control 2 ^{*2}	• The motion control commands from the motion control instructions in the programs in the primary periodic task and priority-5 periodic task are executed.
	 Motion output processing is performed.^{*3}
System common processing 2	 Processing for exclusive control of variables in tasks is performed when refreshing tasks are set.
	• Processing for variables accessed from outside of the Controller is performed to maintain concurrency with task execution (executed for the variable access time that is set in the Task Settings).


*1 The Servo Drive status, axis current values, and other motion control system-defined variables are updated according to data received from the Servo Drives.

*2 For the system-defined variables of the axes that are assigned to Motion control 2, _MC2_AX[0-255] are used. Similarly, for the system-defined variables of the axes groups, _MC2_GRP[0-63] are used. Refer to 3-1-3 Introduction to Axis Variables for the system-defined variables of axes and 3-3-3 Introduction to Axes Group Variables for the system-defined variables of axes groups.

*3 Data is sent to the Servo Drives during I/O refreshing in the next priority-5 periodic task.

• Operation of a Priority-16 Periodic Task

You can refresh I/O in the priority-16 periodic task.



* The CPU Unit will temporarily interrupt the execution of a task in order to execute a task with a higher execution priority.

Task Period

For a single task, the primary period, which is the task period for the primary periodic task, is the standard period for execution. In this case, the primary period is automatically used as the motion control period. (It is also the same as the process data communications cycle for EtherCAT communications.) The NJ-series CPU Unit supports only the single task control.

For multiple tasks, two kinds of period, the primary period and the task period of priority-5 periodic task are the standard periods for execution. In this case, the motion control takes two kinds of period, while the process data communications cycle for EtherCAT communications automatically takes each of the task periods.

Periodic task execution is synchronized with the primary period. Set the task period of a periodic task as an integer multiple of the primary period.

For example, if the primary period is 1 ms, then you can set the task period of a priority-5 periodic task to 2 ms and the task period of a priority-16 periodic task to 4 ms. In that case, the start of the period for the primary periodic task and the priority-5 periodic task will match once every two primary periods. Similarly, the start of the period for the primary periodic task and the priority-16 periodic task will match once every four primary periods.

Refer to the *NJ/NX-series CPU Unit Software User's Manual* (Cat. No. W501) for details on the task period.

Additional Information

If two process data communications cycles need to be identified, the communications cycle for the primary periodic task is called process data communications cycle 1, while the communications cycle for the priority-5 periodic task is called process data communications cycle 2.

Valid Task Periods for NX-series CPU Unit

For the NX-series CPU Unit, valid task periods depend on the type of task as shown below.

Task	Valid task periods
Primary periodic task	125 μ s, 250 μ s to 8ms (specify in increments of 250 μ s)
Priority-5 periodic task	125 μ s, 250 μ s to 100ms (specify in increments of 250 μ s)
Priority-16 periodic task	1ms to 100ms (specify in increments of 250μ s)

Note The setting conditions of task periods of the primary periodic task and the periodic tasks.

- The task periods for periodic tasks must be set to integer multiples of the task period of the primary periodic task.
- Set the task period so that the least common multiple of task periods of each task must be less than or equal to 600 ms.

Valid Task Periods for NJ-series CPU Unit

The following table lists the possible combinations of primary periodic task and priority-16 periodic task periods for the NJ-series CPU Unit.

Primary period	Valid task periods for periodic tasks	
500 μs [*]	1 ms, 2 ms, 3 ms, 4 ms, 5 ms, 8 ms, 10 ms, 15 ms, 20 ms, 25 ms, 30 ms, 40 ms, 50 ms, 60 ms, 75 ms, or 100 ms	
1 ms	1 ms, 2 ms, 3 ms, 4 ms, 5 ms, 8 ms, 10 ms, 15 ms, 20 ms, 25 ms, 30 ms, 40 ms, 50 ms, 60 ms, 75 ms, or 100 ms	
2 ms	2 ms, 4 ms, 8 ms, 10 ms, 20 ms, 30 ms, 40 ms, 50 ms, 60 ms, or 100 ms	
4 ms	4 ms, 8 ms, 20 ms, 40 ms, 60 ms, or 100 ms	


* Unit version 1.03 or later is required to use this setting on the NJ301-□□□. You cannot use this setting on the NJ101-10□□.

2-3-2 Example of Task Operations for Motion Control

Motion control instructions can be used in the primary periodic task, in a priority-5 periodic task, or in a priority-16 periodic task. This section provides examples of task operations.

Using Motion Control Instructions in the Primary Periodic Task

If high-speed motion control is required, place the motion control instructions (FB) in the primary periodic task.



Execution of motion control instructions

1 Loading Data

The input data from the EtherCAT slaves (slave A) is loaded during the I/O refresh (IO).

2 Instruction Execution

The motion control instructions (FB) are executed based on the data that was loaded during user program execution (UPG).

The output variables of the motion control instructions are refreshed at this point.

3 Command Generation

Motion processing according to the motion control instructions (FB) that were executed is performed during motion control (MC) immediately after user program execution in the primary periodic task. During this processing, execution commands for the Servo Drives and other devices are generated.

4 Sending Commands

The execution commands that were generated are sent to the Servo Drive or other device during the I/O refresh (IO) in the next period.

Additional Information


All instructions from inputs to execution command outputs to the Servo Drive or other device are processed quickly in this task. We recommend placing all motion control instructions in the primary periodic task.

Using Motion Control Instructions in a Priority-5 Periodic Task

If second high-speed motion control after the primary periodic task is required, place the motion control instructions (FB) in a priority-5 periodic task.

The basic operation is the same as that of the primary periodic task.

• Timing of Processing



Execution of motion control instructions

1 Loading Data

The input data from the EtherCAT slaves (slave A) is loaded during the I/O refresh (IO).

2 Instruction Execution

The motion control instructions (FB) are executed based on the data that was loaded during user program execution (UPG).

The output variables of the motion control instructions are refreshed at this point.

3 Command Generation

Motion processing according to the motion control instructions (FB) that were executed is performed during motion control (MC) immediately after user program execution in the primary periodic task. During this processing, execution commands for the Servo Drives and other devices are generated.

4 Sending Commands

The execution commands that were generated are sent to the Servo Drive or other device during the I/O refresh (IO) in the next period.



Additional Information

- You can use the priority-5 periodic task only with NX-series CPU Units. You cannot use it with NJ-series CPU Units.
- The priority-5 periodic task is used when you want to divide functions configuring the deivce for separate control, those functions that need high-speed control with the primary periodic task and others with the priority-5 periodic task.

• Axis Variable Update Timing in Multi-motion

The multi-motion refers to execution of parallel control using the primary periodic task and the priority-5 periodic task.


In the multi-motion, the user program for the priority-5 periodic task can access the values of an Axis Variable of an axis that is controlled in the primary periodic task. The reverse is possible: the user program for the primary periodic task can access the values of an Axis Variable of an axis that is controlled in the priority-5 periodic task.

Additional Information


- Refer to 3-1-4 Synchronizing Axis Variables for details on synchronization of axis variables.
- The user program for the priority-16 periodic task can access the values of an Axis Variable of an axis that is controlled in the primary periodic task. Refer to Using Motion Control Instructions in a Priority-16 Periodic Task on page 2-15 and 3-1-4 Synchronizing Axis Variables for details.

The values of an Axis Variable are updated synchronizing to the task period of accessing task. The values of an Axis Variable that is accessed are not written during the user program execution for the task that accesses the values of an Axis Variable.

The timing that the values of an Axis Variable in the primary periodic task update to the priority-5 periodic task is shown below.




Symbol	Description	
(A)	Axis Variable updated.	
	Regardless of where the user program execution for the priority-5 periodic task starts, the execution results from the primary periodic task immediately before the start of the task periods matched are updated.	
(B)	The values of an Axis Variable are not written during the user program execution.	



The update timing is similar if two task periods are the same.


Additional Information

If a Task Period Exceeded error occurs, the execution results from the task period immediately before the start of the task periods matched are not updated. The execution results from one more period before that period are updated.



Symbol	Description	
(A)	Axis Variable updated.	
	If a Task Period Exceeded error occurs, the values of the previous task period is updated.	
(B)	The values of an Axis Variable are not written during the user program execution.	

The timing that the values of an Axis Variable in the priority-5 periodic task update to the primary periodic task is shown below.




Symbol	Description		
(A)	Axis Variable updated.		
	The execution results from the priority-5 periodic task immediately before the start of the task periods		
	matched are updated.		
(B)	The values of an Axis Variable are not written during the user program execution.		

Using Motion Control Instructions in a Priority-16 Periodic Task

If high speed motion control is not required and/or your user program is too large, place motion control instructions in a priority-16 periodic task.

• Timing of Processing

Motion control processing (MC) for the motion control instructions (FB) that are executed in the same task period as the priority-16 periodic task are performed at the same time. Therefore, processing for multiple axes can be simultaneously executed or stopped.




Axis Variable Update Timing

Axis Variables are system-defined variables for some of the axis parameters and for the monitor information, such as the actual position and error information for the axes controlled by the MC Function Module.

If you access an Axis Variable of the primary periodic task during the priority-16 periodic task, the values of the variable that were read at the start of the priority-16 periodic task are used.

Also, the values of an Axis Variable are not written when a motion control instruction (FB) is executed. They are written in motion control processing (MC) at the start of the next priority-16 periodic task.



- *1 The values of an Axis Variable of the primary periodic task are read at the start of user program execution for the priority-16 periodic task.
- *2 The values of an Axis Variable are not written when a motion control instruction (FB) is executed in the priority-16 periodic task.
- *3 The values are written during this motion control processing (MC).

Precautions for Correct Use

- When motion control instructions are placed in a priority-16 periodic task, the response time of the Servo Drive or other device will increase if the task period of the priority-16 periodic task is lengthened.
- Make sure that all axes can be stopped safely for emergency stops, including emergency stops commanded from external devices.
- The execution timing of motion control instructions in a priority-16 periodic task is not the same as the execution timing for I/O control. Design the user program to allow for this.

Additional Information

For information on Axis Variables, refer to 3-1-3 Introduction to Axis Variables.


Using Motion Control Instructions in Two Different Types of Tasks

If you have processes that require high-speed motion control and processes that do not require highspeed motion control for the same axis, you can place the motion control instructions (FB) both in the primary periodic task and in a priority-16 periodic task.

If motion control instructions (FB) are executed in both tasks within the period of the priority-16 periodic task, the MC Function Module will perform motion processing for instructions in the primary periodic task first.

For example, the MC_MoveAbsolute instruction is executed in the priority-16 periodic task. Then, the MC_MoveRelative is executed for the same axis in the primary periodic task. The operation for this is shown below.

• The MC Function Module will execute MC_MoveRelative first. MC_MoveAbsolute is executed with multi-execution of instructions.



The values of output variables for a motion control instruction and the values of system-defined variables for motion control will change during the I/O refresh of the task that executed the instruction. Therefore, you may notice different behavior depending on the task if you use motion control instructions for the same axis in different tasks. Make sure that you thoroughly understand the processes of each task before you start to develop your user program.

Precautions for Correct Use

- If you include motion control instructions for the same axis in both the primary periodic task and the priority-16 periodic task, pay close attention to the following when you develop your user program: the execution order of the motion control instructions, the timing of updates for system-defined variables for motion control, and the output timing of command values.
- If you use system-defined variables for motion control for the same axis in multiple tasks, pay close attention to the differences in timing for updating system-defined variables for motion control when you develop your user program.

Additional Information

For information on multi-execution of instructions, refer to 9-5-7 Multi-execution of Motion Control Instructions (Buffer Mode).


2-4 EtherCAT Communications and Motion Control

The MC Function Module controls Servo Drives, counters, and NX-series Position Interface Units through the PDO communications of the EtherCAT Master Function Module in the CPU Unit. This section describes EtherCAT communications and other items related to the MC Function Module.

2-4-1 CAN Application Protocol over EtherCAT (CoE)

The MC Function Module exchanges data with the slaves on EtherCAT using the CAN application protocol over EtherCAT (CoE). With CoE, the parameters and control information held by the slaves are specified according to data specifications of the object dictionary (OD). To communicate the data between the Controller (communications master) and slaves, two methods are used: process data objects (PDOs), which periodically exchange data in realtime, and service data objects (SDOs), which exchange data when required.

The MC Function Module uses PDO communications for commands to refresh I/O data, such as data for Servomotor position control, on a fixed control period. It uses SDO communications for commands to read and write data at specified times, such as for parameter transfers.



2-4-2 Relationship between EtherCAT Master Function Module and MC Function Module

The NJ/NX-series CPU Unit can perform sequence control and motion control through connections to EtherCAT slaves.

2 Motion Control Configuration and Principles

Sequence Control

- I/O ports for configuration slaves are automatically created when you create the EtherCAT Configuration in EtherCAT Tab Page in the Sysmac Studio.
- You use the I/O Map Tab Page in the Sysmac Studio to assign device variables.
- Perform sequence control through instructions other than motion control instructions.

Motion Control

- I/O ports for configuration slaves are automatically created when you create the EtherCAT Configuration in EtherCAT Tab Page in the Sysmac Studio.
- Create Axis Variables in Motion Control Setup View and assign the EtherCAT slaves for which motion control is performed.
- Perform motion control through motion control instructions.

The following devices can be assigned to Axis Variables: EtherCAT slave Servo Drives, Encoder Input Terminals, and NX-series Position Interface Units.

Additional Information

- Commands are not sent directly through PDO communications to an EtherCAT slave or NXseries Position Interface Unit that is assigned to an Axis Variable for instructions other than motion control instructions. However, the status of such an EtherCAT slave can be accessed indirectly through the Axis Variables.
- You can use SDO communications to read and write the objects of EtherCAT slaves and NXseries Position Interface Units that are assigned to axes variables. However, do not use SDO communications to write objects that are mapped to PDO communications. If you do, the operation of the slaves will depend on slave specifications. For OMRON slaves, SDO communications will result in errors.
- If EtherCAT slave Servo Drives, Encoder Input Terminals, and NX-series Position Interface Units are not assigned to axes variables, you must execute sequence control for them in the same way as for general-purpose EtherCAT slaves.

Version Information


With the Sysmac Studio version 1.09 or higher, you can assign device variables to the I/O ports of slaves and Units that are assigned to the Axis Variables.

The following are the conditions of I/O ports to which you can assign device variables.

- I/O ports with Read/Write attribute set to Read (R: Read only).
- I/O ports with Read/Write attribute set to Write (W: Write only). Also, for these I/O ports, <Not assigned> must be set for the process data field under **Detailed Settings** on the Axis Basic Settings Display in the Sysmac Studio.

If you used the Sysmac Studio version 1.09 or higher to create a project and assign device variables to the Axis Variables, and open the project with the Sysmac Studio version 1.08 or lower, the assignment of the device variables will be cleared.

• NX-series CPU Unit



2

2-4-3 Relationship between Process Data Communications Cycle and Motion Control Period


The PLC Function Module sends motion control commands to the MC Function Module when motion control instructions are executed in the user program. The MC Function Module then performs motion control processing based on those commands and sends the results of processing as commands to the EtherCAT's Servo Drive or other device.

2 Motion Control Configuration and Principles

This type of data exchange is updated as shown in the following processing period.

• NX-series CPU Unit

- Primary period = Motion control 1 period = Process data communications cycle for EtherCAT communications 1
- Task period of the priority-5 periodic task = Motion control 2 period = Process data communications cycle for EtherCAT communications 2




*1 If the sequence control period is primary period, the motion control period and the communications cycle are primary period.

If the sequence control period is the task period of the priority-5 periodic task, the motion control period and the communications cycle are the task period of the priority-5 periodic task.

• NJ-series CPU Unit

 Primary period = Motion control period = Process data communications cycle for EtherCAT communications



3

Configuring Axes and Axes Groups

This section describes the concept of axes and axes groups, the settings for axes that are required for the MC test run function to operate on the Sysmac Studio, and the instructions for creating and configuring axes and axes groups using the Sysmac Studio.

3-1	Axes.		3-2
	3-1-1	Introduction to Axes	.3-2
	3-1-2	Introduction to Axis Parameters	.3-3
	3-1-3	Introduction to Axis Variables	.3-6
	3-1-4	Synchronizing Axis Variables	.3-8
	3-1-5	Specifying an Axis in the User Program	.3-8
3-2	Axis S	etting Procedure	3-9
	3-2-1	Axis Configuration Procedure	.3-9
	3-2-2	Setting Procedure	.3-9
3-3 Axes Groups		Groups	-18
	3-3-1	Introduction to Axes Groups	3-18
	3-3-2	Introduction to Axes Group Parameters	3-19
	3-3-3	Introduction to Axes Group Variables	3-20
	3-3-4	Specifying an Axes Group in the User Program	3-22
3-4	Setting	g Procedures for Axes Groups 3	-23
	3-4-1	Setting Procedure for an Axes Group	3-23
	3-4-2	Setting Procedure	3-23

3-1 Axes

This section describes the axes that are used in a MC Function Module.

3-1-1 Introduction to Axes

In a motion control system, the targets of motion control are called axes. An axis can be an actual Servo Drive or other device or encoder connected using EtherCAT or it can be a virtual Servo Drive or encoder within the MC Function Module.

Axis type	Description
Servo axis	These axes are used by the EtherCAT slave Servo Drives and NX-series Position Interface Units. ^{*1} They are assigned to actual Servo Drives or other devices.
	If you use NX-series Position Interface Units, you can assign more than one device, such as a Pulse Output Unit and Digital Input Unit, to the same axis.
Virtual servo axis	These are virtual axes that exist only inside the MC Function Module. They are not used by actual Servo Drives. For example, they are used as master axes for synchronizing control.
Encoder axis	These axes are used by the EtherCAT slave Encoder Input Terminals and NX-series Position Interface Units. ^{*1} An encoder axis is assigned to an actual encoder input terminal or other device. Encoder axes are assigned to actual encoder input terminals. If one encoder input terminal contains two encoder inputs, the individual encoder inputs will act as one axis.
Virtual encoder axis	These axes are used virtually for encoder operation. A virtual encoder axis is used temporarily in place of an encoder axis when there is no physical encoder. ^{*2}

The MC Function Module supports the axis types that are given in the following table.

*1 Refer to 1-4-3 Function Specifications for the controllable devices.

*2 Virtual encoder axes are used in combination with motion control instructions that update the actual position of the virtual encoder axis. Counting cannot be used with versions of the MC Function Module that do not support these instructions.

The following elements are related to the axes of the MC Function Module.

The number of elements provided is the same as the maximum number of controlled axes for each model. For example, the NJ501-1300 has the elements for 16 axes, the NJ501-1500 has the elements for 64 axes, the NX701-1600 has the elements for 128 axes, and the NX701-1700 has the elements for 256 axes.

Configuration element	Description	Page
Axis parameters	The axis parameters set the maximum velocity, jogging, homing, and other items for the axes operations controlled by the MC Func- tion Module. Use the Sysmac Studio to set the axis parameters.	P. 3-3
Axis Variables	Axis Variables are system-defined variables for the actual position, error information, and other monitor information for axes controlled by the MC Function Module. Axis Variables are created when you add an axis from the Multiview Explorer of the Sysmac Studio. The names of the Axis Variables (called the Axis Variable names) are set here.	P. 3-6
Specifying axes in the user program	In the user program, motion control is implemented with motion con- trol instructions. Motion control instructions that perform single-axis control are used to create axis commands. To control an axis with axis commands, specify the Axis Variable name of the system- defined variable or the Axis Variable name that was set with the Sysmac Studio for the <i>Axis</i> in-out variable of the instruction.	P. 3-8

3-1-2 Introduction to Axis Parameters

• Axis Parameters

Classification	Parameter name
Axis Basic Settings	Axis Number
	Motion Control *1
	Axis Use
	Axis Type
	Input Device/Output Device
Unit Conversion	Unit of Display
Settings	Command Pulse Count Per Motor Rotation
	Work Travel Distance Per Motor Rotation
Operation Settings	Maximum Velocity
	Start Velocity *2
	Maximum Jog Velocity
	Maximum Acceleration
	Maximum Deceleration
	Acceleration/Deceleration Over
	Operation Selection at Reversing
	Velocity Warning Value
	Acceleration Warning Value
	Deceleration Warning Value
	Positive Torque Warning Value
	Negative Torque Warning Value
	Actual Velocity Filter Time Constant
	In-position Range
	In-position Check Time
	Zero Position Range

3

Classification	Parameter name
Other	Immediate Stop Input Stop Method
Operation Settings	Limit Input Stop Method
	Drive Error Reset Monitoring Time
	Maximum Positive Torque Limit
	Maximum Negative Torque Limit
	Immediate Stop Input Logic Inversion *2
	Positive Limit Input Logic Inversion *2
	Negative Limit Input Logic Inversion *2
	Home Proximity Input Logic Inversion *2
Limit Settings	Software Limits
	Positive Software Limit
	Negative Software Limit
	Following Error Over Value
	Following Error Warning Value
Position Count	Count Mode
Settings	Modulo Maximum Position Setting Value
	Modulo Minimum Position Setting Value
	Encoder Type
Servo Drive	Modulo Maximum Position Setting Value
Settings	Modulo Minimum Position Setting Value
	PDS State Control Method
Homing Settings	Homing Method
	Home Input Signal
	Homing Start Direction
	Home Input Detection Direction
	Operation Selection at Positive Limit Input
	Operation Selection at Negative Limit Input
	Homing Velocity
	Homing Approach Velocity
	Homing Acceleration
	Homing Deceleration
	Homing Jerk
	Home Input Mask Distance
	Home Offset
	Homing Holding Time
	Homing Compensation Value
	Homing Compensation Velocity

*1 Set this parameter when using the NX-series CPU Unit.

*2 A CPU Unit with unit version 1.05 or later and Sysmac Studio version 1.06 or higher are required to use this parameter.

Refer to 5-2 Axis Parameters for details on axis parameters.

Settings Required to Use Axes

Classification	Parameter name	Setting	Page
Axis Basic	Axis Number	Axis numbers are automatically set in the order	P. 5-6

The following settings must be made to use t	ne axes that are created with the Sysmac Studio.
--	--

Classification	Parameter name	Setting	Page
Axis Basic Settings	Axis Number	Axis numbers are automatically set in the order that the axes are created.	P. 5-6
	Motion Control ^{*1}	Select Primary periodic task.	
	Axis Use	Select Used axis.	
	Axis Type	Select the type of axis to control.	
	Input Device/Output Device	Specify the node address of the EtherCAT slave device that is assigned to the axis. The Node Address parameter cannot be selected if the Axis Type parameter is set to use a virtual axis.	

*1 Set this parameter when using the NX-series CPU Unit.

Required Settings to Perform a Servo Drive Test Run from the Sysmac Studio

Make the following settings to operate an EtherCAT-connected Servo Drive or other device using the MC test run function of the Sysmac Studio.

Classification	Parameter name	Setting	Page	
Axis Basic Set- tings	Axis Number	The numbers are assigned in the order that the axes are added.	P. 5-6	
	Motion Control ^{*1}	Select Primary periodic task.		
	Axis Use	Select Used axis.		
	Axis Type	Select Servo axis.		
	Input Device/Output Device	Specify the node address of the EtherCAT slave device that is assigned to the axis. The Node Address parameter cannot be selected if the Axis Type parameter is set to use a virtual axis.		
Unit Conversion	Unit of Display	Select the display unit (mm, degrees, etc.).	P. 5-10	
Settings	Command Pulse Count Per Motor Rotation	Set the number of command pulses per motor rotation according to the encoder resolution.* ²		
	Work Travel Distance Per Motor Rotation	Set the workpiece travel distance per motor rota- tion according to the machine specifications.		
Position Count Settings	Count Mode	Set this parameter according to the machine specifications.	P. 5-18	
Limit Settings	Software Limits	Set this parameter according to the device specifications.	P. 5-18	

*1 Set this parameter when using the NX-series CPU Unit.

For example, if the encoder resolution is 10,000 pulses/rotation, set 10,000. *2

Precautions for Correct Use

- Select the appropriate values based on the machine's operating conditions for parameters . such as the maximum velocity, maximum acceleration/deceleration, or stop settings when the motor is actually operated.
- OMRON G5-series Servo Drives can be set to specific node addresses by using the rotary switches on the front panels. If the rotary switches are set to 00, the node address will be determined by the settings made in the EtherCAT Editor of the Sysmac Studio. If the rotary switches are set to 00 for all connected Servo Drives, errors will not occur even if the Servo Drive's connection position is changed. Set the node addresses on the rotary switches to assign specific Servo Drives for each machine control.

3-1 Axes

3-1-3 Introduction to Axis Variables

Axis Variables are system-defined variables for some of the axis parameters and for the monitor information, such as the actual position and error information, for the axes controlled by the MC Function Module. When you create axes with the Sysmac Studio, Axis Variables are registered in the variable table in the order that the axes are created. Axis variables are structures with a data type of _sAXIS_REF.

Axis Variables

Each Axis Variable in the MC Function Module has two variable names: The Axis Variable name in the system-defined variables and the Axis Variable name that is assigned when the axis is added on the Sysmac Studio. The Axis Variable names in the system-defined variables are _MC_AX[0] to _MC_AX[255], _MC1_AX[0] to _MC1_AX[255], _MC2_AX[0] to _MC2_AX[255].

When you add axes on the Sysmac Studio, the *MC_Axis000* to *MC_Axis255* are set by default for *_MC_AX[0]* to *_MC_AX[255]*. The numbers are assigned in the order that the axes are added. You can change each of these Axis Variables as required from the Sysmac Studio. You can use either the Axis Variables for the system-defined variables or the Axis Variables that are added on the Sysmac Studio to specify the Axis Variables in the user program.

Example When _MC_AX[0-255] Is Used

Axis Variable name in the system- defined variables (AT specification in global variable table ^{*1})	Default Axis Variable name when axis is added on the Sysmac Studio	Axis number example
_MC_AX[0]	MC_Axis000	Axis 0
_MC_AX[1]	MC_Axis001	Axis 1
		:
<u>.</u>		-
_MC_AX[255]	MC_Axis255	Axis 255

*1 An error will occur if you change the names in the *AT* column in the global variable table on the Sysmac Studio.

Additional Information

• _*MC_AX[0-255]*, _*MC1_AX[0-255]*, and _*MC2_AX[0-255]* are available for the NX-series CPU Unit.

Only _MC_AX[0-63] is available for the NJ-series CPU Unit.

- When used with the NX-series CPU Unit, you can access the same values of _*MC_AX[0-255]* and _*MC1_AX[0-255]* if the axis numbers of them are the same. You can use either of the Axis Variables, or both of them at the same time.
- The Axis Variable assigned to primary periodic task is _*MC_AX[0-255]* or _*MC1_AX[0-255]*. The Axis Variable assigned to priority-5 periodic task is _*MC2_AX[0-255]*.

Examples of Axis Variable Levels and Changing Axis Variable Names

In the descriptions below, _*MC_AX[0]* is used as an example. The same information applies to the other variables.

_MC_AX[0]	Axis Variable
_MC_AX[0].Status	Level that indicates the axis status
_MC_AX[0].Status.Ready	Variable that indicates that the axis is ready for operation
_MC_AX[0].Status.Disabled	Variable that indicates when the axis is disabled
_MC_AX[0].Details	Level that indicates the axis control status
_MC_AX[0].Details.Idle	Variable that indicates when the axis is idle
_MC_AX[0].Details.InPosWaiting	Variable that indicates in-position waiting
_MC_AX[0].Cmd	Level that indicates the axis command values
_MC_AX[0].Cmd.Pos	Variable that indicates the command current position
_MC_AX[0].Cmd.Vel	Variable that indicates the command current velocity
_MC_AX[0].Cmd.AccDec	Variable that indicates the command current acceleration/decelera- tion rate in the axis monitor
÷	
_MC_AX[0].Act	Level that indicates the axis current values
_MC_AX[0].Act.Pos	Variable that indicates the actual current position
_MC_AX[0].Act.Vel	Variable that indicates the actual current velocity
_MC_AX[0].Cfg	Level that indicates the axis basic settings
_MC_AX[0].Cfg.AxNo	Variable that indicates the axis number
_MC_AX[0].Cfg.AxEnable	Variable that indicates when the axis is enabled
_MC_AX[0].Cfg.AxType	Variable that indicates the axis type
_MC_AX[0].Scale.Units	Variable that indicates the display unit
_MC_AX[1]	Axis Variable
:	

Example: If *MC_Axis000* is changed to *MyAxis1*, then either *MyAxis1.Act.Pos* or *_MC_AX[0].Act.Pos* can be used as the variable that indicates the actual current position.

Refer to Axis Variables on page 6-25 for details on Axis Variables.

3

3-1-4 Synchronizing Axis Variables

The user program for the priority-5 periodic task can access the values of an Axis Variable of an axis that is controlled in the primary periodic task. The reverse is possible: the user program for the primary periodic task can access the values of an Axis Variable of an axis that is controlled in the priority-5 periodic task.

Also, the user program for the priority-16 periodic task can access the values of an Axis Variable that is controlled in the primary periodic task.

The following table shows the relationship between the types of accessing tasks and the Axis Variables.

Tooly type	Axis Variable for motion control 1		Axis Variable for motion control 2		
Task type	User defined *1	System defined ^{*2}	User defined *1	System defined *3	
Primary periodic task	OK	OK	OK*4		
Priority-5 periodic task	OK*5		OK	OK	
Priority-16 periodic task	OK*5	OK*6	OK*4		
Priority-17 or priority-18 periodic task	ОК ^{*5}	OK*7	ОК ^{*4}	0K ^{*8}	
Priority-8 or priority-48 event task	ОК ^{*5}	OK*7	OK*4	0K ^{*8}	

*1 The user-defined Axis Variables, such as *MC_Axis000, Loader1* and other Axis Variables, that are automatically generated when you create the axes on the Sysmac Studio. We recommend that you use the user-defined Axis Variables.

2 _MC_AX[] or _MC1_AX[*]


*3 _*MC2_AX*[*]

*4 The Axis Variable for axis 1 is processed every task period of the priority-5 periodic task.

- *5 The Axis Variable for axis 1 is processed every primary task period.
- *6 The Axis Variables for the maximum number of axes are processed every primary task period. It is not recommended because the task execution time of the primary periodic task is increased.
- *7 The Axis Variables for the maximum number of axes are processed every primary task period.
- *8 The Axis Variables for the maximum number of axes are processed every task period of the priority-5 periodic task.

3-1-5 Specifying an Axis in the User Program

In the user program, an Axis Variable name is specified for the in-out variable *Axis* in motion control instructions. In the following example, the Axis Variable name for the axis that was added for the system-defined Axis Variable name of _*MC*_*AX[0]* has been changed to *MyAxis1* in the Sysmac Studio.



You can also use the _MC_AX[0] system-defined variable in place of MyAxis1.

Refer to 6-2 Motion Control Instructions for details on motion control instructions.

Refer to the instruction descriptions in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508) for details on motion control instructions.

OK: Access possible ---: Access not possible

3-2 Axis Setting Procedure

This section gives the procedures to set servo axes that are newly created with the Sysmac Studio.

3-2-1 Axis Configuration Procedure

(START)				
Create a project.				
Create the EtherCAT Network Configuration.				
Add axes.				
Assign the axes.				
Set the axis parameters.				
Go online and synchronize the data.				
Transfer the project to the Controller.				
END				

3-2-2 Setting Procedure

This section describes how to set an axis.

Starting the Sysmac Studio

- **1** Start the Sysmac Studio and click the **New Project** Button.
- **2** Set the project properties, select the device, and click the **Create** Button.

Author Comment Comment Pype Suided Project Comment Pype Suided Project Comment Select Device Category Contect to Device Category Device N000 100 100 100 100 100 100 100	
	Comment Comment Type Stunded Project ▼ Select Device Category Controller Device To Device ▼ Category Controller Device ▼ 1000 ▼

A new project is displayed.


_	Symac Studio - new Controller_0						
	File Edit Veev Inset Project Controller Simulation Tools Heps X : 예 대 의 그 같 회 전 수 값 53 A 10 R A 10 R A 10 주 개 0						
H	New Project					Toolbox	
	new_Controller_0 V	Programming	× +		୍ରା ପ୍ ପ୍	<search></search>	T P X
	Configurations and Setup						
	Programming Pous						
	▼ (f) Programs ▼ 🖃 Program0						
	L Section0						
	L (2) Function Blocks ►						
Multivis	► En Tasks						7
w Espi							oibox
DIET							
_	E Filter	<u> </u>					

Creating the EtherCAT Network Configuration

There are two methods to create an EtherCAT Network Configuration: online and offline.

Online Method


- **1** Double-click **EtherCAT** in the Multiview Explorer. The EtherCAT Tab Page is displayed.
- **2** Select **Online** from the Controller Menu. The Sysmac Studio goes online with the Controller.
- **3** Right-click the *Master* lcon in the EtherCAT Tab Page and select *Compare and Merge with Actual Network Configuration* from the menu.



When obtaining the information is completed, the physical slave configuration of the EtherCAT slaves is displayed. Right-click the displayed physical configuration and select **Apply actual network configuration**.

Offline Method

1 Double-click **EtherCAT** in the Multiview Explorer. The EtherCAT Tab Page is displayed.




2 Right-click the slave to connect and select **Insert** from the menu.

🖹 Sy	smac Studio			
File	Edit View Insert Project Controller Si	nulation Tools Help		
X	ាំដដែង៤៨ ៩។	K 🔠 🖪 🔍 🗷 🛦 🖄 🖉 🖡 👘		
	New Project	Configurations and Setup	Д QQ Д	All vendors Groups
∑ Nubiten Diplora	verw.1991.0 Configurations and Setup Portugations Port	Configuration and sense Particular Roder Address Indexed. configuration Master	Ren rune Conce non Model Product rune Product rune Communications Cycle Time Total Cable Length Foil communications dating Wait Time for Sales Sarbig Void Time for Sales Sarbig Void Time for Sales Sarbig Sales Sa	Coopy A gradue A gradue
I			- Device name	Model : R880-KN01H-ECT Product name : R880-KN01H-ECT Revision : 2.1 Vendor : OMRON Corporation Comment : 200V/100W ServeOri URL : Open cris Stronger
			Set a name for the master.	
	👔 Filter 📝		,	

🛿 Sysmac Studio					
File Edit View Insert Project Controller Simulation Tools Help					
New Project	7007	All vendors 🔹			
new_NS01_0 V EtherCAT × +		Groups All groups			
Node Address Network configuration		Servo Drives			
Configurations and Setup	Item name Value	Frequency Inverter Digital IO			
▼ 20 EtherCAT E001	Device name E001	Analog 10			
O Node1 : R88D-KN01H-ECT (E R88D-KN01H-ECT Rev:2.1 S OFU/Expansion Racks	Model R88D-KN01	Encoder Input			
o* 1/0 Map	Product name R88D-KN01 Revision 2.1	D APON PRIPAR			
Controller Setup	Node Address 1				
▶ 待 Motion Control Setup	Enable/Disable Settings Enabled Serial Number 0x00000000				
L > Event Settings	0x6040:00	Input Keyword			
L. III Task Settings	0x607A:00 0x60FF:00				
E Data Trace Settings	0x6071:00	R88D-KN01H-ECT Rev:2.1			
▶ Programming	0x6060:00 0x60B8:00	R88D-KN01L-ECT Rev:2.1			
Programming	0x607F:00				
	0x60E0:00 0x60E1:00	B RBBD-RN02H-ECT GS Series ServoDri			
	0%6035-00	R88D-KN02L-ECT Rev:2.1 R88D-KN02L-ECT G5 Series ServoDrik			
He contract of the contract of	PDO Map Settings 0x6041:00 0x6041:00	R880-KN04H-ECT Rev:2.1 R880-IXN04H-ECT G5 Series ServeDrt			
2	0x6077:00	R88D-KN04L-ECT Rev:2.1			
	0x6061:00	R88D-KN06F-ECT Rev:2.1			
	0x60B9:00 0x60BA:00	R08D-R086F-ECT GS Series ServeDrit			
	0x60BC:00	R88D-KN08H-ECT Rev:2.1 R88D-KN08H-ECT GS Series ServoDri			
	0x60FD:00 0x2002:01	R88D-KN10F-ECT Rev:2.1 R88D-KN10F-ECT G5 Series ServeDriv			
	Edit PDO Ma	R88D-KN10H-ECT Rev:2.1 R88D-KN10H-ECT Q5 Series ServeDri			
	Distributed Clock Enable Enabled Reference Clock Exist				
	Setting	R88D-KN150F-ECT G5 Series ServoDr			
	Edit Setting F	R88D-KN150H-ECT Rev:2.1 R88D-KN150H-ECT G5 Series ServeD R R88D-KN15F-ECT Rev:2.1			
		R88D-KN15H-ECT 65 Series ServeDriv R88D-KN15H-ECT Rev;2,1			
		B RBBD-ION15H-ECT GS Series ServeDri			
		R88D-KN20F-ECT G5 Series ServeDrit			
		R88D-KN20H-ECT Rev:2.1 R88D-#X20H-ECT G5 Series ServeDri			
		Model : R88D-KN01H-ECT Product name : R88D-KN01H-EC			
		Revision : 2.1 Vendor : OMRON Corporation			
	- Device name	Comment : 200V/100W ServoDri URL : Open on a browser			
	Set a name for the slave.				
R alter P					


The slave is inserted on the display.



Note: Note: Note: Note: Control: Souther: Note: No	Sysmac Studio					
To represent the second sec	le Edit View Insert Project Controller Simulation Tools Help					
Image: Starting Control (Starting C	X · · · · · · · · · · · · · · · · · · ·	X & & A Ø A X A X A A A A A A A A A A				
	New Indust I configurations and setup Configurations and setup Conf	Configurations and Setup Ether CAT Node Address/Network configuration Master 1 2 2 2 2 2 2 2 2 2 2 2 2 2	Tom name Value Decide rando E203 Anobat name CC 1016 Revision 1.1 Noda Afaris Beakel Scraft Name CC 1016 Revision 1.1 Noda Afaris Beakel Scraft Name CO 1016 PO Map Sattings Do 00100 Distributed Ock Canable — Reference Ock De 10100 Backup Parameters Eith Settings Backup Parameter Sattings Eith Eisöke	Concellent and a second		
	11 Bby (2					

Adding Axes

1 Right-click **Axis Settings** in the Multiview Explorer and select **Axis Settings** from the Add Menu.



An axis is added to the Multiview Explorer. The default name for the new axis is *MC_Axis000*.


📓 New Project - new_Controller_D - Sysmac Studio					
File Edit View Insert Project Controller Simulation Tools Help					
	▲ O º P D Q Q N				
Withweb Epider Image: Control Setup Image: Control Setup Image: Control Setup Image: Control Setu	Nem name Vale Decice name CK201611-0081 Model name CK201611-0081 Protocom SUB1611-1 Protocom Brotocom Protocom Brotocom Protocom Brotocom Protocom Brotocom Protocom Brotocom Protocom Brotocom Brotocom Brotocom Brotocom	Toolbox ● Witeredors ● Etransit All groups ● servo Dives ● ● servo Dives > ● servo Dives > ● servo Dives > ● servo Dives > ● servo Dives > </th			

• Copying an Axis

You can also add an axis by copying the axis settings for an existing axis.

Assigning an Axis

1 Right-click an axis in the Multiview Explorer and select *Edit* from the menu.



The Axis Basic Settings are displayed in the Axis Parameter Settings Tab Page.


New Project - new_Controller_0 - Sysmac Studio				
File Edit View Insert Project Controller Simulation Tools Help				
X ● @ @ ウイ Ø 伊 A & 尿 ☆ A ② R A A & み & ゆ や 言 O 입 2 耳 回 Q 飞				
Multiview Explorer • 7 🔠 EtherCAT Toolbox • Toolbox	÷ 4			
Image: Controller_U Image: Controller_U<				


2 Select from *Primary periodic task* or *Priority-5 periodic task* from *Motion Control*.

Axis Ba	🔃 Axis Basic Settings			
Axis number	0			
Motion control	MC1: Primary periodic task			
Axis use	MC1: Primary periodic task MC2: Priority-5 periodic task			
Axis type	Virtual Servo axis			
Feedback control	No control loop			
Input device 1	<not assigned=""></not>	Channel	T	
Input device 2	<not assigned=""> 🔍</not>	Channel	· · · · · · · · · · · · · · · · · · ·	
Input device 3	<not assigned=""></not>	Channel		

Additional Information


The setting is available for the NX-series CPU Unit, but is not available for the NJ-series CPU Unit.





4 Select the Servo Drive to use.


This setting allows you to use the EtherCAT slave Servo Drive as an axis.



Setting Axis Parameters

Click each of the icons in the Axis Parameter Settings Tab Page.

The settings for each icon are displayed on the Axis Parameter Settings Tab Page.



Right-click **Axis Settings** in the Multiview Explorer and select **Axis Setting Table** to enable setting the axes parameters for all axes at the same time.

S New Project - new_Controller_0 - Sysmac Studio					
File Edit View Insert Project Controller Simulation Tools Help					
X ● ◎ ち C 四 月 A 公 同 出 A 回 K A × A A 5 ~ = O					
New Project	Configurations and Setup		0.0	Toolbox	
	Axis Setting Table × +	А	, 4, 4	<clear search=""> ▼ P</clear>	×
new_Controller_0 Axis Setting Table					
▼ Configurations and Setup					
EtherCAT	Axis Name • Axis Basic Settings	1 MC_Axis000(0)			
CPU/Expansion Racks	Axis use	Used axis	Î		
u a ⁺ I/O Map	Axis type	Servo axis			
▶ ○ Controller Setup ▼ 谷 Motion Control Setup	Feedback control	No control loop			
	Input device 1	-			
」 @ MC Axis000 (0)	Channel				
🛛 🗠 Axes Group Settings					
L & Cam Data Settings	Channel				
Event Settings	Input device 3				
L 백 Task Settings L 단 Data Trace Settings	Channel				
	Output device 1	Node : 1			
Programming	Channel	CH1			
	Output device 2				
	Channel				
M.	Output device 3	•			
itty.	Channel				
Multiview Explo	▼ Unit Conversion Settings				. ĕ
spl	Unit of display	pulse			8
ă	Command pulse count per motor rotation				
	Work travel distance per motor rotation	10000 pulse/rev			
	Operation Settings	40000000 miles (s			
	Maximum velocity Velocity warning value	40000000 pulse/s			
	Start velocity	0 pulse/s			
	Maximum jog velocity	1000000 pulse/s			
	Maximum acceleration	0 pulse/s^2			
	Acceleration warning value	0%			
	Maximum deceleration	0 pulse/s^2			
	Deceleration warning value	0 %			
	Acceleration/deceleration over	Use rapid acceleration/deceleration (Blending is changed to Buffered)			
	Operation selection at Reversing	Deceleration stop			
	Positive torque warning value	0 %			
	Negative torque warning value	0 %			
	In-position range	10 pulse			
	In-position check time	0 ms			
	Actual velocity filter time constant	0 ms			
i Filter	Zero position range	10 pulse	\sim		
	11				

Precautions for Correct Use

When making operation settings such as the display unit, electronic gear (unit conversion formula), maximum velocity, or maximum acceleration/deceleration, be sure to use appropriate values for the operating conditions of the device.

Additional Information

Changing Axis Variable Names in the User Program

Perform the following two procedures to change Axis Variable names that are already used.


- Change the Axis Variable name in the variable table in the variable declarations.
- Change the Axis Variable name in the user program.

Even if you change the Axis Variable names in the variable table, the Axis Variable names in the user program do not change. An error will occur if you use a variable name that is not declared in the variable table, in the user program. Always change the names in both places.

Downloading to the CPU Unit

Use the Synchronization menu command of the Sysmac Studio to download the project to the CPU Unit.

- **1** Select **Online** from the Controller Menu. The Sysmac Studio goes online with the Controller.
- **2** Select *Synchronization* from the Controller Menu and then click the **Transfer to Controller** Button.



Additional Information

Introduction to Servo Drive Settings

The MC Function Module connects to OMRON G5-series Servo Drives with built-in EtherCAT communications or NX-series Pulse Output Units.

Connectable Servo Drive Models

You can connect the R88D-KN — — -ECT and R88D-KN — — -ECT-L Servo Drives. The R88D-KN — — -ECT-R Servo Drives support only Position Control Mode (Cyclic Synchronous Position Control Mode). Therefore, any functions that use Velocity Control Mode (Cyclic Synchronous Velocity Control Mode) or Torque Control Mode (Cyclic Synchronous Torque Control Mode) cannot be used.

Servo Drive Settings

The MC Function Module uses some of the input signals and functions of the Servo Drives. Servo Drive signal wiring and object setting are required to use the MC Function Module properly. Refer to *A-1 Connecting the Servo Drive* for specific settings.

Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for the settings to use NX-series Pulse Output Units.

3-3 Axes Groups

This section describes the axes groups of the MC Function Module.

3-3-1 Introduction to Axes Groups

Use axes groups to perform complex operations on multiple axes, such as linear or circular interpolation. An axes group consists of multiple axes. Use the Sysmac Studio to set Axes Group Variables to enable execution of axes group motion control instructions or to enable access of the status of the axes group. The MC Function Module can handle up to 64 groups. The specifications for axes groups are shown in the following table.

Item	Specification		
nem	NJ-series CPU Unit	NX-series CPU Unit	
Number of axes groups	32 groups max.	64 groups max.	
Number of composition axes	4 axes max. per axes group		

The following elements are related to the axes groups of the MC Function Module.

Configuration element	Description	Page
Axes group parameters	The axes group parameters set the maximum interpolation veloc- ity, maximum interpolation acceleration/deceleration, and other items for the axes groups controlled by the MC Function Module. Use the Sysmac Studio to set the axes group parameters.	P. 3-19
Axes Group Variable	Axes Group Variables are system-defined variables that include a portion of the axes group parameters as well as the command interpolation velocity, error information, and other monitor informa- tion for the axes groups controlled by the MC Function Module. Axes Group Variables are created when you add an axes group from the Multiview Explorer of the Sysmac Studio. The names of the Axes Group Variables (called the Axes Group Variable names) are set here.	P. 3-19
Specifying axes groups in the user program	In the user program, motion control is implemented with motion control instructions. Motion control instructions that perform multi- axes coordinated control are used to create axes group com- mands. To control an axes group with axes group commands, specify the axes group variable name of the system-defined vari- able or the axes group variable name that was set with the Sysmac Studio for the <i>AxesGroup</i> in-out variable of the instruction.	P. 3-22

3-3-2 Introduction to Axes Group Parameters

Classification	Parameter name
Axes Group Basic Set-	Axes Group Number
tings	Motion Control*1
	Axes Group Use
	Composition
	Composition Axes
Axes Group Operation	Maximum Interpolation Velocity
Settings	Maximum Interpolation Acceleration
	Maximum Interpolation Deceleration
	Interpolation Acceleration/Deceleration Over
	Interpolation Velocity Warning Value
	Interpolation Acceleration Warning Value
	Interpolation Deceleration Warning Value
	Axes Group Stop Method
	Correction Allowance Ratio

• Axes Group Parameters

*1 Set this parameter when using the NX-series CPU Unit.

Refer to 5-3 Axes Group Parameters for details on axes group parameters.

• Settings Required to Use an Axes Group

The following settings must be made to use the axes groups that are created with the Sysmac Studio.

Classification	Parameter name	Setting	Page
Axes Group Basic Settings	Axes Group Number	Axes group numbers are automatically set in the order that the axes groups are created.	P. 5-26
	Motion Control ^{*1}	Select Primary periodic task.	
	Axes Group Use	Select Use.	
	Composition	Select the axis composition to control.	
	Composition Axes	This parameter sets the axes to assign to the axes group.	

*1 Set this parameter when using the NX-series CPU Unit.

Precautions for Correct Use

Set appropriate values for the maximum interpolation velocity, stop method, and other items based on the operating conditions.

3-3-3 Introduction to Axes Group Variables

Axes Group Variables are system-defined variables for the setting information and the monitoring information, such as the actual position and error information, for the axes groups controlled by the MC Function Module. When you create axes groups with the Sysmac Studio, Axes Group Variables are registered in the variable table in the order that the axes groups are created. Axes Group Variables are structures with a data type of _sGROUP_REF.

Axes Group Variable Names

Each Axes Group Variable in the MC Function Module has two variable names: The Axes Group Variable name in the system-defined variables and the Axes Group Variable that is assigned when the axes group is added on the Sysmac Studio. The Axes Group Variable names in the system-defined variables are _MC_GRP[0] to _MC_GRP[63], _MC1_GRP[0] to _MC1_GRP[63], _MC2_GRP[0] to _MC2_GRP[63].

When you add axes groups on the Sysmac Studio, *MC_Group000* to *MC_Group063* are set by default for *MC_GRP[0]* to *MC_GRP[63]*. The numbers are assigned in the order that the axes are added. You can change each of these Axes Group Variable names as required from the Sysmac Studio.

You can use either the Axes Group Variable names for the system-defined variables or the Axes Group Variable names that are set on the Sysmac Studio to specify the Axes Group Variables in the user program.

Axes Group Variable name in the system-defined variables (AT specification in global variable table ^{*1})	Default Axes Group Variable name when axes group is added on Sysmac Studio	Axes group number example
_MC_GRP[0]	MC_Group000	Axes group 0
_MC_GRP[1]	MC_Group001	Axes group 1
· · ·	· · · · · · · · · · · · · · · · · · ·	· ·
_MC_GRP[63]	MC_Group063	Axes group 63

• Example When _MC_GRP[0-63] Is Used

*1 An error will occur if you change the names in the AT column in the global variable table on the Sysmac Studio.



Additional Information

- _*MC_GRP[0-63]*, _*MC1_GRP[0-63]*, and _*MC2_GRP[0-63]* are available for the NX-series CPU Unit.
 - Only _MC_GRP[0-63] is available for the NJ-series CPU Unit.
- When used with the NX-series CPU Unit, you can access the same values of _MC_GRP[0-63] and _MC1_GRP[0-63] if the axes group numbers of them are the same. You can use either of the Axes Group Variables, or both of them at the same time.
- The Axes Group Variable assigned to primary periodic task is _*MC_GRP[0-63]* or _*MC1_GRP[0-63]*.
- The Axes Group Variable assigned to priority-5 periodic task is _MC2_GRP[0-63].

Examples of Axes Group Variable Levels and Changing Axes Group Variable Names

In the descriptions below, _*MC_GRP[0]* is used as an example. The same information applies to the other axes group variables.


_MC_GRP[0]	Axes Group Variables
_MC_GRP[0].Status	Level that indicates the axes group status
:	
_MC_GRP[0].Cmd	Level that indicates the axes group command values
_MC_GRP[0].Cmd.Vel	Variable that indicates the command interpolation velocity
_MC_GRP[0].Cmd.AccDec	Variable that indicates the command interpolation accelera- tion/deceleration rate
:	
_MC_GRP[0].Cfg	Level that indicates the axes group basic settings
_MC_GRP[0].Cfg.GrNo	Variable that indicates the axes group number
_MC_GRP[0].Cfg.GrEnable	Variable that indicates when the axes group is enabled
_MC_GRP[0].Kinematics	Level that indicates the kinematics transformation settings
_MC_GRP[0].Kinematics.GrType	Variable that indicates the axis composition
_MC_GRP[0].Kinematics.Axis[0]	Variable that indicates the axis A0 composition axis
÷	
_MC_GRP[0].Kinematics.Axis[3]	Variable that indicates the axis A3 composition axis
_MC_GRP[1]	Axes Group Variable
:	

Example: If *MC_Group000* is changed to *MyGroup1*, then either *MyGroup1.Cmd.Vel* or _*MC_GRP[0].Cmd.Vel* can be used as the variable that indicates the command interpolation velocity.

Refer to Axes Group Variables on page 6-32 for details on Axes Group Variables.

3-3-4 Specifying an Axes Group in the User Program

In the user program, an axes group variable name is specified for the in-out variable *AxesGroup* in motion control instructions. In the following example, the Axes Group Variable name for the axes group that was added for the system-defined Axes Group Variable name of *_MC_GRP[0]* has been changed to *MyGroup1* in the Sysmac Studio.



You can also use the _MC_GRP[0] system-defined variable in place of MyGroup1.


Refer to 6-2 Motion Control Instructions for details on motion control instructions.

Refer to the instruction descriptions in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508) for details on motion control instructions.

3-4 Setting Procedures for Axes Groups

This section gives the procedures to use the Sysmac Studio to set up an axes group. No configuration is required if you are not going to use any axes group command instructions, such as linear interpolation or circular interpolation.

3-4-1 Setting Procedure for an Axes Group



3-4-2 Setting Procedure

This section gives the procedures to use the Sysmac Studio to set up an axes group in a project that already contains the axes.


Starting the Sysmac Studio

1 Start the Sysmac Studio and open the project.


🖉 Offline	Projects
Open Project	New Project
Import	
Conline	
4 Connect to Device	Author Created 12/18/2014 8:54:29 AM Last Modified 12/18/2014 8:54:31 AM
License	Comment Compare Delete Open

Adding an Axes Group

1 Right-click **Axes Group Settings** in the Multiview Explorer and select **Axes Group Settings** from the Add Menu.



An axes group is added to the Multiview Explorer. The default name for the new axes group is *MC_Group000*.




• Copying an Axes Group

You can also create an axes group by copying an axes group from a project.


Setting Axes Group Parameters

1 Right-click an axes group in the Multiview Explorer and select *Edit* from the menu.



The Axes Group Basic Settings are displayed in the Axes Group Parameter Settings Tab Page.


2 Select from Primary periodic task or Priority-5 periodic task from Motion Control.




Additional Information

The setting is available for the NX-series CPU Unit, but is not available for the NJ-series CPU Unit.


- **3** Select *Used axes group* in the *Axes group use* Box.




4 Select the composition of the axes group in the Composition Box. A 2-axis composition is selected in the following example.



5 Assign the axis to use in the Logical axes Box.



6 Click the bottom icon. The Axes Group Operation Settings Display is displayed. Set appropriate values for the settings based on the operating conditions of the device.



Additional Information

Changing Axes Group Variable Names in the User Program

Perform the following two procedures to change Axes Group Variable names that are already used.

- Change the Axes Group Variable name in the variable table in the variable declarations.
- Change the Axes Group Variable name in the user program.


Even if you change the Axes Group Variable names in the variable table, the Axes Group Variable names in the user program do not change. An error will occur if you use a variable name that is not declared in the variable table, in the user program. Always change the names in both places.

Downloading to the CPU Unit

Use the Synchronization menu command of the Sysmac Studio to download the project to the CPU Unit.

1 Select **Online** from the Controller Menu. The Sysmac Studio goes online with the Controller.

2 Select *Synchronization* from the Controller Menu and then click the **Transfer to Controller** Button.



4

Checking Wiring from the Sysmac Studio

This section describes the MC Test Run operations of the Sysmac Studio. You can use the MC Test Run to monitor sensor signals, check motor wiring, and more, all without any programming.

4-1	Functio	ons of the Sysmac Studio	4-2
	4-1-1	MC Test Run Function	.4-2
	4-1-2	Application Procedure	.4-4
	4-1-3	Axis Parameter Setting Example	.4-5
	4-1-4	Starting the MC Test Run Function	.4-6
4-2	Monito	ring Sensor Signals	4-7
4-3	Checki	ng Motor Operation	4-8
	4-3-1	Turning ON the Servo	.4-8
	4-3-2	Jogging	.4-8
	4-3-3	Homing	.4-9
	4-3-4	Absolute Positioning	4-10
	4-3-5	Relative Positioning	4-11

4-1 Functions of the Sysmac Studio

This section describes how to use the MC test run function to check wiring and basic settings. You can use the MC test run function in the Sysmac Studio to check wiring without any programming.

4-1-1 MC Test Run Function

Category	Function	Description	Setting/monitor item
Axis operation	ration Deceleration A deceleration stop is performed during the MC Test Run.		
	Servo ON/OFF	The Servo is turned ON and OFF.	
	Resetting errors	The errors in the MC Function Module are reset.	
	Jogging Jogging is performed in the positive or nega direction.	Jogging is performed in the positive or negative	Target Velocity
-		direction.	Acceleration/Deceleration
	Absolute posi- tioning	Absolute positioning is performed.*	Target Position
			Target Velocity
			Acceleration/Deceleration
			Jerk
	Relative posi- tioning	Relative positioning is performed.	Travel Distance
			Target Velocity
			Acceleration/Deceleration
			Jerk
	Homing	Homing is performed using the homing parameter settings.	Homing Parameters

The MC test run operation supports the following functions.

Category	Function	Description	Setting/monitor item
Monitoring Error list Axis status	The errors in the MC Function Module are mon- itored.	MC Common Errors	
		Axis Errors	
			Axes Group Errors
	Axis status	The status of the axes is monitored.	Axis Ready-to-execute
			Standstill
			Discrete Motion
			Continuous Motion
			Homing
			Stopping
			Home Defined
			In Home Position
	Actual posi- tion monitor	The actual position is monitored.	Command and Actual Cur- rent Positions
Actual veloc- ity monitor Servo Drive status		The actual velocity is monitored.	Command and Actual Cur- rent Velocities
	Servo Drive	The status of the Servo Drive is monitored.	Servo ON/OFF
		Servo Ready	
		Main Power	
	Input signals	The status of the input signals are monitored.	Positive Limit Input
			Negative Limit Input
			Immediate Stop Input
			Home Proximity Input
			Home Input
			External Latch Inputs 1 to 2

* When the Count Mode of the axis is set to Rotary Mode, positioning is performed toward the target position in the positive direction. For details, refer to the MC_MoveAbsolute (Absolute Positioning) instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Note You can use MC Test Runs for OMRON G5-series Servo Drives or NX-series Pulse Output Units. Do not use it with servo drives from any other manufacturer.

4-1-2 Application Procedure

Before you perform an MC Test Run, check the following two items.

- Are the Sysmac Studio and Controller connected and are they online?
- Is the MC Test Run Mode currently in use from any other copy of the Sysmac Studio?

After you have confirmed these two items, perform the following operations as instructed.

	(START)	
		Section 3 Configuring Axes and
Setup	Create the EtherCAT slave configuration, add axes,	Axes Groups
	assign the axes, and set the axis parameters.	
	$ \downarrow $	Continue 4 Charling Wining
Starting the MC	Start the MC test run function.	Section 4 Checking Wiring from the Sysmac Studio
test run function		
Checking wiring	Confirm sensor wiring.	
Checking motor		
operation	Use jogging to check the direction of the motor.	
Checking electronic		
gear settings	Perform relative positioning to check the travel distance.	
Confirming homing	Perform homing to check the homing operation.	

Precautions for Correct Use

- When one of the following operations is performed for a command from the Sysmac Studio, the Servomotor will operate at the set velocity: Servo ON, jogging, relative positioning, absolute positioning, or homing. Always confirm that it is safe for the Servomotor to operate before executing any of these operations.
- When operating the Controller from the Sysmac Studio, always install external emergency circuits so that the Servomotor can be stopped safely whenever necessary. The Sysmac Studio may not be able to send commands under some circumstances, e.g., if an error occurs in the computer.
- Set the EtherCAT communications and establish communications before you attempt to perform operation from the Sysmac Studio.
- Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for the procedures for the NX-series Position Interface Units.

Additional Information


You can perform the following operations to end the MC test run function at any time.

- Select *MC Test Run Stop* from the Controller Menu of the Sysmac Studio.
- Right-click the axis in the Multiview Explorer of the Sysmac Studio and select Stop MC Test Run from the menu.
- Close the MC Test Run Tab Page on the Sysmac Studio.
- Exit the Sysmac Studio.

Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for specific procedures.

4-1-3 Axis Parameter Setting Example

Set the following axis parameters before you execute the MC Test Run Mode in the Sysmac Studio. The following setting example is for a one-axis device.



Encoder Output Pulse Count per Motor Rotation 20 bits = 1,048,576

Parameter name	Setting
Axis Variable Name	Axis1 ^{*1}
Axis Number	1*2
Axis Use	Used axis
Axis Type	Servo axis
Input Device/Output Device	1 ^{*3}
Unit of Display	μm
Command Pulse Count Per Motor Rotation	1,048,576 ^{*4}
Work Travel Distance Per Motor Rotation	10,000 ^{*4}
Maximum Velocity	500,000 ^{*5}
Maximum Jog Velocity	50,000 ^{*6}
Maximum Acceleration	5,000,000 ^{*7}
Maximum Deceleration	5,000,000 ^{*7}
Software Limits	Immediate stop for command position
Positive Software Limit	500,000 ^{*8}
Negative Software Limit	0*8
Count Mode	Linear Mode

*1 If there is more than one axis, a different variable name is set for each axis.

*2 If there is more than one axis, a different value is set for each axis.


*3 Set the same node address as for the Servo Drive. If there is more than one axis, a different value is set for each axis.

- *4 The position command unit will be 1 μ m.
- *5 The maximum velocity will be 3,000 r/min = 30 m/min = 0.5 m/s = 500,000 μ m/s.
- *6 The maximum jog velocity will be 10% of the maximum velocity, i.e., 0.05 m/s = 50,000 μ m/s.
- *7 The maximum acceleration and the maximum deceleration will be 5 m/s². The acceleration time to the maximum velocity (3,000 r/min) will be 0.1 s.
- *8 Set a value that is within the movable range of the device. The positive software limit is set to 50 cm = $500,000 \ \mu m$.

4-1-4 Starting the MC Test Run Function

The MC Test Run Mode is started from the Sysmac Studio.

- **1** Start the Sysmac Studio and open a project in which the axis settings are completed.
- **2** Select **Online** from the Controller Menu. The Sysmac Studio goes online with the Controller.
- **3** Select *MC Test Run Start* from the Controller Menu.



When the following caution dialog box appears, read the message carefully. After you confirm safety, click the **OK** Button.

📓 Test Rur		
	Caution	
A	Special care must be taken for this function because the motor rotates. Be sure to carefully read the operation manual before executing this function. Especially, pay attention to the following:	
	w press the Start operation button, the motor will actually rotates at the specified velocity. Carefully that the motor operation does not cause any danger, and then press the button.	
so that :	ors may not be stopped by the operations from the computer. Install an external emergency stop device ou can stop the motor immediately when required.	
Perform the operation under the conditions where you can check the motor operation so that you can immediately take appropriate actions if motor operation causes a dangerous situation.		
If you a will occu	tempt to start the operation before establishing the EtherCAT communications, a communications error r. Be sure to establish the EtherCAT communications in advance.	
During the operation, only the commands from Sysmac Studio are accepted. All commands from the CPU Unit will become invalid.		
Before o	xecuting the operation, confirm that the axis numbers of the target axes are correct.	
	Operation will be started. Are you sure to start the operation?	
	OK Cancel	


The MC Test Run Tab Page is displayed.

Sysmac Studio			
Elle Edit View Insert Brokett Sontroller Simulation Tools Belp			
Nor Holdst Configurations and Setup If Crief Russiania And setup If Russiania Benetis materia If Russiania Benetis materia	Tobor CCar ando		
	Status Monitor ONLINE 192.168.250.1 ERR/ALM RUN mode		

4-2 Monitoring Sensor Signals

You can use the input signal display to check sensor signal wiring.

1 Select the axis to check on the MC Test Run Tab Page.



2 Check to see if the signals turn ON and OFF properly on the monitor screen by turning ON and OFF the sensor connected to each input signal.

4-3 Checking Motor Operation

Use the functions of the MC Test Run to check motor operation.

4-3-1 Turning ON the Servo

You can use the Servo ON Button to turn the Servo ON and OFF.

1 Select the axis for which to turn ON the Servo.

Fer Edit Vew Invest Project Controler Serulation Tools Help 文書 絵合つ C 11 (月 4 公式 15 A 10) 氏 (本) (人 小 5 年) 〇
Ver Pripet Configurations and Seep DCC end Rule Ver Pripet Configurations and Seep DCC end Rule Ver Pripet In the Configurations and Seep DCC end Rule Ver Pripet In the Configurations and Seep DCC end Rule Ver Pripet In the Configurations and Seep DCC end Rule Ver Pripet In the Configurations and Seep DCC end Rule Ver Pripet In the Configurations and Seep DCC end Rule Ver Pripet In the Configurations and Seep DCC end Rule Ver Pripet In the Configurations and Seep DCC end Rule Ver Pripet In the Configurations and Seep DCC end Rule Ver Pripet In the Configurations and Seep DCC end Rule Ver Pripet In the Rule DCC end Rule Ver Pripet In the Rule DCC end Rule Ver Rule Served Rule Counted ensure Ver Rule Served Rule DCC end Rule Ver Rule Served Rule In the Rule Vertex Rule Served Rule

- Click the Servo ON Button to turn ON the Servo.
- **3** Click the Servo OFF Button to turn OFF the Servo.

Precautions for Correct Use

- When one of the following operations is performed for a command from the Sysmac Studio, the Servomotor will operate at the set velocity: Servo ON, jogging, relative positioning, absolute positioning, or homing. Always confirm that it is safe for the Servomotor to operate before executing any of these operations.
- When you operate the Controller from the Sysmac Studio, always install external emergency circuits so that the Servomotor can be stopped safely whenever necessary. The Sysmac Studio may not be able to send commands under some circumstances, e.g., if an error occurs in the computer.
- Set the EtherCAT communications and establish communications before you attempt to perform operation from the Sysmac Studio.
- If you use an NX-series Pulse Output Unit, you must provide a separate means to turn the power supply to the motor drive ON and OFF. Refer to the NX-series Position Interface Units User's Manual (Cat. No. W524) for details.

4-3-2 Jogging

- **1** Select the axis to jog on the Jogging Tab Page of the MC Test Run Tab Page.
- **2** Click the **Servo ON** Button to turn ON the Servo.
- **3** Enter the target velocity, acceleration rate, and deceleration rate, and then press the **Apply** Button.

4 Click the 🔝 or 💽 Button.

The motor will operate in either the positive or negative direction while one of these buttons is clicked. Check to see if the motor operates in the set direction.

4-3-3 Homing

1 Set the homing parameters in the Homing Settings on the Axis Parameter Settings Tab Page.

2 Click the Homing Tab on the MC Test Run Tab Page.

The following dialog box is displayed.

Sysmac Studio			
File Edit View Insert Project Controller Simulation Tools Help			
又 単 単 中 本 製 専 本 製 専 本 製 単 本 美 単 本 単 申 ○			
	dealand de motion Stapping Stapping Message detals Contenensast Co		
E fiker			

- **3** Select the axis to home.
- 4 Click the Servo ON Button to turn ON the Servo.
- **5** Click the **Apply homing parameters** Button.
- 6 Click the 🛐 Button.

Check to see if the homing operation agrees with the settings.

Additional Information

- When you click the **Homing Settings** Button, the Homing Settings are displayed on the Axis Parameter Settings Tab Page. Set the homing parameters.
- If the homing parameters were set in advance, click the Apply homing parameters Button to apply those settings.

4-3-4 Absolute Positioning

1 Click the **Absolute positioning** Tab on the MC Test Run Tab Page. The following dialog box will appear.

Sysmac Studio	B
File Edit View Insert Project Controller Simulation Tools Help	
2 単 単 9 ご 2 日 2 日 2 日 2 日 2 日 2 日 2 日 2 日 2 日 2	
New Project Configurations and Setup	
No. No. N. State Concerning of the Concerning of	
Avia selection tractice and the rest	
Configurations and detup	
Xature Sature Xature Sature Sature Xature Sature Xature Sature Sature Xature Sature Sature Xature Sature Sature Sature Xature Sature Sature Xature Sature Sature Sature Sature Sature Sature Xature Sature Xature Sature Sature S	
Standstill Discrete motion Continuous motion Homing	
Costructer Solup V - Of Matin Costruct Solup Stopping Error stopping Home defined In home position	
▼ (2) Axis Settings Motion error list	
WC_Adat000 (0) Event LevellSourcelMessage Name! Message details	
er Cam Data Settinos Countermeasur	
e and remody	
L Re Tack Stillings	
▼ Programming Test Run	
Stopping Servo ON	
▼ In Programs Drive status	
I Program0 Command current position Opulse Positive limit input OEE	
Actual current position Actual current position Pulse Negative limit input ON Servo ready ON	
K-scolog K-task current position Actual current webcty Dudge's Immediate stop position Actual current webcty Dudge's Immediate stop position Actual current webcty Dudge's Immediate stop position Actual current webcty Actual current webcty Dudge's Immediate stop position	l Š
Latch input 2 OFF	
Dogging × Absolute positioning × Relative positioning × Homing ×	
Target position 10000 pulse	
Target velocitypulse/s	
Acceleration pulse/s^2 Deceleration pulse/s^2	
Derk publicher 3	
Apply	
I fikor C	

- **2** Select the axis to perform absolute positioning.
- **3** Click the Servo ON Button to turn ON the Servo.
- 4 Enter the target position, target velocity, acceleration rate, deceleration rate, and jerk, and then click the **Apply** Button.
- **5** Click the Button. Absolute positioning will start. Check to see if positioning agrees with the settings.

4-3-5 Relative Positioning

1 Click the **Relative positioning** Tab on the MC Test Run Tab Page. The following dialog box will appear.

Sysmac Studio		
File Edit View Insert Project Controller Sim	nulation Tools Help	
	. X . A	
Nov Prigat Configurations and Setup Configurations and Setup Config	Image: Serve ON Source Level Source Massage Name Certification (mc/_massage Name) Continuous motion Image: Serve ON Test Ran Certification (mc/_massage Name) Certification (mc/_massage Name) Construction (mc/_massage Name) Motion error lat: Certification (mc/_massage Name) Certification (mc/_massage Name) Motion error lat: Certification (mc/_massage Name) Certification (mc/_massage Name) Massage Name Massage Name Massage Name Massage Name Massage Name Massage Name Massage N	H Q Q H
🖬 Filter 🕑		

- **2** Select the axis to perform relative positioning.
- **3** Click the **Servo ON** Button to turn ON the Servo.
- **4** Enter the target travel distance, target velocity, acceleration rate, deceleration rate, and jerk, and then click the **Apply** Button.
- **5** Click the Button. Relative positioning will start. Check to see if the travel distance agrees with the settings.

5

Motion Control Parameters


This section explains about axis parameters and axes group parameters used for motion control.

5-1	Introdu	uction	. 5-2
5-2	Axis P	arameters	. 5-4
	5-2-1	Axis Parameters	5-4
	5-2-2	Axis Basic Settings	5-6
	5-2-3	Unit Conversion Settings	5-10
	5-2-4	Operation Settings	5-13
	5-2-5	Other Operation Settings	5-17
	5-2-6	Limit Settings	5-18
	5-2-7	Position Count Settings	5-18
	5-2-8	Servo Drive Settings	5-20
	5-2-9	Homing Settings	5-21
	5-2-10	Axis Parameter Setting Example	5-22
5-3	Axes G	Group Parameters	5-25
	5-3-1	Axes Group Parameters	5-25
	5-3-2	Axes Group Basic Settings	5-26
	5-3-3	Axes Group Operation Settings	5-28
	5-3-4	Enabling an Axes Group	5-30

5-1 Introduction

You can use motion control instructions to perform single-axis operations and multi-axes operations on axes groups with the NJ/NX-series CPU Unit's MC Function Module. Axis and axes group parameters are used to set these operations. Axis parameters must be set, but axes group parameters are not required if you do not use multi-axes operations for axes groups.

These parameters are called motion control parameter settings (MC parameter settings).



- *1 There are no MC Common Parameter Settings for the current version of the MC Function Module.
- *2 Use the Synchronization menu command of the Sysmac Studio to upload and download the project.
- *3 A CPU Unit with unit version 1.08 or later and Sysmac Studio version 1.09 or higher are required to use the MC_WriteAxisParameter (Write Axis Parameters) and MC_ReadAxisParameter (Read Axis Parameters) instructions.

Data Flow for Setting MC Parameters

- Download your MC Parameter Settings to the CPU Unit using the Sysmac Studio to save those settings in the CPU Unit's non-volatile memory. When you upload the MC Parameter Settings to the Sysmac Studio, the MC Parameter Settings that were saved in the non-volatile memory are uploaded.
- The settings that were saved in the non-volatile memory are applied to the main memory after you download them or when the power is turned ON.
- If there are no problems with the saved settings, the MC Function Module executes control based on the settings in the main memory.
- The settings of some of the parameters can be accessed as system-defined variables for motion control.
- You can upload and download MC parameter settings regardless of the CPU Unit's mode or the status of the MC Function Module.
- When you start the download process, all axes in motion will stop immediately and the Servo will turn OFF.

• Overwriting MC Parameters with Programming Instructions

- You can use motion control instructions like the MC_Write (Write MC Setting), MC_ChangeAxesInGroup (Change Axes in Group) or MC_WriteAxisParameter (Write Axis Parameters) instruction to change the settings of some of the MC parameters in the main memory while the user program is running.
- If the specified set value is outside the valid range, the *Error* output variable from the instruction changes to TRUE and the MC parameter setting is not changed.
- Changes to MC parameter settings become valid in either of the following two situations.
 - The axis or axes group is stopped and you execute an instruction for an axis command or axes group command.
 - You set the Buffer Mode Selection for the instruction to Aborting and execute more than one instruction.
- For details on MC_Write (Write MC Setting), MC_ChangeAxesInGroup (Change Axes in Group), MC_WriteAxisParameter (Write Axis Parameters) and other instructions, refer to the *NJ/NX-series Motion Instructions Reference Manual* (Cat. No. W508).

Precautions for Correct Use

- Changes to the MC Parameter Settings that are made with the MC_Write (Write MC Setting) instruction are saved in the main memory in the CPU Unit. They are not saved in the built-in non-volatile memory in the CPU Unit. Therefore, if you cycle the power supply or download the settings from the Sysmac Studio, the parameter settings in the non-volatile memory are restored. Also, you cannot upload the data in the main memory from the Sysmac Studio. If you need to save settings to the non-volatile memory, use the Sysmac Studio to change the parameter settings and then download those settings to the CPU Unit.
- You can use the following instructions to change the settings of the MC parameters.
 - MC_Write (Write MC Setting) instruction
 - MC_ChangeAxesInGroup (Change Axes in Group) instruction
 - MC_ChangeAxisUse (Changing Axis Use) instruction
 - MC_WriteAxisParameter (Write Axis Parameters) instruction
- Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for information on using the NX-series Position Interface Units.

The following sections provide details on the parameter settings that you can set from the Sysmac Studio.

5-2 Axis Parameters

The axis parameters set the maximum velocity, jerk, homing, and other items for the axes controlled by the MC Function Module.

The number of axis parameters provided is the same as the maximum number of controlled axes for each model. For example, the NJ501-13 \square has the axis parameters for 16 axes, the NJ501-15 \square has the axis parameters for 64 axes, the NX701-16 \square has the axis parameters for 128 axes, and the NX701-17 \square has the axis parameters for 256 axes.

The same parameter settings are provided for each axis. This section describes only the parameters for axis 1.

5-2-1 Axis Parameters

		Temporary changes ^{*1}		Reading		
Classification	Parameter name	Support	Applicable instruction variable			
Axis Basic	Axis Number			OK	P. 5-6	
Settings	Motion Control *3			OK ^{*4}	l	
	Axis Use	ОК ^{*5}	MC_ChangeA xisUse	ОК		
	Axis Type			OK		
	Input Device/Output Device			OK		
Unit Conver-	Unit of Display	OK*6	MC_WriteAxis	OK	P. 5-10	
sion Settings	Command Pulse Count Per Motor Rota- tion	-	Parameter ^{*7}	OK	P. 5-13	
	Work Travel Distance Per Motor Rotation			OK		
Operation Set-	Maximum Velocity	-				
tings	Start Velocity ^{*8}					
	Maximum Jog Velocity					
	Maximum Acceleration					
	Maximum Deceleration					
	Acceleration/Deceleration Over					
	Operation Selection at Reversing					
	Velocity Warning Value	OK	OK MC_Write MC_WriteAxis Parameter ^{*7}			
	Acceleration Warning Value					
	Deceleration Warning Value					
	Positive Torque Warning Value					
	Negative Torque Warning Value	1				
	In-position Range	0K ^{*9}				
	In-position Check Time	OK	1		1	
	Actual Velocity Filter Time Constant	OK*6	MC_WriteAxis]	
	Zero Position Range		Parameter*7			

Use the Sysmac Studio to set the axis parameters for each axis.

		Tempora	ary changes ^{*1}	Reading	
Classification	Parameter name	Support	Applicable instruction	variables ^{*2}	Page
Other Opera-	Immediate Stop Input Stop Method	0K ^{*6}	MC_WriteAxis		P. 5-17
tion Settings	Limit Input Stop Method		Parameter ^{*7}		
	Drive Error Reset Monitoring Time				
	Maximum Positive Torque Limit				
	Maximum Negative Torque Limit				-
	Immediate Stop Input Logic Inversion *8				
	Positive Limit Input Logic Inversion *8				-
	Negative Limit Input Logic Inversion *8				
	Home Proximity Input Logic Inversion *8	-			-
Limit Settings	Software Limits	OK	MC_Write		P. 5-18
	Positive Software Limit		MC_WriteAxis		-
	Negative Software Limit	_	Parameter ^{*7}		-
	Following Error Over Value	-			
	Following Error Warning Value				
Position Count	Count Mode	0K ^{*6}	MC_WriteAxis		P. 5-18
Settings	Modulo Maximum Position Setting Value	-	Parameter*7	OK *4	
	Modulo Minimum Position Setting Value			OK *4	-
	Encoder Type				
Servo Drive	Modulo Maximum Position Setting Value				P. 5-20
Settings	Modulo Minimum Position Setting Value				
	PDS State Control Method ^{*4}				-
Homing Set-	Homing Method	0K ^{*6}	MC_WriteAxis		P. 5-21
tings	Home Input Signal	-	Parameter ^{*7}		-
	Homing Start Direction				
	Home Input Detection Direction				
	Operation Selection at Positive Limit Input				
	Operation Selection at Negative Limit Input				
	Homing Velocity				
	Homing Approach Velocity				
	Homing Acceleration				
	Homing Deceleration				
	Homing Jerk				
	Home Input Mask Distance	1			1
	Home Offset	1			1
	Homing Holding Time	1			1
	Homing Compensation Value]]
	Homing Compensation Velocity]

*1 This column indicates if you can use instructions to temporarily change the settings.

- *2 Indicates whether you can access the parameter with a system-defined variable for motion control in the user program.
- *3 Set this parameter when using the NX-series CPU Unit.
- *4 A CPU Unit with unit version 1.10 or later and Sysmac Studio version 1.12 or higher are required to use this parameter.

- *5 A CPU Unit with unit version 1.04 or later and Sysmac Studio version 1.05 or higher are required for temporary changes.
- *6 A CPU Unit with unit version 1.08 or later and Sysmac Studio version 1.09 or higher are required for temporary changes.
- *7 A CPU Unit with unit version 1.08 or later and Sysmac Studio version 1.09 or higher are required to use the MC_WriteAxisParameter instruction. The parameters that can be temporarily changed with the MC_WriteAxisParameter instruction can be read with the MC_ReadAxisParameter instruction.
- *8 A CPU Unit with unit version 1.05 or later and Sysmac Studio version 1.06 or higher are required to use this parameter.
- *9 A CPU Unit with unit version 1.01 or later and Sysmac Studio version 1.02 or higher are required for temporary changes using the MC_Write instruction. A CPU Unit with unit version 1.08 or later and Sysmac Studio version 1.09 or higher are required for temporary

changes using the MC_WriteAxisParameter instruction.

Refer to 3-2 Axis Setting Procedure for details on how to set axis parameters.

For details on instructions including the MC_Write (Write MC Setting) instruction, refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Refer to 6-6 System-defined Variables for Motion Control for information on system-defined variables for motion control.

5-2-2 Axis Basic Settings

The Axis Basic Settings are used to set whether to use the axis. If you use the axis, set the axis type and the node address of the EtherCAT slave device.

Parameter name	Function	Setting range	Default
Axis Number	Set the logical number of the axis. This number spec- ifies which of the following system-defined variables to use:_ <i>MC_AX[0]</i> to _ <i>MC_AX[63]</i> .		
Motion Control *1	Assign to either of the primary periodic task or prior- ity-5 periodic task.	1 to 2	1
	1: Primary periodic task		
	2: Priority-5 periodic task		
Axis Use	Set whether to enable or disable the axis.*2	0 to 2	0
	0: Undefined axis		
	1: Unused axis ^{*3}		
	2: Used axis		
Axis Type	Set the axis type. I/O wiring is not required for virtual axes.	0 to 3	2
	0: Servo axis		
	1: Encoder axis		
	2: Virtual servo axis		
	3: Virtual encoder axis		
Input Device/Output	Specify the node address of the EtherCAT slave	0 to 65535	
Device	device that is assigned to the axis. *4		
	The Node Address parameter cannot be selected if the Axis Type parameter is set to a virtual axis.		

*1 Set this parameter when using the NX-series CPU Unit. The setting is not available for the NJ-series CPU Unit, which supports only the primary periodic task.

*2 Busy (Controlling) changes to TRUE if you execute a motion control instruction for an undefined or unused axis. Busy changes to FALSE when Execute or Enable changes to FALSE. You can set axes as unused axes to enable using the same user program for different axis configurations without the need to delete programming for axes that are not used.

- *3 With a CPU Unit with unit version 1.04 or later and Sysmac Studio version 1.05 or higher, *Unused axis* (changeable to used axis) and Unused axis (unchangeable to used axis) are displayed by the Sysmac Studio. If you set Unused axis (changeable to used axis), you can set the axis parameters and use the MC_ChangeAxisUse (Change Axis Use) instruction to temporarily change the setting of the Axis Use axis parameter. Refer to 9-8-10 Changing Axis Use for details.
- *4 For an NX-series Position Interface Unit, select the node address of the EtherCAT Coupler Unit and the NX Unit number of the Position Interface Unit.

Precautions for Correct Use

Using Absolute Encoders

When absolute encoders are used, the absolute encoder home offset for each axis is saved to the battery-backup memory along with the axis number. The saved offset is lost if the axis number is changed. If you change the axis number, set the Homing Settings again.

Axis Numbers

The number that you can set for axis numbers is the maximum number of controlled axes. The number of real axes that you can change to used axes is the maximum number of used real axes.

Item	NX701-17□□	NX701-16□□	NJ501-15□□	NJ501-14□□	NJ501-13□□
Settable axis numbers	0 to 255	0 to 127	0 to 63	0 to 31	0 to 15
Maximum number of used real axes	256 axes	128 axes	64 axes	32 axes	16 axes

Item	NJ301-12□□	NJ301-11□□	NJ101-10□□
Settable axis numbers	0 to 14 ^{*1}	0 to 14 ^{*2}	0 to 5
Maximum number of used real axes	8 axes	4 axes	2 axes

*1 For a CPU Unit with unit version 1.05 or earlier, the number is 0 to 7.

*2 For a CPU Unit with unit version 1.05 or earlier, the number is 0 to 3.

Motion Control

For the NX-series CPU Unit, the axes to use are assigned to either of the primary periodic task or priority-5 periodic task.



Additional Information

The **Motion control** setting is not available for the NJ-series CPU Unit, which supports only the primary periodic task.

5

Axis Types

The following table describes the different axis types that you can select in the Axis Type parameter.

Axis type	Description
Servo axis	These axes are used by the EtherCAT slave Servo Drives and NX-series Position Interface Units. ^{*1} They are assigned to actual Servo Drives or other devices. One Servomotor is used as one axis. If you use NX-series Position Interface Units, you can assign more than one device, such as a Pulse Output Unit and Digital Input Unit, to the same axis.
Virtual servo axis	These virtual axes exist only inside the MC Function Module. They are not used by actual Servo Drives. For example, they are used as master axes for synchronizing control.
Encoder axis	These axes are used by the EtherCAT slave Encoder Input Terminals and NX- series Position Interface Units. ^{*2} An encoder axis is assigned to an actual encoder input terminal or other device. If one encoder input terminal contains two counters, each counter will act as one axis.
Virtual encoder axis	These virtual axes are used for encoder operation. A virtual encoder axis is used temporarily in place of an encoder axis when there is no physical encoder.*3

*1 Refer to 1-4-3 Function Specifications for the controllable devices.

*2 Refer to 1-4-3 Function Specifications for the controllable devices.

*3 Virtual encoder axes are used in combination with motion control instructions that update the actual position of the virtual encoder axis. They cannot be used in place of encoder axes for versions of the MC Function Module that do not support such instructions.

• Virtual Servo Axes

A virtual servo axis does not have a physical encoder or external I/O signals. Therefore, virtual servo axes differ from servo axes in the following ways.

- They are always in Servo ON state.
- The actual current position equals the command current position.*
- The actual current velocity equals the command current velocity.*
- External input signals cannot be used.
- If the MC_Home or MC_HomeWithParameter instruction is executed, the instruction is processed as a zero position preset regardless of the setting of the Homing Method axis parameter.
- If a motion control instruction that uses a latch function is executed, you must set the trigger input condition to Controller Mode. An error does not occur if you set it to Drive Mode, but a latch trigger will not occur, so execution of the instruction will not end.
 Latches are used by the following instructions: MC_TouchProbe (Enable External Latch), MC_MoveFeed (Interrupt Feeding), MC_MoveLink (Synchronous Positioning), and other instructions.
- Errors do not occur for immediate stop inputs or positive/negative limit inputs because the input signals do not exist.
- * However, there is sometimes calculation error because processing is performed with long reals in the MC Function Module.

• Encoder Axes and Virtual Encoder Axes

Encoder and virtual encoder axes differ from servo and virtual servo axes in the following ways.

- They do not have command positions. They have only actual positions.
- You cannot use motion-type motion control instructions for them.


Input Device/Output Device

For a servo or encoder axis, the node address specifies the node address of the EtherCAT slave device that is assigned to the axis. For an NX-series Position Interface Unit, select the node address of the EtherCAT Coupler Unit and the NX Unit number of the Position Interface Unit.

The Node Address parameter cannot be selected if the Axis Type parameter is set to a virtual axis.

Additional Information

 The following example shows the EtherCAT device's node address setting for an OMRON G5series Servo Drive with built-in EtherCAT communications.



 The rotary switches in the display area on the Servo Drive are used to set the EtherCAT node address.

Rotary switch setting	Node address setting range		
Rolary Switch Setting	OMRON slaves	Non-OMRON slaves ^{*1}	
00	Value set from the Sysmac Studio (1 to 512 ^{*2})	Value set from the Sysmac Studio (1 to 512 ^{*2})	
01 to 99	Node address switch setting		

- *1 The value set from the Sysmac Studio will be used for all non-OMRON slaves, regardless of any setting at the slave.
- *2 The value changes to 192 for the NJ-series CPU Unit.



Precautions for Correct Use

- OMRON G5-series Servo Drives can be set to specific node addresses by using the node address switches on the front panels. If the node address switches are set to 00, the node address will be determined by the settings made in the EtherCAT Editor of the Sysmac Studio. If the node address switches are set to 00 for all connected Servo Drives, errors will not occur even if the Servo Drive's connection position is changed. Set the node addresses on the node address switches to assign specific Servo Drives for each machine control.
- The value set on the Servo Drive's node address switches is loaded only once when the Servo Drive's control power is turned ON. Such changes are enabled only after the power supply is turned ON again. Do not change the setting on the node address switches after the power supply has been turned ON.
- An error occurs if the same node address is used more than once.

5

5-2-3 Unit Conversion Settings

Parameter name	Function	Setting range	Default
Unit of Display	Set the unit for command positions.	0 to 5	0
	pulse		
	mm		
	μm		
	nm		
	degree		
	inch		
Command Pulse Count Per Motor Rotation ^{*1}	Set the number of pulses per motor rotation for command positions according to the encoder resolution. ^{*2} The command value is converted to a number of pulses based on the electronic gear ratio.	1 to 4,294,967,295	10,000
Work Travel Dis- tance Per Motor Rotation ^{*3}	Set the workpiece travel distance per motor rotation for command positions.	0.00000001 to 4,294,967,295	10,000


These parameters set position units.

*1 This is the numerator of the electronic gear ratio (unit conversion formula).

*2 For example, if the encoder resolution is 10,000 pulses/rotation, set 10,000.

*3 This is the denominator of the electronic gear ratio (unit conversion formula).


Positions are generally given in pulses between the MC Function Module and Servo Drives or encoder input terminals. Use a display unit of millimeters or degrees for motion control instructions so that you can easily understand the operation.



You can use the Unit of Display parameter and electronic gear (unit conversion formula) settings to change from a pulse unit to millimeters or degrees.

Additional Information

For a virtual servo axis, the command current value is converted to pulses and then that value is converted to the unit of display. The resulting value is used as the actual current value.




Unit of Display

You can use the Unit of Display parameter to set the unit to display on the Sysmac Studio. The display shows the position's display unit. The following table describes the units you can set.

Unit	Description	
pulse	Use this unit to express values in pulses.	
mm	Use this unit for comparatively long-distance direct operation.	
μm	Use this unit for precise direct operation.	
nm	Use this unit for more precise direct operation than μm .	
degree	Use this unit for rotary tables or other rotating axes.	
inch	Use this unit for direct operation.	

Electronic Gear Ratio (Unit Conversion Formula)

Use the electronic gear to set the relationship between the display unit and pulse unit in the MC Function Module. Use the Sysmac Studio and set the electronic gear ratio.



Command position value (pulses) = Command position (X units) × Electronic gear ratio

Command Pulse Count Per Motor Rotation*1 (Y Pulses)

Electronic gear ratio = Work Travel Distance Per Motor Rotation*2 (X Units)

*1 For an encoder axis, this is the number of pulses per encoder rotation.


*2 For an encoder axis, this is the travel distance per encoder rotation.

Additional Information

The electronic gear converts units to the values that are used for positioning by the MC Function Module and motion control instructions. Motion control instructions specify the target position as LREAL data. However, an instruction error will occur if the command position after conversion to pulses by the electronic gear exceeds 40 bits.

Setting Example

In this example, an OMRON G5-series Servomotor with a 17-bit absolute encoder is used. The reduction ratio of the reducer is 1/5 and the workpiece moves 10 mm for every rotation of the ball screw.



The Unit of Display parameter is set to millimeters. The Command Pulse Count Per Motor Rotation is set to the resolution of the encoder on the Servomotor.

A reducer with a reduction ratio of 1/5 is used, so the ball screw turns 1/5 of a rotation for every Servomotor rotation. The workpiece moves 2 mm (10 mm \times 1/5), so the Work Travel Distance Per Motor Rotation is set to 2.

Parameter name	Setting
Unit of Display	mm
Command Pulse Count Per Motor Rotation	131072
Work Travel Distance Per Motor Rotation	2

With these settings, the command unit for positions in the user program is 1 mm.

For example, to move to an absolute position of 100.5 mm, the *Position* (Target Position) input variable to the MC_MoveAbsolute (Absolute Positioning) instruction is set to 100.5.

Additional Information

Parameter Settings for a Reduction Ratio of 1/9 for the Setting Example

The travel distance of the workpiece for one rotation of the Servomotor is 10 mm \times 1/9, or 1.1111... mm (a repeating decimal number).

For numbers that do not divide evenly, multiply the command pulse count per motor rotation and the work travel distance per motor rotation by the same coefficient and set the parameters to the results. Here, the reduction ratio is 1/9, so we use 9 as our coefficient.

- Command Pulse Count Per Motor Rotation: 1,179,648 (131072 × 9)
- Work Travel Distance Per Motor Rotation: 10 $(10 \times 1/9 \times 9)$

5-2-4 Operation Settings

These parameters set items for axis operation, such as the maximum velocity and maximum acceleration/deceleration rate. Set them according to the specifications of the device you are controlling.

Parameter name	Function	Setting range	Default
Maximum Velocity	Set the maximum velocity for each axis. *1 Do not set a value that exceeds the maximum speed of the motor that you are using. (Unit: command units/s)	Positive long reals *2	400,000,000
Start Velocity ^{*3}	Set the start velocity for each axis. Set a value that does not exceed the maxi- mum velocity. (Unit: command units/s)	Positive long reals	0
Maximum Jog Velocity	Set the maximum jog velocity for each axis. *4 Set a value that does not exceed the maxi- mum velocity. (Unit: command units/s)	Positive long reals	1,000,000
Maximum Accelera- tion	Set the maximum acceleration rate for an axis operation command. There will be no limit to the acceleration rate if 0 is set. (Unit: command units/s ²)	Non-negative long reals	0
Maximum Decelera- tion	Set the maximum deceleration rate for an axis operation command. There will be no limit to the deceleration rate if 0 is set. (Unit: command units/s ²)	Non-negative long reals	0
Acceleration/Decel- eration Over	 Set the operation for when the maximum acceleration/deceleration rate would be exceeded after excessive acceleration/deceleration during acceleration/deceleration control of the axis because stopping at the target position is given priority. 0: Use rapid acceleration/deceleration. (Blending is changed to Buffered.) *5 	0 to 2	0
	 Use rapid acceleration/deceleration. 2: Minor fault stop *6 		
Operation Selection at Reversing	Specify the operation for reversing rotation for multi-execution of instructions, re-execution of instructions, and interrupt feeding. ^{*7} 0: Deceleration stop 1: Immediate stop	0 to 1	0
Velocity Warning Value	Set the percentage of the maximum velocity at which to output a velocity warning for the axis. No velocity warning is output if 0 is set. (Unit: %)	0 to 100	0
Acceleration Warn- ing Value	Set the percentage of the maximum accelera- tion rate at which to output an acceleration warning for the axis. No acceleration warning is output if 0 is set. (Unit: %)	0 to 100	0
Deceleration Warn- ing Value	Set the percentage of the maximum decelera- tion rate at which to output a deceleration warning for the axis. No deceleration warning is output if 0 is set. (Unit: %)	0 to 100	0
Positive Torque Warning Value	Set the torque command value at which to out- put a positive torque warning. No positive torque warning is output if 0 is set. (Unit: %)	0 to 1,000	0

Parameter name	Function	Setting range	Default
Negative Torque Warning Value	Set the torque command value at which to out- put a negative torque warning. No negative torque warning is output if 0 is set. (Unit: %)	0 to 1,000	0
Actual Velocity Fil- ter Time Constant	Set the time period to calculate the average travel of the actual velocity in milliseconds. The average travel is not calculated if 0 is set. (Unit: ms)	0 to 100	0
	Use this to reduce variations in the actual current velocity when axis velocity is slow.		
In-position Range ^{*8}	Set the in-position width. (Unit: command units)	Non-negative long reals	10
In-position Check Time ^{*4}	Set the in-position check time in milliseconds. Set 0 to check for the end of positioning only when you define the home position during homing and not check positioning at other times. (Unit: ms)	0 to 10,000	0
Zero Position Range	Set the home position detection width. (Unit: command units)	Non-negative long reals	10

*1 The maximum velocity is used as the command velocity if you specify a velocity command value that is greater than the maximum velocity. This parameter also applies to interpolation control operation.

*2 The maximum value that you can set is as follows when the value is converted to pulses: CPU Unit with unit version 1.02 or earlier: 400,000,000 [pulses/s] CPU Unit with unit version 1.03 or later: 500,000,000 [pulses/s]


- *3 A CPU Unit with unit version 1.05 or later and Sysmac Studio version 1.06 or higher are required to use this parameter.
- *4 The maximum jog velocity is used as the command velocity if you specify a velocity command value that is greater than the maximum jog velocity.
- *5 For a CPU Unit with version 1.10 or later, Blending is not changed to Buffered. Refer to 9-5-7 Multi-execution of Motion Control Instructions (Buffer Mode) for details.
- *6 For a CPU Unit with version 1.10 or later, the axis does not stop with an error when Blending is used for operation. Refer to *9-5-7 Multi-execution of Motion Control Instructions (Buffer Mode)* for details.
- *7 Refer to 9-5-6 Re-executing Motion Control Instructions and 9-5-7 Multi-execution of Motion Control Instructions (Buffer Mode) for details on the Operation Selection at Reversing parameter.
- *8 The in-position check is processed by the MC Function Module. The function in the Servo Drive is not used.

Maximum Velocity

This section provides a setting example for the maximum velocity.

Setting Example for the Maximum Velocity

The same machine as in *Setting Example* on page 5-12 is described here for a Servomotor with a maximum speed of 6,000 r/min.




The Maximum Velocity is set to 200 based on a calculation for the conditions (maximum speed: 6,000 r/min, reduction ratio: 1/5, ball screw pitch: 10 mm; 6,000 r/min \times 1/5 \times 10 mm = 12,000 mm/min = 200 mm/s). The default setting of 400,000,000 would exceed the maximum speed of the motor, so you must change the setting.

Parameter name	Setting
Unit of Display	mm
Command Pulse Count Per Motor Rotation	131072
Work Travel Distance Per Motor Rotation	2
Maximum Velocity	200


Start Velocity

Set the start velocity to 0 when you use a servomotor.


If you use a stepper motor, use 10% to 50% of the maximum self-start frequency to prevent loosing the sync at startup. However, this depends on the load, so refer to the manual for the stepper motor.




If the target velocity is less than or equal to the start velocity, acceleration/deceleration are not performed and the axis moves at the target velocity.



If the target velocity changes as the result of re-executing the motion control command or as the result of performing multi-execution of instructions for it during motion, the initial velocity is used. If the target velocity is greater than the start velocity, acceleration/deceleration are performed at the specified acceleration/deceleration rates. If the target velocity is less than or equal to the start velocity, acceleration/deceleration are not performed and the axis moves.



The start velocity is also used if the velocity is changed by the MC_SetOverride instruction. If the target velocity is greater than the start velocity, acceleration/deceleration are performed at the specified acceleration/deceleration rates. If the target velocity is less than the start velocity, acceleration/deceleration are not performed and the axis moves.



The start velocity is not used in the following cases.

- Torque Control Mode
- Cyclic synchronous velocity control
- · Cyclic synchronous positioning
- Synchronized control

Note However, the start velocity is used for the MC_GearOut and MC_CamOut instructions.

• Multi-axes coordinated control

Note However, the start velocity for each axis is used to decelerate the axes to a stop.

5-2-5 Other Operation Settings

These parameters are used to set the stopping methods and torque limits to use when the input signals are enabled.

Parameter name	Function	Setting range	Default
Immediate Stop Input Stop Method	Set the stopping method in the MC Function Module when the immediate stop input is enabled.	0, 2, or 3	0
	0: Immediate stop		
	2: Immediate stop and error reset		
	3: Immediate stop and Servo OFF		
Limit Input Stop Method	Set the stopping method in the MC Function Module when the positive limit input or negative limit input is enabled.	0 to 3	0
	0: Immediate stop		
	1: Deceleration stop		
	2: Immediate stop and error reset		
	3: Immediate stop and Servo OFF		
Drive Error Reset Monitoring Time	Set the monitor time for a drive error reset. (Unit: ms) After the monitor time has elapsed, reset processing will end even if the drive error is not yet reset.	1 to 1,000	200
Maximum Positive Torque Limit	Set the maximum value of the positive torque limit.*1 (Unit: %)	0.0 to 1000.0	300.0
Maximum Negative Torque Limit	Set the maximum value of the negative torque limit.*1 (Unit: %)	0.0 to 1000.0	300.0
Immediate Stop Input Logic Inver-	Set whether to reverse the logic of the immediate stop input signal.	FALSE or TRUE	FALSE ^{*3}
sion ^{*2}	FALSE: Do not reverse.		
	TRUE: Reverse.		
Positive Limit Input Logic Inversion ^{*2}	Set whether to reverse the logic of the positive limit input signal.	FALSE or TRUE	FALSE ^{*3}
	FALSE: Do not reverse.		
	TRUE: Reverse.		
Negative Limit Input Logic Inversion ^{*2}	Set whether to reverse the logic of the negative limit input signal.	FALSE or TRUE	FALSE ^{*3}
	FALSE: Do not reverse.		
	TRUE: Reverse.		
Home Proximity Input Logic Inver-	Set whether to reverse the logic of the home proximity input signal.	FALSE or TRUE	FALSE
sion ^{*2}	FALSE: Do not reverse.		
	TRUE: Reverse.		

*1 If Positive Torque Limit (60E0 hex) and Negative Torque Limit (60E1 hex) are mapped as PDOs, the set values of these parameters are sent with EtherCAT process data communications. If a torque limit is enabled with the MC_SetTorqueLimit instruction, the value that is specified with the input variable to the instruction is sent.

*2 A CPU Unit with unit version 1.05 or later and Sysmac Studio version 1.06 or higher are required to use this parameter. You cannot reverse the logic for a CPU Unit with a unit version of 1.04 or earlier. This parameter is set for devices, such as NX-series Digital Input Units, for which the logic of the input signals cannot be set. For devices, such as OMRON G5-series Servo Drives, for which you can set the input signal logic, set this parameter to not reverse the signal.

*3 If you assign an NX-series Pulse Output Unit to an axis, the default is TRUE.

5-2-6 Limit Settings

Parameter name	Function	Setting range	Default
Software Limits*	Select the software limit function.	0 to 4	0
	0: Disabled.		
	1: Deceleration stop for command position		
	2: Immediate stop for command position		
	3: Deceleration stop for actual position		
	4: Immediate stop for actual position		
Positive Software Limit	Set the software limit in the positive direc- tion. (Unit: command units)	Long reals	2,147,483,647
Negative Software Limit	Set the software limit in the negative direc- tion. (Unit: command units)	Long reals	-2,147,483,648
Following Error Over Value	Set the excessive following error check value. Set 0 to disable the excessive follow- ing error check. (Unit: command units)	Non-negative long reals	0
Following Error Warning Value	Set the following error warning check value. Set 0 to disable the following error warning check. (Unit: command units)	Non-negative long reals that are less than or equal to the Following Error Over Value	0

Use the following parameters to select functions for limiting the following error and for software limits.

* This function is enabled only when the Count Mode is Linear Mode and the home is defined. Refer to *9-8-5 Software Limits* for details on software limits.

5-2-7 Position Count Settings

Set the count mode for the position.

Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for information on using the NX-series Position Interface Units.

Parameter name	Function	Setting range	Default
Count Mode	Set the count mode for the position.	0 to 1	0
	0: Linear Mode (finite length)		
	1: Rotary Mode (infinite length)		
Modulo Maximum Position Setting Value	Set the modulo maximum position when the Count Mode is set to Rotary Mode. (Unit: command units)	Long reals	2,147,483,647
Modulo Minimum Position Setting Value	Set the modulo minimum position when the Count Mode is set to Rotary Mode. (Unit: command units)	Long reals	-2,147,483,648
Encoder Type	Set the encoder type.*1*2	0 to 1	0
	0: Incremental encoder (INC)		
	1: Absolute encoder (ABS)		

*1 Set the encoder type to 1 (absolute encoder (ABS)) when you use any of the following: an OMRON G5-series Servomotor with an absolute encoder or an absolute external scale for fully-closed control, or an OMRON G5-series Linear Motor Type with an absolute external scale.

*2 The settings are as follows when you use an OMRON G5-series Servomotor with an absolute external scale or an OMRON G5-series Linear Motor Type.

0: Incremental external scale

1: Absolute external scale

Count Modes

The Count Mode is the feed mode for the axis. Select the count mode for the command positions for each axis. There are two Count Modes: Linear Mode, which has a finite axis feed range and Rotary Mode, which has an infinite axis feed range.


• Linear Mode (Finite-length Axis)

- The linear mode is centered around 0. This mode is used for devices with a mechanically limited range of motion, such as an XY stage.
- The setting range when the value is converted to pulses is 40 bits (signed integer: 0x800000000 to 0x7FFFFFFFF).
- You cannot specify a target position for relative or absolute positioning that exceeds this range.
- A command position overflow or underflow observation will occur if this range is exceeded for operations that do not have a target position, such as velocity control, homing, or torque control. Command position output will continue, but the actual position is not updated and will be fixed to either the upper limit or the lower limit.
- While the value of the actual position is fixed, you can execute commands and stop the axis with any operation that does not have a target position in the direction toward the linear range. Any command that specifies a direction away from the range will cause an error on execution of the instruction.
- The actual position does not update until the overflow or underflow status is cleared.

0x800000000	0	0x7FFFFFFFFF

• Rotary Mode (Infinite Length Axis)

- This mode repeatedly counts with a ring counter for an infinite amount within the set range. Use this mode for rotary tables or winding shafts.
- Use the Sysmac Studio to set the modulo maximum position and the modulo minimum position to define the range of the ring counter.
- The setting range when the value is converted to pulses is 40 bits (signed integer: 0x800000000 to 0x7FFFFFFFF).



Modulo Maximum Position and Modulo Minimum Position Setting Values

The settings of these parameters are enabled when the Count Mode is set to Rotary Mode. Set the upper and lower limits of the ring counter.

Precautions for Correct Use

- If you set the Count Mode to Rotary Mode, make sure that the value for only cycle of the ring counter converts to an integer in pulses. If the number of pulses for one cycle of the ring counter is not an integer, position offset occurs because the decimal portion is truncated. The command current position will also not be displayed correctly.
- If 0 is not included between the upper and lower limits of the ring counter, an error occurs when the MC_MoveZeroPosition (High-speed Home) instruction is executed.
- When you perform absolute positioning with a MC_MoveAbsolute or MC_Move instruction, make sure that the target position is within the range of the ring counter. An error occurs if the target position is not within the range of the ring counter. If the *Direction* input variable to the instruction is set to *No direction specified*, you can set a target position that is not within the range of the ring counter. If that occurs, relative positioning is performed using the difference between the target position and the command current position as the target distance.

Encoder Type

Set the type of encoder to use for feedback input.

Set the encoder type to 1 (absolute encoder (ABS)) when you use any of the following: an OMRON G5series Servomotor with an absolute encoder or an absolute external scale for fully-closed control, or an OMRON G5-series Linear Motor Type with an absolute external scale.

The setting of this parameter is disabled for a virtual axis.

5-2-8 Servo Drive Settings

Parameter name	Function	Setting range	Default ^{*1}
Modulo Maximum Position Setting Value	Set the modulo maximum position that is set on the Servo Drive or the Encoder Input Terminal. *2	-2 ⁶³ to 2 ⁶³ -1	2,147,483,647
Modulo Minimum Posi- tion Setting Value	Set the modulo minimum position that is set on the Servo Drive or the Encoder Input Terminal. ^{*2}	-2 ⁶³ to 2 ⁶³ -1	-2,147,483,648
PDS State Control Method ^{*3}	Set the state to which PDS state changes when Servo is turned OFF by the MC_Power instruction. ^{*4}	0 to 1	0
	0: Switched on by Servo OFF		
	1: Ready to switched on by Servo OFF		

Set the value that is set on the Servo Drive or the Encoder Input Terminal that is connected.

*1 The default range is all DINT integers. You can use the default range with OMRON G5-series Servo Drives. Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for information on using the NX-series Position Interface Units.

*2 If you use an OMRON GX-series EtherCAT Slave Encoder Input Terminal, the maximum value of the ring counter (index 0x4003) of the Encoder Input Terminal must agree with the Modulo Maximum Position Setting Value. The modulo minimum position setting value must be set to 0.

- *3 A CPU Unit with unit version 1.10 or later and Sysmac Studio version 1.12 or higher are required to use this parameter.
- *4 If you set this parameter to 1, the Servo Ready (Switched on) status of OMRON G5-series Servo Drives cannot be used. To use the Servo Ready (Switched on) status, set this parameter to 0. Refer to A-4 PDS State Transition for details on the PDS state transition.

5-2-9 **Homing Settings**

Set the motor operation to use to determine home.

Parameter name	Function	Setting range	Default
Homing Method*1*2	Set the homing operation. 0: Proximity reverse turn/home proximity input OFF	0, 1, 4, 5, 8, 9, or 11 to 14	14
	1: Proximity reverse turn/home proximity input ON		
	4: Home proximity input OFF		
	5: Home proximity input ON		
	8: Limit input OFF		
	9: Proximity reverse turn/home input mask distance		
	11: Limit inputs only		
	12: Proximity reverse turn/holding time		
	13: No home proximity input/holding home input		
	14: Zero position preset		
Home Input Signal	Select the input to use for the home input signal.	0 or 1	0
	0: Use Z-phase input as home		
	1: Use external home input ^{*3}		
Homing Start Direc-	Set the start direction for when homing is started.	0 or 2	0
tion	0: Positive direction		
	2: Negative direction		
Home Input Detec-	Set the home input detection direction for homing.	0 or 2	0
tion Direction	0: Positive direction		
	2: Negative direction		
Operation Selection at Positive Limit	Set the stopping method when the positive limit input turns ON during homing.	0 to 2	1
Input	0: No reverse turn/minor fault stop (Stop according to Limit Input Stop Method parameter.)		
	1: Reverse turn/immediate stop		
	2: Reverse turn/deceleration stop		
Operation Selection at Negative Limit	Set the stopping method when the negative limit input turns ON during homing.	0 to 2	1
Input	0: No reverse turn/minor fault stop (Stop according to Limit Input Stop Method parameter.)		
	1: Reverse turn/immediate stop		
	2: Reverse turn/deceleration stop		
Homing Velocity	Set the homing velocity. (Unit: command units/s)	Positive long reals	10,000
Homing Approach Velocity	Set the velocity to use after the home proximity input turns ON. (Unit: command units/s)	Positive long reals	1,000
Homing Accelera- tion	Set the acceleration rate for homing. If the homing acceleration is set to 0, the homing velocity or other target velocity is used without any acceleration. (Unit: command units/s ²)	Non-negative long reals	0

5-2-9 Homing Settings

Parameter name	Function	Setting range	Default
Homing Decelera- tion	ra-Set the deceleration rate for homing. If the homing deceleration is set to 0, the homing approach velocity or other target velocity is used without any decelera- tion. (Unit: command units/s2)Non-negative 		0
Homing Jerk	Set the jerk for homing. Set 0 for no jerk. (Unit: com- mand units/s ³)	Non-negative long reals	0
Home Input Mask Distance	Set the home input mask distance when you set the Homing Operation Mode to a proximity reverse turn/home input mask distance. (Unit: command units)	Non-negative long reals	10,000
Home Offset	Preset the actual position for the value that is set after homing. (Unit: command units)	Long reals	0
Homing Holding Time	Set the holding time when you set the Homing Opera- tion Mode to a proximity reverse turn/holding time. (Unit: ms)	0 to 10,000	100
Homing Compensa- tion Value	Set the homing compensation value that is applied after the home is defined. (Unit: command units)	Long reals	0
Homing Compensa- tion Velocity	Set the velocity to use for homing compensation. (Unit: command units/s).	Positive long reals	1,000

*1 These parameters are for homing operation. Refer to Section 8 Homing for details.

- *2 You cannot map the Z-phase input to a PDO for an OMRON G5-series Linear Motor Type. Therefore, if you set the Homing Method to the No home proximity input/holding home input, which can use a Z-phase input mapped to a PDO, do not select the Z-phase input for the home input signal.
- *3 This setting can be used for an OMRON G5-series Servo Drive with built-in EtherCAT communications. In the default setting of the OMRON G5-series Servo Drives, the external home input is allocated to latch 1. The allocation of latch 1 can be changed using a servo parameter object in the Servo Drive. For details, refer to the *G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications User's Manual* (Cat. No. 1576) or the *G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications Linear Motor Type User's Manual* (Cat. No. 1577)


Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for information on using the NX-series Position Interface Units.

5-2-10 Axis Parameter Setting Example

This section provides examples of axis parameter settings related to positioning.

Single-axis Positioning

The following example is for a device that performs single-axis positioning separately for each of two axes.



Devementer nome	Settings		
Parameter name	Axis 1	Axis 2	
Axis Variable Names	Axis1	Axis2	
Axis Number	1	2	
Enabled Axes	Used axis	Used axis	
Axis Type	Servo axis	Servo axis	
Input Device/Output Device	1	2	
Unit of Display	μm ^{*1}	μm	
Command Pulse Count Per Motor Rotation	1,048,576	1,048,576	
Work Travel Distance Per Motor Rota- tion	10,000	10,000	
Maximum Velocity	500,000 ^{*2}	500,000 ^{*2}	
Maximum Jog Velocity	50,000 ^{*3}	50,000 ^{*3}	
Maximum Acceleration	5,000,000 ^{*4}	5,000,000 ^{*4}	
Maximum Deceleration	5,000,000*4	5,000,000 ^{*4}	
Software Limits	Immediate stop for command posi- tion	Immediate stop for command posi- tion	
Positive Software Limit	500,000 ^{*5}	500,000	
Negative Software Limit	0*5	0	
Count Mode	Linear Mode	Linear Mode	

*1 The position command unit will be 1 μ m.


*2 The maximum velocity will be 3,000 r/min = 30 m/min = 0.5 m/s = 500,000 μ m/s.

*3 The maximum jog velocity will be 10% of the maximum velocity, i.e., 0.05 m/s = 50,000 μ m/s.

- *4 The maximum acceleration and the maximum deceleration are 5 m/s². The acceleration time to the maximum velocity (3,000 r/min) is 0.1 s.
- *5 Set a positioning that is within the movable range of the device. The positive software limit is set to 50 cm = $500,000 \ \mu$ m.

Synchronized Control with Encoder as Master Axis

The following example is for a device that uses the actual position of axis 2 (an encoder), which is attached to a conveyor, as the master axis. The Servo Drive on axis 1 is synchronized within a finite range.



Dawamatan nama	Settings		
Parameter name	Axis 1	Axis 2	
Axis Variable Name	Axis1	Axis2	
Axis Number	1	2	
Enabled Axes	Used axis	Used axis	
Axis Type	Servo axis	Encoder axis	
Input Device/Output Device	1	2	
Unit of Display	μm*1	μm ^{*1}	
Command Pulse Count Per Motor Rota- tion	1,048,576	1,048,576	
Work Travel Distance Per Motor Rotation	10,000	10,000	
Maximum Velocity	500,000 ^{*2}		
Maximum Jog Velocity	50,000 ^{*3}		
Maximum Acceleration	5,000,000*4		
Maximum Deceleration	5,000,000*4		
Software Limits	Immediate stop for command position	Disabled.	
Positive Software Limit	500,000 ^{*5}		
Negative Software Limit	0*5		
Count Mode	Linear Mode	Rotary Mode	
Modulo Maximum Position		1,000,000 ^{*6}	
Modulo Minimum Position		0*6	

*1 The position command unit will be 1 μ m.

*2 The maximum velocity will be 3,000 r/min = 30 m/min = 0.5 m/s = 500,000 μ m/s.

- *3 The maximum jog velocity will be 10% of the maximum velocity, i.e., 0.05 m/s = 50,000 μ m/s.
- *4 The maximum acceleration and the maximum deceleration are 5 m/s². The acceleration time to the maximum velocity (3,000 r/min) is 0.1 s.
- *5 Set a positioning that is within the movable range of the device. The positive software limit is set to 50 cm = $500,000 \ \mu$ m.
- *6 The periodic range of the position is 0 to 1 m (1,000,000 $\mu m).$

Additional Information

You can select the axis type for the master axis according to the configuration of the device. There are four axis types: servo axes, virtual servo axes, encoder axes, and virtual encoder axes. In this example, the axis type of the master axis is an encoder axis. Specify the actual position for the motion control instruction input variable *ReferenceType* (Position Type Selection).

5-3 Axes Group Parameters

Use the axes group parameters to set axes group operations related to axes groups that the MC Function Module controls, such as the axis configuration, maximum interpolation velocity, and axes group stopping method. There are axes group parameters for each of 32 groups for the NJ301-11 \square , NJ301-12 \square , NJ501-13 \square , NJ501-14 \square , or NJ501-15 \square , 64 groups for the NX701-16 \square or NX701-17 \square . The same parameter settings are provided for each axes group. This section describes only the parameters for axes group 1.

5-3-1 Axes Group Parameters

			Temporary changes ^{*1}		Page
Classification	Parameter name	Support	Applicable instruction	Reading variables ^{*2}	
Axes Group	Axes Group Number			OK	P. 5-26
Basic Settings	Motion Control ^{*3}			OK*4	
	Axes Group Use			OK	
	Composition			OK	
	Composition Axes	OK ^{*5}	MC_Change AxesInGroup	OK	
Axes Group	Maximum Interpolation Velocity				P. 5-28
Operation Set-	Maximum Interpolation Acceleration				
tings	Maximum Interpolation Deceleration				
	Interpolation Acceleration/Decelera- tion Over				
	Interpolation Velocity Warning Value	OK	MC_Write		
	Interpolation Acceleration Warning Value	OK	MC_Write		
	Interpolation Deceleration Warning Value	ОК	MC_Write		
	Axes Group Stop Method				
	Correction Allowance Ratio				

Use the Sysmac Studio to set the axes group parameters for each axes group.

*1 This column indicates if you can use instructions to temporarily change the settings.

- *2 This column indicates whether you can access the parameter with a variable in the user program.
- *3 Set this parameter when using the NX-series CPU Unit.
- *4 A CPU Unit with unit version 1.10 or later and Sysmac Studio version 1.12 or higher are required to use this parameter.
- *5 A CPU Unit with unit version 1.01 or later and Sysmac Studio version 1.02 or higher are required to use this instruction.

Refer to *3-4 Setting Procedures for Axes Groups* for details on how to set axes group parameters. For details on the MC_Write (Write MC Setting) and MC_ChangeAxesInGroup instructions, refer to the *NJ/NX-series Motion Instructions Reference Manual* (Cat. No. W508).

Refer to 6-6 System-defined Variables for Motion Control for information on system-defined variables for motion control.

5

5-3-2 Axes Group Basic Settings

Set whether to use the axes group. If you are going to use the axes group, set the axis configuration and the axes to use.

Parameter name	Function	Setting range	Default
Axes Group Number	Set the logical number of the axes group. This number specifies which of the following system-defined variables to use: _ <i>MC_GRP[0-63]</i> , _ <i>MC1_GRP[0-63]</i> , _ <i>MC2_GRP[0-63]</i> .		
Motion Control ^{*1}	Assign to either of the primary periodic task or priority-5 periodic task.	1 or 2	1
	1: Primary periodic task		
	2: Priority-5 periodic task		
Axes Group Use	Set whether to enable or disable the axes group. An error occurs if you execute a motion control instruction for an undefined or unused axes group. ^{*2}	0 to 2	0
	0: Undefined axes group		
	1: Unused axes group		
	2: Used axes group		
Composition	Set the axis composition of the axes group.	0 to 2	0
	0: 2 axes		
	1:3 axes		
	2: 4 axes		
Composition Axes	Sets the axis number to assign to the axes group. Set Axis Variable names from the Sysmac Studio to use for the A0 to A3 axes.	2 to 4 axes	0

*1 Set this parameter when using the NX-series CPU Unit. The setting is not available for the NJ-series CPU Unit, which supports only the primary periodic task.

*2 An error occurs if you execute the MC_GroupEnable (Enable Axes Group) instruction for an axes group that contains an unused axis.

Composition

The following table lists the axis compositions you can use with the MC Function Module. Use the Sysmac Studio to set the axis composition according to the actual devices.

Composition	Description
2 axes	A two-axis configuration is used. For example, a machine with a two-axis Cartesian coordinate system is used.
3 axes	A three-axis configuration is used. For example, a machine with a three-axis Cartesian coordinate system is used.
4 axes	A four-axis configuration is used. For example, a machine with a three-axis Car- tesian coordinate system is used with a rotary axis at the end tool.

Composition Axes

The axes that are in an axes group are called composition axes. To make it easier to reuse programming with interpolation instructions for axes groups commands, logical axes (axis A0 to axis A3) are used instead of axis numbers (axis 0 to axis 255). For the Composition Axes parameter, set the axis numbers and logical axis numbers for the axes in the axes group. Servo axes or virtual servo axes can be selected for logical axes.

Use the Sysmac Studio to assign axes from axis A0 for the number of axes you selected in the axis composition.

Set axis numbers from axis A0 for each axes group if you create more than one axes group. You can also set the same axis number in more than one axes group.

Axis composition setting	Settings in Composition Axes parameter	
2 axes	Set Axis Variable names (axis numbers) for axis A0 and axis A1.	
3 axes	Set Axis Variable names (axis numbers) for axis A0, axis A1, and axis A2.	
4 axes	Set Axis Variable names (axis numbers) for axis A0, axis A1, axis A2, and axis A3.	

Precautions for Correct Use

Assign all of the composition axes to the same task.

Version Information

With a CPU Unit with unit version 1.04 or later and Sysmac Studio version 1.05 or higher, you can set any servo axis or virtual servo axis that is set to *a Used axis or an Unused axis (changeable to used axis)* in an axes group.

• Composition Axes Setting Examples

• Example 1: Assigning Four Axes with Axis Numbers 1, 2, 5, and 8 to an Axes Group

Logical axis	Axis number
Axis A0	Axis 1
Axis A1	Axis 2
Axis A2	Axis 5
Axis A3	Axis 8

• Example 2: Assigning Three Axes with Axis Numbers 1, 8, and 2 to an Axes Group

Logical axis	Axis number
Axis A0	Axis 1
Axis A1	Axis 8
Axis A2	Axis 2
Axis A3	None

5-3-3 Axes Group Operation Settings

These parameters set items for axes group operation, such as the maximum interpolation velocity and axes group stopping method. Set them according to the specifications of the device you are controlling.

Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for information on using the NX-series Position Interface Units.

Parameter name	Function	Setting range	Default
Maximum Interpola- tion Velocity	Set the maximum interpolation velocity for the path. Set 0 for no interpolation velocity limit. If a target velocity that exceeds the maxi- mum interpolation velocity is specified for an axes group operation instruction, the axis will move at the maximum interpolation velocity. (Unit: command units/s)	Non-negative long reals	800,000,000
Maximum Interpola- tion Acceleration	Set the maximum interpolation acceleration for the path. Set 0 for no interpolation accel- eration limit. (Unit: command units/s ²)	Non-negative long reals	0
Maximum Interpola- tion Deceleration	Set the maximum interpolation deceleration for the path. Set 0 for no interpolation decel- eration limit. (Unit: command units/s ²)	Non-negative long reals	0
Interpolation Accel- eration/Decelera- tion Over	Set the operation for when the maximum interpolation acceleration/deceleration rate would be exceeded after excessive acceler- ation/deceleration during acceleration/decel- eration control of the axes group because stopping at the target position is given prior- ity.	0 to 2	0
	 0: Use rapid acceleration/deceleration. (Blending is changed to Buffered.) *1 1: Use rapid acceleration/deceleration. 		
	2: Minor fault stop $*^2$		
Interpolation Veloc- ity Warning Value	Set the percentage of the maximum interpo- lation velocity at which to output an interpo- lation velocity warning. No interpolation velocity warning is output if 0 is set. (Unit: %)	0 to 100	0
Interpolation Accel- eration Warning Value	Set the percentage of the maximum interpo- lation acceleration at which to output an interpolation acceleration warning. No inter- polation acceleration warning is output if 0 is set. (Unit: %)	0 to 100	0

Parameter name	Function	Setting range	Default
Interpolation Decel- eration Warning Value	Set the percentage of the maximum interpo- lation deceleration rate at which to output an interpolation deceleration warning. No inter- polation deceleration warning is output if 0 is set. (Unit: %)	0 to 100	0
Axes Group Stop Method	Set the stop method of the composition axes for which an error did not occur when an error occurs that forces an immediate stop of an axis that is in a multi-axes coordinated control motion.	0, 1, or 3	0
	0: Immediate stop		
	1: Decelerate axes to a stop at maximum deceleration rate of the axes		
	3: Immediate stop and Servo OFF		
Correction Allow- ance Ratio	This parameter applies when the center des- ignation method is used for a circular inter- polation instruction. It compensates the distance when the distance between the start point and the center point does not equal the distance between the end point and the center point. Set the allowable range for that correction as a percentage of the radius. Set the percentage to 0.1% or greater. Error checking is not performed if 0 is set.	Single-precision floating-point num- ber between 0 and 100	0

*1 For a CPU Unit with version 1.10 or later, Blending is not changed to Buffered. Refer to 9-5-7 Multi-execution of Motion Control Instructions (Buffer Mode) for details.

*2 For a CPU Unit with version 1.10 or later, the axis does not stop with an error when Blending is used for operation. Refer to *9-5-7 Multi-execution of Motion Control Instructions (Buffer Mode)* for details . 5

5-3-4 Enabling an Axes Group

Specify the number of the axes group to enable in the MC_GroupEnable (Enable Axes Group) instruction to enable operation instructions for an axes group in the user program. An instruction error occurs if you execute a motion control instruction for an axes group that is not enabled. You can enable more than one axes group at the same time, but if you enable more than one axes group that include the same axis, an instruction error occurs.

If you want to operate the same axis in different axes groups for each work process, create multiple axes groups that include that axis. You can then use the MC_GroupEnable (Enable Axes Group) and MC_GroupDisable (Disable Axes Group) instructions to enable and disable these axes groups as you need to use them.

If you execute the MC_GroupDisable (Disable Axes Group) instruction during multi-axes operation, the axes in the group will decelerate to a stop.

6

Motion Control Programming

This section provides the specifications of a motion control program and the operation procedures that are required up through actual program development.

6-1	Introdu	uction	6-2
6-2	Motion	Control Instructions	6-4
	6-2-1	Function Blocks for PLCopen® Motion Control	6-4
	6-2-2	Motion Control Instructions of the MC Function Module	6-4
6-3	State 1	Fransitions	6-5
	6-3-1	Status of the Motion Control Function Module	6-5
	6-3-2	Axis States	6-6
	6-3-3	Axes Group States	6-8
6-4	Execut	tion and Status of Motion Control Instructions	6-10
	6-4-1	Basic Rules for Execution of Instructions	
	6-4-2	Execution Timing Charts	
	6-4-3	Timing Chart for Re-execution of Motion Control Instructions	
	6-4-4	Timing Chart for Multi-execution of Motion Control Instructions	
6-5	6-5 Positions		6-17
	6-5-1	Types of Positions	
	6-5-2	Valid Positions for Each Axis Type	
6-6	System	n-defined Variables for Motion Control	6-19
	6-6-1	Overview of System-defined Variables for Motion Control	
	6-6-2	System for System-defined Variables for Motion Control	6-22
	6-6-3	Tables of System-defined Variables for Motion Control	6-24
6-7	Cam Ta	ables and Cam Data Variables	6-35
6-8	Programming Motion Controls		6-38
6-9	Creating Cam Tables		

6-1 Introduction

The NJ/NX-series CPU Unit can perform both sequence control and motion control.

Write motion control instructions into the user program to perform motion control with EtherCAT slave Servo Drives, NX-series Position Interface Units, and other devices.

Programs that contain motion control instructions are called motion control programs.


You must assign Axis Variables to EtherCAT slave Servo Drives and NX-series Position Interface Units. If you do not assign Axis Variables, assign device variables in the same way as for a general-purpose slave. Motion control instructions can be used in the primary periodic task, in a priority-5 periodic task, and in a priority-16 periodic task.


Version Information

With the Sysmac Studio version 1.09 or higher, you can assign device variables to the I/O ports of slaves and Units that are assigned to the Axis Variables.

Refer to 2-4-2 Relationship between EtherCAT Master Function Module and MC Function Module for details.

NX-series CPU Unit





NJ-series CPU Unit

6-2 Motion Control Instructions

Motion control instructions are used in the user program to execute motion controls for an NJ/NX-series Controller. These instructions are defined as function blocks (FBs). The motion control instructions of the MC Function Module are based on the technical specifications of function blocks for PLCopen[®] motion control. There are two types of motion control instructions: PLCopen[®]-defined instructions and instructions that are unique to the MC Function Module. This section provides an overview of the PLCopen[®] motion control function blocks and gives the specifications of the MC Function Module.

Refer to the *NJ/NX-series CPU Unit Software User's Manual* (Cat. No. W501) for basic information on the NJ/NX-series function blocks (FBs).

A CPU Unit with unit version 1.05 or later and Sysmac Studio version 1.06 or higher are required to use NX-series Position Interface Units. Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for information on using the NX-series Position Interface Units.

6-2-1 Function Blocks for PLCopen[®] Motion Control

PLCopen[®] standardizes motion control function blocks to define a program interface for the languages specified in IEC 61131-3 (JIS B 3503). Single-axis positioning, electronic cams, and multi-axes coordinated control are defined along with basic procedures for executing instructions.

By using PLCopen[®] motion control function blocks, the user program can be more easily reused without hardware dependence. Costs for training and support are also reduced.

Additional Information

PLCopen[®]

PLCopen[®] is an association that promotes IEC 61131-3. It has its headquarters in Europe and a world-wide membership. IEC 61131-3 is an international standard for PLC programming.

• The website of headquarters of PLCopen[®] in Europe is http://www.plcopen.org/.

6-2-2 Motion Control Instructions of the MC Function Module

There are three types of motion control instructions. They are given in the following table.

Туре	Outline
Common commands	Common instructions for the MC Function Module
Axis commands	Instructions for MC Function Module to perform single-axis control
Axes group commands	Instructions for MC Function Module to perform multi-axes coordinated control

For a list of the instructions that you can use with the MC Function Module, refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

6-3 State Transitions

The states of axes and axes groups and state transitions caused by the execution of instructions are based on the technical specifications of function blocks for PLCopen[®] motion control. This section provides an overall description of the MC Function Module, states, and state transitions.

6-3-1 Status of the Motion Control Function Module

State name	Definition
MC Run Mode ^{*1}	Motion control instructions are enabled. The motion control instructions in the user program are interpreted and motion control is performed. You can set the MC Run Mode state regardless of the operating mode of the CPU Unit.
MC Test Mode ^{*2}	In this state, you can execute a test run from the Sysmac Studio.
Saving Cam Table File ^{*3}	This state exists while the system performs save or wait pro- cessing for a cam table file.
Generating Cam Table*4	This state exists while the system is generating the came table. ^{*5}

The overall states of the MC Function Module are described in the following table.

*1 This state can be monitored with the MC Common Variable _MC_COM.Status.RunMode.

*2 This state can be monitored with the MC Common Variable _MC_COM.Status.TestMode.


*3 This state can be monitored with the MC Common Variable _MC_COM.Status.CamTableBusy.

*4 This state can be monitored with the MC Common Variable _MC_COM.Status.GenerateCamBusy.

*5 When you turn OFF the power supply for the CPU Unit, make sure that generation of the cam table is not in progress. If you turn OFF the power supply for the CPU Unit while generation of the cam table is in progress, the cam table will not be generated correctly.

6-3-2 Axis States

The operation of an axis when motion control instructions are executed for it is shown in the following figure. Motion control instructions are executed in sequence and axes enter one of the states listed in the following table.



- *1 Transition into this state occurs when there is an axis error in any state except for Coordinated Motion state.
- *2 Transition into this state occurs when there are no axis errors and the Status output to the MC_Power instruction is FALSE. (The Servo is OFF.)
- *3 Transition into this state occurs if an error is reset with the MC_Reset or ResetMCError instruction when the Servo is OFF.
- *4 Transition into this state occurs if an error is reset with the MC_Reset or ResetMCError instruction when the Servo is ON.
- *5 Transition into this state occurs when the *Enable* input to the MC_Power instruction changes to TRUE and the *Status* (Servo ON) output from the MC_Power instruction changes to TRUE. (The Servo is ON.)
- *6 Transition into this state occurs when the *Done* output from the MC_Stop instruction is TRUE and the *Execute* input to the MC_Stop instruction changes to FALSE.
- *7 Transition into the *Deceleration Stopping* state occurs when the MC_ResetFollowingError instruction is executed.
- *8 The Continuous Motion state exists from when velocity control is set for the *MoveMode* input variable of the MC_MoveFeed instruction until a trigger input is detected.

	State name	Definition
Servo	OFF	In this state, the Servo is OFF for the axis. When this state is moved to, the buffered status for multi-execution of instructions is cleared.
	Axis Disabled	In this state, the Servo is OFF for the axis, the axis is stopped, and execution preparations are completed.
	Error Deceleration Stopping ^{*1}	In this state, the Servo is OFF for the axis, the axis is stopped, and an axis error has occurred.
Servo	ON	In this state, the Servo is ON for the axis.

State name	Definition
Stopped	In this state, the Servo is ON for the axis and the axis is stopped.
Discrete Motion	In this state, positioning is performed for the specified target position. This includes when waiting the in-position status and when the velocity is 0 because the override factor was set to 0 during a discrete motion.
Continuous Motion	In this state, continuous motion control is executed with no specified target position. This state exists during velocity control or torque control. This includes when the velocity is 0 because the target velocity is set to 0 and when the velocity is 0 due to an override factor set to 0 during continuous motion.
Synchronized Motion	In this state, the synchronized control is performed for the axis with synchro- nized control commands. This includes waiting for synchronization after chang- ing to synchronized control instructions.
Deceleration Stopping	In this state, the axis is stopping due to a MC_Stop or MC_TouchProbe (Enable External Latch) instruction. This includes when <i>Execute</i> is TRUE after stopping for the MC_Stop instruction. In this state, it is not possible to execute axis operation commands. If an attempt is made to execute one, <i>CommandAborted</i> for the instruction changes to TRUE.
Error Deceleration Stopping ^{*1}	In this state, the Servo is ON for the axis and an axis error has occurred. This includes during execution of the MC_ImmediateStop (Immediate Stop) instruction and during a deceleration stop for an axis error. It is not possible to execute axis operation commands in this state. The instruction will enter the aborted (<i>CommandAborted</i> = TRUE) status if executed.
Homing	In this state, home is being searched for by the MC_Home or MC_HomeWithParameter instruction.
Coordinated Motion	In this state, the axes group was enabled by an instruction for an axes group command. In this state, the axis is in motion for an axes group state of <i>Group-Moving</i> , <i>GroupStopping</i> , or <i>GroupErrorStop</i> .

*1 The Error Deceleration Stopping state occurs both when the Servo is ON and when the Servo is OFF for the axis.

Note You can monitor the axis status in the member variables of the Axis Variables _*MC_AX[0].Status* to _*MC_AX[255].Status.*

Version Information


L

For the NX-series CPU Unit, the variable names that start with $MC_AX[*]$ may apply to those with $MC1_AX[*]$ and $MC2_AX[*]$.

Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for information on using the NX-series Position Interface Units.

6-3-3 Axes Group States

The operation of an axes group when motion control instructions are executed for it is shown in the following figure.



- *1 The Moving state is entered for any axes group motion control instruction.
- *2 The *ErrorStop* state is entered from any other state. It is even entered if an error occurs when the axes group is disabled.
- *3 The *Standby* state is entered when the MC_GroupReset or ResetMCError instruction is executed for an enabled axes group.
- *4 The *Disabled* state is entered when the MC_GroupReset or ResetMCError instruction is executed for a disabled axes group.
- *5 The same state is returned to if the MC_GroupDisable is executed in *ErrorStop* state.
- *6 *Stopping* state is entered when the *Done* output variable from the MC_GroupStop instruction is TRUE and the *Execute* input variable to the same instruction is FALSE.
- *7 Ready state is entered if all of the following conditions are met in Standby state.
 - The Servo is ON for all composition axes.
 - Execution of the MC_Stop instruction is not in progress for any composition axis.
 - Home is defined for all composition axes.

	State name	Definition
Axes	Group Disabled	The axes group is disabled in this state. When this state is entered, the buffered status for multi-execution of instructions is cleared.
	Error Deceleration Stopping ^{*1}	In this state, an error occurred in an axes group that is disabled.
Axes Group Enabled		The axes group is enabled in this state.

State name	Definition
Standby	In this state, no instructions for axes group commands are executing. (This is independent of the Servo ON/OFF status of the composition axes in the axes group)
Moving	In this state, positioning is performed for the specified target position due to a motion instruction for an axes group command. This includes during the in-position check and when the velocity is 0 because the override factor was set to 0 while the group was in motion.
Deceleration Stopping	In this state, the MC_GroupStop instruction is executing. This includes when <i>Execute</i> is TRUE after stopping for the MC_GroupStop instruction. In this state, it is not possible to execute a motion for an axes group command. If one is executed, <i>CommandAborted</i> for the instruction will change to TRUE.
Error Deceleration Stopping ^{*1}	In this state, an axes group error has occurred. This includes during execution of the MC_GroupImmediateStop (Axes Group ImmediateStop) instruction and during a deceleration stop for an axes group error. It is not possible to execute multi-axes coordinated control commands in this state. If an attempt is made to execute one of them, <i>CommandAborted</i> for the instruction will change to TRUE.

*1 The Error Deceleration Stopping state occurs both when the axes group is enabled and when it is disabled.

Note You can monitor the axes group status in the member variables of the Axes Group Variables __MC_GRP[0-63].Status, _MC1_GRP[0-63].Status, and _MC2_GRP[0-63].Status.

6-4 Execution and Status of Motion Control Instructions

Variables that represent the execution status of instructions and variables that are used to execute motion control instructions are defined in the MC Function Module. There are two input variables that you use to execute motion control instruction functions: *Execute* and *Enable*. The following output variables indicate the execution status of an instruction: *Busy, Done, CommandAborted*, and *Error*.

6-4-1 Basic Rules for Execution of Instructions

The basic rules for the MC Function Module are listed in the following table. You can find execution examples in *6-4-2 Execution Timing Charts*. Refer to these examples as well.

Item	Rule
Exclusiveness of out- puts	The following output variables are exclusively controlled and only one of them can be TRUE at the same time: <i>Busy, Done, Error,</i> and <i>CommandAborted.</i> Similarly, only one of the following output variables can be TRUE at the same time: <i>Active, Done, Error,</i> and <i>CommandAborted.</i> <i>Busy</i> and <i>Active</i> may be TRUE at the same time in some cases.
Output status	The output variables <i>Done</i> , <i>InGear</i> (Gear Ratio Achieved), <i>InSync</i> , <i>InVelocity</i> (Target Velocity Reached), and <i>CommandAborted</i> change to FALSE when the input variable <i>Execute</i> changes to FALSE. The actual execution of a motion control instruction is not stopped when <i>Execute</i> changes to FALSE. Even if <i>Execute</i> changes to FALSE before the instruction finishes execution, the corresponding output variable will be TRUE for at least one period if the status of the instruction instance changes. The output variable <i>Error</i> will not reset to FALSE and the output variable <i>ErrorID</i> (Error Code) will not reset to 0 until you execute one of the following instructions: MC_Reset, MC_GroupReset, or ResetMCError.*1 If the <i>Execute</i> variable of the same instruction instance changes to TRUE again (i.e., if the instruction is restarted) during the execution of a motion control instruction, the <i>CommandAborted</i> variable will not change to TRUE.
Input parameters	For motion control instructions that are started with the input variable <i>Execute</i> , the values of the input parameters when <i>Execute</i> changes to TRUE are used. For motion control instructions that start for the input variable <i>Enable</i> , the current values of the input parameters during each period when <i>Enable</i> is TRUE are used.
Omitting input param- eters	The default value applies if you omit an input parameter for an instruction instance.*2
Position (Target Posi- tion) and Distance (Travel Distance)	The input variable <i>Position</i> is defined as a value in the coordinate system. The input variable <i>Distance</i> is the relative length, i.e., it is the difference between two positions.
Sign rules	The input variables <i>Acceleration</i> , <i>Deceleration</i> , and <i>Jerk</i> are non-negative values. <i>Posi- tion</i> (Target Position), <i>Distance</i> (Travel Distance), and <i>Velocity</i> (Target Velocity) can be positive, negative, or 0.

Item	Rule
Error processing	There are two output variables that represent an error when a problem occurs during the execution of an instruction instance. These outputs are defined as follows:
	• <i>Error</i> . The output variable <i>Error</i> changes to TRUE to indicate that an error occurred during the execution of the instruction instance.
	• ErrorID (Error Code): This is an error code that represents the cause of the error.
	The output variables <i>Done</i> , <i>InVelocity</i> (Target Velocity Reached), <i>InGear</i> (Gear Ratio Achieved), and <i>InSync</i> all represent normal completion or normal operation and therefore will never be TRUE when the output variable <i>Error</i> is TRUE.
	Types of errors:
	 Instruction instance errors (e.g., parameter out of range and illegal condition for state transition)
	 Axis errors (e.g., Following Error Limit Exceeded and Servo Drive errors)
	Some instruction instance errors may not cause an axis error but will cause the axis to stop.
Operation of output variable <i>Done</i>	The output variable <i>Done</i> , <i>InGear</i> (Gear Ratio Achieved), or <i>InSync</i> will change to TRUE when the instruction ends operation normally or when the commanded condition is reached. For movement instructions for which a target position is specified, the timing of when the output variable <i>Done</i> changes to TRUE depends on the setting of the In-position Check Time axis parameter.
	• If the In-position Check Time axis parameter is set to any value but 0, output variable <i>Done</i> changes to TRUE in the next period after the period in which positioning is com- pleted.
	• If the In-position Check Time axis parameter is set to 0, output variable <i>Done</i> changes to TRUE in the next period after the period in which pulse distribution is completed.
	When working with multiple instructions that operate on the same axis, the output variable <i>Done</i> from the first instruction will not change to TRUE if another operation instruction takes over before the axis operation for the first instruction reaches the target position.
Operation of output variable <i>Command-</i> <i>Aborted</i>	The output variable <i>CommandAborted</i> will change to TRUE when another operation instruction interrupts the commanded operation. For the MC Function Module, this variable will change to TRUE when a motion control instruction is executed and the target axis or axes group causes an error or is decelerating to a stop. All other output variables change to FALSE when <i>CommandAborted</i> changes to TRUE.
Input variables out- side of valid range	The instruction instance will output an error when it is executed with an input variable that is outside of the valid range.
Operation of output variable <i>Busy</i>	The output variable <i>Busy</i> is TRUE when the instruction instance is executing. <i>Busy</i> will change to TRUE when the input variable <i>Execute</i> changes to TRUE. <i>Busy</i> will change to FALSE when the output variable <i>Done, CommandAborted</i> , or <i>Error</i> changes to TRUE. It is impossible to know when the above output variables will change. Write your programs so that the instruction instance executes every period ^{*3} while <i>Busy</i> is TRUE so that you can monitor for changes in the output variables. For a single axis or single axes group, the <i>Busy</i> variable of more than one instruction instance can be TRUE at the same time. However, the output variable <i>Active</i> of only one instruction is an exception to this rule.
Output variable Active	The output variable <i>Active</i> changes to TRUE when the instruction instance obtains per- mission to control the applicable axis.
	The output variable Active may change slower than the Busy variable.*4

- *1 Under the PLCopen[®] specifications, *Error* changes to FALSE and *ErrorID* changes to 0 when *Execute* changes to FALSE. When *Error* is TRUE, the motion control instruction is not executed. Instructions are not executed after an error is cleared even if *Execute* is TRUE. *Execute* must change from FALSE to TRUE to execute the instruction. Enable-type motion control instructions are executed if their *Enable* variable is TRUE when an error is reset.
- *2 When you program the instruction in a ladder diagram, insert an input between the input variable *Execute* or *Enable* and the left bus bar. If the instruction is connected directly to the left bus bar without an input, an error occurs when the program is built. Set the initial value for or omit any input variable that is reserved.

- *3 If the condition expressions or set values for ST Structure instructions do not match, the instructions in that statement are not executed. For details, refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).
- *4 Refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508) for an output variable timing chart.

Precautions for Correct Use

• Confirm that EtherCAT process data communications are active and normal before you execute motion control instructions.

Refer to 10-2-1 Monitoring EtherCAT Communications and Turning ON Servos for details.

• Write the user program so that *Execute* is FALSE during the first period in which the instruction is executed.

6-4-2 Execution Timing Charts

The motion control instructions in the MC Function Module are function blocks that are unconditionally executed. This section calls instructions that are executed according to the *Execute* input variable "execute-type instructions" and instructions that are executed according to the *Enable* input variable "enable-type instructions."

Execution condition	Description
<i>Execute</i> variable	These motion control instructions are executed when the input variable <i>Execute</i> to the instruction changes to TRUE. These instructions will continue execution until one of the following status occurs.
	The specified operation is completed.
	 Another motion control instruction is executed and interrupts operation.
	• The instruction is restarted when <i>Execute</i> changes from FALSE to TRUE again.
	Values for the other input variables are input when <i>Execute</i> changes to TRUE.
Enable variable	These motion control instructions are executed every period while the input variable <i>Enable</i> to the motion control instruction is TRUE. As long as <i>Enable</i> is TRUE, the other input variables are also input every period. However, MC_MoveJog input variables <i>Velocity, Acceleration</i> , and <i>Deceleration</i> are an exception to this rule. The values when <i>PositiveEnable</i> or <i>NegativeEnable</i> changes to TRUE are used for these input variables.

Precautions for Correct Use

The timing in the timing charts that are given in this manual may not necessarily be the same as the timing displayed for data traces on the Sysmac Studio. Refer to the *NJ/NX-series CPU Unit Software User's Manual* (Cat. No. W501) for details on data tracing.

Timing Charts for Execute-type Instructions

• The following timing chart shows the operation of the instruction when it is completed while the input variable *Execute* is TRUE. The following timing chart is for when an error does not occur through when *Execute* changes to FALSE.

Execute	
Busy	
Done	
CommandAborted	; ; ;
Error	


• The following timing chart is for when an error occurs while input variable *Execute* is TRUE. After completion, the output variable *Error* will remain TRUE even if *Execute* changes to FALSE.

Execute	
Busy	
Done	۰
CommandAborted	
Error	

• The following timing chart is for when the instruction is interrupted during execution while input variable *Execute* is TRUE.

Execute	
Busy	
Done	i
CommandAborted	
Error	i i

• The following timing chart is for when the input variable *Execute* is TRUE for only one period and an error does not occur for the instruction. The output variable *Done* will change to TRUE for only one period after the instruction operation is completed.




6

• The following timing chart is for when the input variable *Execute* is TRUE for only one period and an error occurs for the instruction. The output variable *Error* will remain TRUE.


Execute	
Busy	
Done	
CommandAborted	
Error	

Timing Charts for Enable-type Instructions

• The following timing chart is for when the input variable *Enable* changes to TRUE and an error does not occur for the instruction.



• The following timing chart is for when the input variable *Enable* changes to TRUE and an error occurs for the instruction.




Additional Information

Enable and *Enabled* change at the same time for instructions such as MC_ZoneSwitch (Zone Monitor) and MC_AxesObserve (Monitor Axis Following Error). For details on the timing of individual instructions, refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

6-4-3 Timing Chart for Re-execution of Motion Control Instructions

If the values of the input variables to the same instance are changed while the motion control instruction is under execution and *Execute* is changed to TRUE, FALSE, and then back to TRUE again, operation will follow the new values.

The following timing chart is for when the velocity is changed for MC_MoveAbsolute (Absolute Positioning) instruction.



For details on re-executing instructions for the MC Function Module, refer to 9-5-6 Re-executing Motion Control Instructions and 9-7-4 Re-executing Motion Control Instructions for Multi-axes Coordinated Control.


6-4-4 Timing Chart for Multi-execution of Motion Control Instructions

Another instance can be executed for an axis during axis motion. Set the input variable *BufferMode* to specify when to start operation.

The following figure shows an example in which *BufferMode* (Buffer Mode Selection) is set to aborting when MC_MoveAbsolute (Absolute Positioning) instructions are executed with multi-execution of instructions.

"FB1" and "FB2" in the following figure are the instance names of the instructions.

FB1



For details on multi-execution of instructions for the MC Function Module, refer to 9-5-7 Multi-execution of Motion Control Instructions (Buffer Mode) and 9-7-5 Multi-execution (Buffer Mode) of Motion Control Instructions for Multi-axes Coordinated Control.

6-5 Positions


This section describes the positions that are used in motion control programming.

6-5-1 Types of Positions

The MC Function Modules uses the following two types of positions.

Type of position	Definition
Command position	This is the position that the MC Function Module outputs to control an axis.
Actual position	The actual position as input from the Servo Drive or encoder input.

The following figure shows the relationship between the command position and the actual position for an EtherCAT slave Servo Drive.



The command position and actual position share the following items.


ltem	Command position	Actual position
Count Mode	You can set Linear Mode or Rotary Mode.	The same Count Mode is used as for the command position.
Position increment	You can set one of the following: mm, μ m, nm, inch, degree, or pulse.	The unit is the same as the unit of the command position.
Software limits	You can set the range of operation of the software.	The range is the same as the range for the command position.
Changing the current position	You can change the actual position to any desired position.	This value will be set to the same position as the command position.*
Defining home	Home is either defined or undefined.	The status of home is the same as the command position.

* If there is any following error before the change, the following error value is maintained in the actual position.



Additional Information

 For a virtual servo axis, the command current value is converted to pulses and then that value is converted to the unit of display. The resulting value is used as the actual current value.



 Refer to the NX-series Position Interface Units User's Manual (Cat. No. W524) for information on the NX-series Position Interface Units. 6

6-5-2 Valid Positions for Each Axis Type

Axis type	Types of positions		
Axis type	Command position	Actual position	
Servo axis	Applicable	Applicable	
Virtual servo axis	Applicable	Applicable ^{*1}	
Encoder axis	Cannot be used.	Applicable	
Virtual encoder axis	Cannot be used.	Applicable ^{*2}	

The following table lists the valid positions for each axis type.

*1 For a virtual servo axis, the actual position is the same as the command position. (However, there is sometimes calculation error because processing is performed with long reals in the MC Function Module.)

*2 This is used when there is no actual encoder.

tings of part of the axis parameters.

You can monitor axes group status and the

settings of part of the axes group parame-

6-6 System-defined Variables for Motion Control

This section describes the variables of the MC Function Module.

6-6-1 Overview of System-defined Variables for Motion Control

The NJ/NX-series Controller is compliant with the IEC 61131-3 standard. Parameter settings, status information, and other data are handled as variables in the user program in the NJ/NX-series Controller. Of these, system-defined variables that belong to the MC Function Module are called system-defined variables for motion control.

Types of System-defined Variables for Motion Control

Level 1	Level 2	Level 3	Description	
System-defined variables	ables for motion Variable		You can monitor the overall status of the MC Function Module.	
	control	Axis Variables	You can monitor axis status and the set-	

Axes Group

Variables

The following table lists all of the types of system-defined variables for motion control.

• MC Common Variable

You can monitor the overall status of the MC Function Module with the MC Common Variable. The variable name is *MC_COM*.

ters.

Axis Variables

Use these variables to handle EtherCAT slaves, Servo Drives, encoder input terminals, NX-series Position Interface Units, virtual Servo Drives, and virtual encoder input terminals.

You can use either the system-defined variables or the variables that are set on the Sysmac Studio to specify the Axes Group Variables in the user program.

You can change any of the Axis Variables that you create on the Sysmac Studio.

• Axes Group Variables in the system-defined variables	: _MC_AX[0] to _MC_AX[255] : _MC1_AX[0] to _MC1_AX[255]
	: _MC2_AX[0] to _MC2_AX[255]
 Default Axes Group Variables when axes 	: MC_Axis000 to MC_Axis255 (default)

groups are created on Sysmac Studio

• Axes Group Variables

Use these variables to handle multiple axes as a single group. You can use either the system-defined variables or the variables that are set on the Sysmac Studio to specify the Axes Group Variables in the user program.

You can change any of the Axes Group Variables that you create on the Sysmac Studio.

• Axes Group Variables in the system-defined	: _MC_GRP[0] to _MC_GRP[63]
variables	: _MC1_GRP[0] to _MC1_GRP[63]
	: _MC2_GRP[0] to _MC2_GRP[63]
 Default Axes Group Variables when axes 	: MC_Group000 to MC_Group063 (default)
groups are created on Sysmac Studio	

Refer to the *NJ/NX-series CPU Unit Software User's Manual* (Cat. No. W501) for details on the variables that are used by an NJ/NX-series Controller.

Data Types Used for System-defined Variables for Motion Control

System-defined variables for motion control use both basic data types and derivative data types.

Category	Data type	Size	Range of values	Notation
Boolean	BOOL	2*	TRUE or FALSE	TRUE or FALSE
Integer	UINT	2	0 to +65,535	Binary expression: "2#" is added to the front of the number
	UDINT 4	4	0 to +4,294,967,295	Octal expression: "8#" is added to the front of the number Decimal expression: "10#" is added to the front of the number Hexadecimal expression: "16#" is added to the front of the number If you do not add any notation to the beginning of a number, that number is treated as a decimal number.
				Example:
				Binary Notation
				2#1111_1111
				2#1110_0000 Octal Notation
				8#377
				8#340
				Decimal Notation
				-12 0 123_456 +986
				10#1234
				Hexadecimal Notation
				16#FF 16#ff
				16#E0 16#e0
Floating- point numbers	LREAL	8	-1.79769313486231e+308 to -2.22507385850721e-308,0, 2.22507385850721e-308 to 1.79769313486231e+308, positive infinity, or posetive	Written as (sign) + integer_part + (decimal_point) + (decimal_part) + (expo- nent). You can omit items in parentheses. Example:
			positive infinity, or negative infinity	2
				-12.0
				0.0
				0.4560
				3.14159_26
				-1.34E-12
			-1.34e-12	
				1.0E+6
				1.0e+6
				1.234E6
				1.234e6

Basic Data Types

* BOOL data is only 1 bit in size but it takes up 2 bytes of memory.

Туре	Description
Enumerated data types	This data type uses one item from a prepared name list as its value. Variables with this data type start with "_e."
Structure data type	This data type consists of multiple data types placed together into a single layered structure. Variables with this data type start with "_s."

• Derivative Data Types

Refer to the *NJ/NX-series CPU Unit Software User's Manual* (Cat. No. W501) for details on the other data types that are used by an NJ/NX-series Controller.

Attributes of System-defined Variables for Motion Control

The attributes that are shown in the following table are the same for all system-defined variables for motion control.


Attribute	Attribute of system-defined variables for motion control
Global/Local	Global variable
R/W access	Read only
Retain	Non-retain
Network Publish	Publish*

* Variables are published on the network with the variable names of the system-defined variables. The variable names that are created when the axes or axes groups are created on the Sysmac Studio are not published to the network.

6-6-2 System for System-defined Variables for Motion Control

System-defined variables for motion control consist of information representing the status of the MC Function Module, status information for slave devices connected via EtherCAT communications, and the portion of the MC parameter settings used to perform motion control.

You can access system-defined variables for motion control as variables in the user program and monitor them from the Sysmac Studio.



Update Timing of System-defined Variables for Motion Control

The update timing of the system-defined variables for motion control is different in the NX-series CPU Unit and NJ-series CPU Unit.

The following shows the difference of the update timing.

• NX-series CPU Unit

When you access the primary periodic task and priority-5 periodic task to an axis, the motion control variables are updated as follows:

- Only the task area that is assigned to the primary periodic task and the basic setting area of the priority-5 periodic task are updated.
- The other area of the priority-5 periodic task is not updated from the default settings and will be updated every task period of the priority-5 periodic task.

Variable area to update	Primary periodic task	Priority-5 periodic task
_MC_AX[0-255]	Updated	
_MC1_AX[0-255]	Updated	
_MC2_AX[0-255]		Updated
_MC_GRP[0-63]	Updated	
_MC1_GRP[0-63]	Updated	
_MC2_GRP[0-63]		Updated

• NJ-series CPU Unit

The system-defined variables for motion control are updated every primary task period.

6-6-3 Tables of System-defined Variables for Motion Control

This section provides tables that describe the system-defined variables for motion control.

MC Common Variable

The variable name _*MC_COM* is used for the MC Common Variable. The data type is _sCOMMON_REF, which is a structure variable. This section describes the configuration of the MC Common Variable and provides details on the members.

V	ariable name	Data type	Meaning	Function
C_	COM	_sCOMMON_REF	MC Common Variable	
Status		_sCOMMON_REF_STA	MC Common Status	
	RunMode	BOOL	MC Run	TRUE during MC Function Module operation.
	TestMode	BOOL	MC Test Run	TRUE during test mode operation from the Sysmac Studio.
	CamTableBusy	BOOL	Cam Table File Save Busy	TRUE while the Cam Table is being saved or on standby.
	Generate CamBusy ^{*1}	BOOL	Generating Cam Table	TRUE while the cam table is being generated.
PF	aultLvl	_sMC_REF_EVENT	MC Common Partial Fault	TRUE while the cam table is being generated.
	Active	BOOL	MC Common Partial Fault Occurrence	TRUE while there is an MC common partial fault.
	Code	WORD	MC Common Partial Fault Code	Contains the code for an MC com- mon partial fault. The upper four dig- its of the event code have the same value.
MF	FaultLvl	_sMC_REF_EVENT	MC Common Minor Fault	
	Active	BOOL	MC Common Minor Fault Occurrence	TRUE while there is an MC common minor fault.
	Code	WORD	MC Common Minor Fault Code	Contains the code for an MC com- mon minor fault. The upper four digits of the event code have the same value.
Ot	osr	_sMC_REF_EVENT	MC Common Obser- vation	
	Active	BOOL	MC Common Obser- vation Occurrence	TRUE while there is an MC common observation.
	Code	WORD	MC Common Obser- vation Code	Contains the code for an MC com- mon observation. The upper four dig its of the event code have the same value.

*1 A CPU Unit with unit version 1.08 or later and Sysmac Studio version 1.09 or higher are required.

Axis Variables

 $_MC_AX[0-255]$, $_MC1_AX[0-255]$, and $_MC2_AX[0-255]$ are the Axis Variables in the system-defined variables. The data type is $_sAXIS_REF$, which is a structure variable. This section describes the configuration of the Axis Variables and provides details on the members using $_MC_AX[0-255]$ as an example. The same information applies to $MC1_AX[0-255]$ and $_MC2_AX[0-255]$.

Variable name	Data type	Meaning	Function
C_AX[0-255]	_sAXIS_REF	Axis Variable	
Status	_sAXIS_REF_STA	Axis Status	
Ready	BOOL	Axis Ready-to-execute	TRUE when preparations for axis execution are finished and the axis is stopped.
			This variable indicates the same status as when _ <i>MC_AX[*].Status.Standstill</i> is TRUE (stopped).
Disabled	BOOL	Axis Disabled	TRUE while the Servo is OFF for the axis.
			The following axis states are mutually exclusive. Only one can be TRUE at the same time.
			Disabled, Standstill, Discrete, Continuous, Syn- chronized, Homing, Stopping, ErrorStop, or Coor- dinated
Standstill	BOOL	Standstill	TRUE while the Servo is ON for the axis.
Discrete	BOOL	Discrete Motion	TRUE while position control is executed toward the target position. This includes when the velocity is 0 because the override factor was set to 0 dur- ing a discrete motion.
Continuous	BOOL	Continuous Motion	TRUE during continuous motion without a target position.
			This state exists during velocity control or torque control.
			This includes when the velocity is 0 because the target velocity is set to 0 and when the velocity is 0 due to an override factor set to 0 during continuous motion.
Synchronized	BOOL	Synchronized Motion	TRUE during execution of synchronized control.
			This includes waiting for synchronization after changing to synchronized control instructions.
Homing	BOOL	Homing	TRUE when homing for the MC_Home or MC_HomeWithParameter instruction.
Stopping	BOOL	Deceleration Stopping	TRUE until the axis stops for a MC_Stop or MC_TouchProbe instruction.
			This includes when <i>Execute</i> is TRUE after the axis stops for an MC_Stop instruction. Axis motion instructions are not executed while decelerating to a stop. (<i>CommandAborted</i> is TRUE.)
ErrorStop	BOOL	Error Deceleration Stopping	This status exists when the axis is stopping or stopped for execution of the MC_ImmdediateStop instruction or a minor fault (while _ <i>MC_AX[*].MFaultLvI.Active</i> is TRUE (Axis Minor Fault Occurrence).
			Axis motion instructions are not executed in this state. (<i>CommandAborted</i> is TRUE.)
Coordinated	BOOL	Coordinated Motion	TRUE when an axes group is enabled by a multi- axes coordinated control instruction.

	iable name	Data type	Meaning	Function
Deta	ails	_sAXIS_REF_DET	Axis Control Status	Gives the control status of the command.
le	dle	BOOL	Idle	TRUE when processing is not currently performed for the command value, except when waiting for in-position state.*1
				<i>Idle</i> and <i>InPosWaiting</i> are mutually exclusive. They cannot both be TRUE at the same time.
li	nPosWaiting	BOOL	In-position Waiting	TRUE when waiting for in-position state. The in- position check performed when positioning for the in-position check.
F	Homed	BOOL	Home Defined	TRUE when home is defined.
				FALSE: Home not defined.
				TRUE: Home is defined
1	nHome	BOOL	In Home Position	TRUE when the axis is in the range for home. It gives an AND of the following conditions.
				Home defined
				• The actual current position is in the zero position range with home as the center.
				TRUE also when the zero position is passed by while the axis is moving in command status.
	VelLimit	BOOL	Command Velocity Saturation	TRUE while the command velocity is limited to th maximum velocity.
Dir		_sAXIS_REF_DIR	Command Direction	Gives the command travel direction.
	Posi	BOOL	Positive Direction	TRUE when there is a command in the positive direction.
	Nega	BOOL	Negative Direction	TRUE when there is a command in the negative direction.
	Status	_sAXIS_REF_STA_ DRV	Servo Drive Status	Gives the status of the Servo Drive.
	ServoOn	BOOL	Servo ON	TRUE when the Servomotor is powered.
	Ready	BOOL	Servo Ready	TRUE when the Servo is ready.*2
	VainPower	BOOL	Main Power	TRUE when the Servo Drive main power is ON.
	P_OT	BOOL	Positive Limit Input	TRUE when the positive limit input is enabled.
	N_OT	BOOL	Negative Limit Input	TRUE when the negative limit input is enabled.
F	HomeSw	BOOL	Home Proximity Input	TRUE when the home proximity input is enabled
F	Home	BOOL	Home Input	TRUE when the home input is enabled.*3*4
l	mdStop	BOOL	Immediate Stop Input	TRUE when the immediate stop input is enabled
L	_atch1	BOOL	External Latch Input 1	TRUE when latch input 1 is enabled.
L	_atch2	BOOL	External Latch Input 2	TRUE when latch input 2 is enabled.
C	DrvAlarm	BOOL	Drive Error Input	TRUE while there is a Servo Drive error.
C	DrvWarning	BOOL	Drive Warning Input	TRUE while there is a Servo Drive warning.
I	LA	BOOL	Drive Internal Limiting	TRUE when the Servo Drive limiting function act ally limits the axis. This corresponds to one of th following limits in the G5-series Servo Drive.*5
				Torque limits, velocity limit, drive prohibit inputs, software limits
C	CSP	BOOL	Cyclic Synchronous Position (CSP) Control Mode	TRUE when the Servo is ON at the Servo Drive and the current mode is CSP Mode.* ⁶
C	CSV	BOOL	Cyclic Synchronous Velocity (CSV) Control Mode	TRUE when the Servo is ON at the Servo Drive and the current mode is CSV Mode.* 3
C	CST	BOOL	Cyclic Synchronous Torque (CST) Control Mode	TRUE when the Servo is ON at the Servo Drive and the current mode is CST Mode.* ³

Variable name	Data type	Meaning	Function
Cmd	_sAXIS_REF_CMD _DATA	Axis Command Values	
Pos	LREAL	Command Current Position	Contains the current value of the command posi- tion. (Unit: command units) When the Servo is OFF and the mode is not posi- tion control mode, this variable contains the actua current position. *7
Vel	LREAL	Command Current Velocity	Contains the current value of the command velocity. (Unit: command units/s) A plus sign is added during travel in the positive direction, and a minus sign during travel in the negative direction. The velocity is calculated from the difference with the command current position When the Servo is OFF and the mode is not the position control mode, the velocity is calculated based on the actual current position.
AccDec	LREAL	Command Current Acceleration/Decelera- tion	Contains the current value of the command accel eration/deceleration rate. (Unit: command units/s ²) The acceleration/deceleration rate is calculated from the difference with the command current velocity. A plus sign is added for acceleration, and a minus sign is added for deceleration. The value is 0 when the command acceleration/deceleration rate of the instruction under execution is 0.
Jerk	LREAL	Command Current Jerk	Contains the current value of the command jerk. (command units/s ³) A plus sign is added when the absolute value of acceleration/deceleration is increasing, and a minus sign is added when it is decreasing. The value is 0 when the command acceleration/decel eration rate and command jerk of the instruction under execution is 0.
Trq	LREAL	Command Current Torque	Contains the current value of the command torque. (Unit: %) A plus sign is added during travel in the positive direction, and a minus sign during travel in the negative direction. Contains the same value as the actual current torque except in torque control mode. *8
Act	_sAXIS_REF_ACT_ DATA	Axis Current Value	
Pos	LREAL	Actual Current Position	Contains the actual current position. (Unit: command units) *7
Vel	LREAL	Actual Current Velocity	Contains the actual current velocity. (Unit: com- mand units/s) A plus sign is added during travel in the positive direction, and a minus sign during travel in the negative direction.
Trq	LREAL	Actual Current Torque	Contains the current value of the actual torque. (Unit: %) A plus sign is added during travel in the positive direction, and a minus sign during travel in the negative direction.
TimeStamp ^{*9}	ULINT	Time Stamp	Contains the time when the current position of the axis was updated. This variable is valid for an axi for which time stamping is operating. (Unit: ns)

Variable name	Data type	Meaning	Function
MFaultLvl	_sMC_REF_EVENT	Axis Minor Fault	
Active	BOOL	Axis Minor Fault Occurrence	TRUE while there is an axis minor fault.
Code	WORD	Axis Minor Fault Code	Contains the code for an axis minor fault.
			The upper four digits of the event code have the same value.
Obsr	_sMC_REF_EVENT	Axis Observation	
Active	BOOL	Axis Observation Occurrence	TRUE while there is an axis observation.
Code	WORD	Axis Observation	Contains the code for an axis observation.
		Code	The upper four digits of the event code have the same value.
Cfg	_sAXIS_REF_CFG	Axis Basic Settings	Gives the settings of the Axis Basic Settings parameters.
AxNo	UINT	Axis Number	Contains the logical number of the axis.
AxEnable	_eMC_AXIS_USE	Axis Use	Shows if the axis is enabled or disabled.
			0: _mcNoneAxis (Undefined Axis)
			1: _mcUnusedAxis (Unused Axis)
			2: _mcUsedAxis (Used Axis)
AxType	_eMC_AXIS_TYPE	Axis Type	Contains the axis type. I/O wiring is not required for virtual axes.
			0: _mcServo (Servo Axis)
			1: _mcEncdr (Encoder Axis)
			2: _mcVirServo (Virtual Servo Axis)
			3: _mcVirEncdr (Virtual Encoder Axis)
NodeAddress	UINT	Node Address	Contains the EtherCAT slave address. A value
			16#FFFF indicates that there is no address. *10
ExecID*11	UNIT	Execution ID	Contains the task execution ID.
			0: Not assigned to task (undefined axis)
			1: Assigned to primary periodic task
			2: Assigned to priority-5 periodic task
Scale	_sAXIS_REF_SCAL E	Unit Conversion Set- tings	Gives settings of the electronic gear ratio.
Num	UDINT	Command Pulse Count Per Motor Rota- tion	Contains the number of pulses per motor rotation for command positions. The command value is converted to the equivalent number of pulses based on the electronic gear ratio.
Den	LREAL	Work Travel Distance Per Motor Rotation	Contains the workpiece travel distance per mot rotation for command positions.
Units	_eMC_UNITS	Unit of Display	Contains the display unit for command position
			0: _mcPls (pulse)
			1: _mcMm (mm)
			2: _mcUm (μm)
			3: _mcNm (nm)
			4: _mcDeg (degree)
			5: _mclnch (inch)
CountMode*11	_eMC_COUNT_MO	Count Mode	Contains the count mode.
	DE		0: _mcCountModeLinear (linear mode)
			1: _mcCountModeRotary (rotary mode)
MaxPos *11	LREAL	Maximum Current	Contains the maximum value of the current
		Position	position indication.*12
MinPos *11	LREAL	Minimum Curernt	Contains the minimum value of the current

- *1 This also includes states where processing is performed while in motion at velocity 0, during following error resets, during synchronized control, and during coordinated motion.
- *2 This variable is TRUE when the PDS state of the Servo Drive is either *Ready to switch on, Switched on* or *Operation enabled* and the main circuit power supply (voltage enabled) is ON. However, if **Main circuit power supply OFF detection** is set to *Do not detect*, ON/OFF status of the main circuit power supply is ignored. For details on the PDS states and the Main circuit power supply OFF detection, refer to *A-4 PDS State Transition*.
- *3 The Detailed Settings Area on the Axis Basic Settings Display of the Sysmac Studio gives the signal that is set for encoder Z-phase detection digital input. You may not be able to map a PDO to this signal for servo drives from other manufacturers. Refer to the manual for the connected servo drive for details.
- *4 You cannot map this signal to a PDO for an OMRON G5-series Linear Motor Type.
- *5 This variable gives the status of bit 11 (internal limit enabled) in the Status Word (6041 hex) that is mapped to a PDO. The conditions for this variable changing to TRUE depend on the specifications of the Servo Drive. Refer to the manual for the connected servo drive for details.
- *6 This variable gives the value of the Modes of Operation Display (6061 hex) that is mapped to a PDO. The conditions CSP, CSV, and CST changing to TRUE depend on the specifications of the Servo Drive. Refer to the manual for the connected servo drive for details.


Always FALSE if Modes of Operation (6061 hex) is not mapped in a PDO.

*7 If the process data communications between the CPU Unit and an EtherCAT slave or NX Unit that is assigned to an axis changed to a non-established state, the variables contain different values as follows depending on the unit version of the CPU Unit.

For a CPU Unit with version 1.09 or earlier, the actual current position and the command current position axis variables will contain 0 or the lower limit. The lower limit is contained when the Count Mode is set to Rotary Mode and 0 is not included in the range of position.

For a CPU Unit with version 1.10 or later, the actual current position and the command current position axis variables will contain the actual current position output that is just before process data communications change to a non-established state.

*8 If you display a data trace that compares the command current torque and the actual current torque in any mode other than Torque Control Mode, the command current torque will change after one task period. This is caused by the timing of processing the data trace. Refer to information on data tracing in the *NJ/NX-series CPU Unit Software User's Manual* (Cat. No. W501) for information on the timing of processing data tracing.



Changes in the display of the command current torque are delayed in respect to the actual current torque.

- *9 A CPU Unit with unit version 1.06 or later and Sysmac Studio version 1.07 or higher are required to use this variable.
- *10 For an NX-series Position Interface Unit, this is the node address of the EtherCAT Coupler Unit under which the Position Interface Unit is mounted.
- *11 A CPU Unit with unit version 1.10 or later and Sysmac Studio version 1.12 or higher are required to use this variable.
- *12 If the Count Mode is set to Linear Mode, the position just before an overflow is given. In Rotary Mode, the modulo maximum position is given.
- *13 If the Count Mode is set to Linear Mode, the position just before an underflow is given. In Rotary Mode, the modulo minimum position is given.

• Relationship between Axis Variables and Axis Types

Axis Variables are enabled or disabled according to the axis type. Disabled members are FALSE or 0.

In the descriptions, $_MC_AX[0-255]$ is used as an example. The same information applies to $_MC1_AX[0-255]$ and $_MC2_AX[0-255]$. Also, the following table shows which members are enabled for each axis type.

Variable name	Data type	Meaning	Servo axis	Virtual servo axis	Encoder axis	Virtual encoder axis
IC_AX[0-255]	_sAXIS_REF	Axis Variable				
Status	_sAXIS_REF_STA	Axis Status			-	
Ready	BOOL	Axis Ready-to-execute	Enabled	Enabled		
Disabled	BOOL	Axis Disabled	Enabled	Enabled	Enabled	Enabled
Standstill	BOOL	Standstill	Enabled	Enabled		
Discrete	BOOL	Discrete Motion	Enabled	Enabled		
Continuous	BOOL	Continuous Motion	Enabled	Enabled		
Synchronized	BOOL	Synchronized Motion	Enabled	Enabled		
Homing	BOOL	Homing	Enabled	Enabled		
Stopping	BOOL	Deceleration Stopping	Enabled	Enabled		
ErrorStop	BOOL	Error Deceleration Stopping	Enabled	Enabled		
Coordinated	BOOL	Coordinated Motion	Enabled	Enabled		
Details	_sAXIS_REF_DET	Axis Control Status				
Idle	BOOL	Idle	Enabled	Enabled	Enabled	Enable
InPosWaiting	BOOL	In-position Waiting	Enabled	Enabled		
Homed	BOOL	Home Defined	Enabled	Enabled		
InHome	BOOL	In Home Position	Enabled	Enabled		
VelLimit	BOOL	Command Velocity Saturation	Enabled	Enabled		
Dir	_sAXIS_REF_DIR	Command Direction				
Posi	BOOL	Positive Direction	Enabled	Enabled		
Nega	BOOL	Negative Direction	Enabled	Enabled		
DrvStatus	_sAXIS_REF_STA_DRV	Servo Drive Status				
ServoOn	BOOL	Servo ON	Enabled			
Ready	BOOL	Servo Ready	Enabled			
MainPower	BOOL	Main Power	Enabled			
P_OT	BOOL	Positive Limit Input	Enabled			
N_OT	BOOL	Negative Limit Input	Enabled			
HomeSw	BOOL	Home Proximity Input	Enabled			
Home	BOOL	Home Input	Enabled			
ImdStop	BOOL	Immediate Stop Input	Enabled			
Latch1	BOOL	External Latch Input 1	Enabled			
Latch2	BOOL	External Latch Input 2	Enabled			
DrvAlarm	BOOL	Drive Error Input	Enabled			
DrvWarning	BOOL	Drive Warning Input	Enabled			
ILA	BOOL	Drive Internal Limiting	Enabled			
CSP	BOOL	Cyclic Synchronous Position (CSP) Con- trol Mode	Enabled			
CSV	BOOL	Cyclic Synchronous Velocity (CSV) Con- trol Mode	Enabled			
CST	BOOL	Cyclic Synchronous Torque (CST) Control Mode	Enabled			

Variable name	Data type	Meaning	Servo axis	Virtual servo axis	Encoder axis	Virtual encoder axis
Cmd	_sAXIS_REF_CMD_DAT A	Axis Command Values				
Pos	LREAL	Command Current Position	Enabled	Enabled		
Vel	LREAL	Command Current Velocity	Enabled	Enabled		
AccDec	LREAL	Command Current Acceleration/Decelera- tion	Enabled	Enabled		
Jerk	LREAL	Command Current Jerk	Enabled	Enabled		
Trq	LREAL	Command Current Torque	Enabled	Enabled		
Act	_sAXIS_REF_ACT_DATA	Axis Current Value				
Pos	LREAL	Actual Current Position	Enabled	Enabled	Enabled	Enabled
Vel	LREAL	Actual Current Velocity	Enabled	Enabled	Enabled	Enabled
Trq	LREAL	Actual Current Torque	Enabled	Enabled		
TimeStamp	ULINT	Time Stamp	Enabled		Enabled	
MFaultLvl	_sMC_REF_EVENT	Axis Minor Fault				
Active	BOOL	Axis Minor Fault Occurrence	Enabled	Enabled	Enabled	Enabled
Code	WORD	Axis Minor Fault Code	Enabled	Enabled	Enabled	Enabled
Obsr	_sMC_REF_EVENT	Axis Observation				
Active	BOOL	Axis Observation Occurrence	Enabled	Enabled	Enabled	Enabled
Code	WORD	Axis Observation Code	Enabled	Enabled	Enabled	Enabled
Cfg	_sAXIS_REF_CFG	Axis Basic Settings				
AxNo	UINT	Axis Number	Enabled	Enabled	Enabled	Enabled
AxEnable	_eMC_AXIS_USE	Axis Use	Enabled	Enabled	Enabled	Enabled
AxType	_eMC_AXIS_TYPE	Axis Type	Enabled	Enabled	Enabled	Enabled
NodeAddress	UINT	Node Address	Enabled		Enabled	
ExecID*1	UNIT	Execution ID	Enabled	Enabled	Enabled	Enabled
Scale	_sAXIS_REF_SCALE	Unit Conversion Set- tings		I	I	I
Num	UDINT	Command Pulse Count per Motor Rota- tion	Enabled	Enabled	Enabled	Enabled
Den	LREAL	Work Travel Distance per Motor Rotation	Enabled	Enabled	Enabled	Enabled
Units	_eMC_UNITS	Unit of Display	Enabled	Enabled	Enabled	Enabled
CountMode*1	_eMC_COUNT_MODE	Count Mode	Enabled	Enabled	Enabled	Enabled
MaxPos ^{*1}	LREAL	Maximum Current Position	Enabled	Enabled	Enabled	Enabled
MinPos ^{*1}	LREAL	Minimum Current Position	Enabled	Enabled	Enabled	Enabled

*1 A CPU Unit with unit version 1.10 or later and Sysmac Studio version 1.12 or higher are required to use this variable.

Axes Group Variables

_*MC_GRP[0-63]*, _*MC1_GRP[0-63]*, and _*MC2_GRP[0-63]* are the system-defined Axes Group Variables. The data type is _sGROUP_REF, which is a structure. This section describes the configuration of the Axes Group Variables and provides details on the members using _*MC_GRP[0-63]* as an example. The same information applies to _*MC1_GRP[0-63]* and _*MC2_GRP[0-63]*.

Also, in the descriptions of functions, $_MC_AX[*]$ is used as an example, but the same information applies to $_MC1_AX[*]$ and $_MC2_AX[*]$.

Va	riable name	Data type	Meaning	Function
_MC_0	GRP[0-63]	_sGROUP_REF	Axes Group Variable	
Sta	atus	_sGROUP_REF_STA	Axes Group Status	
	Ready	BOOL	Ready to Execute	 TRUE when the axes group is stopped and is ready to execute. The condition for being ready to execute is an AND of the following conditions. Execution of the MC_Stop instruction is not in progress for any composition axis. _MC_GRP[*].Status.Standby is TRUE (stopped). The Servo is ON for the composition axes. _MC_AX[*].Details.Homed is TRUE (home is defined) for the composition axes.
	Disabled	BOOL	Axes Group Disabled	TRUE when the axes group is disabled and stopped. The following axes group status are mutually exclusive. Only one of them can be TRUE at a time. <i>Disabled, Standby, Moving, Stopping, or Error-</i> <i>Stop</i>
	Standby	BOOL	Standby	TRUE when the axes group motion instruction is stopped. (This is independent of the Servo ON/OFF status of the composition axes in the axes group)
	Moving	BOOL	Moving	TRUE while an axes group motion instruction is executed toward the target position.
				This includes in-position waiting status and when the velocity is 0 for an override.
	Stopping	BOOL	Deceleration Stopping	TRUE until the axes group stops for an MC_GroupStop instruction. This includes when <i>Execute</i> is TRUE after the axes stop for an MC_GroupStop instruction. Axes group motion instructions are not executed in this state. (<i>CommandAborted</i> is TRUE.)
	ErrorStop	BOOL	Error Deceleration Stopping	TRUE while the axes group is stopping or stopped for the MC_GroupImmediateStop instruction or for an axes group minor fault (when _ <i>MC_GRP[*].MFaultLvI.Active</i> is TRUE). Axes group motion instructions are not executed in this state. (<i>CommandAborted</i> is TRUE.)
De	tails	_sGROUP_REF_DET	Axes Group Control Status	Gives the control status of the instruction.
	ldle	BOOL	Idle	TRUE when processing is not currently per- formed for the command value, except when waiting for in-position state. ^{*1} <i>Idle</i> and <i>InPosWaiting</i> are mutually exclusive. They cannot both be TRUE at the same time.
	InPosWaiting	BOOL	In-position Waiting	TRUE when waiting for in-position state for any composition axis. TRUE during positioning operations during the in-position check. ^{*2}

Variable name	Data type	Meaning	Function
Cmd	_sGROUP_REF_CMD_ DATA	Axes Group Command Values	
Vel	LREAL	Command Interpolation Velocity	Contains the current value of the command interpolation velocity. The interpolation veloc ity is calculated from the difference with the interpolation command current position. A plu sign is added during travel in the positive direction, and a minus sign is added during travel in the negative direction. The value is of when the axes group is disabled.
AccDec	LREAL	Command Interpolation Acceleration/ Deceleration	Contains the current value of the command interpolation acceleration/deceleration. The interpolation acceleration/deceleration rate is calculated from the difference with the com- mand interpolation velocity. A plus sign is added for acceleration, and a minus sign is added for deceleration. The value is 0 when the axes group is disabled, or when the com mand acceleration/deceleration rate of the current axes group motion instruction is 0.
MFaultLvI	_sMC_REF_EVENT	Axes Group Minor Fault	
Active	BOOL	Axes Group Minor Fault Occurrence	TRUE while there is an axes group minor fau
Code	WORD	Axes Group Minor Fault Code	Contains the error code for an axes group minor fault. The upper four digits of the event code have the same value.
Obsr	_sMC_REF_EVENT	Axes Group Observa- tion	
Active	BOOL	Axes Group Observa- tion Occurrence	TRUE while there is an axes group observa- tion.
Code	WORD	Axes Group Observa- tion Code	Contains the code for an axes group observa- tion. The upper four digits of the event code have the same value.
Cfg	_sGROUP_REF_CFG	Axes Group Basic Settings	Gives the settings of the Axes Group Basic Settings parameters.
GrpNo	UINT	Axes Group Number	Contains the logical number of the axes group.
GrpEnable	_eMC_GROUP_USE	Axes Group Use	Shows if the axes group is enabled or dis- abled. 0: _mcNoneGroup (Undefined Axes Group) 1: _mcUnusedGroup (Unused Axes Group) 2: _mcUsedGroup (Used Axes Group)
ExecID ^{*3}	UNIT	Execution ID	Contains the assigned task execution ID. 0: Not assigned to task (undefined axes group) 1: Assigned to primary periodic task 2: Assigned to priority-5 periodic task

Variable name	Data type	Meaning	Function
Kinematics	_sGROUP_REF_KIM	Kinematics Transformation Settings	Contains the definition of the kinematic conversions for the axes group.
GrpType	_eMC_TYPE	Composition	Gives the axis composition of multi-axes coor- dinated control.
			0: _mcXY (two axes)
			1: _mcXYZ (three axes)
			2: _mcXYZU (four axes)
Axis[0]	UINT	Composition Axis for Axis A0	Contains the axis number that is assigned to axis A0.
Axis[1]	UINT	Composition Axis for Axis A1	Contains the axis number that is assigned to axis A1.
Axis[2]	UINT	Composition Axis for Axis A2	Contains the axis number that is assigned to axis A2.
Axis[3]	UINT	Composition Axis for Axis A3	Contains the axis number that is assigned to axis A3.


*1 This also includes states where processing is performed while in motion at a velocity of 0.

*2 This variable is FALSE when all composition axes in the axes group are within the in-position ranges set in the axis parameters.

*3 A CPU Unit with unit version 1.10 or later and Sysmac Studio version 1.12 or higher are required to use this variable.

6-7 Cam Tables and Cam Data Variables

The MC Function Module uses the cam profile curves that you create on the Cam Editor of the Sysmac Studio as cam tables. The cam table data is handled as cam data variables in the user program in the NJ/NX-series Controller.



- *1 Use the Synchronization menu command of the Sysmac Studio to upload and download the project.
- *2 The cam data variables that are uploaded cannot be changed on the Cam Editor. Refer to the following page for the procedure to edit a cam data variable on the computer after editing it from the user program. Also, if the project is rebuilt or the cam profile curve is changed from the Sysmac Studio, the cam data variable that was uploaded is overwritten with the cam profile curve data.
- *3 A CPU Unit with unit version 1.08 or later and Sysmac Studio version 1.09 or higher are required to use the MC_GenerateCamTable (Generate Cam Table) instruction.
- *4 "Cam definition variable" is the generic term for cam property variables and cam node variables.

Cam Table Data Flow

- Use the Sysmac Studio to download the cam profile curves that you created in the Sysmac Studio to the CPU Unit to save them as cam tables in the non-volatile memory in the CPU Unit. When you upload a cam table to the Sysmac Studio, the cam table that was saved in the non-volatile memory is uploaded.
- The cam tables that were saved in non-volatile memory are implemented as cam data variables in the main memory after you download them or when the power is turned ON.
- You can use the user program to edit cam data variables and cam definition variables in the main memory. Refer to 9-2-5 Cam Tables for information on cam data variables and cam definition variables.
- The MC_GenerateCamTable (Generate Cam Table) instruction in the user program can overwrite the cam data variable in main memory according to the value of the cam definition variable.
- The motion control instruction MC_SaveCamTable saves the cam data variables in the main memory to non-volatile memory.


- You can upload the cam definition variable that were created in the Cam Data Settings of the Sysmac Studio even after the variable is changed in the user program. If the cam definition variable was created as a user-defined variable, you cannot upload it after it is changed in the user program.
- Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504-E1-10 or later) for information on creating and transferring the cam definition variable in the Sysmac Studio.
- For details on the MC_GenerateCamTable (Generate Cam Table) instruction and MC_SaveCamTable instruction, refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).
- You can upload and download cam tables regardless of the operating mode of the CPU Unit mode or the status of the MC Function Module. You cannot upload cam data, download cam data, start online operation, perform online editing, or start data traces during a cam table save operation. The MC_SaveCamTable instruction is not executed during online editing.
- All axes in motion will decelerate at the maximum deceleration rate and the Servo will turn OFF when you start the download process.

Precautions for Correct Use

• If you change any cam data in the user program, those changes are lost and the cam table in non-volatile memory is restored if you restart the power or download cam data from the Sysmac Studio. Also, you cannot upload the data in the main memory from the Sysmac Studio.

Editing a Cam Data Variable on the Computer after Editing It from the User Program

If you edit or overwrite a cam data variable from the user program and then use the MC_SaveCamTable instruction to save the cam table to non-volatile memory, you cannot edit the data with the Cam Editor of the Sysmac Studio. This section describes how to use spreadsheet software to edit the data and then use it as a cam table.



* Use the Synchronization menu command of the Sysmac Studio to upload and download the project.

Saving a Cam Table from Non-volatile Memory to a CSV File

- Right-click a cam profile that you edited in the Cam Data Settings of the Sysmac Studio and select *Transfer Cam Table [Controller to File]* from the menu.
- The Save Dialog Box is displayed. Enter the file save location and file name, and then click the **Save** Button.

Editing CSV Files

• Use spreadsheet software or other CSV-compatible software to edit the CSV file.

• Transferring the CSV File to the CPU Unit

- Right-click the cam profile to download and select *Transfer Cam Table [File to Controller]* from the menu.
- The Open File Dialog Box is displayed. Specify the file to transfer, and then click the OK Button.
- To enable the cam table that you transferred, reset the Controller or cycle the power supply to the Controller after the cam table is transferred.

Precautions for Correct Use

- Synchronize the data with the Controller before you transfer a cam table from a file to the Controller.
- If you transfer the cam table to the Controller during a synchronization operation after you transfer a cam table from a file to the Controller, the cam table in the Controller is replaced with the data in the Cam Data Settings. Either transfer the cam data from the file to the Controller again, or do not include the Cam Data Settings in the synchronization data.

You can also export the Cam Data Settings that were entered from the Cam Editor to a CSV file. Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for information on the Cam Data Settings and the export procedure.


Cam Profile Curve Names

When a cam profile is created in the Sysmac Studio, *CamProfile0* is used as the default name. Each time you create another cam profile, the number on the end of the name is incremented. You can change the name of any cam profile as required from the Sysmac Studio.

The cam profile names that are set on the Sysmac Studio are used as the cam table names.

Specifying Cam Tables in the User Program

In the user program, the cam table name is specified for the in-out variable *CamTable* in motion control instructions.



6-8 **Programming Motion Controls**

Place motion control instructions in the user program of the NJ/NX-series Controller to perform motion control. Programs that contain motion control instructions are called motion control programs.

Precautions for Correct Use

- You can set and program up to 256 axes on the Sysmac Studio for any model of CPU Unit. You cannot download a project to the CPU Unit if the project contains more than the maximum number of controlled axes for that CPU Unit.
- When you reuse a project, make sure that the maximum number of control axes for the CPU Unit model is not exceeded.
- Even axes that are set as unused axes are included in the number of control axes.

Refer to the *NJ/NX-series CPU Unit Software User's Manual* (Cat. No. W501) for details on programming.


This section gives the procedure to create a program in an existing project on the Sysmac Studio.

1 Starting the Sysmac Studio

Start the Sysmac Studio and open the project.

2 Adding a Program


Right-click **Programs** in the Multiview Explorer and select *Multipart Ladder* or *Structured Text* from the Add Menu.




A program is added to the Multiview Explorer.

3 Editing the Program

Right-click a section in the new program and select *Edit* from the menu. The Program Edit Tab Page is displayed.



Select the required instructions from the Toolbox and enter the program.



Refer to the *NJ/NX-series CPU Unit Software User's Manual* (Cat. No. W501) for details on programming.


Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for specific procedures.

6-9 Creating Cam Tables


This section will explain how to use the Cam Editor of the Sysmac Studio to create a cam table. Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for details on the Cam Editor.

Adding a Cam Profile

Right-click **Cam Data Settings** in the Multiview Explorer and select **CamProfile (NJ Series)** from the Add Menu.



A cam profile is added to the Multiview Explorer. You can change the name of the cam profile as required from the default name of *CamProfile0*.



2 Editing the Cam Profile

Right-click the cam profile in the Multiview Explorer and select *Edit* from the menu.

Billsymmac Studio Rife Ték Vere Insert Project Controller Simulation Tools Help	
Wen Hoyach Configurations and Setup Wen Hoyach With Hoyach With Hoyach With Hoyach Wit	Tadaa

The Cam Profile Edit Tab Page is displayed.

	nulation Iools Help	
X 単単立 ウイ 目 日	. X 區 A 🛛 R 🔺 X 8 🖗 5 1 0	
Nee Poject	Configurations and Setup Configurations Configurations	Todow CCar sard> Image: Constant of the same state st

Make the settings and enter the cam profile.

Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for specific procedures.

Manual Operation

This section describes manual operation when the MC Function Module is used together with an OMRON G5-series Servo Drive.

Outline		7-2
Turning	g ON the Servo	7-3
7-2-1	Turning ON the Servo	.7-3
7-2-2	Setting Axis Parameters	.7-4
7-2-3	Programming Example	.7-4
Joggin	g	7-5
7-3-1	Jogging Procedure	.7-5
7-3-2	Setting Axis Parameters	.7-6
7-3-3	Setting Example for Input Variables	.7-6
7-3-4	Programming Example	.7-7
	Turning 7-2-1 7-2-2 7-2-3 Joggin 7-3-1 7-3-2 7-3-3	 7-2-2 Setting Axis Parameters 7-2-3 Programming Example Jogging 7-3-1 Jogging Procedure 7-3-2 Setting Axis Parameters 7-3-3 Setting Example for Input Variables

7-1 Outline

This section describes how to combine the MC Function Module and OMRON G5-series Servo Drives together and use motion control instructions from the user program to perform manual operations.

The motion control instructions for manual operation are MC_Power and MC_MoveJog. MC_Power changes the Servo Drive to the Servo ON state and MC_MoveJog performs jogging.

内

Precautions for Correct Use

You must set the axes to perform manual operation. Refer to *Section 3 Configuring Axes and Axes Groups* for details on how to set axes.




Additional Information

- Use the Sysmac Studio if you want to perform manual operation without programming. Refer to 4-3 Checking Motor Operation for information on how to use the Sysmac Studio to perform manual operation.
- Refer to *Section 6 Motion Control Programming* for information on how to create user programs.

7-2 Turning ON the Servo

You can turn the Servo ON or OFF to enable or disable sending operation commands to the Servo Drive. The MC_Power (Power Servo) motion control instruction is used.



Specify the axis to move with the *Axis* in-out variable. Change the *Enable* input variable for MC_Power to TRUE to turn ON the Servo. Change *Enable* to FALSE to turn OFF the Servo.

Precautions for Correct Use

- If you change *Enable* to FALSE while the axis is moving, the command stops immediately and all motion control instructions for that axis are disabled.
- If you use an NX-series Pulse Output Unit, you must provide a separate means to turn the power supply to the motor drive ON and OFF. Refer to the NX-series Position Interface Units User's Manual (Cat. No. W524) for details.

Additional Information

If an OMRON G5-series Servomotor with an absolute encoder or if an OMRON G5-series Linear Motor Type with an absolute external scale is used, home is defined when the *Enable* input variable to the MC_Power instruction changes to TRUE.

Version Information

For a CPU Unit with version 1.10 or later, if an OMRON G5-series Servomotor with an absolute encoder or if an OMRON G5-series Linear Motor Type with an absolute external scale is used, home is also defined when EtherCAT process data communications change from a non-established to an established state, in addition to the step shown in the above Additional Information.

7-2-1 Turning ON the Servo

- Adding and Setting an AxisAdd and set an axis from the Sysmac Studio. For details, refer to *3-2-2 Setting Procedure*.
- 2 Setting Axis Parameters

Set the axis parameters from the Sysmac Studio. For details, refer to 3-2-2 Setting Procedure.

7

3 Writing the User Program

Create the user program from the Sysmac Studio. For details, refer to 6-8 Programming Motion Controls.

4 Downloading Axis Parameters and the User Program

Download the axis parameters and user program to the CPU Unit. Use the Synchronization menu command of the Sysmac Studio to download the project to the CPU Unit. For details, refer to *3-2-2 Setting Procedure*.

5 Executing the User Program

Execute the user program and change the *Enable* input variable for MC_Power to TRUE. The Servo Drive will change to the Servo ON state.

7-2-2 Setting Axis Parameters

Only the following axis parameter settings are required if you want only to change to the Servo ON state. The following table provides examples of the settings.

Parameter name	Setting
Axis Variable Name	Axis1 ^{*1}
Axis Number	1*2
Axis Use	Used axis
Axis Type	Servo axis
Input Device/Output Device	1 ^{*3}

*1 If there is more than one axis, a different variable name is set for each axis.

*2 If there is more than one axis, a different value is set for each axis.


*3 Set the node address to the same value as the node address that is set on the Servo Drive. If there is more than one axis, a different value is set for each axis.

Additional Information

If the OMRON G5-series Servo Drive is connected properly, you can use the network scan function of the Sysmac Studio to automatically set all axis parameters not listed in the previous table.


7-2-3 Programming Example

The following sample programming turns the Servo ON and OFF for an axis named *Axis1* based on the value of bit A.



For details on the MC_Power (Power Servo) instruction, refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

7-3 Jogging



Use the motion control instruction MC_MoveJog for jogging.

Specify the axis to jog with the *Axis* in-out variable. Change the *PositiveEnable* input variable to TRUE to start the axis with the specified positive *Velocity* (Target Velocity) and *Acceleration* (Acceleration Rate). Change *PositiveEnable* to FALSE to decelerate and stop the axis at the specified *Deceleration* (Deceleration Rate).

Similarly, if you change the *NegativeEnable* input variable to TRUE, the axis will start in the negative direction. Change *NegativeEnable* to FALSE to stop the axis. You can perform jogging even if the home has not yet been defined.

7-3-1 Jogging Procedure

- Adding and Setting an Axis
 Add and set an axis from the Sysmac Studio. For details, refer to 3-2-2 Setting Procedure.
- **2** Setting Axis Parameters

Set the axis parameters from the Sysmac Studio. For details, refer to 3-2-2 Setting Procedure.

3 Writing the User Program

Create the user program from the Sysmac Studio. For details, refer to 6-8 Programming Motion Controls.

4 Downloading Axis Parameters and the User Program

Download the axis parameters and user program to the CPU Unit. Use the Synchronization menu command of the Sysmac Studio to download the project to the CPU Unit. For details, refer *3-2-2 Setting Procedure.*


5 Executing the User Program

Execute the user program and change the *Enable* input variable for MC_Power to TRUE to change the Servo Drive to the Servo ON state. Change either the *PositiveEnable* or *NegativeEnable* input variable for the MC_MoveJog instruction to TRUE to jog.

7

7-3-2 Setting Axis Parameters

Set the following axis parameters if you want to jog when home is not defined. The following setting example is for a one-axis device.



20 bits = 1,048,576

Parameter name	Setting
Axis Variable Name	Axis1 ^{*1}
Axis Number	1*2
Enabled Axes	Used axis
Axis Use	Servo axis
Input Device/Output Device	1*3
Command Pulse Count Per Motor Rota- tion	1,048,576 ^{*4}
Work Travel Distance Per Motor Rotation	10,000*4
Software Limits	Enabled for actual position
Unit of Display	μm
Count Mode	Linear Mode
Maximum Velocity	500,000 ^{*5}
Maximum Jog Velocity	50,000 ^{*6}
Maximum Acceleration	5,000,000*7
Maximum Deceleration	5,000,000 ^{*7}

*1 If there is more than one axis, a different variable name is set for each axis.

- *2 If there is more than one axis, a different value is set for each axis.
- *3 Set the node address to the same value as the node address that is set on the Servo Drive. If there is more than one axis, a different value is set for each axis.
- *4 The position command unit will be 1 μ m.
- *5 The maximum velocity will be 3,000 r/min = 30 m/min = 0.5 m/s = 500,000 μ m/s.
- *6 The maximum jog velocity will be 10% of the maximum velocity, i.e., 0.05 m/s = 50,000 μ m/s.
- *7 The maximum acceleration and the maximum deceleration are 5 m/s². The acceleration time to the maximum velocity (3,000 r/min) is 0.1 s.

7-3-3 Setting Example for Input Variables

This section describes the settings for the MC_MoveJog input variables *Velocity* (Target Velocity), *Acceleration* (Acceleration Rate), and *Deceleration* (Deceleration Rate).

- For example, set Velocity to 30,000 to jog at a velocity of 0.03 m/s (30,000 μm/s).
- Set Acceleration and Deceleration to 3,000,000 to accelerate and decelerate at 3 m/s² (3,000,000 μ m/s²).

7-3-4 Programming Example

The following programming example jogs an axis named *Axis1* in the positive direction for the value of bit A and in the negative direction for the value of bit B.

		MC_MoveJog_instance							
		MC_MoveJog							
А	Axis1 🗕	Axis ———	Axis A						
		PositiveEnable	Busy 🗕						
	в 🗕	NegativeEnable	CommandAborted						
	Velo1	Velocity	Error						
	Acce1	Acceleration	ErrorID						
	Dece1 -	Deceleration							

In this example, *Velocity* (Target Velocity) is *Velo1*, *Acceleration* is *Acce1*, and *Deceleration* is *Dece1*. Set the values for each variable in the user program in advance to operate the axis with the example input variable settings.

- Velo1 = 30,000
- Acce1 = 3,000,000
- Dece1 = 3,000,000

For details on the MC_MoveJog (Jog) instruction, refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

7

Homing


This section describes homing.

8-1	Outline	9
8-2	Homin	g Procedure
	8-2-1	Setting Homing Parameters
	8-2-2	Monitoring the Homing Operation8-12
8-3	Homin	g Operation
8-4	Homin	g with an Absolute Encoder 8-14
	8-4-1	Outline of Function
	8-4-2	Setting Procedure
8-5	High-s	peed Homing

8-1 Outline

This section describes the operations that are performed when the MC Function Module is combined with an OMRON G5-series Servo Drive.

To perform positioning to absolute positions in a positioning system, you must first define the home. For example, if you want to perform positioning to the position (axis 1, axis 2) = (100 mm, 200 mm) in the XY plane shown below, you must define the position of home (0,0). The process of defining home is called homing.



In the MC Function Module, use the motion control instruction MC_Home or MC_HomeWithParameter to define home.

Name	Description
Homing	Home is defined by actually moving the motor and using the limit sensors, home prox- imity sensor, and home input signal to determine the position of home.
	Use a proximity sensor or the encoder's Z phase signal as the home input signal.

Precautions for Correct Use

- The defined home is lost in the following situations.
 - When MC_SetPosition is executed.
 - When an overflow or underflow occurs in Linear Mode.
 - When homing is started.
 - The control state of EtherCAT communications is not Operational state.
- Some of the homing functions are restricted for the NX-series Position Interface Units. Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for details.

Additional Information

If an OMRON G5-series Servomotor with an absolute encoder or if an OMRON G5-series Linear Motor Type with an absolute external scale is used, home is defined when the *Enable* input variable to the MC_Power instruction changes to TRUE.

Version Information

For a CPU Unit with version 1.10 or later, if an OMRON G5-series Servomotor with an absolute encoder or if an OMRON G5-series Linear Motor Type with an absolute external scale is used, home is also defined when EtherCAT process data communications change from a non-established to an established state, in addition to the step shown in the above Additional Information.

The MC_MoveZeroPosition (High-speed Home) instruction is also provided to perform positioning to home as defined for the previously described method.

Name	Description
High-speed Homing	The axis returns to home using an absolute position of 0 as the target position.

The MC Function Module can operate the motor even when home is undefined (excluding MC_MoveZeroPosition).

Function	Operation						
Jogging and velocity control	If home is not defined, the position at startup is defined as 0 to control movement.						
High-speed homing	High-speed homing cannot be used.						
	If it is used, an instruction error will occur.						
Positioning	If home is not defined, the position at startup is defined as 0 to control movement.						
Interrupt feeding							
Starting cam operation							
Starting gear operation							
Synchronous positioning							
Combining axes							
Torque control							
Zone monitoring							
Linear interpolation	Interpolation cannot be used.						
Circular interpolation	If it is used, an instruction error will occur.						

Additional Information

Software limits are not valid when home is not defined.

Changes in the home definition status for operations and events are listed in the following table.

Operation or event	Condition for change	Home definition status change		
Servo turned ON or axis	Incremental encoder	No change		
enabled	When absolute data is read normally from the absolute encoder	Home is defined.		
	When absolute data cannot be read from the absolute encoder	Home is undefined.		
Changing the current position	When starting	Home is undefined.		
Homing	When starting	Home is undefined.		
	When ending	Home is defined.		
Overflows and underflows	When overflow or underflow occurs	Home is undefined.		

8



Precautions for Correct Use

- For a virtual axis, home is always defined with a zero position preset. The setting of the Homing Method axis parameter is ignored.
- The positive drive prohibit input (POT), negative drive prohibit input (NOT), and home proximity input (DEC) of the Servo Drive are used by the MC Function Module as the positive limit input, negative limit input, and home proximity input. Make sure that the signal widths for all of these input signals are long enough for the Servo Drive to detect them and longer than the control period of the MC Function Module. If the input signal widths are shorter than the control period, the MC Function Module may not be able to detect the input signals, resulting in incorrect operation.
- You must set the Servo Drive parameters for each Servo Drive input signal. Refer to the manual for your Servo Drive and the appendices and make the proper settings.

8-2 Homing Procedure

This section describes the procedure to perform homing.

- **1** Adding and Setting an Axis Add and set an axis from the Sysmac Studio.
- **2** Setting Axis Parameters

Set the homing method with the homing parameters.

3 Writing the User Program

Create the user program from the Sysmac Studio. For details, refer to 6-8 Programming Motion Controls.

4 Downloading Axis Parameters and the User Program

Download the axis parameters and user program to the CPU Unit. Use the Synchronization menu command of the Sysmac Studio to download the project to the CPU Unit. For details, refer to *3-2-2 Setting Procedure*.


5 Executing the User Program

Execute the user program and change the *Enable* input variable for MC_Power to TRUE to change the Servo Drive to the Servo ON state. Homing is performed when the *Execute* input variable to the MC_Home or MC_HomeWithParameter instruction changes to TRUE.

8-2-1 Setting Homing Parameters

Set the homing parameters to specify the homing procedure. Set the homing parameters from the Sysmac Studio.

Parameter name	Description
Homing Method	Set the homing operation.
Home Input Signal	Select the input to use for the home input signal.
Homing Start Direction	Set the start direction for when homing is started.
Home Input Detection Direction	Set the home input detection direction for homing.
Operation Selection at Positive Limit Input	Set the stopping method when the positive limit input turns ON during homing.
Operation Selection at Negative Limit Input	Set the stopping method when the negative limit input turns ON during homing.
Homing Velocity	Set the homing velocity. (Unit: command units/s)
Homing Approach Velocity	Set the velocity to use after the home proximity input turns ON. (Unit: command units/s)
Homing Acceleration	Set the acceleration rate for homing. If the homing acceleration is set to 0, the homing velocity or other target velocity is used without any acceleration. (Unit: command units/s ²)
Homing Deceleration	Set the deceleration rate for homing. If the homing deceleration is set to 0, the homing approach velocity or other target velocity is used without any deceleration. (Unit: command units/ s^2)
Homing Jerk	Set the jerk for homing. Set 0 for no jerk. (Unit: command units/s ³)
Home Input Mask Distance	Set the home input feeding distance when you set the Homing Opera- tion Mode to the proximity reverse turn/home input mask distance. (Unit: command units)



The homing parameters are described individually below.

Homing Methods

You can select any of the ten operations to define home.

- · Proximity reverse turn/home proximity input OFF
- · Proximity reverse turn/home proximity input ON
- · Home proximity input OFF
- · Home proximity input ON
- · Limit input OFF
- · Proximity reverse turn/home input mask distance
- · Limit inputs only
- · Proximity reverse turn/holding time
- · No home proximity input/holding home input
- · Zero position preset

The following tables shows the homing parameters that are used for each Homing Operation Mode.

(Yes: Parameter is used, No: Parameter is not used.)

		Homing parameters													
Homing Operation Mode	Home Input Signal	Homing Start Direction	Home Input Detection Direction	Operation Selection at Positive Limit Input	Operation Selection at Negative Limit Input	Homing Velocity	Homing Approach Velocity	Homing Acceleration	Homing Deceleration	Homing Jerk	Home Input Mask Distance	Home Position Offset	Homing Holding Time	Homing Compensation Value	Homing Compensation Velocity
Proximity reverse turn/home proximity input OFF	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	No	Yes	Yes
Proximity reverse turn/home proximity input ON	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	No	Yes	Yes
Home proximity input OFF	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	No	Yes	Yes
Home proximity input ON	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	No	Yes	Yes
Limit input OFF	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	No	Yes	Yes
Proximity reverse turn/home input mask distance	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes
Limit inputs only	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	No	Yes	Yes
Proximity reverse turn/holding time	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes
No home proximity input/holding home input	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	No	Yes	Yes
Zero position preset	No	No	No	No	No	No	No	No	No	No	No	Yes	No	No	No

For details on the Homing Operation Modes, refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Additional Information

For an OMRON G5-series Linear Motor Type, the Z-phase input cannot be mapped to a PDO. Therefore, if you use the No Home Proximity Input/Holding Home Input Homing Operation Mode, which can use a Z-phase input mapped to a PDO, do not select the Z-phase input for the home input signal.

Home Input Signal

In a Homing Method that uses a home input signal, select either the Z phase signal of the Servo Drive or an external home signal as the signal to define home.

Precautions for Correct Use


This parameter can be used to set a home input signal only when you are connected to an OMRON G5-series Servo Drive.

Homing Start Direction

Select the direction (positive or negative) in which the axis starts moving when homing is started. If homing starts while the home proximity signal is ON in a Homing Operation Mode that includes reversal operation for a proximity reverse turn, the axis starts motion in the direction opposite to the home input detection direction (regardless of the setting of the homing start direction).

There are four Homing Operation Modes that include reversal operation for a proximity reverse turn. These are listed below.


- 0: Proximity reverse turn/home proximity input OFF
- 1: Proximity reverse turn/home proximity input ON
- 9: Proximity reverse turn/home input mask distance
- 12: Proximity reverse turn/holding time



- (1) and (3): The home proximity signal is OFF, so the axis starts moving in the homing start direction.
- (2): The home proximity signal is ON, so the axis starts moving in the direction opposite to the home input detection direction.

Homing start direction: Negative

Home input detection direction: Negative



- (1) and (3): The home proximity signal is OFF, so the axis starts moving in the homing start direction.
- (2): The home proximity signal is ON, so the axis starts moving in the direction opposite to the home input detection direction.


Home Input Detection Direction

Select the direction (positive or negative) in which to detect home. Refer to *Homing Start Direction* on page 8-8 for the relationship between the home detection method and the initial direction when homing starts.


Operation Selection at Positive Limit Input and Operation Selection at Negative Limit Input

• Select the operation when the axis reaches a limit input in the operating direction during homing: reverse the axis and continue with homing, or do not reverse the axis, create an error, and stop the axis. To reverse the axis, also select the stopping method.

• An error occurs and the axis stops if the axis is set to reverse direction, and the limit signal in the home input detection direction turns ON when traveling at the homing approach velocity. However, if the Homing Operation Mode is 13 (no home proximity input/holding home input), which does not use proximity signals, no error will occur and the axis will not stop.



 An error occurs and the axis stops if the axis is set to reverse direction for the limit input operation in both directions and home cannot be detected after moving from the limit input opposite to the home input detection direction to the other limit input.



Homing Velocity

Set the homing velocity in command units/s.

Homing Approach Velocity

Set the velocity after the home proximity input turns ON in command units per second (command units/s).

Homing Acceleration

Set the homing acceleration rate in command units per seconds squared (command units/s²). If the homing acceleration is set to 0, the homing velocity or other target velocity is used without any acceleration.

Homing Deceleration


Set the homing deceleration rate in command units per seconds squared (command units/s²). If the homing deceleration is set to 0, the homing approach velocity or other target velocity is used without any deceleration.

Homing Jerk

Set the homing jerk in command units per seconds cubed (command units/s³). If the homing jerk is set to 0, acceleration and deceleration are performed without jerk.

Home Input Mask Distance

Set the home input mask distance in command units when you set Homing Operation Mode 9 (proximity reverse turn/home input mask distance). This is the distance from when the home proximity input signal (i.e., from when deceleration starts) until home is defined.




Home Offset

After home is defined, the operation for the homing compensation value is completed if a homing compensation value is set, and then the actual value is preset to the set value.

This means that you can set home to any specified value rather than to 0. For systems with absolute encoders, also the absolute encoder home offset value is calculated and saved to the battery-backup memory in the CPU Unit.

Homing Holding Time

Set the holding time when you set homing operation mode 12 (proximity reverse turn/holding time). This is the time from when the home proximity input signal (i.e., from when deceleration starts) until home is defined.



Homing Compensation Value

After home is defined, relative positioning is performed at the set value to adjust the position of home. This homing compensation is performed at the homing compensation velocity.

Adjusting the workpiece is sometimes difficult after home is defined. The homing compensation can be used to fine-tune the position of home after it is determined. This is useful when you cannot easily replace the home proximity sensor or when home has moved after a motor replacement.

Homing Compensation Velocity

If you set a homing compensation value, set the velocity to use for the compensation in command units per second (command units/s).

8-2-2 Monitoring the Homing Operation

You can read Axis Variables in the user program to monitor the homing status and the input signal status.

In the descriptions, a variable name $_MC_AX[*]$ is used as an example, but the same information applies to $_MC1_AX[*]$ and $_MC2_AX[*]$.

Variable name	Data type	Meaning	Function
_MC_AX[0-255].Status.Homing	BOOL	Homing	TRUE when homing for the MC_Home or MC_HomeWithParameter instruction.
_MC_AX[0-255].Dtails.Homed	BOOL	Home	TRUE when home is defined.
		Defined	FALSE: Home not defined.
			TRUE: Home is defined
_MC_AX[0-255].Dtails.InHome	BOOL	In Home Position	TRUE when the axis is in the range for home. It gives an AND of the following conditions.
			Home defined. Actual current position is within the zero position range of home. This variable is also TRUE when the zero position is passed by while the axis is moving for a command.
_MC_AX[0-255].DrvStatus.P_OT	BOOL	Positive Limit Input	TRUE when the positive limit input is enabled.
_MC_AX[0-255].DrvStatus.N_OT	BOOL	Negative Limit Input	TRUE when the negative limit input is enabled.
_MC_AX[0-255].DrvSta- tus.HomeSw	BOOL	Home Prox- imity Input	TRUE when the home proximity input is enabled.
_MC_AX[0-255].DrvStatus.Home	BOOL	Home Input	TRUE when the home input is enabled.

8-3 Homing Operation

Select the home definition method based on the configuration of the positioning system and its purpose. There are 10 Homing Operation Modes supported by the MC Function Module. You can also fine-tune the home that is detected with a homing compensation value.

Additional Information


- The most suitable mode depends on the configuration of the positioning system and the application. In linear mode (finite length), Proximity Reverse Turn and Home Proximity Input OFF is normally used if there is a home proximity sensor, positive limit input, and negative limit input.
- The override factors are ignored for homing.
- The in-position check will follow the in-position check settings only for the completion of the home definition and homing compensation motions.
- Buffering and blending are not performed if you use multi-execution of other motion control instructions during homing.

For details on homing, refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

8-4 Homing with an Absolute Encoder

This section describes how to use the absolute encoder of the G5-series Servo Drive with built-in Ether-Cat communications.

If you use an absolute encoder, the absolute data can be retained by the battery backup in the encoder even when the power supply to the CPU Unit is turned OFF. When you execute the MC_Power (Power Servo) instruction, the position is determined by reading the actual position from the absolute encoder. Unlike when using an incremental encoder, after home is defined, you do not need to perform the homing operation again.



Precautions for Correct Use

- If you use an absolute encoder, connect a battery to the CPU Unit and an absolute encoder backup battery to the Servo Drive.
- Always execute the MC_Home or MC_HomeWithParameter instruction to define home when you use the absolute encoder for the first time, after you replace the motor, when the battery in the absolute encoder expires, or at any other time when the absolute value data is lost. After home is defined, cycle the power to the Servo Drive. After you complete these steps, home is defined when the *Enable* input variable to the MC_Power instruction changes to TRUE. For a CPU Unit with version 1.10 or later, home is also defined when EtherCAT process data communications change from a non-established to an established state, in addition to the previously mentioned step.
- If there is an error for the Battery in the CPU Unit when the power supply to the Controller is turned ON, an Absolute Encoder Home Offset Read Error (event code:14600000 hex) occurs. You can use the ResetMCError instruction to reset the error and turn ON the Servo.

For a CPU Unit with unit version 1.09 or earlier, when the error is reset and the Servo is turned ON, home is defined with an absolute encoder home offset value of 0.

For a CPU Unit with unit version 1.10 or later, home will be left undefined until it is defined by the MC_Home or MC_HomeWithParameter instruction executed after error reset.

In order to operate with correct positions, execute the MC_Home or MC_HomeWithParameter instruction to define the correct home position. If the power supply to the Controller is turned OFF, home will become undefined.

Additional Information

If you use a G5-series Linear Motor Type, you can set the absolute encoder home position. If you use a Linear Motor Type, observe the following points when reading this section.

- A Linear Motor Type does not use an encoder. It uses an external scale, which functions in a similar way.
- "Absolute encoder" in this section means "absolute external scale" for a Linear Motor Type.
- An absolute external scale does not have the rotation data of an absolute encoder. Any rotation data setting procedures that are required for an absolute encoder and not required. A battery to back up the rotation data is also not required.
- Refer to the G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications Linear Motor Type User's Manual (Cat. No. 1577) for the specifications of Linear Motor Type.

8-4-1 Outline of Function

To define home with an absolute encoder system, the absolute encoder offset compensation is performed when the MC_Power (Power Servo) instruction is executed.

For a CPU Unit with version 1.10 or later, home is also defined when EtherCAT process data communications change from a non-established to an established state, in addition to the previously mentioned step.

Home can also be defined by performing a homing operation in the same way as for an incremental encoder. After home is defined, the difference between the command position and the absolute value data read from absolute encoder is saved to the battery-backup memory in the CPU Unit as the absolute encoder home offset.

The absolute encoder home offset is also set to the difference (i.e., the offset) between the command position after defining home and the absolute value when the MC_Home or MC_HomeWithParameter instruction is executed. The MC Function Module automatically saves the absolute encoder home offset to the battery-backup memory in the CPU Unit. You do not have to perform a save operation from the Sysmac Studio.

Precautions for Correct Use

- When absolute encoders are used, the absolute encoder home offset for each axis is saved to the battery-backup memory along with the axis number. The saved offset is lost if the axis number is changed. If you change the axis number, set the Homing Settings again.
- If you replace the CPU Unit or the Battery in the CPU Unit, make sure home is defined and back up the battery-backup memory before you start the replacement procedure. This ensures that the absolute encoder home offset is backed up.
- You can restore the backed up data after finishing the replacement procedure to use the home that was previously defined.
- Use the Sysmac Studio to back up and restore the data.
 Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for specific procedures.

Applicable Servomotors

The following table lists the Servomotors that use the absolute encoder home setting.

Manufacturer	Series	Servo Drive	Servomotor
OMRON	G5 Series	R88D-KN□□□-ECT	R88M-KS R88M-KT R88M-KC
		R88D-KN□□□-ECT-L	R88L-EC

Precautions for Correct Use

You cannot use this absolute encoder for an NX-series Pulse Output Unit.

Connecting the Servo Drive

Connect the Servo Drive correctly according to information in the NJ/NX-series CPU Unit Built-in Ether-CAT Port User's Manual (Cat. No. W505).

8-4-2 Setting Procedure

This section describes the procedure to set the home of an absolute encoder system.

1 Absolute Encoder Setup

Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for the setup procedures.

2 Setting Axis Parameters

Set the Encoder Type in the Position Count Settings of the axis parameters in the MC Function Module to 1 (absolute encoder (ABS)). For details, refer to *5-2-7 Position Count Settings*.

3 Execute Homing

Execute homing. Set the Homing Method in the Homing Settings axis parameters of the MC Function Module. After home is defined, the difference between the command position and the absolute value data read from the absolute encoder is automatically saved to the battery-backup memory in the CPU Unit as the absolute encoder home offset.

Absolute Encoder Setup

The absolute encoder must be set up the first time it is used, to initialize the rotation data to 0, when the absolute encoder is stored for an extended period of time without a battery connected, etc.

Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for detailed setup procedures.

Precautions for Correct Use


After the absolute encoder is set up, the power supply to the OMRON G5-series Servo Drive must be cycled. When setup processing for the absolute encoder is completed, an Absolute Value Clear Error (A27.1) will occur in the Servo Drive. Cycle the control power supply to the Servo Drive to clear this error and complete the absolute encoder setup procedure.

Using an Absolute Encoder in Rotary Mode

If you set the Count Mode axis parameter to Rotary Mode, the actual position will be a ring-shaped counter in the range between the modulo maximum position setting value and the modulo minimum position setting value. When using an absolute encoder in Rotary Mode, the absolute encoder home offset is automatically calculated and updated in the MC Function Module each motion control period. The updated absolute encoder home offset is automatically saved to the battery-backup memory in the CPU Unit when the power supply to the Controller is turned OFF. This enables recovering the actual position of a rotating axis from the absolute encoder the next time power is turned ON even if the power to the CPU Unit or Servo Drive is turned OFF.

8-5 High-speed Homing

This function performs quick positioning to the home. Home is defined in advance. Use the MC_MoveZeroPosition (High-speed Homing) instruction and specify the target velocity, acceleration rate, deceleration rate, and jerk. If you execute this instruction when home is not defined an instruction error will occur.



Additional Information

For details on the MC_MoveZeroPosition (High-speed Homing) instruction, refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

8 Homing

9

Motion Control Functions

This section describes the motion control functions that are used when connected to OMRON G5-series Servo Drives with built-in EtherCAT communications.

9-1	Single	-axis Position Control	
	9-1-1	Outline of Operation	
	9-1-2	Absolute Positioning	
	9-1-3	Relative Positioning	
	9-1-4	Interrupt Feeding	
	9-1-5	Cyclic Synchronous Positioning	
	9-1-6	Stopping	
	9-1-7	Override Factors	
9-2	Single	-axis Synchronized Control	9-13
	9-2-1	Overview of Synchronized Control	
	9-2-2	Gear Operation	
	9-2-3	Positioning Gear Operation	
	9-2-4	Cam Operation	
	9-2-5	Cam Tables	
	9-2-6	Synchronous Positioning	
	9-2-7	Combining Axes	
	9-2-8	Master Axis Phase Shift	
	9-2-9	Slave Axis Position Compensation	
	9-2-10	Achieving Synchronized Control in Multi-motion	
9-3	Single	-axis Velocity Control	9-29
	9-3-1	Velocity Control	
	9-3-2	Cyclic Synchronous Velocity Control	
9-4	Single	-axis Torque Control	9-31
9-5	Comm	on Functions for Single-axis Control	9-32
	9-5-1	Positions	
	9-5-2	Velocity	
	9-5-3	Acceleration and Deceleration	
	9-5-4	Jerk	
	9-5-5	Specifying the Operation Direction	
	9-5-6	Re-executing Motion Control Instructions	
	9-5-7	Multi-execution of Motion Control Instructions (Buffer Mode)	

9-6	Multi-a	xes Coordinated Control9-53
	9-6-1	Outline of Operation
	9-6-2	Linear Interpolation
	9-6-3	Circular Interpolation
	9-6-4	Axes Group Cyclic Synchronous Positioning9-57
	9-6-5	Stopping Under Multi-axes Coordinated Control
	9-6-6	Overrides for Multi-axes Coordinated Control
9-7	Comme	on Functions for Multi-axes Coordinated Control
	9-7-1	Velocity Under Multi-axes Coordinated Control9-61
	9-7-2	Acceleration and Deceleration Under Multi-axes Coordinated Control9-62
	9-7-3	Jerk for Multi-axes Coordinated Control9-63
	9-7-4	Re-executing Motion Control Instructions for Multi-axes
		Coordinated Control
	9-7-5	Multi-execution (Buffer Mode) of Motion Control Instructions for Multi-axes
		Coordinated Control
9-8	Other F	Functions
	9-8-1	Changing the Current Position9-73
	9-8-2	Torque Limit
	9-8-3	Latching
	9-8-4	Zone Monitoring
	9-8-5	Software Limits
	9-8-6	Following Error Monitoring
	9-8-7	Following Error Counter Reset9-78
	9-8-7 9-8-8	Following Error Counter Reset 9-78 Axis Following Error Monitoring 9-78
		·
	9-8-8	Axis Following Error Monitoring
	9-8-8 9-8-9	Axis Following Error Monitoring 9-78 In-position Check 9-79


9-1 Single-axis Position Control

The MC Function Module can be connected to OMRON G5-series Servo Drives with built-in EtherCAT communications to implement position control, velocity control, and torque control. This section describes positioning operation for single axes.

Some of the functions of the MC Function Module are different when NX-series Pulse Output Units are used. Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for details.

9-1-1 Outline of Operation

The single-axis control function of the MC Function Module consists of control for motion profile commands and synchronized control. There are three Control Modes for motion profile commands: position control, velocity control, and torque control. In synchronized control, the slave axis (i.e., the axis being controlled) operates in a synchronized relationship to the master axis, as expressed by a cam profile curve or a gear ratio. Manual operations such as jogging and homing are also supported.



Note You can use the command position or actual position as the input to the synchronization processing.

Resetting Axis Errors


If an error occurs in an axis, you can use the MC_Reset instruction to remove the error once you have eliminated the cause.

For details on resetting axis errors, refer to the MC_Reset (Reset Axis Error) instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for the differences when you use NX-series Pulse Output Units.

9-1-2 Absolute Positioning


Absolute positioning specifies the absolute coordinates of the target position in relation to home. You can perform positioning, such as shortest way positioning on a rotary table, by setting the Count Mode to Rotary Mode and specifying the operation direction.



For details, refer to the MC_MoveAbsolute (Absolute Positioning) and MC_Move (Positioning) instructions in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-1-3 Relative Positioning

Relative positioning specifies the distance from the actual position. You can specify a travel distance that exceeds the ring counter range by setting the Count Mode to Rotary Mode.



For details, refer to the MC_MoveRelative (Relative Positioning) and MC_Move (Positioning) instructions in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).


9-1-4 Interrupt Feeding

Interrupt feeding feeds the axis at the specified velocity and for the specified distance from the actual position when a trigger signal occurs.

You can also select to output an error if the trigger signal does not occur within the specified travel distance when you specify either absolute or relative positioning.


Feeding is not affected by following error. This is achieved by using the latch function of the Servo Drive to determine the actual position when the trigger signal occurs. You can also use the window function to disable trigger signals that occur outside of a specified position range. For applications such as wrapping machines, this enables feeding only on trigger signals for printed marks on films and eliminates other influences.

Motion Relative to the Actual Position



• Feeding for a Specified Distance in the Moving Direction

• Feeding for a Specified Distance in the Direction Opposite to the Moving Direction



If decelerating to a stop after a reverse turn is specified for the Operation Selection at Reversing axis parameter, an acceleration/deceleration curve is used when reversing.


For details, refer to the MC_MoveFeed (Interrupt Feeding) instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for the differences when you use NX-series Pulse Output Units.

9-1-5 Cyclic Synchronous Positioning

Cyclic synchronous positioning is used to output a target position to a specified axis each control period in the primary periodic task or a periodic task. The target position is specified as an absolute position.

You can use it to move in a specific path that you create.



For details, refer to the MC_SyncMoveAbsolute (Cyclic Synchronous Absolute Positioning) instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Version Information

A CPU Unit with unit version 1.03 or later and Sysmac Studio version 1.04 or higher are required to use cyclic synchronous positioning.

9-1-6 Stopping

Functions to stop axis operation include immediate stop input signal and limit input signals connected to the Servo Drive, stop functions of motion control instructions in the user program, and stopping due to errors.

Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for the differences when you use NX-series Pulse Output Units.

Stopping for Servo Drive Input Signals

Axis motion is stopped for the immediate stop input signal or a limit input signal from the Servo Drive. You can select the stop method with the Sysmac Studio.

• Immediate Stop Input

Stop processing in the MC Function Module is executed according to the state of the Servo Drive input signals. You can select one of the following stopping methods for the MC Function Module.

- · Immediate stop
- · Immediate stop and error reset
- · Immediate stop and Servo OFF

Precautions for Correct Use

The immediate stop input for the OMRON G5-series Servo Drive also causes an error and executes stop processes in the Servo Drive itself.

• Limit Inputs (Positive Limit Input or Negative Limit Input)

Stop processing in the MC Function Module is executed according to the state of the Servo Drive input signals. You can select one of the following stopping methods for the MC Function Module.

- · Immediate stop
- Deceleration stop
- · Immediate stop and error reset
- · Immediate stop and Servo OFF

Precautions for Correct Use

- If a limit input signal turns ON, do not execute an instruction for axis command of the axis in the same direction as the limit input signal.
- If a limit input signal is ON for any axis in an axes group, do not execute an instruction for an axes group command for that axes group.
- If the signal to decelerate to a stop is input during execution of a synchronous movement instruction that has a *Deceleration* input variable, the axis decelerates to a stop at the deceleration rate given by *Deceleration*.
- If the signal to decelerate to a stop is input during execution of a synchronous movement instruction that does not have a *Deceleration* input variable, the axis decelerates to a stop at the maximum deceleration rate that is set in the axis parameters.



Additional Information

- You must set up the Servo Drive in order to use the input signals from the Servo Drive. An OMRON G5-series Servo Drive with built-in EtherCAT communications has an immediate stop input and limit input assigned in its default settings.
- Refer to A-1 Connecting the Servo Drive for setting examples for connection to an OMRON G5-series Servo Drive.

Stopping with Motion Control Instructions

Use the MC_Stop or MC_ImmediateStop instruction to stop single-axis operation.

MC_Stop Instruction

You can specify the deceleration rate and jerk for single-axis control and synchronized control to decelerate to a stop. Specify a deceleration rate of 0 to send a command that immediately stops the Servo Drive. Other operation commands are not acknowledged while decelerating to a stop for this instruction and while the input variable *Execute* is TRUE.

MC_ImmediateStop Instruction

You can perform an immediate stop for single-axis control or synchronized control functions. You can also execute this instruction on axes that are enabled in an axes group.

For details, refer to the MC_Stop and MC_ImmediateStop instructions in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Additional Information

When the input variable *Enable* to the MC_Power (Servo ON) instruction changes to FALSE, the MC Function Module immediately stops the command value and turns OFF the Servo. When the Servo is turned OFF, the Servo Drive will operate according to the settings in the Servo Drive.

Stopping Due to Errors or Other Problems

Stopping for Errors during Single-axis Operation

When an error occurs during single-axis operation, the axis will stop immediately or decelerate to a stop depending on the error. Refer to *11-2-2 Error Descriptions* for details on the stop method for each error.

Stopping for a Software Limit

To stop for a software limit, set the Software Limits axis parameter. You can select from the following stop methods for the software limits.

- Enabled for command position. Decelerate to a stop.
- Enabled for command position. Immediate stop.
- Enabled for actual position. Decelerate to a stop.
- Enabled for actual position. Immediate stop.

Refer to 9-8-5 Software Limits for details on software limits.

• Stopping Due to Motion Control Period Exceeded Error

If motion control processing does not end within two periods, a Motion Control Period Exceeded error occurs. All axes stop immediately.

Precautions for Correct Use

When you use an NX-series CPU Unit and operate in the multi-motion, all axes in both tasks will stop immediately if a Motion Control Period Exceeded error occurs in either of the tasks. Refer to *A-5-2 Motion Control* for multi-motion.

Errors That Cause the Servo to Turn OFF

An immediate stop is performed if an error occurs that causes the Servo to turn OFF. When the Servo is turned OFF, the Servo Drive will operate according to the settings in the Servo Drive.

Stopping Due to Start of MC Test Run

All axes will decelerate to a stop at their maximum deceleration if a MC Test Run is started from the Sysmac Studio.

Stopping Due to End of MC Test Run

All axes will decelerate to a stop at their maximum deceleration if a MC Test Run is stopped from the Sysmac Studio.

- Click the Stop MC Test Run Button on the MC Test Run Tab Page of the Sysmac Studio.
- Close the MC Test Run Tab Page on the Sysmac Studio.
- Exit the Sysmac Studio.

Stopping Due to Change in CPU Unit Operating Mode


All axes will decelerate to a stop at their maximum deceleration if the CPU Unit operating mode changes.

Precautions for Correct Use

- If an error that results in deceleration to a stop occurs during execution of a synchronous movement instruction that has a *Deceleration* input variable, the axis decelerates to a stop at the deceleration rate given by *Deceleration*.
- If an error that results in deceleration to a stop occurs during execution of a synchronous movement instruction that does not have a *Deceleration* input variable, the axis decelerates to a stop at the maximum deceleration rate that is set in the axis parameters.

Additional Information

- When RUN mode changes to PROGRAM mode, any motion control instructions for current motions are aborted. The *CommandAborted* output variable from the instructions remains FALSE. The Servo remains ON even after changing to PROGRAM mode.
- If the operating mode returns to RUN mode while a deceleration stop is in progress after the operating mode changes from RUN to PROGRAM mode, the output variables from motion control instructions are cleared. The *CommandAborted* output variables from the motion control instructions therefore remain FALSE.
- The save process will continue during a save for the MC_SaveCamTable Instruction.
- The generation process will continue when generation of the cam table is in progress for the MC_GenerateCamTable (Generate Cam Table) instruction.




Stop Priorities

The priorities for each stop method are listed in the following table. If a stop with a higher priority stop method occurs while stopping, the stop method will switch to the higher priority method.

Stop method	Priority (higher numbers mean higher priority)
Immediate stop and Servo OFF	4
Immediate stop and error reset	3
Immediate stop	2
Deceleration stop	1

Example:

The following figure is an example of an immediate stop when the limit input signal is ON and the immediate stop input changes to ON during a deceleration to a stop.




9-1-7 Override Factors

You can use the MC_SetOverride instruction to set override factors for the motion of the axes that are currently in motion. The velocity override factor is set as a percentage of the target velocity. It can be set between 0% and 500%. If an override factor of 0% is set for the target velocity, operating status will continue with the axis stopped as a velocity of 0. The set override factor is read as long as the overrides are enabled. If the overrides are disabled, the override factors return to 100%. If the maximum velocity is exceeded when an override factor is changed, the maximum velocity for the axis is used.

Overriding the MC_MoveAbsolute Instruction

An example of a time chart for using the Set Override Factors instruction for the MC_MoveAbsolute (Absolute Positioning) instruction is given below.



Previous Instruction: MC_MoveAbsolute

For details, refer to the MC_SetOverride (Set Override Factors) instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-2 Single-axis Synchronized Control

This section describes the operation of synchronized control for single axes.

9-2-1 Overview of Synchronized Control

Synchronous control synchronizes the position of a slave axis with the position of a master axis. The command position or actual position of any axis can be specified for the master axis. If the command velocity for the slave axis exceeds the maximum velocity that is set in the axis parameters, the command is performed at the maximum velocity of the axis. If this occurs, any insufficient travel distance is distributed and output in the following periods.



Precautions for Correct Use


When you use an NX-series CPU Unit and operate in the multi-motion, assign the master axis and slave axis to the same task.

If you specify the master axis in a different task from the slave axis by executing the synchronized control instructions such as the MC_GearIn (Start Gear Operation) instruction or the MC_Camin (Start Cam Operation) instruction, an Illegal Master Axis Specification (event code: 54620000 hex) occurs.

Refer to *9-2-10 Achieving Synchronized Control in Multi-motion* if you desire to specify the master axis in a different task from the slave axis.

9-2-2 Gear Operation

This function specifies the gear ratio between the master axis and the slave axis and starts operation. Start gear operation with the MC_GearIn (Start Gear Operation) instruction. End synchronization with the MC_GearOut (End Gear Operation) instruction or the MC_Stop instruction.




You can set the gear ratio numerator, gear ratio denominator, position type, acceleration rate, and deceleration rate for the slave axis to operate. For the master axis, you can specify the command position, actual position, or most recent command position.

After operation starts, the slave axis uses the velocity of the master axis times the gear ratio for its target velocity, and accelerates/decelerates accordingly. The catching phase exists until the target velocity is reached. The *InGear* phase exists after that. If the gear ratio is positive, the slave axis and master axis move in the same direction. If the gear ratio is negative, the slave axis and master axis move in the opposite directions.

For details on gear operation, refer to the MC_GearIn (Start Gear Operation), MC_GearOut (End Gear Operation), and MC_Stop instructions in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).


9-2-3 Positioning Gear Operation

This function specifies the gear ratio between the master axis and the slave axis and starts operation. Positioning gear operation allows you to set the positions of the master and slave axes at which to start synchronization. Start positioning gear operation with the MC_GearInPos instruction. End synchronization with the MC_GearOut instruction or the MC_Stop instruction.



You can set the gear ratio numerator, gear ratio denominator, position type, acceleration rate, and deceleration rate for the slave axis to operate. For the master axis, you can specify the command position, actual position, or most recent command position.


After operation starts, the slave axis uses the velocity of the master axis times the gear ratio for its target velocity, and accelerates/decelerates accordingly. The slave axis is in the catching phase until it reaches the slave sync position. The slave axis enters the *InSync* phase after it reaches the slave sync position. For either, the position of the slave axis is synchronized with the master axis. If the gear ratio is positive, the slave axis and master axis move in the same direction. If the gear ratio is negative, the slave axis and master axis move in the opposite directions. The following figure shows the operation when the gear ratio is positive.



For details on positioning gear operation, refer to the MC_GearInPos (Positioning Gear Operation), the MC_GearOut (End Gear Operation), and the MC_Stop instructions in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-2-4 Cam Operation

Cam operation synchronizes the position of the slave axis with the master axis according to a cam table. Start cam operation with the MC_CamIn (Start Cam Operation) instruction. End cam operation with the MC_CamOut (End Cam Operation) instruction or the MC_Stop instruction. Create a cam table using the Cam Editor in the Sysmac Studio and download it to the CPU Unit. Use the Synchronization menu command of the Sysmac Studio to download the project to the CPU Unit.



In a combination of a CPU Unit with unit version 1.06 or later and Sysmac Studio version 1.07 or higher, the following operation is possible: if another MC_CamIn (Start Cam Operation) instruction is executed by using multi-execution with the Buffer Mode set for blending while the current MC_CamIn (Start Cam Operation) instruction is executed, the operation can continue using the switched cam table and the slave axis does not stop.

For details on cam operation, refer to the MC_CamIn (Start Cam Operation), MC_CamOut (End Cam Operation), and MC_Stop instructions in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

For details on the Cam Editor, refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504).


9-2-5 Cam Tables

This section describes the cam tables that are used for cam operation.

Cam Table Terminology

Term	Description
cam operation	An operation that takes one master axis and one slave axis and follows the cam pro- file curve to derive the displacement of the slave axis from the phase of the master axis.
cam profile curve	A curve that shows the relationship between phases and displacements in a cam operation. The cam profile curve is created on the Sysmac Studio. You can use the cam profile curve with a cam data variable after the cam profile curve is downloaded to the CPU Unit. Use the Synchronization menu command of the Sysmac Studio to download the project to the CPU Unit.
cam block	You can select a cam curve in this block. It represents the area between the end point of the previous cam block and the end point of the current cam block.
cam curve	A curve that represents the cam characteristics. You can select a cam curve for each cam block. The Sysmac Studio calculates the phase widths and displacement widths from the specified points and creates the actual cam profile curve. You can choose from different curves, such as straight line, parabolic, and trapecloid.
cam data	Data made up of phases (master axis) and displacements (slave axis) for cam opera- tion.
cam data variable	A variable that represents the cam data as a structure array.
cam table	A data table that contains cam data. If phase data is not in ascending order the cam table is treated as an illegal cam table.
cam start point	The first point in the cam data.
cam end point	The last point of valid cam data in the cam data. If the cam end point is less than the number of cam data, all phases and displacements after the cam end point will be 0.
cam block start point	The start point for a cam block. It is the same as the cam start point at the start of the cam operation. If the cam profile curve continues, this will be the same as the cam block end point.
cam block end point	The end point for a cam block. It is the same as the cam end point at the end of the cam operation. If the cam profile curve continues, this will be the same as the cam block start point. The cam block end point is defined as (horizontal axis, vertical axis) = (phase end point, displacement end point).
original cam data	Cam data that is created by dividing up the cam profile curve in the Cam Editor.
program-modified cam data	The cam data changed by the user program while the CPU Unit is in operation.
master axis	The axis that serves as the input to the cam operation. You can specify either Linear Mode or Rotary Mode.
slave axis	The axis that serves as the output from the cam operation. You can specify either Linear Mode or Rotary Mode.
phase	The relative distance on the master axis from the start point of the cam table.
displacement	The relative distance on the slave axis from the master following distance.
valid cam data	The cam data other than the cam start point and other than data where the phase is 0.
invalid cam data	The cam data other than the cam start point where the phase is 0.
number of valid cam data	The number of sets of cam data.
maximum number of cam data	The maximum number of sets of cam data that the cam table can contain.


Term	Description		
cam data index	The number of the cam data that is executed.		
cam table start position	The absolute position of the master axis that corresponds to the cam start point $(phase = 0)$.		
master following dis- tance	The master start distance where the slave axis starts cam operation represented as either an absolute position or relative position. The relative position is based on the cam start point position.		
start mode	A specification of whether to represent the master following distance as an absolute position or relative position.		
null cam data	Cam data that can be set after the end point where the phase and displacement are 0.		
connecting velocity	The connecting velocity that is used to connect cam profile curves. The connecting velocity cannot be specified for some curves.		
connecting acceleration	The acceleration rate that is used to connect cam profile curves. The connecting acceleration cannot be specified for some curves.		
phase pitch	The width when dividing the cam profile curve by phases (horizontal axis). The points after dividing the curve into the phase pitch correspond to the cam data in the cam table. You must specify the phase pitch for each cam block.		



Cam Tables

The MC Function Module defines a single element of data consisting of the phase of the master axis and the displacement of the slave axis as one cam data. A cam table is defined as the combination of multiple sets of cam data. The cam table is created with the Cam Editor in the Sysmac Studio. You can modify cam data in the cam table from the user program.

The phases and displacements in the cam data that makes up the cam table are represented as relative distances from the start point 0.0. During cam operation, the command position sent to the slave axis is the displacement determined by interpolating linearly between the two cam data elements adjacent to the phase of the master axis. The more cam data there is in the cam table, the more accurate the trajectory and the smoother the cam profile curve will be.





Precautions for Correct Use

- Make sure that the cam data is arranged in the cam table so that the phases are in ascending order. An instruction error occurs if a cam operation instruction is executed when the phases are not in ascending order.
- Cam data variables are global variables. You can therefore access or change the values of cam data variables from more than one task. If you change the values of cam data variables from more than one task, program the changes so that there is no competition in writing the value from more than one task.
- If you use exclusive control of global variables between tasks for a cam data variable, do not use the cam data variable for motion control instructions in a task that does not control the variable. An Incorrect Cam Table Specification (event code: 54390000 hex) will occur.

Cam Table Specifications

Item	Description
Maximum number of cam data per cam table	65,535 points
Maximum size of all cam data	1,048,560 points ^{*1}
Maximum number of cam tables	640 tables ^{*2}
Switching cam operation	You can switch to a different cam operation by executing a motion control instruction
Changing cam data	Cam data can be edited from the user program. Cam data can be overwritten with the Generate Cam Table instruction.*3
Saving cam data	Cam data can be saved to non-volatile memory by using the Save Cam Table instruction.
Information attached to the cam data	Information can be downloaded or uploaded for display in the Cam Editor ^{*4}
Timing to load cam data to main memory	When the data is downloaded from the Sysmac StudioWhen power is turned ON

*1 If 65,535 points are used for each cam table, there will be a maximum of 16 cams. A resolution of 0.1° allows for a maximum of 3,600 points per cam table for a maximum of 291 cams.

- *2 The total size is 10 MB max.
- *3 A CPU Unit with unit version 1.08 or later and Sysmac Studio version 1.09 or higher are required to use the Generate Cam Table instruction.
- *4 Use the Synchronization menu command of the Sysmac Studio to upload and download the project.

Data Type of Cam Tables

A cam table is declared as an array of cam data structures. The type declaration for the cam data structure is shown below.


```
TYPE
(*Cam data structure*)
__sMC_CAM_REF :
STRUCT
Phase : REAL; (*Phase*)
Distance : REAL; (*Displacement*)
END_STRUCT;
```

END_TYPE

You must create the cam data with the Cam Editor in the Sysmac Studio and then specify the name of the cam table and the number of cam data (i.e., the size of the array). For example, to make a cam table called *MyCam1* with 1,000 points use the following declaration.

VAR		
(*Cam table*)		
MyCam1	:	ARRAY [0999] OF _sMC_CAM_REF;
END_VAR		

The following notation is used to specify *MyCam1* for a cam operation instruction. In this example, the master axis is *Axis1* and the slave axis is *Axis2*.




9

9-2-5 Cam Tables

An error will occur if the specified cam table does not exist in the Controller. You can also specify the same cam table for more than one axis.

Switching Cam Tables

You can switch cam tables by re-executing the cam operation instruction during cam operation. After switching, cam operation will be performed with the cam table you specified for re-execution of the instruction. The *EndOfProfile* and *Index* output variables from the MC_CamIn instruction are output according to the new cam table.





Precautions for Correct Use

- The cam table you want to switch to must be saved to non-volatile memory before it can be used.
- Switching cam tables during cam operation will cause discontinuous velocities. Adjust the timing for switching the cam table to avoid excessive velocity discontinuity.

Loading/Saving Cam Data and Saving Cam Tables

Cam data can be loaded and saved from the user program just like any other variables. For example, you can use *MyCam1[0].Phase* to specify the phase and *MyCam1[0].Distance* to specify the displacement in the first array elements of a cam table named MyCam1. Cam data overwritten from the user program can be saved to the non-volatile memory in the CPU Unit as a cam table by executing the MC_SaveCamTable instruction.

Precautions for Correct Use

- Overwritten cam data will be lost if the CPU Unit is turned OFF or the cam data is downloaded from the Sysmac Studio before the Save Cam Table instruction is executed or if the instruction fails to save the data for any reason.
- Overwritten cam data will be lost if the CPU Unit is turned OFF before the Save Cam Table
 instruction is executed or if the instruction fails to save the data for any reason. Be careful not
 to lose the overwritten data when overwriting cam data from the user program in the CPU Unit.
- Cam data saved to non-volatile memory can be loaded by using the upload function of the Sysmac Studio.
- Use the Synchronization menu command of the Sysmac Studio to upload and download the project.

For details on arrays, refer to the NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501).


For details on the Save Cam Table instruction, refer to the MC_SaveCamTable instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Updating Cam Table Properties

The MC Function Module must identify the cam end point of the cam table. If an overwrite is performed from the user program during cam operation and the number of valid cam data changes, you must update the number of valid cam data to the latest value. Use the MC_SetCamTableProperty instruction for this.

The cam end point is the data located one cam data before the first cam data with a phase of 0 after the start point in the cam table. All cam data after phase 0 is detected will be invalid.

For example, refer to the following cam table. The *EndPointIndex* (End Point Index) output variable is 999 and the *MaxDataNumber* (Maximum Number of Cam Data) output variable is 5,000 from the MC_SetCamTableProperty instruction.



Precautions for Correct Use

- · You cannot change the maximum number of cam data from the user program.
- Execute this instruction after overwriting the cam data in any way that changes the number of valid cam data. If the number of valid cam data is not updated, the cam operation and the operation of the *EndOfProfile* (End of Cam Cycle) of the MC_CamIn instruction may not be as expected.

For details on the Set Cam Table Properties instruction, refer to the MC_SetCamTableProperty (Set Cam Table Properties) instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).


Generate Cam Table

With a CPU Unit with unit version of 1.08 or later and the Sysmac Studio version 1.09 or higher, you can generate the cam table by executing the MC_GenerateCamTable (Generate Cam Table) instruction.

The MC_GenerateCamTable instruction calculates the cam data using the values specified for *Cam*-*Property* (Cam Properties) and *CamNodes* (Cam Nodes), and rewrites the cam data variable specified for the *CamTable* (Cam Table) in-out variable.

When rewriting is completed, the MC_GenerateCamTable instruction updates the end point index of the cam table and outputs the element number of the cam end point to *EndPointIndex* (End Point Index).

It is not necessary to execute the MC_SetCamTableProperty (Set Cam Table Properties) instruction after the MC_GenerateCamTable instruction is completed.



The cam data variable is an array variable with the data type of cam data structure _sMC_CAM_REF. You create the cam data variable on the Cam Editor of the Sysmac Studio.

For *CamProperty*, specify the cam property variable. The cam property variable is an array variable with the data type of cam property structure _sMC_CAM_PROPERTY. You create the cam property variable as a user-defined variable on the global variable table of the Sysmac Studio. Or, you create the variable using the cam data settings on the Sysmac Studio.

For *CamNodes*, specify the cam node variable. The cam node variable is an array variable with the data type of cam node structure _sMC_CAM_NODE. You create the cam node variable as a user-defined variable on the global variable table of the Sysmac Studio. Or, you create the variable using the cam data settings on the Sysmac Studio.

The cam property variable and the cam node variable are collectively called "cam definition variable".

If the cam definition variable is created as a user-defined variable, the default of its Retain attribute is Non-retain. You must set the Retain attribute of variable to Retain, if you want to reuse the variable after changing its value and switching the operating mode to PROGRAM mode or cycling the power supply. If you set the variable each time of use from the HMI, etc., the attribute can be left Non-retain.

If the cam definition variable is created with the cam data settings on the Sysmac Studio, the Retain attribute of variable will be fixed to Retain.

By using the HMI, etc. to set the values for the MC_GenerateCamTable instruction, you can create the cam data variable and adjust the cam operation without using the Sysmac Studio. The following is the procedure used to adjust the cam operation.

1 Create a user program, in advance, that includes the following processing.

- Assigning the value of the cam definition variable that is set from the HMI to the Generate Cam Table instruction.
- Displaying the cam variable that is created by the Generate Cam Table instruction graphically on the HMI.
- Displaying the value of EndPointIndex (End Point Index) on the HMI.

2 Set the value of the cam definition variable from the HMI.

3 Execute the Generate Cam Table instruction.

- 4 Verify the curve shape of the generated cam table and the value of the end point index displayed on the HMI.
- **5** If there is no problem with the curve shape of the cam table and the number of the cam data, then execute the cam operation.
- **6** Verify the result of the cam operation and consider changing the value of the cam definition variable.
- **7** Repeat steps 2 to 6.


For details on the cam definition variable and the Generate Cam Table instruction, refer to the MC_GenerateCamTable instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504-E1-10 or later) for information on creating and transferring the cam definition variables using the Sysmac Studio.

9-2-6 Synchronous Positioning

This function performs positioning using a trapezoidal curve while synchronizing the specified slave axis to the specified master axis. This is a type of electronic cam, but it does not use cam tables created in the Cam Editor. Operation starts when the MC_MoveLink (Synchronous Positioning) instruction is executed. Use the MC_Stop instruction to stop the axes in motion. Operation is performed for the *Slave* (Slave Axis) and the following are set: *Master* (Master Axis), *MasterDistance* (Master Axis Travel Distance), *MasterDistanceInACC* (Master Distance In Acceleration), *MasterDistanceInDEC* (Master Distance In Deceleration), *SlaveDistance* (Slave Axis Travel Distance), and *MasterStartDistance* (Master Following Distance). The command position or actual position can be specified for the master axis. You can specify one of the following as the start condition for synchronous operation: start of instruction, when trigger is detected, or when master axis reaches the master following distance.

The velocity and position of the slave axis are determined by the ratio of the travel distances of the master axis and the slave axis as shown in the following figure. The sync start position shown in the following figure represents the position where the sync start condition is met.




For details on synchronous positioning, refer to the MC_MoveLink (Synchronous Positioning) and MC_Stop instructions in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-2-7 Combining Axes

The sum or difference of two positions can be used as the command position for the slave axis. Operation starts when the MC_CombineAxes instruction is executed. Use the MC_Stop instruction to stop axes in motion.

The following figure is an example demonstrating operation when subtracting axes. *Slave* (Slave Axis) command current position = *Master* (Master Axis) command current position – *Auxiliary* (Auxiliary Axis) command current position)




For details on combining axes, refer to the MC_CombineAxes and MC_Stop instructions in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-2-8 Master Axis Phase Shift

The phase of the master axis as viewed from the slave axis can be shifted for the current instruction. The shift amount as viewed from the slave axis is a relative amount. During synchronization, the slave axis will synchronize to the relative distance of the master axis. You can execute the MC_Phasing (Shift Master Axis Phase) instruction to shift the phase for a synchronized control instruction.

You can specify the phase shift amount, target velocity, acceleration rate, deceleration rate, and jerk for the MC_Phasing (Shift Master Axis Phase) instruction.



For details on the shift master axis phase function and the synchronized control instructions for which a master axis phase shift can be applied, refer to the MC_Phasing (Shift Master Axis Phase) instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-2-9 Slave Axis Position Compensation

This function compensates the position of the slave axis currently in synchronized control.

An offset calculated from the value of the input variable is added to the command current position. The result is output to the Servo Drive to compensate the position of the slave axis in synchronized control.

Even when the MC Function Module commands the same travel distance to two axes, their actual travel distance may be different due to mechanical strain or other factors. This function can perform compensation in such a case.

To perform position compensation for the slave axis in synchronized control, execute the MC_SyncOffsetPosition (Cyclic Synchronous Position Offset Compensation) instruction.

For details on slave axis position compensation, refer to the MC_SyncOffsetPosition (Cyclic Synchronous Position Offset Compensation) instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-2-10 Achieving Synchronized Control in Multi-motion

When you use the standard functions of the MC Function Module, if the synchronized control instructions are executed between axes assigned to different tasks in the multi-motion, an Illegal Master Axis Specification (event code: 54620000 hex) occurs.

However, you can perform synchronized control of the master axis that is controlled in the primary periodic task and the slave axis that is controlled in the priority-5 periodic task by using the MC_PeriodicSyncVariables (Periodic Axis Variable Synchronization between Tasks) instruction.


The cam operation and gear operation synchronized with the master axis and slave axis are available for the following combinations.


Mster axis task	Slave axis task			
INISTER AXIS TASK	Primary periodic task	Priority-5 periodic task		
Primray periodic task	Synchronized by motion control instructions	Synchronized control is achieved by executing the MC_PeriodicSyncVariables (Periodic Axis Variable Synchronization between Tasks) instruction and using the virtual master axis in the priority-5 periodic task.		
Priority-5 periodic task	Not available.	Synchronized by motion control instructions		

Axis Composition in Operation Examples

In the following figure, axis 1 is the master axis. Axis 2 is a slave axis that requires high-speed and high-precision control. It is assigned to the primary periodic task. Axis 3 is a slave axis that does not require precision. It is assigned to a priority-5 periodic task. The master axis (axis 1) is assigned to the primary periodic task.

Physical Axis Composition





Programming is placed in both the primary periodic task and priority-5 periodic task to achieve the operation for the above application.

Refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508) for details on the MC_PeriodicSyncVariables (Periodic Axis Variable Synchronization between Tasks) instruction.


9-3 Single-axis Velocity Control

This section describes the operation of velocity control for single axes.

Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for the differences when you use NX-series Pulse Output Units.

9-3-1 Velocity Control

Velocity control is used to constantly move an axis at the specified velocity. You can also specify the acceleration rate, deceleration rate, and jerk. To stop an axis, use the MC_Stop instruction or execute another motion instruction. If you specify a target velocity of 0, the axis will not move but the axis status will indicate that it is moving. If any other motion control instruction is executed with multi-execution of instructions during velocity control, the operation will switch only after reaching the target velocity.



The MC Function Module uses Position Control Mode of the Servo Drive or other device and sends target position commands to achieve the specified target velocity.


The position control loop is enabled in the Servo Drive or other device. Therefore, as the command velocity slows down, e.g., due to disturbance, and the following error increases, the velocity will change to eliminate this following error.

For details, refer to the MC_MoveVelocity (Velocity Control) instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-3-2 Cyclic Synchronous Velocity Control

The control mode of the Servo Drive is set to Velocity Control Mode and a command speed is output every control period. To stop an axis, use the MC_Stop instruction or execute another motion control instruction. If you specify a target velocity of 0, the axis will not move but the axis status will indicate that it is moving.





The Servo Drive will receive commands in the velocity control loop. Therefore, if any disturbance causes the velocity to decrease below the command velocity, no change in velocity will occur to remove the following error.


For details, refer to the MC_SyncMoveVelocity (Cyclic Synchronous Velocity Control) instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Precautions for Correct Use

You cannot use cyclic synchronous velocity control for an NX-series Pulse Output Unit.

9-4 Single-axis Torque Control

Torque control continuously applies the specified amount of torque. You can use *TorqueRamp* to specify the rate of change of the torque until the *Torque* (Target Torque) is reached. To stop an axis, use the MC_Stop instruction or execute another motion instruction. If you specify a *Torque* (Target Torque) of 0, the axis will not move but the axis status will indicate that it is moving.



The MC Function Module uses the Torque Control Mode of the Servo Drive. The Servo Drive receives the torque command value from the MC Function Module in the torque control loop and to control the torque. You can specify the velocity limit value for the Servo Drive in the *Velocity* (Velocity Limit) input variable to the motion control instruction. You can use this to limit high-speed revolution of the motor when the load on the motor is low in Torque Control Mode.

Precautions for Correct Use

- To be safe, always set a velocity limit value for torque control.
- · You cannot use single-axis torque control for an NX-series Pulse Output Unit.

For details, refer to the MC_TorqueControl instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9

9-5 Common Functions for Single-axis Control

This section describes the common functions used for single-axis control.

Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for the differences when you use NX-series Pulse Output Units.


9-5-1 Positions

Types of Positions

The MC Function Module uses the following two types of positions.

Type of position	Definition
Command position	This is the position that the MC Function Module outputs to control an axis.
Actual position	The actual position as input from the Servo Drive or encoder input.

The following figure shows the relationship between the command position and the actual position for an EtherCAT slave Servo Drive.



The command position and actual position share the following items.

Item	Command position	Actual position	
Count Mode	You can set Linear Mode or Rotary Mode.	The same Count Mode is used as for the command position.	
Position increment	You can set one of the following: mm, μ m, nm, inch, degree, or pulse.	The unit is the same as the unit of the command position.	
Software limits	You can set the range of operation of the software.	The range is the same as the range for the command position.	
Changing the current position	You can change the actual position to any desired position.	This value will be set to the same position as the command position.*	
Defining home	Home is either defined or undefined.	The status of home is the same as the command position.	

* If there is any following error before the change, the following error value is maintained in the actual position.

Additional Information

Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for information on the NX-series Position Interface Units.

Parameter name	Function	Setting range	Default
In-position Range	Set the in-position width. (Unit: command units)	Non-negative long reals	10
In-position Check Time	Set the in-position check time in millisec- onds. Set 0 to check for the end of position- ing only when you define the home position during homing and not check positioning at other times. (Unit: ms)		0
Software Limits	Select the software limit function.	0 to 4	0
	0: Disabled.		
	1: Deceleration stop for command position		
	2: Immediate stop for command position		
	3: Deceleration stop for actual position		
	4: Immediate stop for actual position		
Positive Software Limit	Set the software limit in the positive direc- tion. (Unit: command units)	Long reals	2,147,483,647
Negative Software Limit	Set the software limit in the negative direc- tion. (Unit: command units)	Long reals	-2,147,483,648
Following Error Over Value	Set the excessive following error check value. Set 0 to disable the excessive follow- ing error check. (Unit: command units)	Non-negative long reals	0
Following Error Warning Value	Set the following error warning check value. Set 0 to disable the following error warning check. (Unit: command units)	Non-negative long reals that are less than or equal to the Following Error Over Value	0

Axis Parameters That Are Related to Positions

Specifying Target Positions for Axis Operations

The actual position or distance for a positioning motion is specified with the *Position* (Target Position) and *Distance* (Travel Distance) input variables to the motion control instruction.

Monitoring Positions

You can read Axis Variables in the user program to monitor positions.

In the descriptions, a variable name $_MC_AX[*]$ is used as an example, but the same information applies to $_MC1_AX[*]$ and $_MC2_AX[*]$.

Variable name	Data type	Meaning	Function
_MC_AX[0-255].Cmd.Pos	LREAL	Command Current Position	This is the current value of the command posi- tion. When the Servo is OFF and the mode is not the position control mode, the actual cur- rent position is output.
_MC_AX[0-255].Act.Pos	LREAL	Actual Current Posi- tion	This is the actual current position.

9-5-2 Velocity

Types of Velocities

The following two types of axis velocities are used in the MC Function Module.

Velocity type	Definition	
Command velocity	This is the velocity that the MC Function Module outputs to control an axis.	
Actual velocity	This is the velocity calculated in the MC Function Module based on the actual position input from the Servo Drive or encoder input.*	

* This value is given if the Velocity actual value (606C hex) is mapped in the PDOs and assigned to the Actual Current Velocity.

Velocity Unit

A velocity is given in command units/s. The command unit is the value obtained from unit conversion of the position display unit and the electronic gear.

Axis Parameters That Are Related to Velocities

Parameter name	Function	Setting range	Default
Maximum Velocity	Specify the maximum velocity for the axis. If a target velocity that exceeds the maximum velocity is specified for an axis motion instruction, the axis will move at the maximum velocity.	Positive long reals	400,000,000
Start Velocity ^{*1}	Set the start velocity for each axis. Set a value that does not exceed the maximum velocity. (Unit: command units/s)	Positive long reals	0
Maximum Jog Velocity	Set the maximum jog velocity for each axis. ^{*2} Set a value that does not exceed the maximum velocity. (Unit: command units/s)	Positive long reals	1,000,000
Velocity Warning Value	Set the percentage of the maximum velocity at which to output a velocity warning for the axis. No velocity warning is output if 0 is set. (Unit: %)	0 to 100	0
Actual Velocity Filter Time Constant	Set the time period to calculate the average travel of the actual velocity in milliseconds. The average travel is not calculated if 0 is set. (Unit: ms) Use this to reduce variations in the actual cur- rent velocity when axis velocity is slow.	0 to 100	0

*1 A CPU Unit with unit version 1.05 or later and Sysmac Studio version 1.06 or higher are required to use this parameter.

*2 The maximum jog velocity is used as the command velocity if you specify a velocity command value that is greater than the maximum jog velocity.

Specifying Target Velocities for Axis Operations

The velocity used in an actual positioning motion is specified by the *Velocity* (Target Velocity) input variable to the motion control instruction.

Monitoring Velocities

You can read Axis Variables in the user program to monitor velocities.

In the descriptions, a variable name $_MC_AX[*]$ is used as an example, but the same information applies to $_MC1_AX[*]$ and $_MC2_AX[*]$.

Variable name	Data type	Meaning	Function
_MC_AX[0-255].Cmd.Vel	LREAL	Command Current Velocity	This is the current value of the command velocity. A plus sign is added during travel in the positive direction, and a minus sign is added during travel in the negative direction.
_MC_AX[0-255].Act.Vel	LREAL	Actual Current Velocity	This is the actual current velocity. A plus sign is added during travel in the positive direction, and a minus sign is added dur- ing travel in the negative direction.

9-5-3 Acceleration and Deceleration

Unit of Acceleration and Deceleration Rates

Acceleration rates and deceleration rates are given in command units/s². The command unit is the value obtained from unit conversion of the position display unit and the electronic gear.

Axis Parameters That Are Related to Acceleration and Deceleration

Parameter name	Function	Setting range	Default
Maximum Acceleration	Set the maximum acceleration rate for an axis operation command. There will be no limit to the acceleration rate if 0 is set. (Unit: command units/s ²)	Non-negative long reals	0
Maximum Deceleration	Set the maximum deceleration rate for an axis operation command. There will be no limit to the deceleration rate if 0 is set. (Unit: command units/s ²)	Non-negative long reals	0
Acceleration/Decelera- tion Over	Set the operation for when the maximum accel- eration/deceleration rate would be exceeded after excessive acceleration/deceleration dur- ing acceleration/deceleration control of the axis because stopping at the target position is given priority.	0 to 2	0
	 0: Use rapid acceleration/deceleration. (Blending is changed to Buffered.) *1 1: Use rapid acceleration/deceleration. 		
	2: Minor fault stop $*^2$		

Parameter name	Function	Setting range	Default
Acceleration Warning Value	Set the percentage of the maximum accelera- tion rate at which to output an acceleration warning for the axis. No acceleration warning is output if 0 is set. (Unit: %)	0 to 100	0
Deceleration Warning Value	Set the percentage of the maximum decelera- tion rate at which to output a deceleration warn- ing for the axis. No deceleration warning is output if 0 is set. (Unit: %)	0 to 100	0

- *1 For a CPU Unit with version 1.10 or later, Blending is not changed to Buffered. Refer to 9-5-7 Multi-execution of Motion Control Instructions (Buffer Mode) for details.
- *2 For a CPU Unit with version 1.10 or later, the axis does not stop with an error when Blending is used for operation. Refer to *9-5-7 Multi-execution of Motion Control Instructions (Buffer Mode)* for details.

Specifying Acceleration and Deceleration Rates for Axis Operation


The acceleration and deceleration rates used in an actual positioning motions are specified by the *Acceleration* (Acceleration Rate) and *Deceleration* (Deceleration Rate) input variables to the motion control instruction.

Monitoring Acceleration and Deceleration Rates

You can read Axis Variables in the user program to monitor acceleration and deceleration rates.

In the descriptions, a variable name $_MC_AX[*]$ is used as an example, but the same information applies to $_MC1_AX[*]$ and $_MC2_AX[*]$.

Variable name	Data type	Meaning	Function
_MC_AX[0-255].Cmd.AccDec	LREAL	Command Current Accelera- tion/Deceleration	This is the current value of the com- mand acceleration/deceleration rate. A plus sign is added for acceleration, and a minus sign is added for decel- eration.



Example of Acceleration/Deceleration Operation

If you specify a short travel distance or a low acceleration/deceleration rate, the target velocity may not be reached. If the target position is exceeded after re-execution of the motion control instruction with the newly updated acceleration or deceleration rate, positioning is performed at an acceleration or deceleration rate that will enable stopping at the target position.

9-5-4 Jerk

The jerk specifies the rate of change in the acceleration rate or deceleration rate. If the jerk is specified, the velocity waveform during acceleration will be an S-curve, which will reduce the shock and vibration on the machine.

Additional Information

Jerk is also called jolt, surge and lurch.

Jerk Unit

Jerk is given in command units/s³. The command unit is the value obtained from unit conversion of the position display unit and the electronic gear.

Specifying Jerk for Axis Motion


The jerk used in an actual positioning motion is specified with the *Jerk* input variable to the motion control instruction. The same value is used for acceleration and deceleration.

Use the following formula to calculate the value to set for the jerk. Jerk = Acceleration rate \div (Time of acceleration \times Ratio of time to apply jerk during acceleration/2)

Jerk is applied in two sections: at the start of acceleration and at the end of acceleration. The time that jerk is applied is therefore divided by 2.

• Example of Velocity Control When Jerk Is Specified

The acceleration will change at a constant rate over the range where jerk is specified. The command velocity will form a smooth S curve. A fixed acceleration rate is used in areas where the jerk is set to 0. This command velocity will form a straight line.



Example: Acceleration of 25,000 mm/s², Acceleration Time of 0.1 s, and a Jerk Application Rate of 50%

Monitoring Jerk

You can read Axis Variables in the user program to monitor jerk.

In the descriptions, a variable name $_MC_AX[*]$ is used as an example, but the same information applies to $_MC1_AX[*]$ and $_MC2_AX[*]$.

Variable name	Data type	Meaning	Function
_MC_AX[0-255].Cmd.Jerk	LREAL	Command Current Jerk	This is the current value of the com- mand jerk.

9-5-5 Specifying the Operation Direction

If you want to specify a rotation direction, such as shortest way, using an index table, set the Count Mode to Rotary Mode. Next, set the operation direction with the *Direction* input variable to the motion control instruction for an absolute position. If you set the direction to the shortest way, positive direction, negative direction, or current direction, you can specify a position that is greater than or equal to the modulo minimum position and less than the modulo maximum position within one turn of the ring counter. The *Direction* input variable will be ignored when the Count Mode is set to Linear Mode. Positioning will be performed to the target position.


The following table lists the different directions you can specify in the MC Function Module.

Direction	Operation	
Shortest way	Motion starts in the direction where the command current position and the target posi- tion are closer to each other.	
Positive direction	Motion starts in the positive direction.	

Direction	Operation	
Negative direction	Motion starts in the negative direction.	
Current direction	Motion starts in the same direction as the previous operation.	
No direction specified	Motion starts in the direction that does not pass through the upper and lower limits of the ring counter. With this direction specification, you can specify a target position that exceeds the upper or lower limits of the ring counter. If that occurs, relative positioning is performed using the difference between the target position and the command current position as the target distance. This enables you to perform multi-turn positioning on the ring counter.	

Example for Shortest Way


The following example illustrates when positioning is performed towards a target position of –20 when the command current position is 50.



Moves in the same direction as the Current Direction specification if the travel distance is the same in the positive and negative directions.

Example for Positive Direction


The following example illustrates when positioning is performed towards a target position of –20 when the command current position is 50.



9


Example for Negative Direction

The following example illustrates when positioning is performed towards a target position of –20 when the command current position is 50.



Example for Current Direction

The following example illustrates when positioning is performed towards a target position of -20 when the command current position is 50.



The direction of the previous operation is given in the Command Direction in the Axis Variable.


Precautions for Correct Use

Observe the following precautions on the operation direction of the previous operation.


- If the MC_Home or MC_HomeWithParameter instruction exceeds the point where the home input was detected and reverses operation, the opposite direction of the home input detection direction is used.
- If a homing compensation value is set for the MC_Home or MC_HomeWithParameter instruction, the axis will move in the direction of the compensation value.
- If an immediate stop is specified for the MC_TouchProbe (Enable External Latch) instruction, the latch position may be exceeded and the direction may be reversed.
- The direction may be reversed for the MC_MoveFeed (Interrupt Feeding) instruction.
- When the MC_ResetFollowingError instruction is executed, the error is set to zero, so the command direction is used.
- If an immediate stop is specified for an external input signal or resetting the error counter is specified for stopping for a limit input, the operation may reverse direction toward the position where the external input signal was received.

Example for No Direction Specification

The following example illustrates when positioning is performed towards a target position of -20 when the command current position is 50.



Similarly, the following example illustrates when the ring counter upper limit is 100, the lower limit is -70, the command current position is -20, and positioning is performed towards a target position of 290.



9-5-6 Re-executing Motion Control Instructions


This section describes how to modify input variables of the same instance of a motion control instruction during operation of a single axis and re-execute that instruction. The input variables *Position* (Target Position), *Distance* (Travel Distance), *Velocity* (Target Velocity), *Acceleration* (Acceleration Rate), *Deceleration* (Deceleration Rate), and *Torque* (Target Torque) and sometimes other input variables can be changed by re-execution. An instruction error will occur if you change an input variable that cannot be changed and attempt to re-execute the instruction. If you re-execute an instruction that has been buffered due to multi-execution of instructions, the input variables for the instruction in the buffer will change.

For details on input variables that can be changed, refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Changing the Target Position


If you change the target position with re-execution, the operation may change depending on the timing of the change and the new target position. If the direction of motion reverses due to a change in the target position, you can choose to decelerate to a stop after a reverse turn or stop immediately after reversing with the Operation selection at Reversing axis parameter.

• When a Reverse Turn Does Not Occur for the New Command Value




control or during deceleration, acceleration to the target velocity will occur again. In some cases, the axis will not reach the target velocity.

When a Reverse Turn Occurs for the New Command Value



• Triangular Control Patterns


The triangular control shown in the figure below may result if the travel distance is shortened due to a change in the target position.



• Excessive Deceleration Patterns


In the following case, priority is given to stopping at the target position. Therefore, the deceleration rate will exceed the specified deceleration rate. If the deceleration rate exceeds the rate that is set in the Maximum Deceleration axis parameter, the operation set in the Acceleration/Deceleration Over axis parameter setting is performed.

If There Is No Reverse Turn and the Target Position Would Be Exceeded at the Specified Deceleration Rate




If There Is A Reverse Turn and Decelerating to a Stop Would Exceed a Software Limit






If There Is A Reverse Turn and Decelerating to a Stop Would Result in Command Current Position Overflow or Underflow

No Reverse Turn



Changing the Travel Distance

Even if you change the travel distance and re-execute the MC_MoveRelative (Relative Positioning) instruction, positioning is performed for the new travel distance in reference to the position where the motion first started. However, if the instruction is executed again just before positioning is completed, it may be executed as a new instruction rather than as a re-execution of the same instruction.



Precautions for Correct Use

Do not change the travel distance and re-execute the instruction just before the end of positioning.

Changing the Target Velocity

The operation is changed only during acceleration (including acceleration for triangular control) and constant-velocity motion. Changes are also accepted when the axis is decelerating, but operation is not affected.


Changing the Acceleration Rate


The operation is changed only during acceleration and acceleration during triangular control. If it is changed when moving at a constant speed, the changed rate applies to acceleration for an override. Changes are also accepted when the axis is decelerating, but operation is not affected.

Changing the Deceleration Rate

The deceleration rate is changed only during acceleration, constant-velocity motion, deceleration, triangular control, or during deceleration-exceed control. If the new deceleration rate causes the axis to exceed the target position, stopping at the target position is given the highest priority. Therefore, in this case, the actual deceleration rate will exceed the specified deceleration rate.

• Patterns Where Deceleration Rate Increases






Changing the Torque Command

The torque command value will change based on the torque ramp specification when you re-execute a motion control instruction.

Programming Example for Re-execution

This example demonstrates changing the target position from 1000 to 2000 for absolute positioning. In this example, the variable *Axis1Pos* is used as the input parameter to the target position. Specify the target position to 1000 with the MOV instruction and change *Axis1Execute* to TRUE to begin positioning. Specify the target position to 2000 during operation and change *Axis1Execute* to TRUE again to switch to a positioning operation for the new target position of 2000.



• Timing Charts

Variables		
Axis1PosSet1	Π	
Axis1PosSet2	Γ	
Axis1Pos 🗋	1000 2000	
Input Parameter Axis1Execute	ΠΠ	
Output Parameters Axis1Done		П
Axis1Done		L
Axis1Active		
Precautions for	or Correct Use	

For input variables that are not changed, always use the same values as before re-execution of the instruction.

9-5-7 Multi-execution of Motion Control Instructions (Buffer Mode)

You can execute another motion control instruction while an axis is moving. In the PLCopen[®] technical specifications, this functionality is defined as Buffer Mode, but in the MC Function Module this is sometimes referred to as multi-execution of instructions. You can use multi-execution of instructions to execute multiple motion control instructions in sequence without stopping the overall motion.

The following terms are used in relation to multi-execution of instructions in the MC Function Module.

Term		Meaning
This manual	PLCopen [®]	imeaning
Current instruction	Previous function block	The motion control instruction that was in operation just before exe- cuting the multi-execution instruction.
Buffered instruction	Next function block	A motion control instruction that was executed during an axis motion and is waiting to be executed.
Transit velocity	Blending	When blending is specified, it specifies the command velocity to use by the current instruction to move to the specified target position.

You can set the *BufferMode* (Buffer Mode Selection) input variable to motion control instruction to select one of the following Buffer Modes. The main difference between these modes is the timing at which the buffered instructions are executed and the transit velocity.

Buffer Mode		Description of operation	
Aborting		The current instruction is aborted and the multi-executed instruction is executed.	
Buffer	red	The buffered instruction is executed after the operation for the current instruction is normally finished.	
Blend	ing	The buffered instruction is executed after the target position of the cur- rent instruction is reached. In this mode, no stop is performed between the current instruction and the buffered instruction. You can select from the following transit velocities for when the current instruction reaches the target position.	
	Blending Low (low velocity)	The transit velocity is set to the target velocity of the current instruction or the buffered instruction, whichever is lowest.	
	Blending Previous (previous velocity)	The target velocity of the current instruction is used as the transit velocity.	
	Blending Next (next velocity)	The target velocity of the buffered instruction is used as the transit velocity.	
	Blending High (high velocity)	The transit velocity is set to the target velocity of the current instruction or the buffered instruction, whichever is highest.	

The multi-execution instruction is buffered in the MC Function Module and will be executed at the specified *BufferMode* timing and transit velocity for both buffered and blending modes. There is one buffer for each axis. If aborting is specified, the instruction that was executed last is executed immediately, so it is not buffered.




Precautions for Correct Use

- Only one multi-execution instruction is buffered for each axis. If multi-execution is performed for two or more instructions, an instruction error will occur.
- Multi-execution of multi-axes coordinated control instructions (axes group instructions) is not
 possible for axes operating as a single axis. Similarly, multi-execution of single-axis control
 instructions is not possible for axes operating under multi-axes coordinated control (axes
 group instructions). An instruction error will occur if these rules are broken.


Aborting

This is the default mode. No buffering is performed in this mode. The current command is aborted and the new instruction is executed. Aborting Mode can be used for multi-execution of instructions for motion control instructions for both single-axis control and synchronized control.

When a Reverse Turn Does Not Occur for the Command Position of the Multiexecution Instruction




Multi-execution during Acceleration/Deceleration




If you use multi-execution of an instruction during triangular control or during deceleration, the axis will accelerate to the target velocity of the buffered instruction. In some cases, the axis will not reach the target velocity.

When a Reverse Turn Occurs for the Command Position of the Multi-execution Instruction



Buffered

The buffered instruction remains in the buffer until the operation of the current instruction is finished. The buffered instruction is executed after the operation for the current instruction is normally ended.



Blending

The buffered instruction remains in the buffer until the target position of the current instruction is reached. The buffered instruction is executed after the current instruction's target position is reached. However, motion does not stop at this time. Operation transitions to the next instruction at the velocity specified with the *BufferMode* (Buffer Mode Selection) input variable. For relative travel, the final position will be the total of the values for both instruction. The Acceleration/Deceleration Over axis parameter is used to select one of the following operations for when the target position would be exceeded with the values that are set in the Maximum Acceleration and Maximum Deceleration axis parameters.

- Use rapid acceleration/deceleration. (Blending is changed to Buffered.)
- Use rapid acceleration/deceleration.
- Minor fault stop

Version Information

For a CPU Unit with version 1.10 or later, Blending is not changed to Buffered even if you select *Use rapid acceleration/deceleration. (Blending is changed to Buffered.)* In this case, the maximum acceleration/deceleration rate is used and the blending operation is continued.


Also, the axis does not stop with an error even if you select *Minor fault stop*. Similar to the previous case, the maximum acceleration/deceleration rate is used and the blending operation is continued.

• Example of Acceleration/Deceleration Over Operation

An example for an Acceleration/Deceleration Over operation is given below.

Use Rapid Acceleration/Deceleration (Blending Is Changed to Buffered)

• For a CPU Unit with Version 1.09 or Earlier




• For a CPU Unit with Version 1.10 or Later

The operation with the following setting is shown below.


Here, BufferMode is set to Blending Next.

- Use rapid acceleration/deceleration. (Blending is changed to Buffered.)
- · Minor fault stop




Use Rapid Acceleration/Deceleration

BufferMode Is Set to Blending Previous



BufferMode Is Set to Blending Next



In a blending mode you cannot combine single-axis and synchronized control.


• Blending Low (Low Velocity)

Operation is performed using the target position of the current instruction and the target velocity that is the slower of the target velocities for the current instruction and buffered instruction.


• Blending Previous (Previous Velocity)

Operation is performed with the target velocity of the current instruction until the target position of the current instruction is reached. Operation is performed after acceleration/deceleration to the target velocity of the buffered instruction once the target position is reached.

When the Direction of Operation Does Not Change




When the Direction of Operation Changes



Blending Next (Next Velocity)

Operation is performed using the target position of the current instruction and the target velocity of the buffered instruction.



• Blending High (High Velocity)

Operation is performed using the target position of the current instruction and the target velocity that is the faster of the target velocities for the current instruction and buffered instruction.


9-6 Multi-axes Coordinated Control

This section describes the operation of multi-axes coordinated control. With the MC Function Module, you can set an axes group in advance from the Sysmac Studio to perform interpolation control for multiple axes.

9-6-1 Outline of Operation

Multi-axes coordinated control performs a motion with multiple related axes together as a single group to control the path of the target control object. The MC Function Module treats all axes that perform coordinated operation as an axes group. Axes groups are set from the Sysmac Studio. In the user program, turn ON the Servo for each axis and then enable the axes group that is going to perform the multi-axes coordinated control. The purpose of multi-axes coordinated control is the coordinated operation of all axes belonging to the target axes group. Therefore, you cannot execute any single-axis operation motion control instructions on the axes in an enabled axes group. Furthermore, if any error occurs for any axis in an axes group, all axes in the axes group will stop according to the setting of the Axis Group Stop Method group axes parameter.

The MC Function Module can perform linear interpolation with two to four axes or circular interpolation with two axes.



Additional Information


For devices that require you to modify the grouping of axes in motion to perform interpolation control, you must create multiple axes groups that include the axes to modify from the Sysmac Studio beforehand. After completing this step, you can execute by specifying the enabled axes groups from the user program during operation.

With a CPU Unit with a unit version of 1.01 or later and Sysmac Studio version 1.02 or higher, you can use the MC_ChangeAxesInGroup (Change Axes in Group) instruction to change the composition axes for an axes group that is disabled.

For details on axes groups, refer to 3-3 Axes Groups.

Enabling and Disabling Axes Groups

To enable an axes group, specify the axes group for the MC_GroupEnable (Enable Axes Group) instruction. An instruction error will occur if you try to execute an axes group instruction when the axes group is still disabled. To disable an axes group, specify the axes group for the MC_GroupDisable (Disable Axes Group) instruction. When you disable an axes group that is in operation, all axes in that axes group will decelerate to a stop at the maximum deceleration rate that is specified in their axis parameter settings.



For details on enabling and disabling axes groups, refer to the MC_GroupEnable (Enable Axes Group) and MC_GroupDisable (Disable Axes Group) instructions in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Changing the Axes in an Axes Group

You can use the MC_ChangeAxesInGroup (Change Axes in Group) instruction to temporarily change the composition axes for an axes group that is disabled. If the axes group is enabled, use the MC_GroupDisable (Disable Axes Group) instruction to disable the axes group before you change the composition axes. A CPU Unit with unit version 1.01 or later and Sysmac Studio version 1.02 or higher are required to use this instruction.

Precautions for Correct Use

Changes made using the MC_ChangeAxesInGroup (Change Axes in Group) instruction will not be saved to non-volatile memory in the CPU Unit. If you cycle the power supply or download the settings from the Sysmac Studio, the parameter settings in the non-volatile memory are restored.

For details on changing the composition axes of an axes group, refer to the MC_ChangeAxesInGroup (Change Axes in Group) instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Reading Axes Group Positions

You can use the MC_GroupReadPosition (Read Axes Group Position) instruction to read the command current positions and the actual current positions of an axes group. A CPU Unit with unit version 1.01 or later and Sysmac Studio version 1.02 or higher are required to use this instruction.

For details on reading the axis positions for an axes group, refer to the MC_GroupReadPosition (Read Axes Group Position) instruction in the NJ/NX-series Motion Control Instructions Reference Manual (Cat. No. W508).

Resetting Axes Group Errors

If an error occurs in an axes group, you can use the MC_GroupReset instruction to remove the error once you have eliminated the cause.

For details on resetting axes group errors, refer to the MC GroupReset (Group Reset) instruction in the NJ/NX-series Motion Control Instructions Reference Manual (Cat. No. W508).

Refer to the NX-series Position Interface Units User's Manual (Cat. No. W524) for the differences when you use NX-series Pulse Output Units.

9


9-6-2 Linear Interpolation

Linear interpolation is used to move 2 to 4 of the logical axes A0 to A3 in a straight line between a start point and an end point. Either absolute or relative positioning is possible. You can specify the interpolation velocity, interpolation acceleration, interpolation deceleration, and jerk.

The MC Function Modules uses the following three kinds of linear interpolation instructions.

- MC_MoveLinear (Linear Interpolation) You can specify the *MoveMode* input variable to select between linear interpolation to an absolute value or linear interpolation to a relative value. This instruction is unique to the MC Function Module.
- MC_MoveLinearAbsolute (Absolute Linear Interpolation) This instruction performs linear interpolation to an absolute value. This instruction is defined in the PLCopen[®] technical specifications.
- MC_MoveLinearRelative (Relative Linear Interpolation) This instruction performs linear interpolation to a relative value. This instruction is defined in the PLCopen[®] technical specifications.


The following figure shows linear interpolation of 2 axes from point A to point B.



For details on linear interpolation, refer to the MC_MoveLinear (Linear Interpolation), MC_MoveLinearAbsolute (Absolute Linear Interpolation), and MC_MoveLinearRelative (Relative Linear Interpolation) instructions in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-6-3 Circular Interpolation

Circular interpolation is used to move two of the logical axes A0 to A3 in a circular motion on a 2D plane. Either absolute or relative positioning is possible. You can specify the circular interpolation mode, path direction, interpolation velocity, interpolation acceleration, interpolation deceleration, and combined jerk for the two axes.



With the MC Function Module, you can specify the following three kinds of circular interpolation methods with the input variable *CircMode* (Circular Interpolation Mode).

- Border point
- Center
- Radius

Precautions for Correct Use

Set the Count Mode to Linear Mode for the axis that you use for circular interpolation. If the instruction is executed with this axis in Rotary Mode, an instruction error will occur.

9-6-4 Axes Group Cyclic Synchronous Positioning

You can cyclically output specified target positions for the axes in an axes group. You can specify target positions that are calculated in the user program as absolute positions to move the axes in any desired path.

A CPU Unit with unit version 1.01 or later and Sysmac Studio version 1.02 or higher are required to use this instruction.

For details on axes group cyclic synchronous positioning for an axes group, refer to the MC_GroupSyncMoveAbsolute (Axes Group Cyclic Synchronous Absolute Positioning) instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-6-5 Stopping Under Multi-axes Coordinated Control

Multi-axes coordinated control of axes groups will stop when you execute certain motion control instructions in the user program or when an error or some other problem occurs.

Stopping with Motion Control Instructions

Use the MC_GroupStop or MC_GroupImmediateStop instruction to stop axes group operation.

MC_GroupStop Instruction

For linear interpolation or circular interpolation performed on an axes group, you can decelerate to a stop along the control path. You specify the deceleration rate and jerk. Specify a deceleration rate of 0 to send a command that immediately stops the Servo Drive or other device. Other operation commands are not acknowledged while decelerating to a stop for this instruction and while the input variable *Execute* is TRUE.

MC_GroupImmediateStop Instruction

You can perform an immediate stop for all axes in the axes group. The immediate stopping method is determined by the setting of the Immediate Stop Input Stop Method axis parameter for each axis. The MC_GroupImmediateStop instruction can also be executed for an axes group that is decelerating to a stop for an MC_GroupStop instruction.

For details, refer to the MC_GroupStop and MC_GroupImmediateStop instructions in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Stopping Due to Errors or Other Problems

Stopping for Errors during Axes Group Motion

If an error that results in a deceleration stop occurs for any composition axis in the axes group during an axes group motion, all of the axes will decelerate to a stop on the interpolation path at the interpolation deceleration rate. The interpolation deceleration rate is determined by the deceleration rate that is specified for the controlling instruction. If an error that results in an immediate stop occurs for any composition axis in the axes group during an axes group motion, the other axes in the axes group will stop according to the setting of the Axes Group Stop Method parameter in the axes group parameters.

You can select one of the following stop methods for axes groups.

- Immediate stop
- Decelerate axes to a stop at maximum deceleration rate of the axes.
- · Immediate stop and Servo OFF

Stopping Due to Motion Control Period Exceeded Error

If motion control processing does not end within two periods, a Motion Control Period Exceeded error occurs. All axes stop immediately.



Precautions for Correct Use

When you use an NX-series CPU Unit and operate in the multi-motion, all axes in both tasks will stop immediately if a Motion Control Period Exceeded error occurs in either of the tasks.

Refer to A-5-2 Motion Control for multi-motion.

Stopping Due to Start of MC Test Run

All axes will decelerate to a stop at their maximum deceleration if a MC Test Run is started from the Sysmac Studio.

• Stopping Due to Change in CPU Unit Operating Mode

All axes will decelerate to a stop at their maximum deceleration when the CPU Unit operating mode changes.

Additional Information


- If you execute the MC_GroupDisable (Disable Axes Group) instruction during axes group operation, the axes in the group will decelerate to a stop at their maximum deceleration rates.
- If you execute the MC_Stop instruction while an axes group is in operation, an error will occur for the axes and axes group and the axes group operation will decelerate to a stop with interpolation. The interpolation deceleration rate is determined by the deceleration rate that is specified for the controlling instruction.
- When the input variable *Enable* to the MC_Power (Servo ON) instruction changes to FALSE during axes group motion, the MC Function Module immediately stops the command value for that axis and turns OFF the Servo. When the Servo is turned OFF, the Servo Drive or other device will operate according to the settings in the Servo Drive or other device. Other axes in that axes group will stop with the stop method that is set in the Axes Group Stop Method axes group parameter. An error will occur for the axes group if this happens.
- When RUN mode changes to PROGRAM mode, any motion control instructions for current motions are aborted. The *CommandAborted* output variable from the instructions remain TRUE and the Servo remains ON.
- If the operating mode returns to RUN mode while a deceleration stop is in progress after the operating mode changes from RUN to PROGRAM mode, the output variable *Command-Aborted* from the current motion control instructions change to TRUE.
- The save process will continue during a save for the MC_SaveCamTable Instruction.
- The generation process will continue when generation of the cam table is in progress for the MC_GenerateCamTable (Generate Cam Table) instruction.

9-6-6 Overrides for Multi-axes Coordinated Control

You can use the MC_GroupSetOverride (Set Group Overrides) instruction to set override factors for multi-axes coordinated control of the axes group in the current interpolation operation. The velocity override factor is set as a percentage of the target velocity for interpolation. It can be set between 0% and 500%. If an override factor of 0% is set for the interpolation target velocity, operating status will continue with the axis stopped at a velocity of 0. The set override factor is read as long as the overrides are enabled. If the overrides are disabled, the override factors return to 100%. If the maximum interpolation velocity for the axes group is used.

Overrides for the MC_MoveLinear (Linear Interpolation) Instruction

An example of a time chart for using the Set Override Factors instruction for the MC_MoveLinear (Linear Interpolation) instruction is given below.



For details, refer to the MC_GroupSetOverride (Set Group Overrides) instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-7 Common Functions for Multi-axes Coordinated Control

This section describes the common functions for multi-axes coordinated control.

9-7-1 Velocity Under Multi-axes Coordinated Control

To specify the velocity for multi-axes coordinated control, specify the interpolation velocity on the path. The unit is the same as for single axes, command units/s.

Types of Velocities

The following is the only type of interpolation velocity for axes groups supported by the MC Function Module.

Velocity type	Definition
Command interpolation velocity	This is the actual value of the command interpolation velocity output by the MC Function Module to control an axes group.

Axis Parameters That Are Related to Velocities

Parameter name	Function	Setting range	Default
Maximum Interpolation Velocity	Set the maximum interpolation velocity for the path. Set 0 for no interpolation velocity limit. If a target velocity that exceeds the maximum interpolation velocity is specified for an axes group operation instruction, the axis will move at the maximum interpolation velocity.	Non-negative long reals	800,000,000
Interpolation Velocity Warning Value	Set the percentage of the maximum inter- polation velocity at which to output an inter- polation velocity warning. No interpolation velocity warning is output if 0 is set. (Unit: %)	0 to 100	0

Specifying Target Velocities for Axis Operations

The interpolation velocity used in an actual positioning motion is specified by the *Velocity* (Target Velocity) input variable to the motion control instruction.

Monitoring Velocities

You can read Axes Group Variables from the user program to monitor the interpolation velocity. In the descriptions, a variable name $_MC_GRP[*]$ is used as an example, but the same information applies to $_MC1_GRP[*]$ and $_MC2_GRP[*]$.

Variable name	Data type	Meaning	Function
_MC_GRP[0-63].Cmd.Vel	LREAL	Command Interpo- lation Velocity	This is the current value of the com- mand interpolation velocity. A plus sign is added during travel in the pos- itive direction, and a minus sign is added during travel in the negative direction.

9-7-2 Acceleration and Deceleration Under Multi-axes Coordinated Control

Multi-axes coordinated control performs control on the path for the interpolation acceleration and interpolation deceleration rates. The unit is the same as for single axes, command units/s².

Axis Parameters That Are Related to Interpolation Acceleration and Interpolation Deceleration

Parameter name	Function	Setting range	Default
Maximum Interpolation Acceleration	Set the maximum interpolation acceleration for the path. Set 0 for no interpolation accel- eration limit. (Unit: command units/s ²)	Non-negative long reals	0
Maximum Interpolation Deceleration	Set the maximum interpolation deceleration for the path. Set 0 for no interpolation decel- eration limit. (Unit: command units/s ²)	Non-negative long reals	0
Interpolation Accelera- tion/Deceleration Over	Set the operation for when the maximum interpolation acceleration/deceleration rate would be exceeded after excessive acceler- ation/deceleration during accelera- tion/deceleration control of the axes group because stopping at the target position is given priority. 0: Use rapid acceleration/deceleration. (Blending is changed to Buffered.) *1 1: Use rapid acceleration/deceleration. 2: Minor fault stop *2	0 to 2	0
Interpolation Accelera- tion Warning Value	Set the percentage of the maximum inter- polation acceleration at which to output an interpolation acceleration warning. No inter- polation acceleration warning is output if 0 is set. (Unit: %)	0 to 100	0
Interpolation Decelera- tion Warning Value	Set the percentage of the maximum inter- polation deceleration rate at which to output an interpolation deceleration warning. No interpolation deceleration warning is output if 0 is set. (Unit: %)	0 to 100	0

- *1 For a CPU Unit with version 1.10 or later, Blending is not changed to Buffered. Refer to 9-5-7 Multi-execution of Motion Control Instructions (Buffer Mode) for details.
- *2 For a CPU Unit with version 1.10 or later, the axis does not stop with an error when Blending is used for operation. Refer to *9-5-7 Multi-execution of Motion Control Instructions (Buffer Mode)* for details.

Specifying an Interpolation Acceleration and Interpolation Deceleration for an Axes Group

The interpolation acceleration and interpolation deceleration rates used in an actual positioning motion are specified by the *Acceleration* (Acceleration Rate) and *Deceleration* (Deceleration Rate) input variables to the motion control instruction.

Monitoring Interpolation Acceleration and Interpolation Deceleration Rates

You can read Axes Group Variables in the user program to monitor interpolation acceleration and interpolation deceleration rates.

In the descriptions, a variable name _*MC_GRP*[*] is used as an example, but the same information applies to _*MC1_GRP*[*] and _*MC2_GRP*[*].

Variable name	Data type	Meaning	Function
_MC_GRP[0-63].Cmd.AccDec	LREAL	Command Interpo- lation Accelera- tion/Deceleration	This is the current value of the com- mand interpolation accelera- tion/deceleration rate. A plus sign is added for acceleration, and a minus sign is added for deceleration.

9-7-3 Jerk for Multi-axes Coordinated Control


Jerk for multi-axes coordinated control is used to reduce shock and vibration on the machine by smoothing the interpolation acceleration/deceleration rate along the interpolation path into an S-curve. The unit is the same as for single axes, command units/s³.

Specifying Jerk for Axes Group Motion

The jerk used in an actual interpolation is specified by the *Jerk* input variable to the motion control instruction.

Jerk Example (Setting Other than 0)


The acceleration/deceleration rate will change at a constant rate over the range where jerk is specified. The command interpolation velocity will form a smooth S-curve. A fixed interpolation acceleration rate is used in areas where the jerk is set to 0. This command interpolation velocity will form a straight line.



Vt: Specified interpolation velocity, At: Specified acceleration rate, Dt: Specified deceleration rate, Jt: Specified jerk

9-7-4 Re-executing Motion Control Instructions for Multi-axes Coordinated Control

If you re-execute a linear interpolation or circular interpolation instruction, an instruction error will occur.




You can change the deceleration rate if you re-execute the MC_GroupStop instruction, but you cannot change the jerk in this way.

If you re-execute the MC_GroupReset instruction, the re-execution command will be ignored and error reset processing will continue.

For details on re-executing motion control instructions, refer to each instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-7-5 Multi-execution (Buffer Mode) of Motion Control Instructions for Multi-axes Coordinated Control

You can perform multi-execution for multi-axes coordinated control in axes groups the same way as you can for axis operations. You can perform path control for multiple continuous lines and/or arcs if you use Buffer Mode under multi-axes coordinated control.



Point A

You can set the *BufferMode* input variable to motion control instruction to select one of the same Buffer Modes as are supported for single-axis operations. There are a total of eight instruction buffers for axes groups. Each axes group has one buffer for the instruction currently in operation and seven buffers for multi-execution instructions. Multi-execution of instruction cannot be used from an axis operation instruction to an axes group operation instruction and vice-versa.


Precautions for Correct Use

- Up to seven instructions can be buffered at the same time for a single axes group. If multi-execution is performed for eight or more instructions, an instruction error will occur.
- Multi-execution of multi-axes coordinated control instructions (axes group instructions) is not
 possible for axes operating as a single axis. Similarly, multi-execution of single-axis control
 instructions is not possible for axes operating under multi-axes coordinated control (axes
 group instructions). An instruction error will occur if these rules are broken.


Aborting

This is the default mode. No buffering is performed in this mode. The current command is aborted and the new instruction is executed. Multi-execution of motion control instructions that have no *BufferMode* input variable will operate in Aborting Mode. Operation of the multi-execution instruction starts at the current interpolation velocity when the multi-execution instruction is executed. With Aborting Mode you cannot combine single-axis control, including synchronized single-axis control and axes group control. An instruction error will occur at the time of multi-execution if you execute an axes group operation on an axis currently in a single-axis motion. This will stop both the axes group and the single axis.






Multi-execution during Acceleration/Deceleration




Multi-execution for axes groups is done so that the interpolation velocity remains continuous between instructions. If continuous operation is performed with an instruction with a travel distance of 0, the velocity changes for the axes will not be continuous.

Example: Interpolation Velocity and Velocities of Axes for Two-axis Cartesian Coordinates



Buffered

The multi-execution instruction remains in the buffer until the current operation is finished. The buffered instruction is executed after the operation for the current instruction is normally ended.



Blending

Blending for axes groups works in the same way as blending for single-axis operations. The buffered instruction remains in the buffer until the target position of the current instruction is reached. The buffer ered instruction is executed after the target position of the current instruction is reached. The axes do not stop at the target position. The two motions are blended together at the interpolation velocity specified with the *BufferMode* input variable.

The Interpolation Acceleration/Deceleration Over axes group parameter is used to select one of the following operations for when the acceleration/deceleration that is specified in the buffered instruction would exceed the target position.

• Use rapid acceleration/deceleration. (Blending is changed to Buffered.)

- Use rapid acceleration/deceleration.
- · Minor fault stop

Version Information

- For a CPU Unit with version 1.10 or later, Blending is not changed to Buffered even if you select *Use rapid acceleration/deceleration. (Blending is changed to Buffered.)* In this case, the maximum acceleration/deceleration rate is used and the blending operation is continued. Also, the axis does not stop with an error even if you select *Minor fault stop*. Similar to the previous case, the maximum acceleration/deceleration/deceleration rate is used and the blending operation is continued.
- Note that the following restriction applies to CPU Units with unit version 1.09 or earlier. For blending in multi-axes coordinated control, buffered operation is used if the results of profile processing show that the execution time of the current instruction is less than four control periods. A Notice of Insufficient Travel Distance to Achieve Blending Transit Velocity observation will occur.


The above restriction does not apply to CPU Units with unit version 1.10 or later.

Blending Low (Low Velocity)

Operation is performed using the target position of the current instruction and the target velocity that is the slower of the target velocities for the current instruction and buffered instruction.


• Blending Previous (Previous Velocity)

Operation is performed with the target velocity of the current instruction until the target position of the current instruction is reached. Operation is performed after acceleration/deceleration to the target velocity of the buffered instruction once the target position is reached.



Blending Next (Next Velocity)

Operation is performed using the target position of the current instruction and the target velocity of the buffered instruction.



• Blending High (High Velocity)

Operation is performed using the target position of the current instruction and the target velocity that is the faster of the target velocities for the current instruction and buffered instruction.

Transition Modes

Multi-execution of instructions for axes groups may create some shock on the device and/or workpiece due to changes in the direction of the interpolation path. You can specify the *TransitionMode* input variable to the motion control instruction to select a transition method to use between instructions in order to lessen this shock. You can choose from the following transition modes in the MC Function Module.

No.	Transition mode	Description
0	Transition Disabled (_ <i>mcTMNone</i>)	Do not perform any processing for transitions (default). No attempt is made to lessen the shock, but this results in a shorter operation time.
10	Superimpose Corners (_ <i>mcTMCornerSuperimposed</i>)	The deceleration of the current instruction is superimposed on the acceleration of the buffered instruction. You can keep the linear velocity of the interpolation path constant.

Additional Information


The PLCopen[®] technology specifications define numbers 0 through 9. Number 10 is unique to the MC Function Module.

• Transition Disabled (0: _mcTMNone)

No processing is performed to connect the two positions.


TransitionMode = _mcTMNone and BufferMode = _mcBuffered

The axis moves to position End1, stops, and then moves to position End2.




TransitionMode = _mcTMNone and BufferMode = _mcBlending

The axis moves to position End1, and then moves to position End2.




TransitionMode = _mcTMNone and BufferMode = _mcAborting


The axis moves from End1' (multi-execution of instruction) to End2.



• Superimpose Corners (10: _mcTMCornerSuperimposed)

The deceleration of the current instruction is superimposed on the acceleration of the buffered instruction. Operation is executed in the same amount of time as for the deceleration of the current instruction, no matter what is specified as the acceleration for the buffered instruction. The superimposed area will apply no jerk even if jerk is specified.





9



Additional Information

The path linear velocity is constant if the following two conditions are met.

- The target velocities of the current instruction and the buffered instruction are the same.
- The deceleration rate of the current instruction and the acceleration rate of the buffered instruction are the same.

Combining Transition Modes and Multi-execution of Instructions

The following table shows the combinations of Transition Modes and Buffer Modes.

	OK: Operation possible: Generates an error and stops					or and stops.
Buffer Mode Transition Mode	Aborting	Buffered	Blending Low	Blending Previous	Blending Next	Blending High
Transition Disabled (_ <i>mcTMNone</i>)	OK	ОК	OK	OK	OK	OK
Superimpose Corners ^{*1} (_ <i>mcTMCornerSuperimposed</i>)			OK	OK	OK	OK

*1 For superimpose corners, the deceleration for the current instruction and the acceleration for the buffered instruction will be superimposed.

9-8 Other Functions

This section describes other functions of the MC Function Module.

Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for the differences when you use NX-series Pulse Output Units.

9-8-1 Changing the Current Position

The command current position of a Servo axis can be changed to a specified value. The actual current position changes to a value that maintains the current following error with the command current position. For an encoder axis, you can change the actual current position. Use the MC_SetPosition instruction to specify the actual position you want to modify.

You can change the actual position even while an axis is in motion. If positioning to an absolute value is being executed, positioning will be performed to the target position using the new absolute coordinates. However, the travel distance will stay the same when you position to a relative value.



Precautions for Correct Use

- When the Count Mode is Rotary Mode, an instruction error will occur if you specify a position outside the ring counter range.
- After changing the current position the home will be undefined and you will not be able to use the following functions and instructions.

Software limits High-speed homing Interpolation instructions (linear and circular interpolation)

• Timing Chart for Execution While Axis Is Stopped

Execute		
Busy		
Active		
Done		
Add	itional Information	

You can change the actual position while home is defined by specifying a zero position preset for the MC_Home or MC_HomeWithParameter instruction.

For details on the MC_SetPosition instruction, refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-8-2 Torque Limit

The output torque is limited by enabling and disabling the torque limit function of the Servo Drive and by setting the torque limit value.

Different limits can be specified for the positive torque limit and negative torque limit.

For details, refer to the MC_SetTorqueLimit instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).



Precautions for Correct Use

You cannot use the torque limit function for an NX-series Pulse Output Unit.


9-8-3 Latching

Latching is used to control positioning based on the position where a trigger signal occurs, such as a signal from a sensor input. The position of the axis is recorded (i.e., latched) when the trigger signal occurs. You can set up to two trigger signals for each axis. Use the MC_TouchProbe (Enable External Latch) instruction to specify the Trigger Input Condition variable, Window Only variable, and Stopping Mode Selection variable for the axis you want to latch. In addition to signals that connect to the Servo Drive, you can also specify variables in the user program to use as a trigger. Use the MC_AbortTrigger (Disable External Latch) instruction to abort latching. You can use latching only with a Servo Drive that support latching (touch probe), such as the G5-series Servo Drives, or a GX-EC0211/EC0241 Encoder Input Terminal.

Use *WindowOnly* to detect only trigger signals within a specific start point and end point. The following chart shows the ranges for different Count Modes.


• Linear Mode

- The FirstPosition must be less than or equal to the LastPosition.
- An instruction error will occur if the *FirstPosition* is greater than the *LastPosition*.
- An instruction error will occur if a position beyond the position range of Linear Mode is specified.



• Rotary Mode

- The *FirstPosition* can be less than, equal to, or greater than the *LastPosition*. If the *FirstPosition* is greater than the *LastPosition*, the setting will straddle the modulo minimum position setting value.
- An instruction error will occur if a position beyond the upper and lower limits of the ring counter is specified.



For details on latching, refer to the MC_TouchProbe (Enable External Latch) and MC_AbortTrigger (Disable External Latch) instructions in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for the differences when you use NX-series Pulse Output Units.


9-8-4 Zone Monitoring

This function detects whether the command position or actual position of an axis is in the specified range (zone). Use the MC_ZoneSwitch (Zone Monitor) instruction to specify the first position and last position of the zone to check. The *InZone* output variable for the Zone Monitor instruction will change to TRUE when the position of the axis enters the specified zone. You can also specify multiple zones for a single axis. Zones can overlap.

For details on zone monitoring, refer to the MC_ZoneSwitch (Zone Monitor) instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-8-5 Software Limits

Actual positions can be monitored in the MC Function Module software. This function is separate from the hardware-based limit input signals. Set the range to monitor by setting the software limits in the Positive Software Limit and Negative Software Limit axis parameters. During normal positioning, motion is possible within the range of these software limits. Set software limits to prevent potential damage to machinery caused by mistakes in the user program or improper operation.



Axis Parameters That Are Related to Software Limits

Parameter name	Function	Setting range	Default
Software Limits	Select the software limit function.	0 to 4	0: Disabled
	0: Disabled		
	1: Deceleration stop for command position*1		
	2: Immediate stop for command position		
	3: Deceleration stop for actual position ^{*1}		
	4: Immediate stop for actual position		
Positive Software Limit	Set the software limit in the positive direction. The unit is command units.	Long reals ^{*2}	2,147,483,647
Negative Software Limit	Set the software limit in the negative direction. The unit is command units.		-2,147,483,648

- *1 If the actual position goes beyond a software limit during execution of a movement instruction that has a *Deceleration* input variable, the axis decelerates to a stop at the deceleration rate given by *Deceleration*. If the actual position goes beyond a software limit during execution of a movement instruction that does not have a *Deceleration* input variable, the axis decelerates to a stop at the maximum deceleration that is set in the axis parameters.
- *2 Positions can be set within a 40-bit signed integer range when converted to pulses.

You can use the axis settings of the Sysmac Studio, the MC_Write (Write MC Setting) instruction, or the MC_WriteAxisParameter (Write Axis Parameters) instruction to set the above axis parameters. If any setting values are changed for an axis or axes group in operation, those settings are enabled when the next operation begins.

Software limits function in the following two cases based on the axis operation state and the motion control instruction that is used.

Executing Motion Instructions

• When the Actual Position Is within the Software Limits An instruction error will occur if the target position is outside the software limit range. • When the Actual Position Is outside the Software Limits Motion is allowed only toward the software limit range. As long as the motion is toward the range, the target position does not need to be within the software limit range.

Precautions for Correct Use

Do not execute an instruction for an axis command for a target position that is outside of the software limit range.

• During Axis Motion

When the axis is in discrete motion, synchronized motion, continuous motion, or coordinated motion:

- An axis error will occur if the software limits are enabled for the command position and the command position leaves the range.
- An axis error will occur if the software limits are enabled for the actual position and the actual position leaves the range.

Additional Information

Software limits can be enabled when the Count Mode is set to Linear Mode and home is defined. Software limits are disabled in the following situations no matter what axis parameters have been set.

- When Count Mode is set to Rotary Mode.
- When home is not defined.
- During homing.

For details on the instruction to write the MC settings and the instruction to write the axis parameters, refer to the MC_Write instruction and MC_WriteAxisParameter instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

9-8-6 Following Error Monitoring

Following error is the difference between the command position and the actual position of an axis. The MC Function Module monitors the following error every motion control period.

If the value of the following error exceeds the Following Error Over Value that is set in the axes parameters, Following Error Limit Exceeded minor fault level error occurs. If it exceeds the Following Error Warning Value, a Following Error Warning observation occurs. Monitoring the following error is disabled during execution of the holding operation for homing.

• Axis Parameters That Are Related to Monitoring the Following Error

You can set the check values for monitoring the following error by setting the appropriate axis parameters. Set the Following Error Warning Value so that it is less than the Following Error Over Value.

Parameter name	Function	Setting range	Default
Following Error Over Value	Set the excessive following error check value. Set 0 to disable the excessive follow- ing error check. (Unit: command units)	Non-negative long reals	0
Following Error Warning Value	Set the following error warning check value. Set 0 to disable the following error warning check. (Unit: command units)	Non-negative long reals that are less than or equal to the Following Error Over Value	0

Set the axis parameters from the Sysmac Studio.

Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for the differences when you use NX-series Pulse Output Units.

9-8-7 Following Error Counter Reset

Resetting the following error counter resets the following error to 0.

Use the MC_ResetFollowingError instruction in the user program to reset the following error counter. You can use the MC_ResetFollowingError instruction for each axis during positioning or during homing. If you execute a following error counter reset while the axis is in motion, the current motion control instruction will be aborted and the command position will be set to the same value as the actual position.

The home will remain defined even after executing a following error counter reset.

For details on resetting the following error counter, refer to the MC_ResetFollowingError instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

• Axis Parameters That Are Related to Resetting the Following Error Counter

You can choose to reset the following error counter on an immediate stop, on a limit input stop, or after homing is completed by setting the appropriate axis parameters. Set the axis parameters from the Sysmac Studio.

Parameter name	Function	Setting range	Default
Immediate Stop Input Stop Method	Set the stopping method in the MC Function Module when the immediate stop input is enabled.	0, 2, or 3	0
	0: Immediate stop		
	2: Immediate stop and error reset		
	3: Immediate stop and Servo OFF		
Limit Input Stop Method	Set the stopping method in the MC Function Module when the positive limit input or nega- tive limit input is enabled.	0 to 3	0
	0: Immediate stop		
	1: Deceleration stop		
	2: Immediate stop and error reset		
	3: Immediate stop and Servo OFF		

Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for the differences when you use NX-series Pulse Output Units.

9-8-8 Axis Following Error Monitoring

You can monitor the amount of following error for the command position or the actual position between two axes. Use the MC_AxesObserve (Monitor Axis Following Error) instruction to specify the permitted following error and the two axes to monitor. If the permitted following error is exceeded, the *Invalid* output variable for the Monitor Axis Following Error instruction will change to TRUE.

You can use this monitoring function to program the actions to take when the following error between axes grows too large for gantry control and other devices where both axes perform the same operation.

Precautions for Correct Use


Even if the permitted following error between axes is exceeded, no error will occur in the MC Function Module. Check the *Invalid* output variable to stop axis operation or to take some other action as appropriate in the user program.

For details on axis following error monitoring, refer to the MC_AxesObserve (Monitor Axis Following Error) instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for the differences when you use NX-series Pulse Output Units.

9-8-9 In-position Check

You can check to see if the actual current position has reached the specified range for the target position during positioning or homing. After command output of the target position is completed, positioning is considered to be finished when the difference between the target position and the actual current position is within the in-position range. An instruction error occurs if the position is not within the in-position within the in-position check time.



• Axis Parameters That Are Related to In-position Checks

You can set the check conditions for the in-position check by setting the appropriate axis parameters. Set the in-position check time if you want to start any of the following operations only after confirming that axes are in position.

Parameter name	Function	Setting range	Default
In-position Range	Set the in-position width. (Unit: command units)	Non-negative long reals	10
In-position Check Time	Set the in-position check time in milliseconds. Set 0 to check for the end of positioning only when you define the home position during homing and not check positioning at other times. (Unit: ms)	0 to 10,000	0

Additional Information

- The in-position check is processed by the MC Function Module. The function in the Servo Drive is not used.
- Do not set an in-position check time if you want to start the next operation as quickly as possible without waiting for positioning to finish.

You can use the axis settings of the Sysmac Studio, the MC_Write (Write MC Setting) instruction, or the MC_WriteAxisParameter (Write Axis Parameters) instruction to set the above axis parameters.

Additional Information

The value set from the Sysmac Studio is restored if power to the CPU Unit is cycled or the user program is downloaded with the Synchronization menu command of the Sysmac Studio. Use the MC_Write (Write MC Setting) and MC_WriteAxisParameter (Write Axis Parameters) instructions only when you need to temporarily change the in-position check time.

Monitor Information That Is Related to In-position Checks

You can read Axis Variables from the user program to monitor when positioning finishes.

In the descriptions, a variable name $_MC_AX[*]$ is used as an example, but the same information applies to $_MC1_AX[*]$ and $_MC2_AX[*]$.

Variable name	Data type	Meaning	Function
_MC_AX[0-255].Details.Idle	BOOL	Idle	TRUE when processing is not currently performed for the command value, except when waiting for in-position state.* <i>Idle</i> and <i>InPosWaiting</i> are mutu- ally exclusive. They cannot both be TRUE at the same time.
_MC_AX[0-255].Details.InPosWaiting	BOOL	In-position Waiting	TRUE when waiting for in-position state. The in-position check is performed when positioning for the in-position check.

* This also includes states where processing is performed while in motion at velocity 0, during following error counter resets, during synchronized control, and during coordinated motion.

You can read Axes Group Variables from the user program to monitor when positioning finishes for the axes group.

In the descriptions, a variable name _*MC_GRP[*]* is used as an example, but the same information applies to _*MC1_GRP[*]* and _*MC2_GRP[*]*.

Variable name	Data type	Meaning	Function
_MC_GRP[0-63].Details.Idle	BOOL	Idle	TRUE when processing is not currently performed for the command value, except when waiting for in-position state.*1
			<i>Idle</i> and <i>InPosWaiting</i> are mutually exclusive. They cannot both be TRUE at the same time.
_MC_GRP[0-63].Details.InposWaiting	BOOL	In-position Waiting	TRUE when waiting for in-position state for any composition axis.*2
			The in-position check is performed when positioning for the in-position check.

*1 This also includes states where processing is performed while in motion at a velocity of 0.

*2 This variable is FALSE when all composition axes in the axes group are within the in-position ranges set in the axis parameters.

For details on the instruction to write the MC settings and the instruction to write the axis parameters, refer to the MC_Write (Write MC Setting) and MC_WriteAxisParameter (Write Axis Parameters) instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for the differences when you use NX-series Pulse Output Units.

9-8-10 Changing Axis Use

You can use the MC_ChangeAxisUse (Change Axis Use) instruction to temporarily change the setting of the Axis Use axis parameter. To change an axis in this way, it must be set as a *Used axis* or as an *Unused axis (changeable to used axis)* in the Axis Use axis parameter. If the Axis Use axis parameter is set to *Unused axis (changeable to used axis)* and the Axis Type parameter is set to a servo axis or virtual servo axis, you can set the axis in an axes group. A CPU Unit with unit version 1.04 or later and Sysmac Studio version 1.05 or higher are required.



Precautions for Correct Use

- Do not attempt to change an axis that is set to Unused axis (unchangeable to used axis) to a used axis.
- You cannot set an axis in an axes group if the Axis Use axis parameter is set to *Unused axis* (unchangeable to used axis).

For details, refer to the MC_ChangeAxisUse instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

For an application example of the MC_ChangeAxisUse instruction, refer to the *NJ/NX-series CPU Unit Software User's Manual* (Cat. No. W501).

9-8-11 Enabling Digital Cam Switch

You can use the MC_DigitalCamSwitch (Enable Digital Cam Switch) instruction to turn the digital outputs ON or OFF according to the axis position.

The setting of the *ValueSource* input variable to the instruction also allows you to adjust for the acceleration or deceleration rate.

Always use this function together with the NX_AryDOutTimeStamp instruction and with a Digital Output Unit that supports time stamp refreshing. The NX_AryDOutTimeStamp instruction turns the specified digital outputs ON or OFF at specified timing of the time stamp.

A CPU Unit with unit version 1.06 or later and Sysmac Studio version 1.07 or higher are required to use this function.



Precautions for Correct Use

You can use this instruction for an axis that is assigned to an NX-series Position Interface Unit. The NX Units that can be used are NX-EC0 and NX-ECS, also must be running the time stamping.

Refer to the MC_DigitalCamSwitch (Enable Digital Cam Switch) instruction in the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508) for details on enabling digital cam switch.

Refer to the *NJ/NX-series Instructions Reference Manual* (Cat. No. W502) for details on NX_AryDOutTimeStamp instruction.

Refer to the *NX-series Digital I/O Units User's Manual* (Cat. No. W521-E1-02 or later) for Digital Output Unit that supports time stamp refreshing.

Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524-E1-02 or later) for time stamping and time stamps.

9-8-12 Displaying 3D Motion Monitor for User Coordinate System

In the case that coordinate systems (such as SCARA robot and vertical articulated robot) other than orthogonal coordinate system are implemented by user programs, this function can be used to display the path of robot hands, etc. in 3D with Sysmac Studio.

You can create an _sMC_POSITION_REF type user-defined variable and display in 3D Motion Monitor Display Mode.

A CPU Unit with unit version 1.06 or later and Sysmac Studio version 1.07 or higher are required to use this function.

sMC_POSITION_REF

The followings are the members of _sMC_POSITION_REF type data.

Member	Data type	Meaning
CommandPosition	ARRAY [05] OF LREAL	Command Current Position
ActualPosition	ARRAY [05] OF LREAL	Actual Current Position

The following list describes each member.

Member	Description
User-defined variable.CommandPosition[0]	This is an X-axis component for the command current position.
	This member is assigned a user-defined variable that indi- cates the X-axis position of the command current position gen- erated by a user program.
User-defined variable.CommandPosition[1]	This is a Y-axis component for the command current position.
	This member is assigned a user-defined variable that indi- cates the Y-axis position of the command current position gen- erated by a user program.
User-defined variable.CommandPosition[2]	This is a Z-axis component for the command current position.
	This member is assigned a user-defined variable that indi- cates the Z-axis position of the command current position gen- erated by a user program.
User-defined variable.CommandPosition[3] to [5]	Not used.
User-defined variable.ActualPosition[0]	This is an X-axis component for the actual current position.
	This member is assigned a user-defined variable that indi- cates the X-axis position of the actual current position handled in a user program.
User-defined variable.ActualPosition[1]	This is a Y-axis component for the actual current position.
	This member is assigned a user-defined variable that indi- cates the Y-axis position of the actual current position handled in a user program.
User-defined variable.ActualPosition[2]	This is a Z-axis component for the actual current position.
	This member is assigned a user-defined variable that indi- cates the Z-axis position of the actual current position handled in a user program.
User-defined variable.ActualPosition[3] to [5]	Not used.

Name	Data type	Description
3D_position	_sMC_POSITION_REF	User-defined variable for 3D display
MCS_Cmd_TransX	LREAL	User-defined variable that indicates the X-axis position of the command current position generated by a user program
MCS_Cmd_TransY	LREAL	User-defined variable that indicates the Y-axis position of the command current position gen- erated by a user program
MCS_Cmd_TransZ	LREAL	User-defined variable that indicates the Z-axis position of the command current position generated by a user program
MCS_Act_TransX	LREAL	User-defined variable that indicates the X-axis position of the actual current position handled in a user program
MCS_Act_TransY	LREAL	User-defined variable that indicates the Y-axis position of the actual current position handled in a user program
MCS_Act_TransZ	LREAL	User-defined variable that indicates the Z-axis position of the actual current position handled in a user program

Each member is assigned a user-defined variable. The followings are the examples.

- 3D_position.CommandPosition[0] := MCS_Cmd_TransX;
- 3D_position.CommandPosition[1] := MCS_Cmd_TransY;
- 3D_position.CommandPosition[2] := MCS_Cmd_TransZ;
- 3D_position.ActualPosition[0] := MCS_Act_TransX;
- 3D_position.ActualPosition[1] := MCS_Act_TransY;
- 3D_position.ActualPosition[2] := MCS_Act_TransZ;

Overview of Operating Procedures

- **1** Create an _sMC_POSITION_REF type user-defined variable.
- 2 Create a program in which user-defined variables that indicate the command current position and actual current position for 3D display are assigned to each member of the created user-defined variable.
- **3** Select Specified coordinate in the Type Box in the 3D Machine Model List.

The _sMC_POSITION_REF data type is displayed in the 3D Machine Model Parameter Settings section.

- **4** Set the created user-defined variable in the *Value* Column in the 3D Machine Model Parameter Settings section.
- **5** Execute the user program.
- **6** Start tracing the data with the data trace to sample the data.
 - Check the trace results on the Data Trace Tab Page.

Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for details on 3D Motion Monitor Display Mode.

10

10

Sample Programming

This section describes basic application methods for homing, error monitoring, and other functions, and provides programming samples for absolute positioning, cam operation, and other axis operations.

10-1	Overvie	ew of Sample Programming	. 10-2
	10-1-1	Devices	10-2
	10-1-2	Installation and Wiring	10-2
	10-1-3	Setup	10-2
10-2	Basic P	Programming Samples	. 10-3
	10-2-1	Monitoring EtherCAT Communications and Turning ON Servos	10-3
	10-2-2	Interlocking Axis Operation with Master Control Instructions	10-5
	10-2-3	Error Monitoring and Error Resetting for Single-axis Operation and Synchronized Operation	10-7
	10-2-4	Error Monitoring and Error Resetting for Multi-axes Coordinated Operation	10-9
	10-2-5	Monitoring for Instruction Errors	.10-15
	10-2-6	Checking to See If Errors Are Reset	.10-17
	10-2-7	Stopping Axes during Single-axis Operation	. 10-19
	10-2-8	Stopping an Axes Group in Coordinated Motion	.10-23
	10-2-9	Homing and Absolute Positioning	.10-29
	10-2-10	Changing the Target Position by Re-execution of an Instruction	.10-34
	10-2-11	Interrupt Feeding	.10-40
	10-2-12	Changing the Cam Table by Re-execution of an Instruction	.10-44
	10-2-13	Using a Cam Profile Curve to Correct the Sync Position	. 10-53
	10-2-14	Shifting the Phase of a Master Axis in Cam Motion	. 10-63
	10-2-15	Changing the Actual Position during Velocity Control	. 10-71
	10-2-16	Changing a Cam Data Variable and Saving the Cam Table	. 10-77
	10-2-17	Temporarily Changing Axis Parameters	. 10-86
	10-2-18	Updating the Cam Table End Point Index	. 10-89

10-1 Overview of Sample Programming

This section provides information that applies to all of the sample programming.



Precautions for Correct Use

- The sample programming that is provided includes only programming that uses the MC Function Module.
- When programming actual applications, also program device interlocks, I/O with other devices, and other control procedures.
- Create a user program that will produce the intended device operation.
- Check the user program for proper execution before you use it for actual operation.
- Refer to the NX-series Position Interface Units User's Manual (Cat. No. W524) for application examples for the NX-series Position Interface Units.

10-1-1 Devices

The following devices are used in the sample programming.

Device	Servo configuration example
CPU Unit	NJ501-1□00 (unit version 1.0)
Power Supply Unit	NJ-Px3001
Servo Drive	R88D-KN□-ECT (version 2.1)
Servomotor	R88M-K
Encoder Input Terminal	GX-EC0211 (version 1.1)

10-1-2 Installation and Wiring

Refer to the following manual for details on installing and wiring the devices.

Device	Manual	
CPU Unit and Power Supply Unit	NJ-series CPU Unit Hardware User's Manual (Cat. No. W500)	
Servo Drive and Servomotor	G5-series AC Servo Drives/Servomotors with Built-in EtherCAT Commu- nications User's Manual (Cat. No. I576)	
Encoder Input Terminal	GX-series EtherCAT Slave User's Manual (Cat. No. W488)	
EtherCAT communications cables	GX-series EtherCAT Slave User's Manual (Cat. No. W488)	

10-1-3 Setup

Refer to the following manual for details on settings.

Setup	Manual		
Controller Setup	NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501)		
Motion Control Setup	<i>3-2 Axis Setting Procedure, 5-2 Axis Parameters, and A-1 Connecting the Servo Drive</i> in this manual.		
Servo parameters	G5-series AC Servo Drives/Servomotors with Built-in EtherCAT Communica- tions User's Manual (Cat. No. I576)		

10-2 Basic Programming Samples

This section provides programming samples for the basic functions of the MC Function Module.



Precautions for Correct Use

- When you use these programming samples for reference, be sure to add programming for suitable interlocks that suit the operating conditions of the devices.
- Enter the variables that are used in the programming samples from the Programming Layer in the Edit Pane of the Sysmac Studio.

10-2-1 Monitoring EtherCAT Communications and Turning ON Servos

In this sample, the MC_Power (Power Servo) instruction is executed to turn ON the Servo for the Servo Drive when EtherCAT process data communications are established with the Servo Drive.

Samples are provided for both ladder diagram and ST programming.

Main Variables Used in the Programming Samples

Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 0.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
MC_Axis000.Cfg.NodeAddress	UINT		This is the node address.
_EC_PDSlavTbl[N]	BOOL	FALSE	TRUE when EtherCAT process data communi- cations for node address N are in Operational state.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.


10

Ladder Diagram


When StartPg is TRUE, the status of process data communications is checked to see if communications are active and normal.



The Servo for axis 0 is turned ON if process data communications are active and normal.



If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.



ST Programming

// When StartPg is TRUE, the Servo is turned ON for axis 0 if process data communications are active and normal. IF (StartPg=TRUE)

AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)

AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN

Pwr_En:=TRUE;

ELSE

Pwr_En:=FALSE;

END_IF;

// If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed. // Program the FaultHandler according to the device.

IF MC_Axis000.MFaultLvI.Active=TRUE THEN FaultHandler();

END_IF;

// MC_Power PWR(:= MC_Axis000, Axis Enable := Pwr_En, Busy

Status => Pwr_Status, => Pwr_Bsy, Error => Pwr_Err, ErrorID => Pwr_ErrID

);

10-2-2 Interlocking Axis Operation with Master Control Instructions


You can place the MC_Power (Power Servo) instruction between the MC (Master Control Start) and MCR (Master Control End) instructions in ladder diagrams to interlock axis operation. When *Mc_On* is FALSE in this sample, the MC_Power (Power Servo) instruction between the MC and MCR instructions is disabled to turn OFF the Servo. The *CommandAborted* output variable from the current motion control instruction changes to TRUE at the same time, and axis motion stops.

You cannot use the MC instruction in ST. Therefore, a sample is provided only for a ladder diagram.

Main Variables Used in the Programming Samples

Variable name	Dete turne	Default	Comment
variable name	Data type	Delault	Comment
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 0.
MC_Axis000.MFaultLvI.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
Mc_On	BOOL	FALSE	This variable enables and disables the MC instruction. Control programming is not given in this sample. In actual programming, program controls for the required device operation.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.

Timing Chart






When Mc_On is TRUE, master control is started.




When *StartPg* is TRUE, the status of process data communications is checked to see if communications are active and normal.




The Servo for axis 0 is turned ON if process data communications are active and normal.



Master control is ended.



If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.



10-2-3 Error Monitoring and Error Resetting for Single-axis Operation and Synchronized Operation


You can monitor error status by monitoring the status of Axis Minor Fault Occurrence in the Axis Variable. If a minor fault level error occurs in this sample, the *Enable* input variable for the MC_Power instruction changes to FALSE to turn OFF the Servo. If the external button is ON and the command current velocity is zero, the error is reset with the MC_Reset (Reset Axis Error) instruction. Samples are provided for both ladder diagram and ST programming.

Main Variables Used in the Programming Samples


Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 0.
MC_Axis000.MFaultLvI.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
MC_Axis000.Status.ErrorStop	BOOL	FALSE	TRUE while there is a minor fault level error for axis 0 and the axis is decelerating to a stop or stopped.
MC_Axis000.Details.Idle	BOOL	FALSE	TRUE when the command current velocity for axis 0 is zero, except when waiting for in-position state.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.
ResetON	BOOL	FALSE	This variable gives the status of the external button that is used to reset errors.

Ladder Diagram


When *StartPg* is TRUE, the status of process data communications is checked to see if communications are active and normal.




The Servo for axis 0 is turned ON if process data communications are active and normal.



If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.



If ResetON is TRUE (i.e., when the external button is ON) and the command current velocity is zero, the error is reset.



ST Programming

// When StartPg is TRUE, the status of process data communications is checked to see if communications are active and normal. // The Servo is turned ON for axis 0 if process data communications for axis 0 are active and normal. // If process data communications are not active, the Servo for axis 0 is turned OFF. IF (StartPg=TRUE) AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE) AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN Pwr_En:=TRUE; ELSE Pwr_En:=FALSE; END_IF; // If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed. // Program the FaultHandler according to the device. IF MC_Axis000.MFaultLvI.Active=TRUE THEN FaultHandler(); END_IF; // If ResetON is TRUE (i.e., when the external button is ON) and the command current velocity is zero, the error is reset. IF (ResetOn=TRUE) AND (MC_Axis000.Status.ErrorStop=TRUE) AND (MC_Axis000.Details.Idle=TRUE) THEN Reset_Ex := TRUE; // Minor fault is reset. END_IF; // MC_Power PWR(:= MC Axis000, Axis Enable := Pwr_En, Status => Pwr_Status, Busy => Pwr_Bsy, => Pwr_Err, Error ErrorID => Pwr_ErrID); // MC Reset RESET(:= MC_Axis000, Axis Execute := Reset_Ex, => Reset D. Done Busy => Reset_Bsy, Failure => Reset_Fai, Error => Reset_Err, ErrorID => Reset_ErrID

);

10-2-4 Error Monitoring and Error Resetting for Multi-axes Coordinated Operation

You can monitor error status by monitoring the status of Axis Minor Fault Occurrence in the Axis Variables and Axes Group Minor Fault Occurrence in the Axes Group Variable. If a minor fault level error occurs in this sample, the *Execute* input variable for the MC_GroupDisable (Disable Axes Group) instruction changes to TRUE to disable the axes group. If the external button is ON and the command current velocity for the axes group is zero, the error is reset with the MC_GroupReset (Reset Axes Group Error) instruction.

Samples are provided for both ladder diagram and ST programming.

Main Variables Used in the Programming Samples

Variable name	Data type	Default	Comment
MC_Group000	_sGROUP_REF		This is the Axes Group Variable for axes group 0.
MC_Group000.MFaultLvI.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axes group 0.
MC_Group000.Details.Idle	BOOL	FALSE	TRUE when the command interpolation velocity for axes group 0 is zero, except when waiting for in-position state.
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 0.
MC_Axis000.MFaultLvI.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 0.
MC_Axis001	_sAXIS_REF		This is the Axis Variable for axis 1.
MC_Axis001.MFaultLvI.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 1.
MC_Axis001.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
Pwr1_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
Pwr2_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR2 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.
ResetON	BOOL	FALSE	This variable gives the status of the external button that is used to reset errors.

I

Ladder Diagram

When *StartPg* is TRUE, the status of process data communications for axis 0 is checked to see if communications are active and normal.

StartPg _EC_PDSIavTbl[MC_Axis000.Cfg.NodeAddress] _EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress Lock1

When *StartPg* is TRUE, the status of process data communications for axis 1 is checked to see if communications are active and normal.

Star	Pg _EC_PDSlavTbl[MC_A	xis001.Cfg.NodeAddress]	_EC_CommErrTbl[MC_A	Axis001.Cfg.NodeAddress Lo	ock	<2
	-			A	\frown	-
			V			

The Servo for axis 0 is turned ON if process data communications for axis 0 are active and normal.

	PWR1	
	MC_Power	
Lock1 MC_Axis000 -	Axis — Axis	— Pwr1_Status
┝ <u></u>	Enable Status	└──── ○ ──
	Busy	– Pwr1_Bsy
		– Pwr1_Err
		– Pwr1_ErrID


The Servo for axis 1 is turned ON if process data communications for axis 1 are active and normal.



If a minor fault level error occurs for any of the composition axes in the axes group, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.

MC_Axis000.MFaultLvl.Active		FaultHandler EN FaultHandler
MC_Axis001.MFaultLvI.Active		
MC_Group000.MFaultLvI.Active		

If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.



10-2 Basic Programming Samples


10

10-2-4 Error Monitoring and Error Resetting for Multi-axes Coordinated Operation

If the Servo is ON for axis 1 and home is not defined, the MC_Home instruction is executed.

	HM2
	MC_Home
Pwr2_Status MC_Axis001.Details.Homed MC_Axis001 -	Axis — — Axis — Hm2_D
<i>\</i>	Execute Done
	Busy – Hm2_Bsy
	CommandAborted — Hm2_Ca
	Error – Hm2_Err
	ErrorID – Hm2_ErrID


The status of the axes group and the status of home for axis 0 and axis 1 are checked.



If home is defined for axis 0 and axis 1, the axes group is enabled.

GRP_EN
MC_GroupEnable
MC_Group000 — AxesGroup — AxesGroup — Grp_En_D
Execute Done
Busy – Grp_En_Bsy
CommandAborted – Grp_En_Ca
Error – Grp_En_Err
ErrorID — Grp_En_ErrID

If there is a minor fault level error for the axes group, the axes group is disabled.



If the external button is ON, the status of *ResetON* and the status of axes group motion is checked.



If ResetON is TRUE and the axes group is stopped, the error is

			GRP_RES	SET	
			MC_Group	Reset	
	Lock4	MC_Group000 —	AxesGroup ——	AxesGroup	Grp_Reset_D
ł			Execute	Done	O
				Busy	 Grp_Reset_Bsy
				Failure	 Grp_Reset_Failure
				Error	 Grp_Reset_Err
				ErrorID	— Grp_Reset_ErrID
			/ Moodinoup	Done Busy Failure Error	— Grp_Reset_Bsy — Grp_Reset_Failure — Grp_Reset_Err

10-11

ST Programming

// When StartPg is TRUE, the status of process data communications is checked to see if communications are active and normal. // The Servo is turned ON for axis 0 if process data communications for axis 0 are active and normal. // If process data communications are not active, the Servo for axis 0 is turned OFF. IF (StartPg =TRUE) AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE) AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN // Turn ON the Servo for axis 0. Pwr1 En:=TRUE; FI SF // Turn OFF the Servo for axis 0. Pwr1_En:=FALSE; END IF; // When StartPq is TRUE, the status of process data communications is checked to see if communications are active and normal. // The Servo is turned ON for axis 1 if process data communications for axis 1 are active and normal. // If process data communications are not active, the Servo for axis 1 is turned OFF. IF (StartPg =TRUE) AND (EC_PDSlavTbl[MC_Axis001.Cfg.NodeAddress]=TRUE) AND (_EC_CommErrTbl[MC_Axis001.Cfg.NodeAddress]=FALSE) THEN Pwr2 En:=TRUE; // Turn ON the Servo for axis 1. ELSE // Turn OFF the Servo for axis 1. Pwr2_En:=FALSE; END_IF; // If there is a minor fault level error for a composition axis in the axes group. // execute the error handler (FaultHandler). IF (MC Axis000.MFaultLvI.Active=TRUE) OR (MC Axis001.MFaultLvI.Active=TRUE) OR (MC Group000.MFaultLvI.Active=TRUE) THEN FaultHandler(); // Program the FaultHandler according to the device. END_IF; // If the Servo is ON for axis 0 and home is not defined, the MC Home instruction is executed. IF (Pwr1_Status=TRUE) AND (MC_Axis000.Details.Homed=FALSE) THEN $Hm1_Ex:=TRUE;$ END_IF; // If the Servo is ON for axis 1 and home is not defined, the MC Home instruction is executed. IF (Pwr2_Status=TRUE) AND (MC Axis001.Details.Homed=FALSE) THEN Hm2_Ex:= TRUE; END_IF; // If the axes group is disabled and home is defined for axis 0 and axis 1, the axes group is enabled. IF (MC_Group000.Status.Disabled=TRUE) AND (Hm1_D=TRUE) AND (Hm2_D=TRUE) THEN Grp_En_Ex:= TRUE; END IF; // If there is a minor fault level error for the axes group, the axes group is disabled. IF MC Group000.MFaultLvI.Active=TRUE THEN Grp Dis Ex:=TRUE; END_IF; // If ResetON is TRUE (i.e., if the external button is ON) and the axes group is stopped, the error is reset. IF (ResetON=TRUE) AND (MC_Group000.Status.ErrorStop=TRUE) AND (MC_Group000.Details.Idle=TRUE) THEN Grp_Reset_Ex := TRUE; END_IF;

```
//MC_Power1
PWR1(
        Axis
               := MC_Axis000,
        Enable := Pwr1_En,
        Status => Pwr1_Status,
        Busy
               => Pwr1_Bsy,
               => Pwr1_Err,
        Error
        ErrorID => Pwr1_ErrID
);
//MC_Power2
PWR2(
        Axis
               := MC_Axis001,
        Enable := Pwr2 En,
        Status => Pwr2_Status,
        Busy
               => Pwr2_Bsy,
        Error
               => Pwr2 Err,
        ErrorID => Pwr2_ErrID
);
// MC_Home1
HM1(
                               := MC_Axis000,
        Axis
                               := Hm1_Ex,
        Execute
        Done
                               => Hm1 D,
                               => Hm1_Bsy,
        Busy
        CommandAborted
                               => Hm1 Ca.
        Error
                               => Hm1 Err.
        ErrorID
                               => Hm1 ErrID
);
// MC_Home2
HM2(
                               := MC_Axis001,
        Axis
                               := Hm2_Ex,
        Execute
        Done
                               => Hm2_D,
        Busy
                               => Hm2_Bsy,
                               => Hm2_Ca,
        CommandAborted
        Error
                               => Hm2_Err,
        ErrorID
                               => Hm2_ErrID
);
//MC GroupEnable
GRP_EN(
        AxesGroup
                               := MC_Group000,
        Execute
                               := Grp_En_Ex,
       Done
                               => Grp_En_D,
        Busy
                               => Grp_En_Bsy,
        CommandAborted
                               => Grp_En_Ca,
        Error
                               => Grp_En_Err,
        ErrorID
                               => Grp_En_ErrID
);
//MC_GroupDisable
GRP_DIS(
                               := MC_Group000,
        AxesGroup
        Execute
                               := Grp_Dis_Ex,
        Done
                               => Grp_Dis_D,
        Busy
                               => Grp_Dis_Bsy,
                               => Grp_Dis_Ca,
        CommandAborted
        Error
                               => Grp_Dis_Err,
        ErrorID
                               => Grp_Dis_ErrID
```

);

//MC_GroupReset GRP_RESET(
AxesGroup	:= MC_Group000,
Execute	:= Grp_Reset_Ex,
Done	=> Grp_Reset_D,
Busy	=> Grp_Reset_Bsy,
Failure	=> Grp_Reset_Fai,
Error	=> Grp_Reset_Err,
ErrorID	=> Grp_Reset_ErrID
).	

);

10-2-5 Monitoring for Instruction Errors

In this sample, further processing is not performed if there is an error when the MC_Power (Power Servo) instruction is executed. Whether further processing is possible is indicated by the *UpgOn* variable.

Samples are provided for both ladder diagram and ST programming.

Main Variables Used in the Programming Samples


Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 0.
Pwr_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR instance of the MC_Power instruction. It is TRUE when the Servo is ON.
Pwr_Bsy	BOOL	FALSE	This variable is assigned to the <i>Busy</i> output variable from the PWR instance of the MC_Power instruction. It is TRUE when the Servo is ON.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.
UpgOn	BOOL	FALSE	TRUE if further program execution is performed.

Ladder Diagram


When *StartPg* is TRUE, the status of process data communications is checked to see if communications are active and normal.



The Servo for axis 0 is turned ON if process data communications are active and normal.



A check is made to see if any errors occurred when MC_Power was executed before execution of further processing.



ST Programming

// When StartPg is TRUE, the Servo is turned ON for axis 0 if process data communications are active and normal. // If process data communications are not active, the Servo is turned OFF. IF (StartPg=TRUE) AND (_EC_PDSIavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE) AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN Pwr_En:=TRUE; ELSE Pwr_En:=FALSE; END_IF; IF (Pwr_Status=TRUE) OR (Pwr_Bsy=TRUE) THEN UpgOn := TRUE; // Further processing executed. ELSE UpgOn := FALSE; // Further processing not executed. END_IF;

```
// MC_Power
PWR(
Axis := MC_Axis000,
Enable := Pwr_En,
Status => Pwr_Status,
Busy => Pwr_Bsy,
Error => Pwr_Err,
ErrorID => Pwr_ErrID
```

);

10-2-6 Checking to See If Errors Are Reset

In this sample, the MC_Reset (Reset Axis Error) instruction is executed if an external button turns ON while there is a minor fault level error. Further normal processing is not executed until the *Done* output variable from the MC_Reset instruction changes to TRUE.

If the *Failure* output variable changes to TRUE, the axis decelerated to a stop or an MC common error has occurred. The cause that made the *Failure* output variable from the MC_Reset instruction turn ON is read.


Samples are provided for both ladder diagram and ST programming.

Main Variables Used in the Programming Samples

Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 0.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
Pwr_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR instance of the MC_Power instruction. It is TRUE when the Servo is ON.
ResetON	BOOL	FALSE	This variable gives the status of the external button that is used to reset errors.
GetFaultFactor			This is the process to read the cause of the error. Program it according to the device.
RegularProcess			This is the normal processing. Program it according to the device.

Ladder Diagram

In this sample, the MC_Reset (Reset Axis Error) instruction is executed if an external button turns ON (i.e., if *ResetOn* changes to TRUE) while there is a minor fault level error.



If the *Failure* output variable from the MC_Reset instruction changes to TRUE, processing is performed to read the cause of the device error with GetFaultFactor. Program GetFaultFactor according to the device.

MC_Axis000.MFaultLvI.Active	Reset_Fail	GetFaultFactor EN GetFaultFactor	
			I

If a minor fault level error did not occur or was reset, normal device processing (RegularProcess) is performed. Program GetFaultFactor according to the device.

MC_Axis000.MFaultLvI.Active	RegularProcess EN RegularProcess	
νı	Liv negulari locess	

ST Programming

```
// If the external button is ON (i.e., if ResetOn changes to TRUE) while there is a minor fault level error,
// the MC_Reset (Reset Axis Error) instruction is executed.
IF (MC_Axis000.MFaultLvI.Active=TRUE)
AND (ResetOn=TRUE) THEN
        Reset Ex := TRUE;
                                 // Minor fault is reset.
ELSE
        Reset_Ex := FALSE;
END_IF;
// If the Failure output variable from the MC_Reset instruction changes to TRUE,
// processing is performed to read the cause of the error with GetFaultFactor.
// Program GetFaultFactor according to the device.
IF (MC_Axis000.MFaultLvI.Active=TRUE)
AND (Reset Fail=TRUE) THEN
        GetFaultFactor();
END IF;
// If a minor fault level error did not occur or was reset,
// normal device processing (RegularProcess) is performed.
// Program GetFaultFactor according to the device.
IF MC_Axis000.MFaultLvI.Active=FALSE THEN
        RegularProcess();
END_IF;
// MC Reset
RESET(
        Axis
                := MC Axis000.
        Execute := Reset Ex,
        Done => Reset_D,
        Busy => Reset_Bsy,
        Failure => Reset_Fail,
        Error => Reset_Err,
        ErrorID => Reset_ErrID
```

);

10-2-7 Stopping Axes during Single-axis Operation

In this sample, the MC_Stop instruction is executed to decelerate to a stop if an external button turns ON during execution of the MC_MoveAbsolute (Absolute Positioning) instruction. If there is a minor fault level error, the *CommandAborted* output variable from the MC_Stop instruction changes to TRUE. In that case, the MC_ImmediateStop instruction is executed to stop immediately. If for any reason the *Error* output variable from the MC_Stop instruction is executed to stop instruction is executed, the axis status is Error Deceleration Stopping.

Samples are provided for both ladder diagram and ST programming.

Main Variables Used in the Programming Samples


Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 0.
MC_Axis000.MFaultLvI.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 0.
Pwr_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR instance of the MC_Power instruction. It is TRUE when the Servo is ON.
Stp_Ca	BOOL	FALSE	This variable is assigned to the <i>Command-</i> <i>Aborted</i> output variable from the STP instance of the MC_Stop instruction.
Stp_Err	BOOL	FALSE	This variable is assigned to the <i>Error</i> output variable from the STP instance of the MC_Stop instruction.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.
StopOn	BOOL	FALSE	This variable gives the status of the external button that is used to stop. The MC_Stop instruction is executed to stop the axis if this variable is TRUE.

Ladder Diagram


When *StartPg* is TRUE, the status of process data communications of axis 0 is checked to see if communications are active and normal.




The Servo for axis 0 is turned ON if process data communications for axis 0 are active and normal.




If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.




If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed for axis 0.




After homing is completed for axis 0, the MC_MoveAbsolute (Absolute Positioning) instruction is executed.



If *StopOn* is TRUE, the MC_Stop instruction is executed.



If the *Error* or *CommandAborted* output variable from the MC_Stop instruction changes to TRUE, the MC_ImmediateStop instruction is executed to stop immediately.



10

ST Programming

// If the input parameters for absolute positioning and stopping are not set, the target values and other parameters are set.
IF InitFlag=FALSE THEN

// The input parameters for the MC_MoveAbsolute (Absolute Positioning) instruction are set. Mv_Abs_Pos := LREAL#10000.0; Mv_Abs_Vel := LREAL#500.0; Mv_Abs_Acc := LREAL#500.0; Mv_Abs_Dec := LREAL#500.0; Mv_Abs_Dir := _eMC_DIRECTION#_mcPositiveDirection;

// The input parameters for the MC_Stop instruction are set.
Stp_Dec:=LREAL#5000.0;

// The input parameters for the MC_Immediate Stop instruction are set. Imd_Stp_SM :=_eMC_STOP_MODE#_mcFreeRunStop;

// The Input Parameter Initialization Completed Flag is changed to TRUE. InitFlag := TRUE;

END_IF;

// When *StartPg* is TRUE, the Servo is turned ON for axis 0 if process data communications are active and normal. IF (StartPg=TRUE)

- AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
- AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN

Pwr_En:=TRUE;

ELSE

Pwr_En:=FALSE; END_IF;

// If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed.
// Program the FaultHandler according to the device.
IF MC_Axis000.MFaultLvI.Active=TRUE THEN

FaultHandler(); END_IF;

// If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed. IF (Pwr_Status=TRUE) AND (MC_Axis000.Details.Homed=FALSE) THEN Hm_Ex:=TRUE;

END_IF;

// If *StopOn* is TRUE, stopping is executed. IF StopOn=TRUE THEN Stp_Ex:=TRUE; END_IF;

//MC_Power PWR(

```
:= MC_Axis000,
       Axis
       Enable := Pwr_En,
        Status => Pwr_Status,
               => Pwr_Bsy,
       Busy
       Error
               => Pwr_Err,
       ErrorID => Pwr_ErrID
);
//MC_Home
HM(
        Axis
                               := MC_Axis000,
       Execute
                                := Hm_Ex,
       Done
                               => Hm_D,
                               => Hm_Bsy,
       Busy
       CommandAborted
                               => Hm Ca,
       Error
                               => Hm_Err,
       ErrorID
                                => Hm_ErrID
);
//MC_MoveAbsolute
MV_ABS(
                               := MC_Axis000,
        Axis
                               := Mv_Abs_Ex,
       Execute
                               := Mv_Abs_Pos,
       Position
                               := Mv_Abs_Vel,
       Velocity
                               := Mv_Abs_Acc,
       Acceleration
       Deceleration
                               := Mv_Abs_Dec,
       Direction
                               := Mv Abs Dir.
       Done
                               => Mv Abs D.
       Busy
                               => Mv Abs Bsv.
        Active
                               => Mv_Abs_Act,
       CommandAborted
                               => Mv Abs Ca,
       Error
                               => Mv_Abs_Err,
       ErrorID
                               => Mv_Abs_ErrID
);
//MC_Stop
STP(
                               := MC_Axis000,
        Axis
       Execute
                               := Stp_Ex,
       Deceleration
                               := Stp_Dec,
       Done
                               => Stp D,
                               => Stp_Bsy,
       Busy
                               => Stp_Act,
        Active
       CommandAborted
                               => Stp_Ca,
       Error
                               => Stp_Err,
       ErrorID
                               => Stp_ErrID
);
//MC_ImmediateStop
IMD_STP(
       Axis
                               := MC_Axis000,
        Execute
                               := Imd_Stp_Ex,
       StopMode
                               := Imd Stp SM,
       Done
                               => Imd_Stp_D,
                               => Imd_Stp_Bsy,
       Busy
                               => Imd_Stp_Ca,
       CommandAborted
                               => Imd_Stp_Err,
       Error
       ErrorID
                               => Imd_Stp_ErrID
);
```

10-2-8 Stopping an Axes Group in Coordinated Motion

In this sample, the MC_GroupStop instruction is executed to decelerate to a stop if an external button turns ON during execution of the MC_MoveLinearAbsolute (Absolute Linear Interpolation) instruction. If there is a minor fault level error, the *CommandAborted* output variable from the MC_GroupStop instruction changes to TRUE. In that case, the MC_GroupImmediateStop instruction is executed to stop immediately. If for any reason the *Error* output variable from the MC_GroupStop instruction changes to TRUE, the MC_GroupImmediateStop instruction is executed to stop immediately. If the MC_GroupImmediateStop instruction is executed to stop immediately. If the MC_GroupImmediateStop instruction is executed to stop immediately. If the MC_GroupImmediateStop instruction is executed, the axes group status is Error Deceleration Stopping.

Main Variables Used in the Programming Samples

Variable name	Data type	Default	Comment
MC_Group000	_sGROUP_REF		This is the Axes Group Variable for axes group 0.
MC_Group000.Status.Disabled	BOOL	FALSE	TRUE when axes group 0 is disabled.
MC_Group000.MFaultLvI.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axes group 0.
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 0.
MC_Axis000.MFaultLvI.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 0.
MC_Axis001	_sAXIS_REF		This is the Axis Variable for axis 1.
MC_Axis001.MFaultLvI.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 1.
MC_Axis001.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
Pwr1_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
Pwr2_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR2 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
Grp_Stp_Ca	BOOL	FALSE	This variable is assigned to the <i>CommandAborted</i> output variable from the GRP_EN instance of the MC_GroupStop instruction.
Grp_Stp_Err	BOOL	FALSE	This variable is assigned to the <i>Error</i> output variable from the GRP_EN instance of the MC_GroupStop instruction.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.
StopOn	BOOL	FALSE	This variable gives the status of the external button that is used to stop. The MC_GroupStop instruction is executed to stop the axes group if this variable is TRUE.
InitFlag	BOOL	FALSE	TRUE if the input parameters are set for the MC_MoveLinearAbsolute and MC_GroupStop instructions.
Grp_En_Ex	BOOL	FALSE	This variable is used to execute the GRP_EN instance of the MC_GroupEnable instruction. It is used in ST programming.
Mv_Lin_Abs_Ex	BOOL	FALSE	This variable is used to execute the MV_LIN_ABS instance of the MC_MoveLinear instruction. It is used in ST programming.
Grp_Stp_Ex	BOOL	FALSE	This variable is used to execute the GRP_STP instance of the MC_GroupStop instruction. It is used in ST programming.
Grp_Imd_Stp_Ex	BOOL	FALSE	This variable is used to execute the GRP_IMD_STP instance of the MC_GroupImmediateStop instruction. It is used in ST programming.

Ladder Diagram


When StartPg is TRUE, the status of process data communications of axis 0 is checked to see if communications are active and normal.




When StartPg is TRUE, the status of process data communications of axis 1 is checked to see if communications are active and normal.

StartPg _EC_PDSlavTbl[MC_Axis	s001.Cfg.NodeAddress]	_EC_CommErrTbl[MC_A	xis001.Cfg.NodeAddress	Lock1
			1	()
		V		\neg \square
				<u> </u>


The Servo for axis 0 is turned ON if process data communications for axis 0 are active and normal.




The Servo for axis 1 is turned ON if process data communications for axis 1 are active and normal.



If a minor fault level error occurs for the axes group, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.



If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.



After home is defined for axis 0 and axis 1, the axes group is enabled.

			(GRP_EN			
Hm1_D	Hm2_D MC_ Hm2_D MC_Group000.Status.Disab	_Group000 —			esGroup Done Busy IAborted Error	Ca Err	D

The input parameters for the MC_MoveLinearAbsolute and MC_GroupStop instructions are set.

InitFlag	1		IC_MoveLinearAbsolute	
	2	Mv_Lin_Abs_Pos [
	3	Mv_Lin_Abs_Pos [1] := LREAL#3000	
	4	Mv_Lin_Vel	:= LREAL#1000	
	5	Mv_Lin_Abs_Acc	:= LREAL#1000	
	6	Mv_Lin_Abs_Dec	:= LREAL#1000.0;	
	7	Mv_Lin_Abs_Jrk	:= LREAL#1000.0;	
	8	// Parameters for M	IC_GroupStop	
	9	Grp_Stp_Dec	:= LREAL#1000.0;	
	10	Grp_Stp_Jrk	:= LREAL#1000.0;	
	11	InitFlag:=TRUE;	// InitFlag is made TRUE.	


If the axes group is enabled, linear interpolation is executed.

		MV_	LIN_ABS	
MC_Group000.Status.Ready	MC_Group000 —		IoveLinear — — AxesGroup Done	– Mv_Lin_Abs_D
	Mv_Lin_Abs_Pos —	Position	Busy	- Mv_Lin_Abs_Bsy
	Mv_Lin_Abs_Vel — Mv_Lin_Abs_Acc —	•		— Mv_Lin_Abs_Act — Mv_Lin_Abs_Ca
	Mv_Lin_Abs_Dec —	Deceleration	Error	— Mv_Lin_Abs_Err
	Mv_Lin_Abs_Jrk — Mv_Lin_Abs_Cs —			— Mv_Lin_Abs_ErrID
	Mv_Lin_Abs_Bm — Mv_Lin_Abs_Tm —		0	
		Tansiloniviou	C	

If the external button turns ON (i.e., *StopOn* changes to TRUE) during execution of linear interpolation, the MC_GroupStop instruction is executed to decelerate the axes to a stop.

GRP_STP				
		GroupStop	Grp_Stp_D	
StopOn MC_Group000.Status.Moving MC_Group000 -		– — AxesGroup		
	Execute	Done	()	
Grp_Stp_Dec -	Deceleration	Busy	- Grp_Stp_Bsy	
-	Jerk	Active	— Grp_Stp_Act	
-	BufferMode	CommandAborted	— Grp_Stp_Ca	
		Error	— Grp_Stp_Err	
		ErrorID	- Grp_Stp_ErrID	

If the *Error* or *CommandAborted* output variable of the MC_GroupStop instruction is TRUE, the MC_GroupImmediateStop instruction is executed to stop immediately.



ST Programming

// If the input parameters for absolute linear interpolation and stopping the axes group are not set, the target values and other parameters are set.
IF InitFlag=FALSE THEN

// The input parameters for the MC_MoveLinearAbsolute (Absolute Linear Interpolation) instruction are set.

Mv_Lin_Abs_Pos[0]	:= LREAL#3000.0;
Mv_Lin_Abs_Pos[1]	:= LREAL#3000.0;
Mv_Lin_Abs_Vel	:= LREAL#1000.0;
Mv_Lin_Abs_Acc	:= LREAL#1000.0;
Mv_Lin_Abs_Dec	:= LREAL#1000.0;
Mv_Lin_Abs_Jrk	:= LREAL#1000.0;

// The input parameters for the MC_GroupStop instruction are set.
Grp_Stp_Dec := LREAL#1000.0;
Grp_Stp_Jrk := LREAL#1000.0;

// The Input Parameter Initialization Completed Flag is changed to TRUE. InitFlag := TRUE;

END_IF;

```
// When StartPg is TROE, the Serve is turned ON for axis T in process data communications are active and normal
// If process data communications are not active, the Serve is turned OFF.
IF (StartPg =TRUE)
AND (_EC_PDSIavTbl[MC_Axis001.Cfg.NodeAddress]=TRUE) THEN
```

Pwr2_En:=TRUE; // Turn ON the Servo for axis 1.

ELSE

Pwr2_En:=FALSE; // Turn OFF the Servo for axis 1.

END_IF;

// If a minor fault level error occurs, the error handler for the device (FaultHandler) is executed. // Program the FaultHandler according to the device. IF (MC_Axis000.MFaultLvI.Active=TRUE) OR (MC_Axis001.MFaultLvI.Active=TRUE) OR (MC_Group000.MFaultLvI.Active=TRUE) THEN FaultHandler(); END_IF;

```
// If home is defined for axis 0 and axis 1 and the axes group is disabled, the axes group is enabled.
IF (MC_Group000.Status.Disabled=TRUE)
AND (Hm1_D=TRUE) AND (Hm2_D=TRUE) THEN
        Grp_En_Ex:= TRUE;
// If the axes group is enabled, absolute linear interpolation is executed.
IF MC Group000.Status.Ready=TRUE THEN
        Mv_Lin_Abs_Ex:=TRUE;
// If the external button turns ON (i.e., StopOn changes to TRUE) during execution of absolute linear interpolation,
the axes group is stopped.
IF (MC Group000.Status.Moving=TRUE)
AND (StopOn=TRUE) THEN
        Grp Stp Ex := TRUE;
// If the CommandAborted or Error output variable from the Group Stop instruction are TRUE, the axes group is
stopped immediately.
IF (Grp_Stp_Ca=TRUE)
OR (Grp_Stp_Err=TRUE) THEN
        Grp_Imd_Stp_Ex:=TRUE;
                := MC Axis000,
        Enable := Pwr1_En,
        Status => Pwr1_Status,
        Busy
               => Pwr1_Bsy,
        Frror
               => Pwr1_Err,
        ErrorID => Pwr1_ErrID
                := MC Axis001,
        Enable := Pwr2 En.
        Status => Pwr2_Status,
        Busy
                => Pwr2 Bsv.
                => Pwr2_Err,
        Error
        ErrorID => Pwr2_ErrID
                                := MC_Axis000,
                                := Hm1 Ex.
        Execute
        Done
                                => Hm1 D,
                                => Hm1_Bsy,
        CommandAborted
                                => Hm1 Ca.
                                => Hm1 Err,
        ErrorID
                                => Hm1 ErrID
                                := MC_Axis001,
        Execute
                                := Hm2_Ex,
                                => Hm2 D,
        Done
                                => Hm2_Bsy,
        CommandAborted
                                => Hm2_Ca,
```

=> Hm2_Err,

=> Hm2_ErrID

END_IF;

END_IF;

END_IF;

END IF;

);

);

);

HM2(

//MC_Home HM1(

PWR2(

//MC Power PWR1(

Axis

Axis

Axis

Busv

Error

Axis


Busy

Error ErrorID);

//MC_G GRP_E);	roupEnable N(AxesGroup Execute Done Busy CommandAborted Error ErrorID	:= MC_Group000, := Grp_En_Ex, => Grp_En_D, => Grp_En_Bsy, => Grp_En_Ca, => Grp_En_Err, => Grp_En_ErrID
//MC_M MV_LIN	loveLinearAbsolute I_ABS(AxesGroup Execute Position Velocity Acceleration Deceleration Jerk Done Busy Active CommandAborted Error ErrorID	:= MC_Group000, := Mv_Lin_Abs_Ex, := Mv_Lin_Abs_Pos, := Mv_Lin_Abs_Vel, := Mv_Lin_Abs_Acc, := Mv_Lin_Abs_Dec, := Mv_Lin_Abs_Jrk, => Mv_Lin_Abs_Bsy, => Mv_Lin_Abs_Act, => Mv_Lin_Abs_Err, => Mv_Lin_Abs_Err, => Mv_Lin_Abs_ErrlD
);		
//MC_G GRP_S	roupStop TP(AxesGroup Execute Deceleration Done Busy Active CommandAborted Error ErrorID	:= MC_Group000, := Grp_Stp_Ex, := Grp_Stp_Dec, => Grp_Stp_D, => Grp_Stp_Bsy, => Grp_Stp_Act, => Grp_Stp_Ca, => Grp_Stp_Err, => Grp_Stp_ErrlD
);		
	roupImmediateStop /ID_STP(AxesGroup Execute Done Busy CommandAborted Error ErrorID	:= MC_Group000, := Grp_Imd_Stp_Ex, => Grp_Imd_Stp_D, => Grp_Imd_Stp_Bsy, => Grp_Imd_Stp_Ca, => Grp_Imd_Stp_Err, => Grp_Imd_Stp_ErrID

10-2-9 Homing and Absolute Positioning

In this sample, the starting point for homing is assumed to be where the home proximity input is ON. The Homing Method is set to *home proximity input OFF*. After homing is completed to define home, absolute positioning is executed.



Samples are provided for both ladder diagram and ST programming.

Axis Parameter Settings That Are Related to Homing

Parameter name	Setting	Description
Homing Method	4: Home proximity input OFF	Home is defined where the home proximity input turns OFF.
Operation Selection at Posi- tive Limit Input	1: Reverse turn/immediate stop	The positive limit input is not used, so the default setting is used for this parameter.
Operation Selection at Neg- ative Limit Input	2: Reverse turn/deceleration stop	The axis decelerates to a stop and reverses direc- tion when the negative limit input is detected.
Homing Start Direction	2: Negative direction	When homing is performed, the axis starts moving in the negative direction.
Home Input Detection Direction	1: Positive direction	Home is detected while the axis moves in the pos- itive direction.


Main Variables Used in the Programming Samples

Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 0.
MC_Axis000.Status.StandStill	BOOL	FALSE	TRUE while the Servo is OFF for axis 0.
MC_Axis000.MFaultLvI.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 0.
Pwr_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR instance of the MC_Power instruction. It is TRUE when the Servo is ON.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.
Hm_Ex	BOOL	FALSE	This variable is used to execute the MC_Home instruction. It is used in ST programming.


Variable name	Data type	Default	Comment
Mv_Abs_Ex	BOOL	FALSE	This variable is used to execute the MC_MoveAbsolute (Absolute Positioning) instruction. It is used in ST programming.

Timing Chart

Ladder Diagram




• ST Programming




Ladder Diagram

When *StartPg* is TRUE, the status of process data communications of axis 0 is checked to see if communications are active and normal.




The Servo for axis 0 is turned ON if process data communications for axis 0 are active and normal.



If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.

MC_Axis000.MFaultLvI.Active	FaultHandler
	EN FaultHandler

If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.



If the Servo is ON and home is defined, absolute positioning is executed.

MV_ABS		
	MC_MoveAbsolute	
Pwr_Status Hm_D MC_Axis000 -	Axis — Axis	Mv_Abs_D
	Execute Done	O
LREAL#50000.0 -	Position Busy	Mv_Abs_Bsy
LREAL#10000.0 -	Velocity Active	— Mv_Abs_Act
LREAL#1000.0 -	Acceleration CommandAborted	— Mv_Abs_Ca
LREAL#1000.0 -	Deceleration Error	— Mv_Abs_Err
LREAL#0.0 —	Jerk ErrorID	— Mv_Abs_ErrID
_eMC_DIRECTION#_mcShortestWay -	Direction	
	BufferMode	

ST Programming

// If the input parameters for absolute positioning are not set, the target values and other parameters are set. IF InitFlag=FALSE THEN

```
// The input parameters for the MC_MoveAbsolute (Absolute Positioning) instruction are set.
Mv_Abs_Pos := LREAL#50000.0;
Mv_Abs_Vel := LREAL#10000.0;
Mv_Abs_Acc := LREAL#1000.0;
```

Mv_Abs_Dec := LREAL#1000.0; Mv_Abs_Dir := _eMC_DIRECTION#_mcShortestWay;

// The Input Parameter Initialization Completed Flag is changed to TRUE. InitFlag := TRUE;

END_IF;

```
// When StartPg is TRUE, the Servo is turned ON for axis 0 if process data communications are active and normal.
IF (StartPg=TRUE)
AND ( EC PDSIavTbl[MC Axis000.Cfg.NodeAddress]=TRUE)
AND ( EC CommErrTbl[MC Axis000.Cfg.NodeAddress]=FALSE) THEN
        Pwr_En:=TRUE;
ELSE
        Pwr_En:=FALSE;
END_IF;
// If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed.
// Program the FaultHandler according to the device.
IF MC_Axis000.MFaultLvI.Active=TRUE THEN
        FaultHandler();
END IF:
// If the Servo is ON for axis 0 and home is not defined, the MC Home instruction is executed.
IF (Pwr_Status=TRUE)
AND (MC_Axis000.Details.Homed=FALSE) THEN
        Hm_Ex:=TRUE;
ELSE
        Hm_Ex:=FALSE;
END_IF;
// If the Servo is ON and home is defined, absolute positioning is executed.
IF (Pwr Status=TRUE)
AND (Hm_D=TRUE) THEN
        Mv_Abs_Ex:=TRUE;
END IF;
//MC Power
PWR(
                := MC_Axis000,
        Axis
        Enable := Pwr_En,
        Status => Pwr_Status,
        Busy
                => Pwr_Bsy,
                => Pwr Err,
        Error
        ErrorID => Pwr_ErrID
);
//MC Home
HM(
        Axis
                                := MC_Axis000,
        Execute
                                := Hm_Ex,
        Done
                                => Hm_D,
                                => Hm_Bsy,
        Busy
        CommandAborted
                                => Hm_Ca,
        Frror
                                => Hm_Err,
        ErrorID
                                => Hm_ErrID
```

);

//MC_ MV /	_MoveAbsolute \BS(
	Axis	:= MC Axis000.
	Execute	:= Mv Abs Ex,
	Position	:= Mv Abs Pos,
	Velocity	:= Mv Abs Vel,
	Acceleration	:= Mv Abs Acc,
	Deceleration	:= Mv Abs Dec,
	Direction	:= Mv Abs Dir,
	Done	=> Mv_Abs_D,
	Busy	=> Mv_Abs_Bsy,
	Active	=> Mv_Abs_Act,
	CommandAborted	=> Mv_Abs_Ca,
	Error	=> Mv_Abs_Err,
	ErrorID	=> Mv_Abs_ErrID
).		

);

10-2-10 Changing the Target Position by Re-execution of an Instruction


This sample starts absolute positioning to a target position of 1000 and then uses the same instance of the absolute positioning instruction to change the target position to 2000.

Main Variables Used in the Programming Samples


Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 0.
MC_Axis000.MFaultLvl.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 0.
Pwr_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR instance of the MC_Power instruction. It is TRUE when the Servo is ON.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.
ReExeSw	BOOL	FALSE	This variable is used to re-execute the instruc- tion.
Mv_Abs_Ex	BOOL	FALSE	This variable is used to execute the MC_MoveAbsolute (Absolute Positioning) instruction. It is used in ST programming.
Hm_Ex	BOOL	FALSE	This variable is used to execute the MC_Home instruction. It is used in ST programming.

Timing Chart

Ladder Diagram



• ST Programming




10


10-2-10 Changing the Target Position by Re-execution of an Instruction

Ladder Diagram

When StartPg is TRUE, the status of process data communications of axis 0 is checked to see if communications are active and normal.



The Servo for axis 0 is turned ON if process data communications for axis 0 are active and normal.



If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.

MC_Axis000.MFaultLvI.Active	FaultHandler
	EN FaultHandler

If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.

	HIVI	
	MC_Home	
Pwr_Status MC_Axis000.Details.Homed MC_Axis000 -	Axis — Ax	s Hm_D
┝───┤┝───────//─────	Execute Dor	e
	Bus	
	CommandAborte	d — Hm_Ca
		or – Hm_Err
		D – Hm_ErrID


After home is defined for axis 0, absolute positioning is executed if it is not already in progress.

MC_Axis000.Details.Homed	Mv_Abs_Act	Mv_Abs_Ex
	//	\frown

. When ReExeSw changes to TRUE, the absolute positioning instruction is re-executed to change the target position to 2000.

ReExeSw	1 Mv_Abs_Pos := LREAL#2000.0;	
		Restart_Ex
		\bigcirc

Absolute positioning is executed according to the status of Mv_Abs_Ex.



ST Programming

// If the input parameters for absolute positioning are not set, the target values and other parameters are set. IF InitFlag = FALSE THEN

```
// Parameters for MC_MoveAbsolute
Mv_Abs_Pos := LREAL#1000.0;
Mv_Abs_Vel := LREAL#500.0;
Mv_Abs_Acc := LREAL#500.0;
Mv_Abs_Dec := LREAL#500.0;
Mv_Abs_Dir := _eMC_DIRECTION#_mcPositiveDirection;
```

// The Input Parameter Initialization Completed Flag is changed to TRUE. InitFlag:=TRUE;

END_IF;

```
// If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed.
// Program the FaultHandler according to the device.
IF MC_Axis000.MFaultLvI.Active=TRUE THEN
FaultHandler();
```

END_IF;

END_IF;

// When *ReExeSw* changes to TRUE, the absolute positioning instruction is re-executed to change the target position to 2000.

//MC_Power PWR(Axis := MC_Axis000, Enable := Pwr_En, Status => Pwr_Status, Busy => Pwr_Bsy, Error => Pwr_Err,

);		
//MC_H HM(lome	
);	Axis Execute Done Busy CommandAborted Error ErrorID	:= MC_Axis000, := Hm_Ex, => Hm_D, => Hm_Bsy, => Hm_Ca, => Hm_Err, => Hm_ErrID
//MC_M MV_AB	NoveAbsolute SS(Axis Execute Position Velocity Acceleration Direction Done Busy Active CommandAborted Error ErrorID	:= MC_Axis000, := Mv_Abs_Ex, := Mv_Abs_Pos, := Mv_Abs_Vel, := Mv_Abs_Acc, := Mv_Abs_Dec, := Mv_Abs_Dir, => Mv_Abs_D, => Mv_Abs_Bsy, => Mv_Abs_Act, => Mv_Abs_Ca, => Mv_Abs_Err, => Mv_Abs_ErrID
);		

ErrorID => Pwr_ErrID


10 Sample Programming

10-2-11 Interrupt Feeding

This sample performs interrupt feeding when an interrupt occurs during velocity control. One of the following is specified for the *Direction* variable when velocity control is performed in Rotary Mode.

- _mcPositiveDirection
- _mcNegativeDirection
- _mcCurrentDirection

This sample uses _mcCurrentDirection. A positive value is specified for the FeedDistance input variable to perform feeding in the same direction as the motion before the interrupt input. A negative value is specified for the FeedDistance input variable to perform feeding in the opposite direction as the motion before the interrupt input. For example, if a positive value is specified for the FeedDistance input variable when the motion was in the negative direction before the interrupt input, feeding is performed in the negative value is specified for the FeedDistance input variable when the motion.



Axis Parameter Settings

Parameter name	Setting	Description
Count Mode	Rotary Mode	Rotary Mode is set as the count mode for the position.
Modulo Maximum Position Setting Value	360	The Modulo Maximum Position is set to 360.
Modulo Minimum Position Setting Value	0	The Modulo Minimum Position is set to 0.
Homing Method	Zero position preset	A zero position preset is performed to define home.

Main Variables Used in the Programming Samples

Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 0.
MC_Axis000.MFaultLvI.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 0.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communica- tions are active and normal.
Pwr_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR instance of the MC_Power instruction. It is TRUE when the Servo is ON.
TrigRef	_sTRIGGER_REF		This parameter specifies the trigger input condition to use for the interrupt input. Latch 1 of the Servo Drive is used in this sample.
Hm_Ex	BOOL	FALSE	This variable is used to execute the MC_Home instruction. It is used in ST pro- gramming.


Variable name	Data type	Default	Comment
Mv_Feed_Ex	BOOL	FALSE	This variable is used to execute the
			MC_MoveFeed (Interrupt Feeding) instruc- tion. It is used in ST programming.
InitFlag	BOOL	FALSE	TRUE if the input parameters are set for the MC_MoveFeed instruction.

Ladder Diagram

When *StartPg* is TRUE, the status of process data communications of axis 0 is checked to see if communications are active and normal.

StartPg	_EC_PDSlavTbl[MC_Ax	is000.Cfg.NodeAddress]	_EC_CommErrTbl[MC	Axis000.Cfg.NodeAddress	Lock	0
┝┥┝┈				-N	-()	Н


The Servo for axis 0 is turned ON if process data communications for axis 0 are active and normal.



If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.

MC_Axis000.MFaultLvI.Active		FaultHandler	
1	ΕN	FaultHandler	


If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.



The input parameters for interrupt feeding are set.

1

InitFlag	1	// Parameters for MC MoveFe	eed	
/	2	Mv_Feed_TrigRef.Mode	:= _eMC_TRIGGER_MODE#_mcDrive;	
	3	Mv_Feed_TrigRef.LatchID	:= _eMC_TRIGGER_LATCH_ID#_mcLatch1;	
	4	Mv_Feed_TrigRef.InputDrive	:= _eMC_TRIGGER_INPUT_DRIVE#_mcEncoderMark;	
	5	Mv_Feed_TrigVar	:= FALSE;	
	6	Mv_Feed_Pos	:= LREAL#2000.0;	
	7	Mv_Feed_Vel	:= LREAL#1000.0;	
	8	Mv_Feed_Acc	:= LREAL#10000.0;	
	9	Mv_Feed_Dec	:= LREAL#10000.0;	
	10	Mv_Feed_Dir	:= _eMC_DIRECTION#_mcCurrentDirection;	
	11	Mv_Feed_Mm	:= _eMC_MOVE_MODE#_mcVelocity;	
	12	Mv_Feed_FeedDis	:= LREAL#500.0;	
	13	Mv_Feed_FeedVel	:= LREAL#500.0;	
	14	// The Input Parameter Initializ	zation Completed Flag is changed to TRUE.	
	15	InitFlag := TRUE;		



If homing is completed, interrupt feeding is executed.

ST Programming

// If the input parameters for interrupt feeding are not set, the target values and other parameters are set. IF InitFlag=FALSE THEN

// Parameters for MC_MoveFeed	
Mv_Feed_TrigRef.Mode	:= _eMC_TRIGGER_MODE#_mcDrive;
Mv_Feed_TrigRef.LatchID	:= _eMC_TRIGGER_LATCH_ID#_mcLatch1;
Mv_Feed_TrigRef.InputDrive	:= _eMC_TRIGGER_INPUT_DRIVE#_mcEncoderMark;
Mv_Feed_TrigVar	:= FALSE;
Mv_Feed_Pos	:= LREAL#2000.0;
Mv_Feed_Vel	:= LREAL#1000.0;
Mv_Feed_Acc	:= LREAL#10000.0;
Mv_Feed_Dec	:= LREAL#10000.0;
Mv_Feed_Dir	:= _eMC_DIRECTION#_mcCurrentDirection;
Mv_Feed_Mm	:= _eMC_MOVE_MODE#_mcVelocity;
Mv_Feed_FeedDis	:= LREAL#500.0;
Mv_Feed_FeedVel	:= LREAL#500.0;

// The Input Parameter Initialization Completed Flag is changed to TRUE. InitFlag := TRUE;

END_IF;

// When *StartPg* is TRUE, the Servo is turned ON for axis 0 if process data communications are active and normal. IF (StartPg=TRUE)

AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)

 $\label{eq:and_and_and_constraint} AND \ (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) \ THEN$

Pwr_En:=TRUE;

ELSE

Pwr_En:=FALSE;

END_IF;

// If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed. // Program the FaultHandler according to the device. IF MC_Axis000.MFaultLvI.Active=TRUE THEN FaultHandler();

END_IF;

```
// If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.
IF (Pwr_Status=TRUE)
AND (MC_Axis000.Details.Homed=FALSE) THEN
        Hm_Ex:=TRUE;
END_IF;
// If homing is defined, interrupt feeding is executed.
IF Hm_D=TRUE THEN
        Mv_Feed_Ex:=TRUE;
END_IF;
// MC_Power
PWR(
        Axis
                := MC_Axis000,
        Enable := Pwr_En,
        Status => Pwr Status,
        Busy
               => Pwr_Bsy,
                => Pwr Err,
        Error
        ErrorID => Pwr_ErrID
);
// MC_Home
HM(
        Axis
                                := MC Axis000,
        Execute
                                := Hm Ex,
        Done
                                => Hm D.
                                => Hm_Bsy,
        Busv
        CommandAborted
                                => Hm Ca,
        Error
                                => Hm_Err,
        ErrorID
                                => Hm_ErrID
);
//MC_MoveFeed
MV_FEED(
                                := MC_Axis000,
        Axis
        TriggerInput
                                := Mv_Feed_TrigRef,
        TriggerVariable
                                := Mv Feed TrigVar,
        Execute
                                := Mv Feed Ex.
        Position
                                := Mv Feed Pos,
                                := Mv_Feed_Vel,
        Velocity
                                := Mv_Feed_Acc,
        Acceleration
                                := Mv_Feed_Dec,
        Deceleration
                                := Mv_Feed_Dir,
        Direction
                                := Mv_Feed_Mm,
        MoveMode
                                := Mv_Feed_FeedDis,
        FeedDistance
        FeedVelocity
                                := Mv_Feed_FeedVel,
        Done
                               => Mv_Feed_D,
        InFeed
                                => Mv Feed InFeed,
        Busy
                                => Mv_Feed_Bsy,
        Active
                                => Mv_Feed_Act,
        CommandAborted
                                => Mv Feed Ca.
        Error
                                => Mv Feed Err,
        ErrorID
                                => Mv_Feed_ErrID
);
```

10-2-12 Changing the Cam Table by Re-execution of an Instruction

This sample changes the cam table during cam motion. *CamProfile0* is used when the command position for axis 0 is 5000 or less and *CamProfile1* is used when it is over 5000.


Main Variables Used in the Programming Samples

Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 0.
MC_Axis001	_sAXIS_REF		This is the Axis Variable for axis 1.
CamProfile0	ARRAY[0100] OF _sMC_CAM_REF		This is the cam data variable.*
CamProfile1	ARRAY[010] OF _sMC_CAM_REF		This is the cam data variable.*
Pwr1_S	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
Pwr2_S	BOOL	FALSE	This variable is assigned to the <i>Status</i> out- put variable from the PWR2 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
CamTable0	BOOL	FALSE	TRUE when <i>CamProfile0</i> is used for the cam table.
CamTable1	BOOL	FALSE	TRUE when <i>CamProfile1</i> is used for the cam table.
Camin_InCam0	BOOL	FALSE	This variable is assigned to the <i>InCam</i> output variable from the CAMIN instance of the MC_CamIn instruction. It is TRUE during cam motion for <i>CamProfile0</i> . After this variable changes to TRUE, it remains TRUE until the operation is completed or canceled.
Camin_InCam1	BOOL	FALSE	This variable is assigned to the <i>InCam</i> output variable from the CAMIN instance of the MC_CamIn instruction. It is TRUE during cam motion for <i>CamProfile1</i> . After this variable changes to TRUE, it remains TRUE until the operation is completed or canceled.
Mv_Abs_Act	BOOL	FALSE	This variable is assigned to the <i>Active</i> out- put variable from the MV_ABS instance of the MC_MoveAbsolute instruction.
Hm1_Ex	BOOL	FALSE	This variable is used to re-execute the MC_Home instruction for axis 0.
Hm2_Ex	BOOL	FALSE	This variable is used to re-execute the MC_Home instruction for axis 1.
Mv_Abs_Ex	BOOL	FALSE	This variable is used to execute the MC_MoveAbsolute (Absolute Positioning) instruction.
Camin_Ex	BOOL	FALSE	This variable is used to execute the MC_CamIn (Start Cam) instruction. It is used in ST programming.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communica- tions are active and normal.

* The array elements ARRAY[0..N] are set with the Cam Editor in the Sysmac Studio. The range of the array is 0 to 109 in this sample.

Timing Chart

Ladder Diagram



Ladder Diagram

To change from one cam table to another, two instances of the MC_CamIn (Start Cam Operation) instruction with the same instance name are used. A different output parameter is assigned to the *InCam* (Cam Motion) output variable from each instance. An error will occur if you assign the same output parameter. In this sample, a JMP (Jump) instruction is used so that both instances are not executed at the same time.

When *StartPg* is TRUE, the status of process data communications of axis 0 is checked to see if communications are active and normal.

StartPg _EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress] _EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress Lock0

When *StartPg* is TRUE, the status of process data communications of axis 1 is checked to see if communications are active and normal.

StartPg _EC_PDSlavTbl[MC_A>	kis001.Cfg.NodeAddress]	_EC_CommErrTbl[MC_Ax	is001.Cfg.NodeAddress	Lock1
		——И		-()+
				•

The Servo for axis 0 is turned ON if process data communications for axis 0 are active and normal.

	PWR1
	MC_Power
Lock0 MC_Axis000	Axis — Axis Pwr1_Status
┝━┫┠━━━━━	Enable Status
	Busy — Pwr1_Bsy
	Error – Pwr1_Err
	ErrorID - Pwr1_ErrID

The Servo for axis 1 is turned ON if process data communications for axis 1 are active and normal.

	PWR2
	MC_Power
Lock1 MC_Axis001	Axis Axis Pwr2_Status
┝ <u></u>	Enable Status
	Busy – Pwr2_Bsy
	Error – Pwr2_Err
	ErrorID – Pwr2_ErrID

If a minor fault level error occurs for axis 0 or axis 1, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.


MC_Axis000.MFaultLvI.Active	FaultHandler EN FaultHandler
MC_Axis001.MFaultLvI.Active	

10-2 Basic Programming Samples


10

10-2-12 Changing the Cam Table by Re-execution of an Instruction


If the Servo is ON for axis 0 and home is not defined, the MC Home instruction is executed.



If the Servo is ON for axis 1 and home is not defined, the MC_Home instruction is executed.



If homing is completed for axis 0, absolute positioning is executed.



If the command position for axis 0 is 5000 or less, CamTable0 is changed to TRUE and CamTable1 is changed to FALSE. If it is over 5000, CamTable0 is changed to FALSE and CamTable1 is changed to TRUE. I


1	IF MC_A	xis000.Cmd.Pos<=LREAL#5000.0 THEN	
2		CamTable0:=BOOL#TRUE;	
3		CamTable1:=BOOL#FALSE;	
4	ELSE		
5		CamTable0:=BOOL#FALSE;	
6		CamTable1:=BOOL#TRUE;	
7	END_IF;		

If CamTable0 is TRUE during absolute positioning, then the instance that uses CamProfile0 for the cam table is executed.

If InCam is TRUE, then Execute is changed to FALSE.

CamTable0	SkipCamTable0
11	
VI	//


Mv_Abs_Act CamTable0 Camin_InCam0 Lock3 4 1




If *CamTable1* is TRUE during absolute positioning, then the instance that uses *CamProfile1* for the cam table is executed.

SkipCamTable0

CamTable1 SkipCamTable1



SkipCamTable1



10

ST Programming

// If the input parameters for absolute positioning and starting cam operation are not set, the target values and other parameters are set.

```
IF InitFlag=FALSE THEN
```

// The input parameters for the MC_MoveAbsolute (Absolute Positioning) instruction are set.

Mv Abs Pos := LREAL#10000.0; Mv_Abs_Vel := LREAL#2000.0; Mv_Abs_Acc := LREAL#2000.0; Mv Abs Dec := LREAL#2000.0; // The input parameters for the MC CamIn (Start Cam Operation) instruction are set. Camin EM := TRUE; Camin_StMode := _eMC_START_MODE#_mcAbsolutePosition; Camin_StPos := LREAL#1.0: Camin MStDis := LREAL#1.0; Camin MSc := LREAL#1.0: Camin SSc := LREAL#1.0: Camin MO := LREAL#0.0; Camin SO := LREAL#0.0; Camin_RT := _eMC_REFERENCE_TYPE#_mcCommand; Camin Dir := _eMC_DIRECTION#_mcNoDirection; // The cam table is selected. :=BOOL#TRUE; CamTable0 :=BOOL#FALSE; CamTable1

// The Input Parameter Initialization Completed Flag is changed to TRUE.

```
InitFlag := TRUE;
```

END_IF;

```
// When StartPg is TRUE, the Servo is turned ON for axis 0 if process data communications are active and normal.
IF (StartPg=TRUE)
AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)
```

AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN

Pwr_En:=TRUE;

ELSE Pwr_En:=FALSE;

```
END_IF;
```

// When *StartPg* is TRUE, the Servo is turned ON for axis 1 if process data communications are active and normal. IF (StartPg=TRUE)

AND (_EC_PDSIavTbl[MC_Axis001.Cfg.NodeAddress]=TRUE)

AND (_EC_CommErrTbl[MC_Axis001.Cfg.NodeAddress]=FALSE) THEN

```
Pwr2_En:=TRUE;
```

ELSE

Pwr2_En:=FALSE;

```
END_IF;
```

// If a minor fault level error occurs for axis 0 or axis 1, the error handler for the device (FaultHandler) is executed. // Program the FaultHandler according to the device. IF (MC_Axis000.MFaultLvI.Active=TRUE) OR (MC_Axis001.MFaultLvI.Active=TRUE)

OR (MC_Axis001.MFaultLvI.Active=TRUE) THEN FaultHandler();

END_IF;

// If the Servo is ON for axis 1 and home is not defined, the MC_Home instruction is executed.

```
IF (Pwr2_S=TRUE)
AND (MC_Axis001.Details.Homed=FALSE) THEN
       Hm2_Ex:=TRUE;
END_IF;
// If homing is completed for axis 0, absolute positioning is executed.
IF Hm1_D=TRUE THEN
       Mv_Abs_Ex := TRUE;
END_IF;
// If the command position for axis 0 is 5000 or less, CamTable0 is changed to TRUE and CamTable1 is changed to
FALSE.
// If it exceeds 5000, CamTable0 is changed to FALSE and CamTable1 is changed to TRUE.
IF MC Axis000.Cmd.Pos<=LREAL#5000.0 THEN
       CamTable0
                    :=BOOL#TRUE;
       CamTable1
                       :=BOOL#FALSE;
ELSE
       CamTable0
                       :=BOOL#FALSE;
       CamTable1
                       :=BOOL#TRUE;
END IF;
// If CamTable0 is TRUE during absolute positioning,
// then the instance that uses CamProfile0 for the cam table is executed.
// If InCam is TRUE, Execute is changed to FALSE.
IF (Mv Abs Act=TRUE)
AND (CamTable0=TRUE)
AND (Camin_InCam0=FALSE) THEN
       Camin Ex
                      := TRUE;
ELSE
       Camin_Ex
                       := FALSE;
END_IF;
// If CamTable1 is TRUE during absolute positioning,
// then the instance that uses CamProfile1 for the cam table is executed.
IF (Mv_Abs_Act=TRUE)
AND (CamTable1=TRUE) THEN
       Camin_Ex
                   := TRUE:
END_IF;
//MC Camin
IF CamTable0=TRUE THEN
       CAMIN(
               Master
                                       := MC_Axis000,
                                       := MC_Axis001,
               Slave
                                       := CamProfile0,
               CamTable
               Execute
                                       := Camin_Ex,
               Periodic
                                       := Camin_EM,
               StartMode
                                       := Camin_StMode,
               StartPosition
                                       := Camin StPos.
               MasterStartDistance
                                       := Camin MStDis,
               MasterScaling
                                       := Camin MSc.
               SlaveScaling
                                       := Camin_SSc,
               MasterOffset
                                       := Camin_MO,
               SlaveOffset
                                       := Camin_SO,
               ReferenceType
                                       := Camin_RT,
               Direction
                                       := Camin_Dir,
               InCam
                                       => Camin_InCam0,
               InSync
                                       => Camin_InSync,
               EndOfProfile
                                       => Camin_EOP,
               Index
                                       => Camin Index,
```

=> Camin_Bsy,

Busy

Active	=> Camin_Act,
CommandAborted	=> Camin_Ca,
Error	=> Camin_Err,
ErrorID	=> Camin_ErrID

END_IF;

); IF CamTable1=TRUE THEN CAMIN(:= MC_Axis000, Master Slave := MC_Axis001, CamTable := CamProfile1, Execute := Camin_Ex, Periodic := Camin_EM, StartMode := Camin StMode, StartPosition := Camin_StPos, MasterStartDistance := Camin_MStDis, MasterScaling := Camin MSc, SlaveScaling := Camin_SSc, MasterOffset := Camin_MO, SlaveOffset := Camin_SO, ReferenceType := Camin_RT, Direction := Camin_Dir, InCam => Camin_InCam1, => Camin_InSync, InSync EndOfProfile => Camin_EOP, Index => Camin Index, => Camin_Bsy, Busv Active => Camin Act. CommandAborted => Camin Ca, Error => Camin_Err, ErrorID => Camin_ErrID); END_IF: // MC_Power for axis 0 PWR1(:= MC Axis000, Axis Enable := Pwr1_En, Status => Pwr1_S, Busy => Pwr1 Bsv. => Pwr1_Err, Error ErrorID => Pwr1_ErrID);


```
// MC_Power for axis 1
PWR2(
               := MC_Axis001,
        Axis
        Enable := Pwr2 En,
        Status => Pwr2_S,
               => Pwr2_Bsy,
        Busv
        Error
               => Pwr2 Err,
        ErrorID => Pwr2 ErrID
);
// MC_Home for axis 0
HM1(
                               := MC_Axis000,
        Axis
        Execute
                               := Hm1_Ex,
        Done
                               => Hm1_D,
        Busy
                               => Hm1_Bsy,
        CommandAborted
                               => Hm1_Ca,
```

	Error ErrorID	=> Hm1_Err, => Hm1_ErrID
);		
// MC_H HM2(lome for axis 1	
);	Axis Execute Done Busy CommandAborted Error ErrorID	:= MC_Axis001, := Hm2_Ex, => Hm2_D, => Hm2_Bsy, => Hm2_Ca, => Hm2_Err, => Hm2_ErrID
//MC_M MV_AB	oveAbsolute	
	Axis Execute Position Velocity Acceleration Deceleration Direction Done Busy Active CommandAborted Error ErrorID	:= MC_Axis000, := Mv_Abs_Ex, := Mv_Abs_Pos, := Mv_Abs_Vel, := Mv_Abs_Acc, := Mv_Abs_Dec, := Mv_Abs_Dir, => Mv_Abs_D, => Mv_Abs_Bsy, => Mv_Abs_Act, => Mv_Abs_Ca, => Mv_Abs_Err, => Mv_Abs_ErrID

);

10-2-13 Using a Cam Profile Curve to Correct the Sync Position

This sample uses a cam profile curve to correct a slave axis in a gear motion. The slave axis for gear motion is $MC_Axis001$, a virtual Servo axis, and the slave axis for cam motion is $MC_Axis002$, also a virtual Servo axis. These slave axes are combined with $MC_CombineAxes$ and the results is output to $MC_Axis003$, a Servo axis. The master axis is $MC_Axis000$, a Servo axis. The processing flow is as follows:



• Axis Type Settings

The axes types are set in the axis parameters for each axis as given below.

Parameter name	Setting			
Falameter hame	Axis 1	Axis 2	Axis 3	Axis 4
Axes variable name	MC_Axis000	MC_Axis001	MC_Axis002	MC_Axis003
Axis type	Servo axis	Virtual servo axis	Virtual servo axis	Servo axis


Main Variables Used in the Programming Samples

Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 0.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 0.
MC_Axis000.MFaultLvI.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
MC_Axis001	_sAXIS_REF		This is the Axis Variable for axis 1.
MC_Axis001.MFaultLvI.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 1.
MC_Axis002	_sAXIS_REF		This is the Axis Variable for axis 2.
MC_Axis002.MFaultLvI.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 2.
MC_Axis003	_sAXIS_REF		This is the Axis Variable for axis 3.
MC_Axis003.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 3.
MC_Axis003.MFaultLvI.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 3.
CamProfile0	ARRAY[0109] OF _sMC_CAM_REF		This is the cam data variable.*1
Pwr1_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
Pwr4_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR4 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
Vel_InVel	BOOL	FALSE	TRUE when the target velocity for <i>MC_MoveVelocity</i> for axis 0 is reached.

Variable name	Data type	Default	Comment
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communica- tions are active and normal.
Gearin_Ex	BOOL	FALSE	This variable is used to execute the MC_GearIn (Start Gear Operation) instruc- tion.*2
Camin_Ex	BOOL	FALSE	This variable is used to execute the MC_CamIn (Start Cam Operation) instruc- tion. ^{*2}
Combine_Ex	BOOL	FALSE	This variable is used to execute the MC_CombineAxes (Combine Axes) instruction.*2

*1 The array elements ARRAY[0..N] are set with the Cam Editor in the Sysmac Studio. The range of the array is 0 to 109 in this sample.

*2 The variable is used in ST programming.



• ST Programming

VEL	Vel_InVel	
GEARIN	Gearin_Ex	
	Gearin_InGear	
	Gearin_Bsy	
	Gearin_Act	
CAMIN	Camin_Ex	
	Camin_InCam	
	Camin_InSync	
	Camin_Bsy	
	Camin_Act	
COMBINE	Combine_Ex	
	Combine_Bsy	
	Combine_Act	
	Position	
	MC_Axis000	
		→
	MC_Axis001	
	MC_Axis002	
	MC_Axis003	Time

10

Ladder Diagram

When *StartPg* is TRUE, the status of process data communications of axis 0 is checked to see if communications are active and normal.

StartPg	_EC_PDSlavTbl[MC_A	xis000.Cfg.NodeAddress]	_EC_CommErrTbl[MC_A	xis000.Cfg.NodeAddress	Lock0	1
		- I I		A	ፈ ኑ	_
11		11			\cup	


When *StartPg* is TRUE, the status of process data communications of axis 3 is checked to see if communications are active and normal.

	StartPg	_EC_PDSlavTbl[MC_Axis003.Cfg.NodeAddress]	_EC_CommErrTbl[MC_Axis003.Cfg.NodeAddress	LOCK3
1				
		11	VI	

The Servo for axis 0 is turned ON if process data communications for axis 0 are active and normal.

		PWR1		
Lock0	MC_Axis000 —		— Axis	– Pwr1_Status
├──┤		Enable	Error	— Pwr1_Bsy — Pwr1_Err
			ErrorID	– Pwr1_ErrID


The Servo for axis 3 is turned ON if process data communications for axis 3 are active and normal.




If a minor fault level error occurs for any of the composition axes in the axes group, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.

FaultHandler	


If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.




If the Servo is ON for axis 3 and home is not defined, the MC_Home instruction is executed.



If homing is completed for axis 0, velocity control is executed.




If homing is completed for axis 0, gear operation is executed.



When axis 0 reaches the target velocity, cam operation is executed.

	CAM	IN	
	MC_C	amIn	
MC_Axis000 —	Master —	— Master	_
MC_Axis002 –	Slave ——	—— Slave	-
Vel_InVel CamProfile0 -	CamTable ——	—— CamTable	CamIn_InCam
┝──┥┝────	Execute	InCam	—O
BOOL#TRUE -	Periodic	InSync	- CamIn_InSync
_eMC_START_MODE#_mcRelativePosition -	StartMode	EndOfProfile	— CamIn_Eop
LREAL#20.0 –	StartPosition	Index	— CamIn_Index
LREAL#40.0 —	MasterStartDistance	Busy	— CamIn_Bsy
LREAL#1.0 —	MasterScaling	Active	- CamIn_Act
LREAL#1.0 —	SlaveScaling	CommandAborted	— CamIn_Ca
LREAL#0.0 —	MasterOffset	Error	— CamIn_Err
LREAL#0.0 —	SlaveOffset	ErrorID	- CamIn_ErrID
_eMC_REFERENCE_TYPE#_mcCommand -	ReferenceType		
_eMC_DIRECTION#_mcNoDirection -	Direction		
-	CamTransition		
	BufferMode		



ST Programming

// If the input parameters for the motion instructions are not set, the target values and other parameters are set. IF InitFlag=FALSE THEN

// The input paramete	ers for the MC_MoveVelocity (Velocity Control) instruction are set.
Vel Vel := I	LREAL#100.0;
	LREAL#0.0;
Vel_Dec := l	LREAL#0.0;
	eMC_DIRECTION#_mcPositiveDirection;
	,
// The input paramete	ers for the MC_CamIn (Start Cam Operation) instruction are set.
Camin_Em := ⁻	TRUE;
Camin_Sm := _	_eMC_START_MODE#_mcRelativePosition;
Camin_Sp := I	LREAL#20.0;
Camin_Msd :=	LREAL#40.0;
Camin_Ms := I	LREAL#1.0;
Camin_Ss := I	LREAL#1.0;
Camin_Mo := I	LREAL#0.0;
Camin_So := I	LREAL#0.0;
Camin_Rt :=	_eMC_REFERENCE_TYPE#_mcCommand;
Camin_Dir := _	_eMC_DIRECTION#_mcNoDirection;
Gearin_RatN := Gearin_RatD := Gearin_RefTyp := Gearin_Acc := Gearin_Dec := // The input paramete Combine_Cm := _eM Combine_RefMas:=_ Combine_RefAux:=_	_eMC_REFERENCE_TYPE#_mcCommand;
// When <i>StartPg</i> is TRUE, the IF (StartPg=TRUE)	Servo is turned ON for axis 0 if process data communications are ac

// When \$ active and normal. IF (StartF AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE) AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN Pwr1_En:=TRUE; ELSE Pwr1_En:=FALSE; END_IF;

// When StartPg is TRUE, the Servo is turned ON for axis 3 if process data communications are active and normal. IF (StartPg=TRUE) AND (_EC_PDSlavTbl[MC_Axis003.Cfg.NodeAddress]=TRUE) AND (_EC_CommErrTbl[MC_Axis003.Cfg.NodeAddress]=FALSE) THEN Pwr4_En:=TRUE; ELSE Pwr4_En:=FALSE; END_IF; // If a minor fault level error occurs for axis 0 to axis 3, the error handler for the device (FaultHandler) is executed. // Program the FaultHandler according to the device. IF (MC_Axis000.MFaultLvI.Active=TRUE) OR (MC Axis001.MFaultLvI.Active=TRUE) OR (MC_Axis002.MFaultLvI.Active=TRUE) OR (MC_Axis003.MFaultLvI.Active=TRUE) THEN FaultHandler(); END_IF; // If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed for axis 0. IF (Pwr1_Status=TRUE) AND (MC_Axis000.Details.Homed=FALSE) THEN Hm1_Ex:=TRUE; END_IF; // If the Servo is ON for axis 3 and home is not defined, the MC Home instruction is executed for axis 3. IF (Pwr4 Status=TRUE) AND (MC_Axis003.Details.Homed=FALSE) THEN Hm4 Ex:=TRUE; END_IF; // If homing is completed for axis 0, velocity control is executed. IF Hm1_D=TRUE THEN Vel_Ex:=TRUE; END IF; // When axis 0 reaches the target velocity, gear operation is executed. IF Vel InVel=TRUE THEN Gearin_Ex := TRUE; END IF: // When axis 0 reaches the target velocity, cam operation is executed. IF Vel_InVel=TRUE THEN Camin_Ex := TRUE; END_IF; // If both gear and cam operation are in progress, the Combine Axes instruction is executed. IF (Gearin Act=TRUE) AND (Camin_Act=TRUE) THEN Combine_Ex:=TRUE; END IF: // MC_Power for axis 0 PWR1(Axis := MC_Axis000, Enable := Pwr1_En, Status => Pwr1_Status, Busy = Pwr1_Bsy,

Error => Pwr1_Err,

```
ErrorID => Pwr1_ErrID
```

);

```
// MC_Power for axis 3
PWR4(
        Axis
                := MC_Axis003,
        Enable := Pwr4_En,
        Status => Pwr4_Status,
        Busy
                => Pwr4_Bsy,
        Error
               => Pwr4_Err,
        ErrorID => Pwr4_ErrID
);
// MC_Home for axis 0
HM1(
        Axis
                                 := MC_Axis000,
        Execute
                                 := Hm1_Ex,
                                 => Hm1_D,
        Done
        Busy
                                 => Hm1_Bsy,
        CommandAborted
                                 => Hm1_Ca,
        Error
                                 => Hm1 Err,
        ErrorID
                                 => Hm1_ErrID
);
// MC_Home for axis 3
HM4(
                                 := MC_Axis003,
        Axis
                                 := Hm4_Ex,
        Execute
        Done
                                 => Hm4 D,
                                 => Hm4_Bsy,
        Busv
        CommandAborted
                                 => Hm4 Ca.
        Error
                                 => Hm4 Err.
        ErrorID
                                 => Hm4 ErrID
);
//MC_MoveVelocity
VEL(
                                 := MC_Axis000,
        Axis
        Execute
                                 := Vel_Ex,
        Velocity
                                 := Vel_Vel,
        Acceleration
                                 := Vel_Acc,
        Deceleration
                                 := Vel_Dec,
        Direction
                                 := Vel_Dir,
                                => Vel_Invel.
        InVelocitv
        Busy
                                 => Vel Bsv.
        Active
                                => Vel_Act,
        CommandAborted
                                => Vel_Ca,
        Error
                                 => Vel_Err,
        ErrorID
                                 => Vel_ErrID
);
//MC CamIn
CAMIN(
                                 := MC Axis000,
        Master
        Slave
                                 := MC_Axis002,
        CamTable
                                 := CamProfile0.
        Execute
                                 := Camin Ex,
        Periodic
                                 := Camin Em,
        StartMode
                                 := Camin Sm,
                                 := Camin_Sp,
        StartPosition
                                 := Camin_Msd,
        MasterStartDistance
        MasterScaling
                                 := Camin_Ms,
        SlaveScaling
                                 := Camin_Ss,
        MasterOffset
                                 := Camin_Mo,
        SlaveOffset
                                 := Camin_So,
        ReferenceType
                                 := Camin_Rt,
        Direction
                                 := Camin_Dir,
```

10-2 Basic Programming Samples

10

=> Camin_InCam,

InCam

);	InSync EndOfProfile Index Busy Active CommandAborted Error ErrorID	=> Camin_InSync, => Camin_Eop, => Camin_Index, => Camin_Bsy, => Camin_Act, => Camin_Ca, => Camin_Err, => Camin_ErrID
//MC_G GEARI		:= MC_Axis000, := MC_Axis001,
	Execute RatioNumerator RatioDenominator ReferenceType Acceleration	:= Gearin_Ex, := Gearin_RatN, := Gearin_RatD, := Gearin_RefTyp, := Gearin_Acc,
	Deceleration InGear Busy Active	:= Gearin_Acc, := Gearin_Dec, => Gearin_InGear, => Gearin_Bsy, => Gearin_Act,
);	CommandAborted Error ErrorID	=> Gearin_Ca, => Gearin_Err, => Gearin_ErrID
	CombineAxes	
COMB		
	Master Auxiliary Slave Execute CombineMode ReferenceTypeMaster	:= MC_Axis001, := MC_Axis002, := MC_Axis003, := Combine_Ex, := Combine_CM, := Combine_RefMas,
	ReferenceTypeAuxiliary InCombination Busy Active	:= Combine_RefAux, => Combine_InComb, => Combine_Bsy, => Combine_Act,
	CommandAborted Error	=> Combine_Ca, => Combine_Err,

=> Combine_ErrID

);

ErrorID


10-2-14 Shifting the Phase of a Master Axis in Cam Motion

This sample synchronizes a slave axis in cam motion with a master axis in velocity control. If *StartOn* is TRUE, the phase of the master axis is shifted with the MC_Phasing (Shift Master Axis Phase) instruction. The slave axis is synchronized with the shifted phase.

Main Variables Used in the Programming Samples

Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 0.
MC_Axis000.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 0.
MC_Axis000.MFaultLvI.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
MC_Axis001	_sAXIS_REF		This is the Axis Variable for axis 1.
MC_Axis001.Details.Homed	BOOL	FALSE	TRUE when home is defined for axis 1.
MC_Axis001.MFaultLvI.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 1.
CamProfile0	ARRAY[0360] OF _sMC_CAM_REF		This is the cam data variable.*
Pwr1_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR1 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
Pwr2_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR2 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
StartOn	BOOL	FALSE	This variable is used to start shifting the phase of the master axis.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communica- tions are active and normal.
Camin_Ex	BOOL	FALSE	This variable is used to execute the MC_CamIn (Start Cam) instruction. It is used in ST programming.
Vel_Ex	BOOL	FALSE	This variable is used to execute the MC_MoveVelocity (Velocity Control) instruction. It is used in ST programming.
Phasing_Ex	BOOL	FALSE	This variable is used to execute the MC_Phasing (Shift Master Axis Phase) instruction. It is used in ST programming.

* The array elements ARRAY[0..N] are set with the Cam Editor in the Sysmac Studio. The range of the array is 0 to 360 in this sample.



NJ/NX-series CPU Unit Motion Control User's Manual (W507)

ST Programming

StartOn	
MC_Phasing	
Phasing_Ex	
Phasing_Bsy	
Phasing_Act	
Phasing_D	
MC_MoveVelocity	
_ Vel_Ex	
Vel_InVel	
MC_CamIn	
Camin_Ex	
Camin_InCam	
Camin_InSync	
Camin_Bsy	
Command velocity	
MC_Axis000	
MC_Axis001	Time

Ladder Diagram

When *StartPg* is TRUE, the status of process data communications of axis 0 is checked to see if communications are active and normal.

StartPg	_EC_PDSlavTbl[MC_/	Axis000.Cfg.NodeAddress]	_EC_CommErrTbl[MC_	Axis000.Cfg.NodeAddress	Lock
	-		-		<u> </u>
		11			\cup


When *StartPg* is TRUE, the status of process data communications of axis 1 is checked to see if communications are active and normal.

StartPg _EC_PDSlavTbl[MC_Axis001.Cfg.NodeAddress] _EC_CommErrTbl[MC_Axis001.Cfg.NodeAddress Lock1

The Servo for axis 0 is turned ON if process data communications for axis 0 are active and normal.

	PWR1	
	MC_Power	
Lock0 MC_Axis000 -	Axis — Axis	 Pwr1_Status
	Enable Status	\longrightarrow
	Busy-	– Pwr1_Bsy
	Error	– Pwr1_Err
	ErrorID	– Pwr1_ErrID

The Servo for axis 1 is turned ON if process data communications for axis 1 are active and normal.



If a minor fault level error occurs for any of the composition axes in the axes group, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.

MC_Axis000.MFaultLvI.Active	FaultHandler EN FaultHandler
MC_Axis001.MFaultLvI.Active	

If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.

	HM1
	MC_Home
Pwr1_Status MC_Axis000.Details.Homed MC_Axis000 -	Axis — Axis Hm1_D
├───┤ ├──────/	Execute Done
	Busy – Hm1_Bsy
	CommandAborted — Hm1_Ca
	Error Hm1_Err
	ErrorID — Hm1_ErrID

If the Servo is ON for axis 1 and home is not defined, the MC_Home instruction is executed.

	HM2
	MC_Home
Pwr1_Status MC_Axis001.Details.Homed MC_Axis001 -	
	Execute Done Busy Hm2_Bsy
	CommandAborted — Hm2_Ca
	Error – Hm2_Err
	ErrorID — Hm2_ErrID

If homing is completed for axis 0, velocity control is executed.


	VEL
	MC_MoveVelocity
Hm1_D MC_Axis000 -	Axis — Vel_InVel
	Execute InVelocity
LREAL#1000.0 —	Velocity Busy Vel_Bsy
LREAL#100000.0	Acceleration Active - Vel_Act
LREAL#100000.0	Deceleration CommandAborted - Vel_Ca
_	Jerk Error – Vel_Err
_eMC_DIRECTION#_mcPositiveDirection —	Direction ErrorID Vel_ErrID
_	Continuous
_	BufferMode

When axis 0 reaches the target velocity, cam operation is executed.

ı

	CAN	lin	
	MC_C	amIn	
MC_Axis00	– Master –	— Master	
MC_Axis00		—— Slave	
Vel_InVel MC_Axis001.Details.Homed CamProfile	CamTable —	—— CamTable	_ CamIn_InCam
<u>├</u> ─┤├────┤├────	Execute	InCam	
	- Periodic	InSync	— CamIn_InSync
_eMC_START_MODE#_mcRelativePosition	- StartMode	EndOfProfile	— CamIn_Eop
-	- StartPosition	Index	— CamIn_Index
LREAL#40.0	 MasterStartDistance 	Busy	— CamIn_Bsy
LREAL#1.0	 MasterScaling 	Active	— CamIn_Act
LREAL#1.0	 SlaveScaling 	CommandAborted	— CamIn_Ca
LREAL#0.0	 MasterOffset 	Error	— CamIn_Err
LREAL#0.0	- SlaveOffset	ErrorID	— CamIn_ErrID
_eMC_REFERENCE_TYPE#_mcComman			
_eMC_DIRECTION#_mcNoDirection	 Direction 		
	 CamTransition 		
	- BufferMode		

If StartOn is TRUE and cam motion is in sync, shifting the phase of the master axis is started.



ST Programming

// If the input parameters for the motion instructions are not set, the target values and other parameters are set. IF InitFlag=FALSE THEN

// The input parameters for the MC_MoveVelocity (Velocity Control) instruction are set.

```
Vel_Vel
               := LREAL#1000.0;
               := LREAL#100000.0;
Vel Acc
Vel Dec
               := LREAL#100000.0;
Vel Dir
               := _eMC_DIRECTION#_mcPositiveDirection;
// The input parameters for the MC Phasing (Shift Master Axis Phase) instruction are set.
Phasing_Ps
               := LREAL#500.0;
Phasing_Vel
               := LREAL#1000.0;
Phasing_Acc
               := LREAL#0.0;
Phasing_Dec
               := LREAL#0.0;
// The input parameters for the MC CamIn (Start Cam Operation) instruction are set.
Camin Em
               := TRUE;
Camin Sm
               := eMC START MODE# mcRelativePosition;
Camin_Sp
               := LREAL#20.0;
Camin_Msd
               := LREAL#40.0;
Camin_Ms
               := LREAL#1.0;
Camin_Ss
               := LREAL#1.0;
               := LREAL#0.0;
Camin_Mo
Camin_So
               := LREAL#0.0;
               := _eMC_REFERENCE_TYPE#_mcCommand;
Camin_Rt
               := _eMC_DIRECTION#_mcNoDirection;
Camin Dir
```

// The Input Parameter Initialization Completed Flag is changed to TRUE. InitFlag := TRUE;

END_IF;

// When *StartPg* is TRUE, the Servo is turned ON for axis 0 if process data communications are active and normal. IF (StartPg=TRUE)

AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)

AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN

Pwr1_En:=TRUE;

ELSE

Pwr1_En:=FALSE;

END_IF;

// When *StartPg* is TRUE, the Servo is turned ON for axis 1 if process data communications are active and normal. IF (StartPg=TRUE)

AND (_EC_PDSlavTbl[MC_Axis001.Cfg.NodeAddress]=TRUE)

AND (_EC_CommErrTbl[MC_Axis001.Cfg.NodeAddress]=FALSE) THEN

Pwr2_En:=TRUE;

ELSE

Pwr2_En:=FALSE;

END_IF;

// If a minor fault level error occurs for axis 0 or axis 1, the error handler for the device (FaultHandler) is executed.
// Program the FaultHandler according to the device.

IF (MC_Axis000.MFaultLvI.Active=TRUE)

OR (MC_Axis001.MFaultLvI.Active=TRUE) THEN FaultHandler();

END_IF;

// If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed for axis 0. IF (Pwr1_Status=TRUE) AND (MC_Axis000 Details Homed=EALSE) THEN

AND (MC_Axis000.Details.Homed=FALSE) THEN

Hm1_Ex:=TRUE;

END_IF;

// If the Servo is ON for axis 1 and home is not defined, the MC_Home instruction is executed for axis 1. IF (Pwr2_Status=TRUE)

```
AND (MC_Axis001.Details.Homed=FALSE) THEN
        Hm2_Ex:=TRUE;
END_IF;
// If homing is completed for axis 0, velocity control is executed.
IF Hm1_D=TRUE THEN
        Vel_Ex:=TRUE;
END_IF;
// When axis 0 reaches the target velocity and the home is defined for axis 1, cam operation is executed.
        (Vel_InVel=TRUE)
IF
AND (MC_Axis001.Details.Homed=TRUE) THEN
        Camin_Ex := TRUE;
END_IF;
// If StartOn is TRUE and cam motion is in sync, shifting the phase of the master axis is started.
IF (StartOn=TRUE)
AND (Camin InSync=TRUE) THEN
        Phasing_Ex:=TRUE;
END IF;
// MC Power for axis 0
PWR1(
        Axis
                := MC Axis000.
        Enable := Pwr1 En,
        Status => Pwr1 Status,
                => Pwr1_Bsy,
        Busv
                => Pwr1 Err.
        Error
        ErrorID => Pwr1 ErrID
);
// MC_Power for axis 1
PWR2(
                := MC_Axis001,
        Axis
        Enable := Pwr2_En,
        Status => Pwr2_Status,
        Busy
                => Pwr2_Bsy,
        Error
                => Pwr2 Err,
        ErrorID => Pwr2_ErrID
);
// MC_Home for axis 0
HM1(
                                := MC_Axis000,
        Axis
        Execute
                                := Hm1_Ex,
        Done
                                => Hm1_D,
        Busv
                                => Hm1_Bsy,
        CommandAborted
                                => Hm1_Ca,
        Frror
                                => Hm1_Err,
        ErrorID
                                => Hm1_ErrID
);
// MC Home for axis 1
HM2(
        Axis
                                := MC_Axis001,
        Execute
                                := Hm2_Ex,
        Done
                                => Hm2_D,
                                => Hm2_Bsy,
        Busy
        CommandAborted
                                => Hm2_Ca,
                                => Hm2_Err,
        Frror
        ErrorID
                                => Hm2_ErrID
);
```

//MC_MoveVelocity

10-2 Basic Programming Samples

VEL(
);	Axis Execute Velocity Acceleration Deceleration Direction InVelocity Busy Active CommandAborted Error ErrorID	:= MC_Axis000, := Vel_Ex, := Vel_Vel, := Vel_Acc, := Vel_Dec, := Vel_Dir, => Vel_Invel, => Vel_Bsy, => Vel_Act, => Vel_Ca, => Vel_Err, => Vel_ErrID
//MC_P		
PHASIN);	IG(Master Slave Execute PhaseShift Velocity Acceleration Deceleration Done Busy Active CommandAborted Error ErrorID	:= MC_Axis000, := MC_Axis001, := Phasing_Ex, := Phasing_Ps, := Phasing_Vel, := Phasing_Acc, := Phasing_Dec, => Phasing_Dec, => Phasing_Bsy, => Phasing_Ca, => Phasing_Err, => Phasing_ErrID
//MC_C		
CAMIN	Master	:= MC_Axis000,
	Slave CamTable Execute Periodic StartMode StartPosition MasterStartDistance	:= MC_Axisodo, := MC_Axisodo1, := CamProfile0, := Camin_Ex, := Camin_Em, := Camin_Sm, := Camin_Sp, := Camin_Msd,

:= MC_Axis000,
:= MC_Axis001,
:= CamProfile0,
:= Camin_Ex,
:= Camin_Em,
:= Camin_Sm,
:= Camin_Sp,
:= Camin_Msd,
:= Camin_Ms,
:= Camin_Ss,
:= Camin_Mo,
:= Camin_So,
:= Camin_Rt,
:= Camin_Dir,
=> Camin_Incam,
=> Camin_Insync,
=> Camin_Eop,
=> Camin_Index,
=> Camin_Bsy,
=> Camin_Act,
=> Camin_Ca,
=> Camin_Err,
=> Camin_ErrID

);

10-2-15 Changing the Actual Position during Velocity Control

This sample changes the absolute values of the command current position and the actual current position for an axis in velocity control.



Precautions for Correct Use


- When you use the MC_SetPosition instruction for an axis in motion, the travel distance between execution of the instruction and changing the actual position will remain as error.
- Home will become undefined when the MC_Set Position instruction is executed.

Axis Parameter Settings

Parameter name	Setting	Description
Count Mode	Rotary Mode	Rotary Mode is set as the count mode for the position.
Modulo Maximum Position Setting Value	360	The Modulo Maximum Position is set to 360.
Modulo Minimum Position Setting Value	0	The Modulo Minimum Position is set to 0.
Homing Method	Zero position preset	A zero position preset is performed to define home.


Main Variables Used in the Programming Samples

Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 0.
MC_Axis000.MFaultLvI.Active	BOOL	FALSE	TRUE when there is a minor fault level error for axis 0.
Pwr_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR instance of the MC_Power instruction. It is TRUE when the Servo is ON.
StartSetPos	BOOL	FALSE	This variable gives the status of the external button that is used to change the actual position.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.
Vel_Ex	BOOL	FALSE	This variable is used to execute the MC_MoveVelocity (Velocity Control) instruction. It is used in ST programming.
SetPos_Ex	BOOL	FALSE	This variable is used to execute the MC_SetPosition instruction. It is used in ST programming.



NJ/NX-series CPU Unit Motion Control User's Manual (W507)

• ST Programming



Ladder Diagram

When StartPg is TRUE, the status of process data communications of axis 0 is checked to see if communications are active and normal. Lock0 StartPg _EC_PDSIavTbl[MC_Axis000.Cfg.NodeAddress] _EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress] ┥┠ ┥┠ łЛ The Servo for axis 0 is turned ON if process data communications for axis 0 are active and normal. PWR MC_Power Lock0 MC_Axis000 -Pwr_Status Axis Axis Enable Status ┥┝ - Pwr_Bsy Busy Pwr_Err Error ErrorID Pwr_ErrID


If a minor fault level error occurs for axis 0, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.

MC_Axis000.MFaultLvl.Active		FaultHandler FaultHandler	
	EN		

If the Servo is ON for axis 0, velocity control is executed.

	VEL				
		MC_MoveVelocity			
Pwr_Status	MC_Axis000 —	Axis ———	— Axis	Vel_I	nvei
		Execute	InVelocity	(\rightarrow
	LREAL#36.0 —	Velocity	Busy	— Vel_Bsy	
	LREAL#1000.0 -	Acceleration	Active	— Vel_Act	
	LREAL#1000.0 -	Deceleration	CommandAborted	— Vel_Ca	
	LREAL#100.0 —	Jerk	Error	— Vel_Err	
		Direction	ErrorID	— Vel_ErrID	
		Continuous			
		BufferMode			
				1	

If StartSetPos is TRUE while the Servo is ON, the Set Position instruction is executed.



ST Programming

// If the input parameters for the instructions are not set, the target values and other parameters are set.
IF InitFlag=FALSE THEN

```
// The input parameters for the MC_MoveVelocity (Velocity Control) instruction are set.
```

```
        Vel_Vel
        := LREAL#36.0;

        Vel_Acc
        := LREAL#1000.0;

        Vel_Dec
        := LREAL#1000.0;

        Vel_Jrk
        := LREAL#100.0;
```

```
// The input parameters for the MC_SetPosition instruction are set.
Set_Pos_Pos := LREAL#0.0;
```

```
// The Input Parameter Initialization Completed Flag is changed to TRUE. InitFlag:=TRUE;
```

```
END_IF;
```

```
FaultHandler();
END_IF;
```

(Axis	:= MC_Axis000,
	Execute	:= Vel_Ex,

10 Sample Programming

Velocity		:= Vel_Vel,
Accelerat	tion	:= Vel_Acc,
Decelera	tion	:= Vel_Dec,
Jerk		:= Vel_Jrk,
InVelocity	/	=> Vel_InVel,
Busy		=> Vel_Bsy,
Active		=> Vel_Act,
Comman	dAborted	=> Vel_Ca,
Error		=> Vel_Err,
ErrorID		=> Vel_ErrID
);		
//MC_SetPosition SET_POS(
Axis		:= MC_Axis000,
Execute		:= Set_Pos_Ex,
Position		:= Set_Pos_Pos,
Done		=> Set_Pos_D,
Busy		=> Set_Pos_Bsy,
Comman	dAborted	=> Set_Pos_Ca,

=> Set_Pos_Err, => Set_Pos_ErrID

);

Error ErrorID

10-2-16 Changing a Cam Data Variable and Saving the Cam Table

This sample uses the user program to change a cam data variable that was created on Cam Editor of the Sysmac Studio. The displacements for phases of 0° to 180° are multiplied by 2 and the displacements for phases of 181° to 360° are multiplied by 0.5.

If the changes to the cam data are completed, the motion control instruction MC_SaveCamTable is used to save the cam data variable to non-volatile memory in the CPU Unit. When saving the data is completed, the MC_CamIn (Start Cam Operation) instruction is executed to start cam motion.

Precautions for Correct Use

- If the phases are not in ascending order, an error occurs when the MC_CamIn (Start Cam Operation) instruction is executed. The order of the phases are not checked in this sample. To check the order of the phases, execute the MC_SetCamTableProperty (Set Cam Table Properties) instruction.
- There is a limit to the number of times that you can write non-volatile memory in the CPU Unit. Save cam table data only when necessary.
- If the power supply to the Controller is turned OFF before the data is saved with the MC_SaveCamTable instruction, the cam data variable will revert to the contents from before it was changed by the user program.

Main Variables Used in the Programming Samples

Maniah la manaa	Data tama	Defeult	O - mark
Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 0.
MC_Axis001	_sAXIS_REF		This is the Axis Variable for axis 1.
CamProfile0	ARRAY[0360] OF sMC_CAM_REF		This is the cam data variable.*
Pwr1_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output vari- able from the PWR1 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
Pwr2_Status	BOOL	FALSE	This variable is assigned to the <i>Status</i> output variable from the PWR2 instance of the MC_Power instruction. It is TRUE when the Servo is ON.
StartPg	BOOL	FALSE	When <i>StartPg</i> is TRUE, the Servo is turned ON if EtherCAT process data communications are active and normal.
WriteCamdata	BOOL	FALSE	This variable is used to start changing the cam data. It is changed to TRUE to start editing.
WriteDone	BOOL	FALSE	This variable is used to indicate that the changes to the cam data are completed. It is changed to TRUE when the changes to the cam data are completed.
SaveCamtable	BOOL	FALSE	This variable is used to execution the Save Cam Table instruction.
_MC_COM.Status. CamTableBusy	BOOL	FALSE	This system-defined variable is TRUE while cam table data is being saved.
Sv_Cam_Ex	BOOL	FALSE	This variable is used to execute the MC_SaveCamTable instruction.
Camin_Ex	BOOL	FALSE	This variable is used to execute the MC_CamIn (Start Cam) instruction. It is used in ST programming.

* The array elements ARRAY[0..N] are set with the Cam Editor in the Sysmac Studio. The range of the array is 0 to 360 in this sample.

Timing Chart

• Ladder Di	agram	
	Write_Camdata	
	WriteDone	
	SaveCamtable	
_MC_COM.Statu	is.CamTableBusy	
SV_CAM	Sv_Cam_Ex	
	Sv_Cam_Bsy	
	Sv_Cam_D	
CAMIN	Camin_Ex	
	Camin_Bsy	
	Camin_Act	
	Camin_InCam	
	Camin_InSync	
• ST Progra	amming	
	Write_Camdata	
	WriteDone	
	SaveCamtable	
_MC_COM.Statu	is.CamTableBusy	
SV_CAM	Sv_Cam_Ex	
	Sv_Cam_Bsy	
	Sv_Cam_D	
CAMIN	Camin_Ex	
	Camin_Bsy	
	Camin_Act	
	Camin_InCam	
	Camin_InSync	

10-2-16 Changing a Cam Data Variable and Saving the Cam Table

Ladder Diagram

When *StartPg* is TRUE, the status of process data communications of axis 0 is checked to see if communications are active and normal.

StartPg	_EC_PDSIavTbl[MC_Axis000.Cfg.NodeAddress]	_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress	LOCKU
ت ا		/	
11	11	V I	\cup


When *StartPg* is TRUE, the status of process data communications of axis 1 is checked to see if communications are active and normal.

StartPo	g _EC_PDSlavTbl[MC_	Axis001.Cfg.NodeAddress]	_EC_CommErrTbl[MC_	_Axis001.Cfg.NodeAddress	LOCKI
				-1/	_(
		11		V 1	\cup


The Servo for axis 0 is turned ON if process data communications for axis 0 are active and normal.

	PWR	1	
	MC_Pov	wer	
MC_Axis000 —	Axis ————	— Axis	 Pwr1_Status
	Enable	Status	O
		Busy	– Pwr1_Bsy
			– Pwr1_Err
		ErrorID	 Pwr1_ErrID
	MC_Axis000 —	MC_Axis000 Axis — -	Enable Status Busy Error


The Servo for axis 1 is turned ON if process data communications for axis 1 are active and normal.



If a minor fault level error occurs in the MC Common Error Status variable or for any of the axes, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.



If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed.



If the Servo is ON for axis 1 and home is not defined, the MC_Home instruction is executed.

		HM2			
	N	MC_Home			
Pwr1_Status MC_Axis001.Details.Homed MC_Axis001 -	Axis ——		Axis	ب -	lm2_D
///	Execute		Done		\frown
				— Hm2_Bsy	_
		CommandAl	borted	— Hm2_Ca	
			Error	— Hm2_Err	
		E	rrorID	— Hm2_ErrID	

If *WriteCamData* is TRUE and a cam table file is not being saved, the values in the cam data variable are changed. The displacements for phases from 0° to 180° are multiplied by 2 and the displacements for phases from 181° to 360° are multiplied by 0.5. When the changes to the displacements are completed, *WriteDone* is changed to TRUE.

WriteCamdata _MC_COM.Statu	s.CamT	ableBusy	
	1	FOR Index := UINT#0 TO UINT#360 DO	L
	2	IF Index <uint#180 td="" then<=""><td></td></uint#180>	
	3	CamProfile0[INDEX].Distance:=CamProfile0[Index].Distance*REAL#2.0;	
	4	ELSE	
	5	CamProfile0[INDEX].Distance:=CamProfile0[Index].Distance*REAL#0.5;	
	6	END_IF;	
	7	END_FOR;	
	8	WriteDone:=TRUE;	
	9	WriteCamData:=FALSE;	


If the changes to the cam data variable are completed, *SaveCamtable* is TRUE, and a cam table file save operation is not in progress, *Sv_Cam_Ex* is changed to TRUE.

1	IF (WriteDone=TRUE) AND (SaveCamtable=TRUE) AND (_MC_COM.Status.CamTableBusy=FALSE) THEN	L
2	Sv Cam Ex := TRUE;	
3	END IF:	

If *Sv_Ca_TimeUp* is TRUE, *Sv_Cam_Ex* is changed to FALSE. If *Sv_Cam_Ex* changes to FALSE, *Sv_Ca_TimeUp* changes to FALSE and *Sv_Cam_Ex* changes to TRUE. The MC_SaveCamTable instruction is executed again.

Sv_Cam_Ex	Sv_Ca_TimeUp	Sv_Cam_E	X
	VI	\bigcirc	

If Sv_Cam_Ex changes to TRUE, the MC_SaveCamTable instruction is executed.



If Sv_Ca_CountUp is FALSE, a Cannot Execute Save Cam Table error occurs and Sv_Cam_Disable is changed to TRUE.

Sv_Ca_CountUp Sv_Cam_Ca	Sv_Cam_Disable
	\bigcirc


One second after a Cannot Execute Save Cam Table error occurs, *Sv_Ca_TimeUp* is changed to TRUE. When *Sv_Ca_TimeUp* changes to TRUE, *Sv_Cam_Ex* changes to FALSE.

	Sv_Ca_TON	l
Sv_Cam_Disable	TON	Sv_Ca_TimeUp
	ln Q	
	T#1s - PT ET	\smile


 $Sv_Ca_CountLoad$ changes to TRUE for one period when the cam table is saved. If $Sv_Ca_CountLoad$ is TRUE, the retry counter is reset.



If a Cannot Execute Save Cam Table error occurs three times, *Sv_Ca_CountUp* is changed to TRUE. When *Sv_Ca_CountUp* changes to TRUE, *Sv_Cam_Disable* is changed to FALSE. Retry processing for the MC_SaveCamTable instruction is completed.



If homing is completed for axis 0, velocity control is executed.



If the changes to the cam data variable and saving the cam table are completed and axis 0 is at the target velocity, the cam operation is executed.

CAMIN					
	MC_C	amIn			
MC_Axis000 —	Master —	— Master	_		
MC_Axis001 —	Slave —	—— Slave	_		
WriteDone Vel_InVel Sv_Cam_D CamProfile0 -	CamTable ——	—— CamTable	CamIn_InCam		
	Execute	InCam	O		
BOOL#True —	Periodic	InSync	- CamIn_InSync		
_eMC_START_MODE#_mcRelativePosition -	StartMode	EndOfProfile	— CamIn_Eop		
LREAL#0.0 —	StartPosition	Index	— CamIn_Index		
LREAL#0.0 —	MasterStartDistance	Busy	— CamIn_Bsy		
LREAL#1.0 —	MasterScaling	Active	— CamIn_Act		
LREAL#1.0 —	SlaveScaling	CommandAborted	— CamIn_Ca		
LREAL#0.0 —	MasterOffset	Error	— CamIn_Err		
LREAL#0.0 —	SlaveOffset	ErrorID	— CamIn_ErrID		
_eMC_REFERENCE_TYPE#_mcCommand —	ReferenceType				
_eMC_DIRECTION#_mcNoDirection —	Direction				
	CamTransition				
	BufferMode				
	CamTransition				

ST Programming

// If the input parameters for the instructions are not set, the target values and other parameters are set. IF InitFlag=FALSE THEN

// The input parameters for the MC_MoveVelocity (Velocity Control) instruction are set.

```
Vel_Vel
              := LREAL#1000.0;
Vel Acc
              := LREAL#0.0;
Vel_Dec
              := LREAL#0.0;
Vel Dir
              := _eMC_DIRECTION#_mcPositiveDirection;
// The input parameters for the MC CamIn (Start Cam Operation) instruction are set.
Camin Em
              := TRUE;
Camin_Sm
              := _eMC_START_MODE#_mcRelativePosition;
Camin_Sp
              := LREAL#0.0:
Camin_Msd
              := LREAL#0.0;
Camin Ms
              := LREAL#1.0;
Camin Ss
              := LREAL#1.0:
Camin Mo
              := LREAL#0.0;
Camin So
              := LREAL#0.0;
Camin Rt
              := _eMC_REFERENCE_TYPE#_mcCommand;
Camin Dir
              := _eMC_DIRECTION#_mcNoDirection;
```

// The Input Parameter Initialization Completed Flag is changed to TRUE. InitFlag:=TRUE;

END_IF;

// When StartPg is TRUE, the Servo is turned ON for axis 0 if process data communications for axis 0 are active and normal.

// If process data communications are not active, the Servo is turned OFF. IF (StartPg=TRUE) AND (_EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress]=TRUE)

AND (_EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]=FALSE) THEN

Pwr1_En:=TRUE; ELSE

Pwr1_En:=FALSE;

END_IF;

// When *StartPg* is TRUE, the Servo is turned ON for axis 1 if process data communications for axis 1 are active and normal.

// If process data communications are not active, the Servo is turned OFF.

IF (StartPg=TRUE)

AND (_EC_PDSlavTbl[MC_Axis001.Cfg.NodeAddress]=TRUE)

AND (_EC_CommErrTbl[MC_Axis001.Cfg.NodeAddress]=FALSE) THEN Pwr2_En:=TRUE;

ELSE

Pwr2_En:=FALSE;

 $\mathsf{END}_\mathsf{IF};$

// If a minor fault level error occurs in the MC Common Error Status variable or for any of the axes, the error handler for the device (FaultHandler) is executed. // Program the FaultHandler according to the device. IF (MC_Axis000.MFaultLvI.Active=TRUE) OR (MC_Axis001.MFaultLvI.Active=TRUE) OR (_MC_COM.MFaultLvI.Active=TRUE) THEN FaultHandler(); END_IF;

// If the Servo is ON for axis 0 and home is not defined, the MC_Home instruction is executed for axis 0. IF (Pwr1_Status=TRUE) AND (MC_Axis000.Details.Homed=FALSE) THEN

IF (Pwr2_Status=TRUE) AND (MC_Axis001.Details.Homed=FALSE) THEN Hm2_Ex:=TRUE; END_IF; // If WriteCamData is TRUE and a cam table file is not being saved, the values in the cam data variable are changed. // The displacements for phases of 0° to 180° are multiplied by 2 and the displacements for phases of 181° to 360° are multiplied by 0.5. // When the changes are completed, WriteDone is changed to TRUE. IF (WriteCamdata=TRUE) AND (_MC_COM.Status.CamTableBusy=FALSE) THEN FOR Index := UINT#0 TO UINT#360 DO IF Index<UINT#180 THEN CamProfile0[Index].Distance:=CamProfile0[Index].Distance*REAL#2.0; ELSE CamProfile0[Index].Distance:=CamProfile0[Index].Distance*REAL#0.5; END_IF; END_FOR; WriteDone:=TRUE: WriteCamdata:=FALSE; END IF; // If homing is completed for axis 0, velocity control is executed. IF Hm1 D=TRUE THEN Vel_Ex:=TRUE; END_IF; // If the changes to the cam data variable are completed, SaveCamtable is TRUE, and a cam table file save operation is not in progress, // Sv_Cam_Ex is changed to TRUE. // If Sv_Cam_Ex is TRUE, the MC_SaveCamTable instruction is executed. IF (WriteDone=TRUE) AND (SaveCamtable=TRUE) AND (_MC_COM.Status.CamTableBusy=FALSE) THEN Sv Cam Ex := TRUE; END_IF; // If Sv_Ca_TimeUp is TRUE, Sv_Cam_Ex is changed to FALSE. // If Sv_Cam_Ex is FALSE, Sv_Ca_TimeUp changes to FALSE and Sv_Cam_Ex changes to TRUE. $\ensuremath{\textit{//}}\xspace$ The MC_SaveCamTable instruction is executed again. IF (Sv_Cam_Ex=TRUE) AND (Sv_Ca_TimeUp=FALSE) THEN Sv_Cam_Ex := TRUE; ELSE Sv_Cam_Ex := FALSE; END IF; // If Sv_Ca_CountUp is FALSE and a Cannot Execute Save Cam Table error occurs, // Sv_Cam_Disable is changed to TRUE. IF (Sv_Ca_CountUP=FALSE) AND (Sv_Cam_Ca=TRUE) THEN Sv_Cam_Disable := TRUE; FLSF Sv_Cam_Disable := FALSE; END_IF;

// If the Servo is ON for axis 1 and home is not defined, the MC_Home instruction is executed for axis 1.

Hm1_Ex:=TRUE;

END_IF;

// One second after the Cannot Execute Save Cam Table error occurs, Sv_Ca_TimeUp is changed to TRUE. // If Sv_Ca_TimeUp changes to TRUE, Sv_Cam_Ex is changed to FALSE. Sv_Ca_TON(

In := Sv_Cam_Disable , PT := T#1s , Q => Sv_Ca_TimeUp

);

// Sv_Ca_CountLoad is changed to TRUE for one period when the cam table is saved. // If Sv_Ca_CountLoad changes to TRUE, the retry counter is reset. R_TRIG1(SaveCamtable, Sv_Ca_CountLoad);

);

 $\prime\prime$ If the changes to the cam data variable and saving the cam table are completed and axis 0 is at the target velocity, the cam operation is executed.

```
IF (Vel_InVel=TRUE)
AND (WriteDone=TRUE)
AND (Sv_Cam_D=TRUE) THEN
Camin_Ex:=TRUE;
```

END_IF;

```
//MC_SaveCamTable
SV_CAM(
                             :=CamProfile0,
       CamTable
       Execute
                             := Sv_Cam_Ex,
       Done
                             => Sv_Cam_D,
       Busy
                             => Sv_Cam_Bsy,
       CommandAborted
                             => Sv_Cam_Ca,
       Error
                             => Sv_Cam_Err,
       ErrorID
                             => Sv_Cam_ErrID
```

);

CAMIN

N(
Master	:= MC_Axis000,
Slave	:= MC_Axis001,
CamTable	:= CamProfile0,
Execute	:= Camin_Ex,
Periodic	:= Camin_Em,
StartMode	:= Camin_Sm,
StartPosition	:= Camin_Sp,
MasterStartDistance	:= Camin_Msd,
MasterScaling	:= Camin_Ms,
SlaveScaling	:= Camin_Ss,
MasterOffset	:= Camin_Mo,
SlaveOffset	:= Camin_So,
ReferenceType	:= Camin_Rt,
Direction	:= Camin_Dir,
InCam	=> Camin_InCam,
InSync	=> Camin_InSync,
EndOfProfile	=> Camin_Eop,
Index	=> Camin_Index,
Busy	=> Camin_Bsy,
Active	=> Camin_Act,
CommandAborted	=> Camin_Ca,

```
Error
                                => Camin_Err,
        ErrorID
                                => Camin_ErrID
);
// MC_Power for axis 0
PWR1(
                := MC_Axis000,
        Axis
        Enable := Pwr1_En,
        Status => Pwr1_Status,
               => Pwr1_Bsy,
        Busy
        Error
               => Pwr1_Err,
        ErrorID => Pwr1_ErrID
);
// MC Power for axis 1
PWR2(
        Axis
                := MC_Axis001,
        Enable := Pwr2 En,
        Status => Pwr2_Status,
              => Pwr2_Bsy,
        Busy
                => Pwr2_Err,
        Error
        ErrorID => Pwr2_ErrID
);
// MC_Home for axis 0
HM1(
        Axis
                                := MC Axis000,
        Execute
                                := Hm1_Ex,
        Done
                                => Hm1 D.
        Busy
                                => Hm1 Bsy,
        CommandAborted
                                => Hm1_Ca,
        Error
                                => Hm1_Err,
        ErrorID
                                => Hm1_ErrID
);
// MC_Home for axis 1
HM2(
                                := MC_Axis001,
        Axis
                                := Hm2_Ex,
        Execute
                                => Hm2_D,
        Done
        Busv
                                => Hm2_Bsy,
        CommandAborted
                                => Hm2 Ca.
                                => Hm2_Err,
        Error
                                => Hm2_ErrID
        ErrorID
);
//MC_MoveVelocity
VEL(
                                := MC_Axis000,
        Axis
        Execute
                                := Vel_Ex,
                                := Vel Vel,
        Velocity
        Acceleration
                                := Vel_Acc,
        Deceleration
                                := Vel_Dec,
        Direction
                                := Vel Dir,
        InVelocity
                                => Vel InVel,
        Busy
                                => Vel_Bsy,
        Active
                                => Vel_Act,
        CommandAborted
                                => Vel_Ca,
        Error
                                => Vel_Err,
        ErrorID
                                => Vel_ErrID
```

10-2-17 Temporarily Changing Axis Parameters

This sample uses the MC_Write (Write MC Setting) instruction to change the settings of the In-Position Check Time, Positive Software Limit, and Negative Software Limit.

Main Variables Used in the Programming Samples

Variable name	Data type	Default	Comment
MC_Axis000	_sAXIS_REF		This is the Axis Variable for axis 0.
InitFlag	BOOL	FALSE	This variable indicates the status of parameter settings.
			FALSE while parameters are changed.
			TRUE after the changes to the parameters are completed.
StartPg	BOOL	FALSE	This variable is used to execute the MC_Write instruction.

Ladder Diagram

The axis parameters are set. When setting the parameters is completed, *InitFlag* is changed to TRUE.

۸	1	// In-position Check Time
•	2	Write1_Sv := UINT#10;
	3	Write1_Pn := _eMC_PARAMETER_NUMBER#_mcInPosTime;
	4	// Positive Software Limit
	5	Write2_Sv := LREAL#10000.0;
	6	Write2_Pn := _eMC_PARAMETER_NUMBER#_mcPosiSwLmt;
	7	// Negative Software Limit
	8	Write3_Sv := LREAL#-10000.0;
	9	Write3_Pn := _eMC_PARAMETER_NUMBER#_mcNegaSwLmt;
	10	// The Initialization Completed Flag is changed to TRUE.
	11	InitFlag := TRUE;


If *StartPg* is TRUE, the setting of the In-position Check Time is changed.

WRITE1	.
MC_Write	
	Write1 D
Execute Done	
-	— Write1_Bsy
CommandAborted	Write1_Ca
-	— Write1_Err — Write1_ErrID
	MC_Write Target — Target SettingValue — SettingValue Execute Done ParameterNumber Busy

If changing the setting of the In-Position Check Time is completed, the setting of the Positive Software Limit is changed.

	WRITE2	
	MC_Write	
	SettingValue — SettingValue Execute Done	Write2_D
Write2_Pn —	ParameterNumber Busy CommandAborted Error ErrorID	— Write2_Bsy — Write2_Ca — Write2_Err — Write2_ErrID

I



ST Programming

// The axis parameters are set. When setting the parameters is completed, *InitFlag* is changed to TRUE. IF InitFlag=FALSE THEN

```
// In-position Check Time
Write1_Sv := UINT#10;
Write1_Pn := _eMC_PARAMETER_NUMBER#_mcInPosTime;
// Positive Software Limit
Write2_Sv := LREAL#10000.0;
Write2_Pn := _eMC_PARAMETER_NUMBER#_mcPosiSwLmt;
// Negative Software Limit
Write3_Sv := LREAL#-10000.0;
Write3_Pn := _eMC_PARAMETER_NUMBER#_mcNegaSwLmt;
```

// The Input Parameter Initialization Completed Flag is changed to TRUE. InitFlag := TRUE;

END_IF;

// If changing the setting of the In-Position Check Time is completed, the setting of the Positive Software Limit is changed.

IF Write1_D = TRUE THEN Write2_Ex := TRUE; END_IF;

// If changing the setting of the Positive Software Limit is completed, the setting of the Negative Software Limit is changed.

IF Write2_D = TRUE THEN Write3_Ex := TRUE; END_IF;

```
// MC_Write
WRITE1(
```

Target	:= MC_Axis000,
SettingValue	:= Write1_Sv,
Execute	:= Write1_Ex,
ParameterNumber	:= Write1_Pn,
Done	=> Write1_D,
Busy	=> Write1_Bsy,
CommandAborted	=> Write1_Ca,
Error	=> Write1_Err,
ErrorID	=> Write1_ErrID

);

WRITE2(

Target	:= MC_Axis000,
SettingValue	:= Write2_Sv,
Execute	:= Write2_Ex,
ParameterNumber	:= Write2_Pn,
Done	=> Write2_D,
Busy	=> Write2_Bsy,
CommandAborted	=> Write2_Ca,
Error	=> Write2_Err,
ErrorID	=> Write2_ErrID

);

WRITE3(
Target	:= MC_Axis000,
SettingValue	:= Write3_Sv,
Execute	:= Write3_Ex,
ParameterNumber	:= Write3_Pn,
Done	=> Write3_D,
Busy	=> Write3_Bsy,
CommandAborted	=> Write3_Ca,
Error	=> Write3_Err,
ErrorID	=> Write3_ErrID

);

10-2-18 Updating the Cam Table End Point Index

This sample increases the valid number of data points by 10 in a cam table with a maximum number of data points of 110 and a valid number of data points of 100. It also updates the end point index.

Main Variables Used in the Programming Samples

Variable name	Data type	Default	Comment
CamProfile0	ARRAY[0109] OF _sMC_CAM_REF		This is a cam data variable with a maximum number of data points of 110.* It contains 100 valid cam data points and 10 null cam data points.
WriteCamdata	BOOL	FALSE	This variable is used to start changing the cam data. It is changed to TRUE to start editing.
WriteDone	BOOL	FALSE	This variable is used to indicate when the changes to the cam data are completed. It changes to TRUE when the changes to the cam data are completed.

* The array elements ARRAY[0..N] are set with the Cam Editor in the Sysmac Studio. The range of the array is 0 to 109 in this sample.

Ladder Diagram

The axis parameters are set. When setting the parameters is completed, *InitFlag* is changed to TRUE.

	1	// The phases and displacements for null cam data are set.	
· ·	2	PhaseData:=REAL#99.0;	
	3	DistanceData:=REAL#250.0;	
	4	// The Initialization Completed Flag is changed to TRUE.	
	5	InitFlag := TRUE;	

If a minor fault level error occurs in the MC Common Error Status variable, the error handler for the device (FaultHandler) is executed. Program the FaultHandler according to the device.

_MC_COM.MFaultLvI.Active	FaultHandler
	EN FaultHandler

If *StartPg* and *WriteCamData* are TRUE, the values in the cam data variable are changed. Phases and displacements are set for *CamProfile[100]* to *CamProfile[109]*. When the changes to the cam data variable are completed, *WriteDone* is changed to TRUE.

StartPg WriteCamData		
	1 FOR Index := UINT#100 TO UINT#109 DO	
	2 PhaseData:=PhaseData+REAL#1.0;	
	3 DistanceData:=DistanceData+REAL#3.0;	
	4 CamProfile0[Index].Phase:=PhaseData;	
	5 CamProfile0[Index].Distance:=DistanceData;	
	6 END_FOR;	
	7 WriteDone:=TRUE;	

10

I

	SET_CAM
	MC_SetCamTableProperty
WriteDone CamProfi	CamTable — CamTable – CamProfile0 Set_Cam_D
	Execute Done
	EndPointIndex — Set_Cam_Epi
	MaxDataNumber – Set_Cam_Mdn
	Busy – Set_Cam_B
	CommandAborted - Set_Cam_Ca
	Error – Set_Cam_Err
	ErrorID - Set_Cam_ErrID

If the changes to the cam data variable are completed, the Set Cam Table Properties instruction is executed.

ST Programming

// The axis parameters are set. When setting the parameters is completed, *InitFlag* is changed to TRUE.
IF InitFlag=FALSE THEN

// The phases and displacements for null cam data are set. PhaseData:=REAL#99.0; DistanceData:=REAL#250.0;

// The Initialization Completed Flag is changed to TRUE. InitFlag := TRUE;

END_IF;

// If a minor fault level error occurs in the MC Common Error Status variable, the error handler for the device is executed.

// Program the FaultHandler according to the device.

IF _MC_COM.MFaultLvI.Active=TRUE THEN

```
FaultHandler();
```

```
END_IF;
```

// If StartPg and WriteCamData are TRUE, the values in the cam data variable are changed. // The phases and displacements are set in CamProfile[100] to CamProfile[109]. // When the changes to the cam data variable are completed, WriteDone is changed to TRUE. IF StartPg=TRUE AND WriteCamData=TRUE THEN FOR Index := UINT#100 TO UINT#109 DO PhaseData :=PhaseData+REAL#1.0; DistanceData :=DistanceData+REAL#3.0; CamProfile0[Index].Phase :=PhaseData; CamProfile0[Index].Distance :=DistanceData; END_FOR;

WriteDone:=TRUE;

END_IF;

 $\prime\prime$ If the changes to the cam data variable are completed, the Set Cam Table Properties instruction is executed. IF WriteDone=TRUE THEN

Set_Cam_Ex := TRUE;

END_IF;

//MC_SetCamTableProperty SET_CAM(

CamTable	:= CamProfile0,
Execute	:= Set_Cam_Ex,
Done	=> Set_Cam_D,
EndPointIndex	=> Set_Cam_Epi,
MaxDataNumber	=> Set_Cam_Mdn,
Busy	=> Set_Cam_B,
CommandAborted	=> Set_Cam_Ca,
Error	=> Set_Cam_Err,
ErrorID	=> Set_Cam_ErrID

Troubleshooting

This section describes the items to check when problems occur in the MC Function Module. It includes error diagnosis and countermeasures for error indications, and error diagnosis and countermeasures for operating conditions.


11-1 Overvi	ew of Errors	
11-1-1	How to Check for Errors	
11-1-2	Errors Related to the Motion Control Function Module	
11-2 Troubl	eshooting	
11-2-1	Error Table	
11-2-2	Error Descriptions	
11-2-3	Error Causes and Remedies	

11-1 Overview of Errors


You manage all of the errors that occur on the NJ/NX-series Controller as events. The same methods are used for all events. This allows you to see what errors have occurred and find corrections for them with the same methods for the entire range of errors that is managed (i.e., CPU Unit, NX-series Slave Terminals, EtherCAT slaves,* and CJ-series Units).

* Only Sysmac devices are supported.

NX-series CPU Unit



NJ-series CPU Unit



You can use the troubleshooting functions of the Sysmac Studio or the Troubleshooter on an HMI to quickly check for errors that have occurred and find corrections for them.

To perform troubleshooting from an HMI, connect the HMI to the built-in EtherNet/IP port on the CPU Unit.

This manual describes the errors that originate in the Motion Control Function Module. Refer to the *NJ/NX-series Troubleshooting Manual* (Cat. No. W503) for specific corrections when errors occur and for troubleshooting information on the entire NJ/NX-series Controller. For information on errors that occur when motion control instructions are executed, refer to each instruction in the *NJ/NX-series Motion Control Instruction Reference Manual* (Cat. No. W508).



Precautions for Correct Use

Refer to the appendices of the *NJ/NX-series Troubleshooting Manual* (Cat. No. W503) for the applicable range of the HMI Troubleshooter.

11-1-1 How to Check for Errors

Checking method	What you can check
Checking the indicators	CPU Unit operating status
Troubleshooter of the Sysmac Studio	You can check for current Controller errors, a log of past Controller errors, error sources, error causes, and corrections.
Checking with the Troubleshooter of an HMI*	You can check for current Controller errors, a log of past Controller errors, error sources, causes, and corrections.
Checking with instructions that read function module error status	You can check the highest-level status and highest-level event code in the current Controller errors.
Checking with System-defined Variables	You can check the current Controller error status for each function module.

You can check to see if an error has occurred with the following methods.

* To perform troubleshooting from an HMI, connect the HMI to the built-in EtherNet/IP port on the CPU Unit. Refer to the appendices of the *NJ/NX-series Troubleshooting Manual* (Cat. No. W503) for the applicable range of the HMI Troubleshooter.

This section describes the above checking methods.

Checking the Indicators

You can use the PWR indicator on the Power Supply Unit and the RUN and ERROR indicators on the CPU Unit to determine the event level for an error. The following table shows the relationship between the Controller's indicators and the event level.

Indicator			CPU Unit operating status	Error confirmation with the Sysmac
PWR	RUN	ERROR	CPO Onit operating status	Studio or an HMI
Not lit	Not lit	Not lit	Power Supply Error	Not possible:
Lit	Not lit	Not lit	CPU Unit Reset ^{*1, *2}	Refer to the <i>NJ/NX-series Trouble-shooting Manual</i> (Cat. No. W503).
Lit	Not lit or flashing	Lit	CPU Error ^{*2, *3}	
Lit	Flashing more than 30 sec- onds	Lit	System Initialization Error	
Lit	Not lit	Lit	Major fault level*2, *3	Possible:
Lit	Lit	Flashing	Partial fault level	Connect the Sysmac Studio or an HMI
Lit	Lit	Flashing	Minor fault level	and check the cause of and correction for the error in the troubleshooting
Lit	Lit	Not lit	Observation	functions of the Sysmac Studio or the Troubleshooter of the HMI.
Lit	Lit	Not lit	Normal operation in RUN mode	
Lit	Not lit	Not lit	Normal operation in PROGRAM mode ^{*1, *2}	
Lit	Flashing	Not lit	Normal operation in startup state	

• NX-series CPU Unit

*1 If you can go online with the CPU Unit from the Sysmac Studio with a direct USB connection, the CPU Unit is in PROGRAM mode. If you cannot go online, the CPU Unit is being reset.

- *2 If you cannot go online with the CPU Unit from the Sysmac Studio, it is also possible that the USB cable is faulty or that the network type on the Sysmac Studio is not set for a direct USB connection. Refer to the *NJ/NX-series Troubleshooting Manual* (Cat. No. W503) if you cannot go online with the CPU Unit.
- *3 If you can go online with the CPU Unit from the Sysmac Studio with a direct USB connection, a major fault level error has occurred. If you cannot go online, a CPU error has occurred.

Indicator			CPU Unit operating status	Error confirmation with the Sysmac	
PWR	RUN	ERROR	GFO Onit operating status	Studio or an HMI	
Not lit	Not lit	Not lit	Power Supply Error	Not possible:	
Lit	Not lit	Not lit	CPU Unit Reset ^{*1, *2}	Refer to the <i>NJ/NX-series Trouble-</i> shooting Manual (Cat. No. W503).	
Lit	Flashing	Lit	Incorrect Power Supply Unit Con- nected		
Lit	Not lit	Lit	CPU Unit Watchdog Timer Error ^{*2, *3}		
Lit	Not lit	Lit	Major fault level*2, *3	Possible:	
Lit	Lit	Flashing	Partial fault level	Connect the Sysmac Studio or an HMI and check the cause of and correction	
Lit	Lit	Flashing	Minor fault level	for the error in the troubleshooting	
Lit	Lit	Not lit	Observation	functions of the Sysmac Studio or the Troubleshooter of the HMI.	
Lit	Lit	Not lit	Normal operation in RUN mode		
Lit	Not lit	Not lit	Normal operation in PROGRAM mode ^{*1, *2}		
Lit	Flashing	Not lit	Normal operation in startup state		

• NJ-series CPU Unit

*1 If you can go online with the CPU Unit from the Sysmac Studio with a direct USB connection, the CPU Unit is in PROGRAM mode. If you cannot go online, the CPU Unit is being reset.

- *2 If you cannot go online with the CPU Unit from the Sysmac Studio, it is also possible that the USB cable is faulty or that the network type on the Sysmac Studio is not set for a direct USB connection. Refer to the *NJ/NX-series Troubleshooting Manual* (Cat. No. W503) if you cannot go online with the CPU Unit.
- *3 If you can go online with the CPU Unit from the Sysmac Studio with a direct USB connection, a major fault level error has occurred. If you cannot go online, a watchdog timer error has occurred in the CPU Unit.

Checking with the Troubleshooting Function of Sysmac Studio

When an error occurs, you can connect the Sysmac Studio online to the Controller to check current Controller errors and the log of past Controller errors. You can also check the cause of the error and corrections.

Refer to the *NJ/NX-series Troubleshooting Manual* (Cat. No. W503) for the procedures to check for errors with the Sysmac Studio.

Checking with the Troubleshooter of an HMI

If you can connect communications between an HMI and the Controller when an error occurs, you can check for current Controller errors and the log of past Controller errors. You can also check the cause of the error and corrections.

To perform troubleshooting from an HMI, connect the HMI to the built-in EtherNet/IP port on the CPU Unit.

Refer to the *NJ/NX-series Troubleshooting Manual* (Cat. No. W503) for the procedures to check for errors with an HMI.

Checking with Instructions That Read Error Status

You can use instructions in the user program to check the error status of each function module. The following table gives the instruction that is used to get error information for the Motion Control Function Module.

Instruction	Name	Outline of function
GetMCError	Get Motion Control Error Status	The GetMCError instruction gets the highest level status (partial fault or minor fault) and highest level event code of the current Controller errors in the Motion Control Function Module.

For details on the instructions that get error status, refer to the *NJ/NX-series Instructions Reference Manual* (Cat. No. W502).

Checking with System-defined Variables

You can use the error status variables in the system-defined variables and the system-defined variables for motion control to check for errors that have occurred in the Motion Control Function Module.

• Error Status Variables

You can check for errors in each function module of the NJ/NX-series Controller with error status variables. The following variables show the error status of the Motion Control Function Module.

Variable name	Data type	Meaning	Function
_MC_ErrSta	WORD	MC Error Status	Gives the collective error status of all error status for the Motion Control Function Module.
_MC_ComErrSta	WORD	MC Common Error Status	Gives the collective error status of all errors that occur for common processing in the Motion Control Function Module.
_MC_AX_ErrSta	ARRAY[] OF WORD	Axis Error Status	Gives the collective error status of all error status for each axis.
_MC_GRP_ErrSta	ARRAY[] OF WORD	Axes Group Error Status	Gives the collective error status of all error status for each axes group.

The meanings of the individual bits in the above error status variables are given below.

Bit	Name	Description	Value	Meaning
15	Master Detection*1	This bit indicates whether the master detected an	TRUE	Error
		error in the slaves that it manages.	FALSE	No error
14	Slave Summary*2	Gives the collective error status of all error status for	TRUE	Error
		EtherCAT slaves that are assigned to axes in the Motion Control Function Module.	FALSE	No error
8 to 13	Reserved		•	•
7	Major Fault	Indicates if there is a major fault level error.	TRUE	Error
			FALSE	No error
6	Partial Fault	Indicates if there is a partial fault level error.	TRUE	Error
			FALSE	No error
5	Minor Fault	Indicates if there is a minor fault level error.	TRUE	Error
			FALSE	No error
4	Observation	Indicates if there is an observation level error.	TRUE	Error
			FALSE	No error
0 to 3	Reserved			•

*1 This bit is not used in the error status variables for the Motion Control Function Module.

*2 For the Motion Control Function Module, only _MC_ErrSta (MC Error Status) is used.

• System-defined Variables for Motion Control

You can monitor the MC Common Variable, Axis Variables, and Axes Group Variables of the system-defined variables for motion control to see if errors have occurred in the Motion Control Function Module.

Refer to 6-6 System-defined Variables for Motion Control for information on system-defined variables for motion control.


11-1-2 Errors Related to the Motion Control Function Module

This section describes the errors that are related to the Motion Control Function Module.

Sources of Errors Related to the Motion Control Function Module

Errors can occur internally in the Motion Control Function Module, or they can occur in EtherCAT communications, which are used to connect to the Servo Drives and other slaves.

- Inside MC Function Module
- EtherCAT Master Function Module
- Built-in EtherCAT communications port hardware
- EtherCAT slaves



You can check the sources and causes of the errors in the system-defined variables or from the Sysmac Studio or an HMI.

Precautions for Correct Use

Refer to the appendices of the *NJ/NX-series Troubleshooting Manual* (Cat. No. W503) for the applicable range of the HMI Troubleshooter.

Classifications

There are the following three sources of errors in the Motion Control Function Module.

Classification	Description
MC Common Errors	If an error is detected in the common portion of the Motion Control Function Mod- ule, the corresponding bit in the MC Common Error Status variable shows the error.
Axis Error	If an error is detected for an axis, the corresponding bit in the Axis Error Status variable shows the error.*
Axes Group Errors	If an error is detected for an axes group, the corresponding bit in the Axes Group Error Status variable shows the error.

* If an axis error with a minor fault level or higher level occurs, operation is also not possible for an axes group that contains the axis as a composition axis.

Event Levels

This section describes the operation of the Motion Control Function Module for each event level.

Event level of the error	Operation
Major fault	All NJ/NX-series Controller control operations stop for errors in this event level.
Partial fault	All control operations for one of the function modules in the NJ/NX-series Control- ler stop for errors in this event level. If a partial fault level error occurs in the Motion Control Function Module, all function of the Motion Control Function Mod- ule, such as axis operation, stop.
Minor fault	Some of the control operations for one of the function modules in the NJ/NX- series Controller stop for errors in this event level. If a minor fault level error occurs in the Motion Control Function Module, the relevant axis or axes group stops.
Observation	Errors in the observation level do not affect NJ/NX-series Controller control opera- tions. Observations are reported in order to prevent them from developing into errors at the minor fault level or higher.
Information	Events that are classified as information provide information that do not indicate errors.

MC Function Module Errors by Source

The following tables list the errors in each event level that can occur for each source.

MC Common Errors

Level	Error name		
Major fault	None		
Partial fault	Motion Control Parameter Setting Error		
	Cam Data Read Error		
	Required Process Data Object Not Set		
	Axis Slave Disabled		
	 Network Configuration Information Missing for Axis Slave 		
	Motion Control Initialization Error		
	Motion Control Period Exceeded Error		
	Absolute Encoder Home Offset Read Error		
Minor fault	Cam Table Save Error		
	Other execution errors for motion control instructions		
Observation	Cannot Execute Save Cam Table Instruction		
	Too Many Reset Motion Control Error Instructions		
Information	Error Clear from MC Test Run Tab Page		

• Axis Errors

Level	Error name
Major fault	None
Partial fault	• None
Minor fault	Cam Table Data Error during Cam Motion Home Proximity/Homing Direction Limit Input Detected
Observation	MotionLimit Input Detected• Immediate Stop Instruction Executed• Home Input/Homing Opposite Direction Limit Input Detected• Negative Software Limit Exceeded• Home Input/Homing Direction Limit Input Detected• In-position Check Time Exceeded• Home Input/Homing Direction Limit Input Detected• Inmediate Stop Input• No Home Input• Positive Limit Input Detected• No Home Input• Negative Limit Input Detected• No Home Proximity Input• Negative Limit Input Detected• No Home Proximity Input• Negative Limit Input Detected• MC Common Error Occurrence• Latch Position Calculation Failed• Master Sync Direction Error• Servo Main Circuit Power OFF• Interrupt Feeding Interrupt Signal Missing• Error in Changing Servo Drive Control Mode• Homing Opposite Direction Limit Input Detected• Master Axis Position Read Error• Homing Limit Inputs Detected in Both Directions• Other execution errors for motion con- trol instructions• Following Error Warning• Command Position Underflow
	Velocity Warning Actual Position Overflow
	Acceleration Warning Actual Position Underflow
	Deceleration Warning Slave Observation Detected
	Positive Torque Warning Notice of Insufficient Travel Distance
	Negative Torque Warning to Achieve Blending Transit Velocity
	Command Position Overflow Other execution errors for motion con- trol instructions
Information	Slave Error Code Report

Axes Group Errors

Level	Error name
Major fault	None
Partial fault	None
Minor fault	Axes Group Immediate Stop Instruction Executed
	Home Undefined during Coordinated Motion
	Axes Group Composition Axis Error
	 Other execution errors for motion control instructions
Observation	Velocity Warning
	Acceleration Warning
	Deceleration Warning
	 Notice of Insufficient Travel Distance to Achieve Blending Transit Velocity
Information	None

You can change the event level for some events. Refer to *NJ/NX-series CPU Unit Software User's Manual* (Cat. No. W501) for information on changing event levels. Refer to *11-2 Troubleshooting* in this manual to see the events for which you can change the event level.

Errors Related to EtherCAT Communications, EtherCAT Slaves, and NX Units

The following Motion Control Function Module error can occur due to errors in EtherCAT communications, EtherCAT slaves, or NX Units.

Error name	Event code	Cause	Operation for error
EtherCAT Slave Communications Error	8440 0000 hex	A communications error occurred for the EtherCAT slave or NX Unit that is allocated to an axis in the Motion Control Function Mod- ule.*1	The Servo is turned OFF for the axis with an error and operations other than error resets are not acknowledged.*2
Slave Error Detected	742F 0000 hex	An error was detected for the EtherCAT slave or NX Unit that is allocated to an axis in the Motion Control Function Module.	The Servo is turned OFF for the axis with an error and operations other than error resets are not acknowledged.

*1 When an error occurs in communications with an EtherCAT slave, an error also occurs in the EtherCAT Master Function Module. If you assign more than one device to the same axis, a communications error occurs for the axis if a communications error occurs for even one of the devices.

*2 When an error occurs in slave communications, home becomes undefined for the axis.

Servo Drive Errors

This section describes the notification that is provided for errors that occur in OMRON G5-series Servo Drives.

There is a difference between the timing of when the Motion Control Function Module detects the error in the Servo Drive and when the error code is obtained from the Servo Drive. The Motion Control Function Module therefore reports different events for the error in the Servo Drive and the error code.

• Error Notification

When the Motion Control Function Module detects an error, a Slave Error Detected minor fault level error (742F0000 hex) occurs. At this point, the Motion Control Function Module performs the error operation (i.e., it turns OFF the Servo).

• Error Code Notification

When the Servo Drive reports the error code, the Motion Control Function Module generates a Slave Error Code Report information event (94220000 hex). The error code (the main part of the error display number) from the Servo Drive is included in the lower two digits of the attached information of the Slave Error Code Report event. For example, if the attached information is displayed as FF13, the error with display number 13 (Main Circuit Power Supply Undervoltage) occurred in the Servo Drive.

You must change the settings to receive notification of the Slave Error Code Report event. Map object 603F hex (Error Code) in the PDO Edit Pane.

Errors Related to NX Units

Error and error code notifications are provided for errors that occur for OMRON NX-series Position Interface Units in the same way as they are for OMRON G5-series Servo Drives.

However, NX-series Position Interface Units do not have an object that corresponds to object 603F hex (Error Code), so 0000 hex is given for the Slave Error Code Report (94220000 hex) in the attached information.

Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) or the *NX-series Ether-CAT Coupler Unit User's Manual* (Cat. No. W519) for details on errors that occur in NX-series Position Interface Units.

11-2 Troubleshooting

This section describes the errors that can occur and the corrections for them.

11-2-1 Error Table

The errors (i.e., events) that can occur in the Motion Control Function Module are given on the following pages.

The following abbreviations and symbols are used in the event level column.

Abbreviation	Name
Maj	Major fault level
Prt	Partial fault level
Min	Minor fault level
Obs	Observation
Info	Information

Symbol Meaning							
S	Event levels that are defined by the system.						
U	Event levels that can be changed by the user.*						

* This symbol appears only for events for which the user can change the event level.

The upper four digits of the event codes that are given in the following table are output as the error codes to the system-defined variable for motion control.

A version in parentheses in the *Event code* column is the unit version of the CPU Unit when the event occurs for only specific unit versions of the CPU Unit.

Refer to the NJ/NX-series Troubleshooting Manual (Cat. No. W503) for all NJ/NX-series event codes.

Event and a	Eventurence	name Meaning	A			Leve	I		Reference
Event code	Event name		Assumed cause	Maj	Prt	Min	Obs	Info	
4421 0000 hex	Motion Con- trol Function Processing Error	A fatal error was detected in the Motion Control Function Module.	 An error occurred in the soft- ware. 	S					page 11-23
1460 0000 hex	Absolute Encoder Home Offset Read Error	The absolute encoder current position that is retained during power interruptions was lost.	 The life of the Battery in the CPU Unit has expired. Backup memory failure 		S				page 11-23
14610000 hex	Motion Con- trol Parame- ter Setting Error	The MC parameters that were saved in non-volatile mem- ory are missing.	 The power supply to the Controller was interrupted or communications with the Sysmac Studio were disconnected while downloading the motion control parameter settings or clearing memory. Non-volatile memory failure 		S				page 11-24
14620000 hex	Cam Data Read Error	The cam data that was saved in non- volatile memory is missing.	 Power was interrupted during save processing for cam data Non-volatile memory failure 		S				page 11-24
34600000 hex	Required Process Data Object Not Set	The object that is required for the axis type is not allocated to PDO.	 The required PDOs are not mapped when the axis type is set to a servo axis or encoder axis. Non-volatile memory failure 		S				page 11-25

Eventerde	Event	Meening	Accurred				Reference		
Event code	Event name	Meaning	Assumed cause	Мај	Prt	Min	Obs	Info	Reference
34630000 hex	Axis Slave Disabled	The slave to which the axis is assigned is disabled.	 The slave to which the axis is assigned is disabled. 		S				page 11-25
34640000 hex	Network Configura- tion Informa- tion Missing for Axis Slave	The network config- uration information is not registered for the slave to which the axis is assigned.	• The EtherCAT network configu- ration information is not regis- tered for the slave to which the axis is assigned.		S				page 11-26
44200000 hex	Motion Con- trol Initializa- tion Error	A fatal error occurred in the sys- tem and prevented initialization of the Motion Control Function Module.	Hardware has failed.		S				page 11-26
7420 0000 hex	Motion Con- trol Period Exceeded	Processing for the primary periodic task was not fin- ished within two control periods.	 The processing load in the pri- mary periodic task is too heavy. 		S				page 11-27
14630000 hex	Cam Table Save Error	Saving a cam table to a file failed.	 Saving a cam table to a file failed. 			S			page 11-27
54770000 hex	Cam Table Data Error during Cam Motion	The phases are not in ascending order in the cam table.	• Data containing cam table phases that are not in ascend- ing order was detected during cam motion.			S			page 11-28
			• The phase and displacement of the start point in the cam table were not 0 during cam opera- tion.						
			 The phase of the end point in the cam table when converted to pulses was not 1 pulse or greater during cam operation. 						
54850000 hex	Immediate Stop Instruc- tion Executed	An Immediate Stop (MC_ImmediateSto p) instruction was executed.	 An Immediate Stop instruction was executed. 			S			page 11-28
54860000 hex	Axes Group Immediate Stop Instruc- tion Executed	An Axes Group Immediate Stop (MC_GroupImmedi ateStop) instruction was executed.	A Group Immediate Stop instruction was executed.			S			page 11-29
64450000 hex	Positive Soft- ware Limit Exceeded	The position exceeded the posi- tive software limit while the axis is in motion.	The position exceeded the pos- itive software limit.			S			page 11-29
6446 0000 hex	Negative Software Limit Exceeded	The position exceeded the nega- tive software limit while the axis is in motion.	The position exceeded the neg- ative software limit.			S			page 11-30
64470000 hex	In-position Check Time Exceeded	The in-position check was not com- pleted within the monitoring time.	 Time is required to complete positioning. 			S			page 11-30

Event e e de	Event name	Meaning	Assumed cause	Level					Deference
Event code				Maj	Prt	Min	Obs	Info	Reference
64480000 hex	Following Error Limit Exceeded	The error between the command cur- rent position and actual current value exceeded the Fol- lowing Error Over Limit Value.	• The positioning operation has poor following performance and the actual motion is slower than the command.			S			page 11-31
64490000 hex	Immediate Stop Input	The immediate stop input turned ON.	 An immediate stop input signal was detected. The immediate stop input signal is not connected correctly or the logic setting for the immediate stop input is wrong. 			S			page 11-31
644A0000 hex	Positive Limit Input Detected	The positive limit input turned ON.	 A positive limit input signal was detected. The positive limit input signal is not connected correctly or the logic setting for the positive limit input is wrong. 			S			page 11-32
644B0000 hex	Negative Limit Input Detected	The negative limit input turned ON.	 A negative limit input signal was detected. The negative limit input signal is not connected correctly or the logic setting for the negative limit input is wrong. 			S			page 11-32
64560000 hex	Illegal Fol- lowing Error	The difference between the com- mand position and the actual current position exceeds the range of 30-bit data when con- verted to pulses.	 The command current position was restricted so that the axis velocity of the slave axis would not exceed the axis maximum velocity for the specified travel distance. Performance of slave axis positioning operation is poor and the actual motion is slower than the command. 			S			page 11-33
64570000 hex	Servo OFF Error	The Servo was turned OFF for an axis due to an axes group error.	 The Servo was turned OFF for an axis due to an axes group error. 			S			page 11-33
64580000 hex	Absolute Encoder Cur- rent Position Calculation Failed	It was not possible to correctly restore the current position from the absolute encoder information that was saved when power was interrupted.	 The ring counter setting in the Controller or the ring counter setting in the Servo Drive set- tings was changed. The position to restore when converted to pulses exceeded the range of signed 40-bit data. 			S			page 11-34
64590000 hex	Home Unde- fined during Coordinated Motion	Home of the logical axis became unde- fined during axes group motion or while decelerating to a stop.	 The command position or actual position overflowed or underflowed for a logical axis in an axes group motion or a logi- cal axis that was decelerating to a stop and the home definition was lost. A slave communications error occurred for a logical axis and home became undefined during axes group motion or while decelerating to a stop. A slave for a logical axis left the network or was disabled and home became undefined during axes group motion or while decelerating to a stop. 			S			page 11-35

Eventerit	Eventury	Maaning	Assumed as			Leve	1		Deferrer
Event code	Event name	Meaning	Assumed cause	Maj	Prt	Min	Obs	Info	Reference
74210000 hex	Servo Main Circuit Power OFF	The main circuit power of the Servo Drive turned OFF while the Servo was ON.	 The main circuit power of the Servo Drive was interrupted while the Servo was ON. 			S			page 11-35
74230000 hex	Interrupt Feeding Interrupt Sig- nal Missing	An interrupt input was not received during execution of an MC_MoveFeed (Interrupt Feeding) instruction.	 The latch enabled range specification is invalid. There is a problem with the wiring of the interrupt signal. The sensor that outputs the interrupt signal has failed. 			S			page 11-36
74240000 hex	Homing Opposite Direction Limit Input Detected	The limit signal in the direction oppo- site to the homing direction was detected during a homing operation.	 The Operation Selection at Negative Limit Input or Opera- tion Selection at Positive Limit Input parameter is set to <i>No</i> <i>reverse turn.</i> The location of the homing input signal sensors, homing settings, and homing start posi- tion cause a limit input to be reached. The input signal sensor wiring is incorrect or the sensor is faulty. 			S			page 11-36
74250000 hex	Homing Direction Limit Input Detected	The limit signal in the homing direc- tion was detected during a homing operation.	 The Operation Selection at Negative Limit Input or Opera- tion Selection at Positive Limit Input parameter is set to <i>No</i> <i>reverse turn</i>. The location of the homing input signal sensors, homing settings, and homing start posi- tion cause a limit input to be reached. The input signal sensor wiring is incorrect or the sensor is faulty. 			S			page 11-37
74260000 hex	Homing Limit Inputs Detected in Both Direc- tions	The limit signals in both directions were detected dur- ing a homing opera- tion.	 The wiring of the limit signal is incorrect. The limit sensor is installed in the wrong location. The contact logic of the limit signal is not correct. The limit sensor failed. 			S			page 11-37
74270000 hex	Home Prox- imity/Homing Opposite Direction Limit Input Detected	The home proxim- ity input and the limit signal in the direction opposite to the homing direc- tion were detected during a homing operation.	 The wiring of the home proximity signal or limit signal is incorrect. The home proximity sensor or limit sensor is installed in the wrong location. The contact logic of the home proximity signal or limit signal is not correct. The home proximity sensor or limit sensor failed. 			S			page 11-38

Event e e de	Event name	Meaning	Assumed cause	Level					Defenses
Event code				Maj	Prt	Min	Obs	Info	Reference
74280000 hex	Home Prox- imity/Homing Direction Limit Input Detected	The home proxim- ity input and the limit signal in the homing direction were detected at the same time dur- ing a homing opera- tion.	 The wiring of the home proximity signal or limit signal is incorrect. The home proximity sensor or limit sensor is installed in the wrong location. The contact logic of the home proximity signal or limit signal is not correct. The home proximity sensor or limit sensor failed. 			S			page 11-38
74290000 hex	Home Input/Hom- ing Opposite Direction Limit Input Detected	The home input and the limit signal in the direction oppo- site to the homing direction were detected at the same time during a homing operation.	 The wiring of the home input signal or limit signal is incorrect. The home input sensor or limit sensor is installed in the wrong location. The contact logic of the home input signal or limit signal is not correct. The home input signal output device or limit sensor failed. 			S			page 11-39
742A0000 hex	Home Input/Hom- ing Direction Limit Input Detected	The home input and the limit signal in the homing direc- tion were detected at the same time during a homing operation.	 The wiring of the home input signal or limit signal is incorrect. The home input sensor or limit sensor is installed in the wrong location. The contact logic of the home input signal or limit signal is not correct. The home input signal output device or limit sensor failed. 			S			page 11-39
742B0000 hex	Invalid Home Input Mask Distance	The setting of the home input mask distance is not suit- able for the MC_Home or MC_HomeWithPar ameter instruction.	• The set value of the home input mask distance when the oper- ating mode of the MC_Home instruction is set to <i>Proximity</i> <i>Reverse Turn/Home Input Mask</i> <i>Distance</i> is insufficient to decel- erate from the homing velocity to the homing approach veloc- ity.			S			page 11-40
742C0000 hex	No Home Input	There was no home signal input during the homing opera- tion. Or, a limit sig- nal was detected before there was a home input.	 There was no home signal input during the homing operation. A limit signal was detected before there was a home input. 			S			page 11-40
742D0000 hex	No Home Proximity Input	There was no home proximity signal input during the homing operation.	 There was no home proximity signal input during the homing operation when a home proxim- ity input signal was specified. 			S			page 11-41
742F0000 hex	Slave Error Detected	An error was detected for the EtherCAT slave or NX Unit that is allo- cated to an axis.	• An error was detected for the EtherCAT slave or NX Unit that is allocated to an axis.			S			page 11-41
74300000 hex	Axes Group Composition Axis Error	An error occurred for an axis in an axes group.	 An error occurred for an axis in an axes group that was in motion. 			S			page 11-42
74330000 hex	MC Com- mon Error Occurrence	An MC common error occurred.	Partial fault level MC common error occurred.			S			page 11-42

Eventeede	Event	Meersing	Accument			Leve	I		Deferrer
Event code	Event name	Meaning	Assumed cause	Maj	Prt	Min	Obs	Info	Reference
74340000 hex	Latch Posi- tion Overflow	An overflow occurred for the latched position for the MC_TouchProbe (Enable External Latch) instruction.	• An overflow occurred for the latched position for the MC_TouchProbe (Enable External Latch) instruction.			S			page 11-42
74350000 hex	Latch Posi- tion Under- flow	An underflow occurred for the latched position for the MC_TouchProbe (Enable External Latch) instruction.	• An underflow occurred for the latched position for the MC_TouchProbe (Enable External Latch) instruction.			S			page 11-43
74360000 hex	Master Sync Direction Error	The master axis continued to move in the direction opposite to the sync direction.	 The master axis continued to move in the direction opposite to the sync direction of the mas- ter and slave axes, resulting in an overflow. 			S			page 11-43
74370000 hex	Slave Dis- connection during Servo ON	An EtherCAT slave or NX Unit that is allocated to an axis was disconnected, replaced, or dis- abled while the Servo was ON.	 An EtherCAT slave or NX Unit that is allocated to an axis was disconnected, replaced, or dis- abled while the Servo was ON. 			S			page 11-43
74380000 hex	Feed Dis- tance Over- flow	The target position after the interrupt input was received for the MC_MoveFeed (Interrupt Feeding) instruction over- flowed or under- flowed.	• The target position after the interrupt input was received for the MC_MoveFeed (Interrupt Feeding) instruction exceeded the range of signed 40-bit data when converted to pulses.			S			page 11-44
74390000 hex	Error in Changing Servo Drive Control Mode	Changing the Con- trol Mode was not completed within the specified time.	 When the MC_SyncMoveVelocity instruction was stopped, the actual current velocity was not reduced to 10% or less of the maximum velocity within 10 seconds for three consecutive periods after a command veloc- ity of 0 was output. For an OMRON G5-series Servo Drive, the actual current velocity was not reduced to 10% or less of the maximum velocity within 10 seconds for three consecutive periods when the MC_TorqueControl instruc- tion was stopped. Changing the Control Mode of the Servo Drive between CSP, CSV, and CST was not com- pleted within one second after the command was executed. 			S			page 11-44

Event ende	Europh norma	Maaning	Assumed cause			Leve	I		Reference
Event code	Event name	Meaning		Maj	Prt	Min	Obs	Info	Reference
743A0000 hex	Master Axis Position Read Error	The synchronized control instruction was not executed because an error occurred in the position of the mas- ter axis of the syn- chronized control instruction.	 EtherCAT process data communications are not established for the master axis of the synchronized control instruction or the I/O data of the NX Unit cannot be used for control. The slave of the master axis for the synchronized control instruction was disconnected or disabled. An Absolute Encoder Current Position Calculation Failed error (64580000 hex) was detected for the master axis of the synchronized control instruction. The master axis for the synchronized control instruction. 			S			page 11-45
743B0000 hex	Auxiliary Axis Position Read Error	The synchronized control instruction was not executed because an error occurred in the position of the auxil- iary axis of the syn- chronized control instruction.	 EtherCAT process data communications are not established for the auxiliary axis of the synchronized control instruction or the I/O data of the NX Unit cannot be used for control. The slave of the auxiliary axis for the synchronized control instruction was disconnected or disabled. An Absolute Encoder Current Position Calculation Failed error (64580000 hex) was detected for the auxiliary axis of the synchronized control instruction. The auxiliary axis for the synchronized control instruction. 			S			page 11-46
84400000 hex	EtherCAT Slave Com- munications Error	A communications error occurred for the EtherCAT slave or NX Unit that is allocated to an axis.	 A communications error occurred for the EtherCAT slave or NX Unit that is allo- cated to an axis. 			S			page 11-47
571D0000 hex (Ver. 1.02 to Ver. 1.09)	Too Many Reset Motion Control Error Instructions	There are more than 100 instances of the ResetMCEr- ror (Reset Motion Control Error) instruction.	There are more than 100 instances of the ResetMCError (Reset Motion Control Error) instruction declared in the user program. Instances inside func- tion blocks are included.				S		page 11-47
644C0000 hex	Following Error Warn- ing	The following error exceeded the Fol- lowing Error Warn- ing Value.	 Performance of positioning operation is poor and the actual motion is slower than the com- mand. 				S		page 11-48
644D0000 hex	Velocity Warning	The command velocity exceeded the velocity warn- ing value.	The command velocity exceeded the velocity warning value.			U	S		page 11-48
644E0000 hex	Acceleration Warning	The command acceleration exceeded the acceleration warn- ing value.	The command acceleration rate exceeded the acceleration warning value.			U	S		page 11-49

Event code	Event name	Meaning	Assumed cause		Level				Reference
			Assumed cause	Maj	Prt	Min	Obs	Info	neierence
644F0000 hex	Deceleration Warning	The command deceleration exceeded the deceleration warn- ing value.	The command deceleration rate exceeded the deceleration warning value.			U	S		page 11-49
64500000 hex	Positive Torque Warning	The torque com- mand value exceeded the posi- tive torque warning value.	The torque command value exceeded the positive torque warning value.			U	S		page 11-50
64510000 hex	Negative Torque Warning	The torque com- mand value exceeded the nega- tive torque warning value.	 The torque command value exceeded the negative torque warning value. 			U	S		page 11-50
64520000 hex	Command Position Overflow	The number of pulses for the com- mand position over- flowed.	 In Linear Mode, the command position when converted to pulses exceeded the upper limit of signed 40-bit data. 			U	S		page 11-51
64530000 hex	Command Position Underflow	The number of pulses for the com- mand position exceeded the valid range. (It under- flowed.)	 In Linear Mode, the command position when converted to pulses exceeded the lower limit of signed 40-bit data. 			U	S		page 11-51
64540000 hex	Actual Posi- tion Overflow	The number of pulses for the actual position overflowed.	• The actual position when con- verted to pulses exceeded the upper limit of signed 40-bit data.			U	S		page 11-52
64550000 hex	Actual Posi- tion Under- flow	The number of pulses for the actual position underflowed.	The actual position when con- verted to pulses exceeded the lower limit of signed 40-bit data.			U	S		page 11-52
74320000 hex	Slave Obser- vation Detected	A warning was detected for an EtherCAT slave or NX Unit.	• A warning was detected for the EtherCAT slave or NX Unit that is allocated to an axis.			U	S		page 11-53
743C 0000 hex	Cannot Exe- cute Save Cam Table Instruction	You cannot save a cam table to a file when non-volatile memory is being accessed by another operation.	 An attempt was made to exe- cute the MC_SaveCamTable instruction when another opera- tion was accessing the non-vol- atile memory (e.g., transfer or data trace operation from the Sysmac Studio). 				S		page 11-53
94200000 hex	Notice of Insufficient Travel Dis- tance to Achieve Blending Transit Velocity	There is not suffi- cient travel distance to accelerate or decelerate to the transit velocity dur- ing blending opera- tion.	 When the Acceleration/Deceleration Over parameter was set to Use rapid acceleration/deceleration (Blending is changed to Buffered), the results of profile creation caused the acceleration/deceleration/deceleration rate to be exceeded when blending was specified, so buffered was used. Blending was specified, but the target position was already reached, so it was changed to Buffered because the profile could not be created. 			U	S		page 11-54
94210000 hex	Error Clear from MC Test Run Tab Page	An error was cleared from the MC Test Run Pane of the Sysmac Stu- dio.	 An error was cleared from the MC Test Run Pane of the Sys- mac Studio. 					S	page 11-54

Event code	Event name	Meaning	Assumed cause		·	Reference			
					Prt	Min	Obs	Info	nelelelice
94220000 hex	Slave Error Code Report	The error code was reported by the slave when a Slave Error Detected error occurred.	The error code was reported by the slave when a Slave Error Detected error (742F0000 hex) occurred.					S	page 11-55

11-2-2 Error Descriptions

This section describes the information that is given for individual errors.

Controller Error Descriptions

The items that are used to describe individual errors (events) are described in the following copy of an error table.

Event name	Gives the name of the error.			Event code	Gives the code of the error.					
Meaning	Gives a short description of the error.									
Source	Gives the source	of the error.	Source details	Gives details on the source of the error.	Detection timing	Tells when the error is detected.				
Error attributes	Level	Tells the level of influence on con-trol.*1	Recovery	Gives the recovery method.*2	Log category	Tells which log the error is saved in.* ³				
Effects	User program	Tells what will hap- pen to execution of the user pro- gram.*4	Operation	Provides special ir from the error.	formation on the operation that results					
Indicators	Gives the status of the built-in EtherNet/IP port and built-in EtherCAT port indicators. Indicator status is given only for errors in the EtherCAT Master Function Module and the EtherNet/IP Function Module.									
System-defined variables	Variable		Data type		Name					
	Lists the variable names, data types, and meanings for system-defined variables that provide direct error notification, that are directly affected by the error, or that contain settings that cause the error.									
Cause and cor- rection	Assumed cause		Correction		Prevention					
	Lists the possible causes, corrections, and preventive measures for the error.									
Attached information	This is the attached information that is displayed by the Sysmac Studio or an HMI.*5									
Precautions/ Remarks	Provides precautions, restrictions, and supplemental information. If the user can set the event level, the event levels that can be set, the recovery method, operational information, and other information is also provided.									

*1 One of the following:

Major fault: Major fault level Partial fault: Partial fault level Minor fault: Minor fault level Observation Information

*2 One of the following:

Automatic recovery: Normal status is restored automatically when the cause of the error is removed. Error reset: Normal status is restored when the error is reset after the cause of the error is removed. Cycle the power supply: Normal status is restored when the power supply to the Controller is turned OFF and then back ON after the cause of the error is removed. Controller reset: Normal status is restored when the Controller is reset after the cause of the error is removed. Depends on cause: The recovery method depends on the cause of the error.

- *3 One of the following: System: System event log Access: Access event log
- *4 One of the following: Continues: Execution of the user program will continue. Stops: Execution of the user program stops. Starts: Execution of the user program starts.
- *5 Refer to the appendices of the *NJ/NX-series Troubleshooting Manual* (Cat. No. W503) for the applicable range of the HMI Troubleshooter.

Version Information

With NX-series CPU Units, a variable name that starts with _MC_AX[*] may start with _MC1_AX[*] or _MC2_AX[*] instead.

Error Descriptions

Event name	Motion Control Function Processing Error			Event code	44210000 hex			
Meaning	A fatal error was d	etected in the Motion	n Control Function N	lodule.	•			
Source	PLC Function Module		Source details	MC Common	Detection timing	Continuously		
Error attributes	Level	Major fault	Recovery	Cycle the power supply.	Log category	System		
Effects	User program	Stops.	Operation	Operation It will not be possible to perform axis control. The ler will stop.		ontrol. The Control-		
System-defined	Variable		Data type		Name			
variables	None							
Cause and	Assumed cause		Correction		Prevention			
correction	An error occurred	in the software.	Contact your OMRON representative.		None			
Attached	Attached informati	on 1: System inform	ation					
information	Attached informati	on 2: System inform	ation					
	Attached informati	on 3: System inform	ation					
	Attached informati	Attached information 4: System information						
Precautions/ Remarks	None							

Event name	Absolute Encoder	Home Offset Read E	Error	Event code	14600000 hex	
Meaning	The absolute enco	der current position	that is retained durir	ng power interruption	is was lost.	
Source	Motion Control Fur			Detection timing	At power ON, at Controller reset, or when down- loading	
Error attributes	Level	Partial fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	It will not be possib	ole to perform axis c	ontrol.
System-defined	Variable		Data type		Name	
variables	_MC_COM.PFaultLvl.Active		BOOL		MC Common Partial Fault Occur- rence	
Cause and	Assumed cause		Correction		Prevention	
correction	The life of the Battery in the CPU Unit has expired.		Replace the Battery in the CPU Unit, reset the error, and perform homing to define home.		Periodically replace the Battery in the CPU Unit. For the Battery life, refer to the <i>NX-series CPU Unit Hardware</i> <i>User's Manual</i> (Cat. No. W535) or the <i>NJ-series CPU Unit Hardware User's</i> <i>Manual</i> (Cat. No. W500)	
	Backup memory failure		If the error occurs even after the above correction is performed, CPU backup memory has failed. Replace the CPU Unit and perform homing to define home.		None	
Attached information	None		•		•	
Precautions/ Remarks	None					

Event name	Motion Control Pa	rameter Setting Erro	r	Event code	14610000 hex		
Meaning	The MC parameter	ers that were saved ir	n non-volatile mem	ory are missing.			
Source	Motion Control Function Module		Source details	MC common	Detection timing	At power ON, at Controller reset, or when down- loading	
Error attributes	Level	Partial fault	Recovery	Cycle the power supply or reset the Controller.	Log category	System	
Effects	User program	Continues.	Operation	It will not be possi	ble to perform axis	control.	
System-defined	Variable		Data type		Name		
variables	_MC_COM.PFaultLvI.Active		BOOL		MC Common Partial Fault Occur- rence		
Cause and	Assumed cause		Correction		Prevention		
correction	was interrupted of with the Sysmac S nected while down	The power supply to the Controller was interrupted or communications with the Sysmac Studio were discon- nected while downloading the motion control parameter settings or clearing memory		Download the MC parameters from the Sysmac Studio.		Do not turn OFF the power supply during save processing for the param- eters.	
	Non-volatile memory failure		If the error occurs even after the above correction is performed, non- volatile memory has failed. After you replace the CPU Unit, download all settings including the Axis Settings from the Sysmac Studio.		None		
Attached information	None				•		
Precautions/ Remarks	None						

Event name	Cam Data Read E	Error		Event code	14620000 hex		
Meaning	The cam data tha	t was saved in non-	olatile memory is missing.				
Source	Motion Control Function Module		Source details	MC Common	Detection timing	At power ON, at Controller reset, or when down- loading	
Error attributes	Level	Partial fault	Recovery	Cycle the power supply or reset the Controller.	Log category	System	
Effects	User program	Continues.	Operation	It will not be possib	ole to perform axis	control.	
System-defined	Variable		Data type		Name		
variables	_MC_COM.PFaultLvl.Active		BOOL	BOOL		MC Common Partial Fault Occur- rence	
Cause and	Assumed cause		Correction	Correction			
correction	Power was interrupted during save processing for cam data		Download the ca mac Studio.	Download the cam data from the Sysmac Studio.		Do not turn OFF the power supply during save processing for the cam data.	
	Non-volatile memory failure		above correction volatile memory f replace the CPU settings including	If the error occurs even after the above correction is performed, non- volatile memory has failed. After you replace the CPU Unit, download all settings including the Axis Settings from the Sysmac Studio.			
Attached information	None		-				
Precautions/ Remarks	None						

Event name	Required Process	Data Object Not Set	t	Event code	34600000 hex	
Meaning	The object that is r	equired for the axis	type is not allocated	to PDO.	-	
Source	Motion Control Function Module		Source details	MC Common	Detection timing	At power ON, at Controller reset, or when down- loading
Error attributes	Level	Partial fault	Recovery	Cycle the power supply or reset the Controller.	Log category	System
Effects	User program	Continues.	Operation	It will not be possil	ole to perform axis o	control.
System-defined	Variable		Data type	Data type		
variables	_MC_COM.PFaultLvl.Active		BOOL		MC Common Partial Fault Occur- rence	
Cause and	Assumed cause		Correction	Correction		
correction	The required PDOs are not mapped when the axis type is set to a servo axis or encoder axis.		the relevant axis ty	Map the PDOs that are required for the relevant axis type. Refer to <i>A-1-2</i> <i>Servo Drive Settings</i> for the required PDOs.		at are required for t are used. Refer to e <i>Settings</i> for the
	Non-volatile memory failure		If the error occurs even after the above correction is performed, non- volatile memory has failed. After you replace the CPU Unit, download all settings including the Axis Parameter Settings from the Sysmac Studio.		None	
Attached information	None					
Precautions/ Remarks	None					

Event name	Axis Slave Disabl	ed		Event code	34630000 hex			
Meaning	The slave to whic	h the axis is assigi	ned is disabled.		·			
Source	Motion Control Function Module		Source details	MC Common	Detection timing	At power ON, at Controller reset, or when down- loading		
Error attributes	Level	Partial fault	Recovery	Cycle the power supply or reset the Controller.	Log category	System		
Effects	User program	Continues.	Operation	It will not be possi	It will not be possible to perform axis control.			
System-defined	Variable		Data type	Data type		Name		
variables	_MC_COM.PFaultLvI.Active		BOOL	BOOL		MC Common Partial Fault Occur- rence		
Cause and	Assumed cause		Correction	Correction		Prevention		
correction	The slave to which the axis is assigned is disabled.		assigned in the E	Enable the slave to which the axis is assigned in the EtherCAT settings. If there is no slave, set the axis type to a virtual axis.		Enable the slaves to which axes are assigned in the EtherCAT settings. If there are no slaves, set the axis type to a virtual axis when using an axis in the program.		
Attached information	None		·					
Precautions/ Remarks	None							

Event name	Network Configura	tion Information Mis	sing for Axis Slave	Event code	34640000 hex	
Meaning	The network config	guration information	is not registered for	the slave to which th	e axis is assigned.	
Source	Motion Control Function Module		Source details	MC Common	Detection timing	At power ON, at Controller reset, when download- ing, when starting Servo ON status, or when changing an unused axis to a used axis
Error attributes	Level	Partial fault	Recovery	Cycle the power supply or reset the Controller.	Log category	System
Effects	User program	Continues.	Operation	It will not be possib	ole to perform axis c	ontrol.
System-defined	Variable	Variable		Data type		
variables	_MC_COM.PFault	Lvl.Active	BOOL		MC Common Partial Fault Occur- rence	
Cause and	Assumed cause		Correction		Prevention	
correction	The EtherCAT network configuration information is not registered for the slave to which the axis is assigned.		Register the EtherCAT network con- figuration information for the slave to which the axis is assigned. Or, set the axis type to a virtual axis.		Register the network configuration information for the slaves to which axes are assigned.	
Attached information	None					
Precautions/ Remarks	None					

Event name	Motion Control In	Motion Control Initialization Error			44200000 hex			
Meaning	A fatal error occu	A fatal error occurred in the system and prevented initialization of the Motion Control Function Module.						
Source	Motion Control Function Module		Source details	MC Common	Detection timing	At power ON, at Controller reset, or when down- loading		
Error attributes	Level	Partial fault	Recovery	Cycle the power supply.	Log category	System		
Effects	User program	Continues.	Operation		tot be possible to perform axis control. It will not be le to execute motion control instructions.			
System-defined	Variable		Data type	Data type				
variables	_MC_COM.PFau	tLvl.Active	BOOL	BOOL		MC Common Partial Fault Occur- rence		
Cause and	Assumed cause		Correction	Correction		Prevention		
correction	Hardware has fail	ed.	Replace the CPU	Replace the CPU Unit.		None		
Attached information	Attached informat	Attached information 1: Controller information						
Precautions/ Remarks	None	None						

Event name	Motion Control Pe	riod Exceeded		Event code	74200000 hex			
Meaning	Processing for the	Processing for the primary periodic task was not finished within two control periods.						
Source	Motion Control Function Module		Source details	MC Common	Detection timing	Continuously		
Error attributes	Level	Partial fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation Operation is not possible for all axes. Axes in m immediately.			Axes in motion stop		
System-defined	Variable	Variable			Name			
variables	_MC_COM.PFaultLvl.Active		BOOL		MC Common Partial Fault Occur- rence			
Cause and	Assumed cause		Correction	Correction				
correction	The processing load in the primary periodic task is too heavy.		the primary period control period to a enough not to cau lems. Check the t	Reduce the amount of processing in the primary periodic task or set the control period to a value that is long enough not to cause operation prob- lems. Check the task period in the Task Period Monitor of the Sysmac Studio.		Write the programs for the primary periodic task so that they perform only the processes required in the speci- fied period. Or, set the period of the primary periodic task to be long enough to complete all required pro- cessing.		
Attached information	None							
Precautions/ Remarks	None	None						

Event name	Cam Table Save Error			Event code	14630000 hex			
Meaning	Saving a cam tat	Saving a cam table to a file failed.						
Source	Motion Control Function Module		Source details	MC Common	Detection timing	During instruc- tion execution		
Error attributes	Level	Minor fault	Recovery	Error reset or cycling power supply	Log category	System		
Effects	User program	Continues.	Operation		is error may occur when you read a cam table because e cam data in non-volatile memory may be corrupted.			
System-defined	Variable		Data type	Data type				
variables	_MC_COM.MFat	_MC_COM.MFaultLvl.Active		BOOL		MC Common Minor Fault Occurrence		
Cause and	Assumed cause		Correction	Correction		Prevention		
correction	Saving a cam table to a file failed.		occurs, non-vola	Save the file again. If the problem still occurs, non-volatile memory has failed. Replace the CPU Unit.		None		
Attached information	None							
Precautions/ Remarks	None							

11-2 Troubleshooting

11

11-2-2 Error Descriptions

Event name	Cam Table Data E	Error during Cam Mot	tion	Event code	54770000 hex	
Meaning	The phases are n	ot in ascending order	in the cam table.			
Source	Motion Control Fu	nction Module	Source details	Source details Axis I		During instruc- tion execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation Operation is not possible for relevant axes. Redecelerates to a stop if it is in motion.		ixes. Relevant axis	
System-defined variables	Variable		Data type		Name	
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault C	Axis Minor Fault Occurrence
Cause and correction	Assumed cause		Correction		Prevention	
	Data containing cam table phases that are not in ascending order was detected during cam motion.		Correct the cam table data so that the phases are in ascending order.		Place the phase data into ascending order in the cam table data.	
	The phase and displacement of the start point in the cam table were not 0 during cam operation.		Correct the cam table data so that the phase and displacement of the start point are 0.		Set the cam table data so that the phase and displacement of the start point are 0.	
	The phase of the end point in the cam table when converted to pulses was not 1 pulse or greater during cam operation.		Correct the cam table data so that the phase of the end point is 1 pulse or greater when converted to pulses.		Set the cam table data so that the phase of the end point is 1 pulse or greater when converted to pulses.	
Attached information	None					
Precautions/ Remarks	None					

Event name	Immediate Stop In	struction Executed		Event code	54850000 hex				
Meaning	An Immediate Sto	An Immediate Stop (MC_ImmediateStop) instruction was executed.							
Source	Motion Control Function Module		Source details	Axis	Detection timing	At instruction execution			
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System			
Effects	User program	Continues.	Operation	Mode that is set in MC_ImmediateSto axes group in moti	mediate stop is performed according to the Stop that is set in the <i>StopMode</i> input variable to the mmediateStop instruction. If the axis is part of an group in motion, all other axes will act according to xes Group Stop Mode Selection.				
System-defined	Variable		Data type		Name				
variables	_MC_AX[*].MFaul	tLvI.Active	BOOL		Axis Minor Fault Occurrence				
Cause and	Assumed cause		Correction		Prevention				
correction	An Immediate Stop instruction was executed.								
Attached information	None								
Precautions/ Remarks	None								

Event name	Axes Group Imme	diate Stop Instruction	n Executed	Event code	54860000 hex		
Meaning	An Axes Group Im	An Axes Group Immediate Stop (MC_GroupImmediateStop) instruction was executed.					
Source	Motion Control Function Module		Source details	Axes group	Detection timing	At instruction execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	An immediate stop is performed for all axes in the axe group according to the Immediate Stop Input Stop Met axis parameter.			
System-defined	Variable		Data type		Name	Name	
variables	_MC_GRP[*].MFaultLvl.Active		BOOL		Axes Group Minor Fault Occurrence		
Cause and	Assumed cause		Correction		Prevention		
correction	A Group Immediate Stop instruction was executed.						
Attached information	None	None					
Precautions/ Remarks	None	None					

Event name	Positive Software Limit Exceeded			Event code	64450000 hex		
Meaning	The position exce	eded the positive so	ftware limit while the	axis is in motion.	-		
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruc- tion execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	Operation Follows the setting of the Software Limit Function tion.		it Function Selec-	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence		
Cause and	Assumed cause	Assumed cause		Correction			
correction	The position exceeded the positive software limit.			Find the reason that the software limit was exceeded and make suitable corrections.		(The goal is to enable detecting the software limits when they are exceeded due to unanticipated causes. Preventative measures are not required.)	
Attached information	None	None					
Precautions/ Remarks	Whenever you cha	ange the positive so	ftware limit setting, r	nake sure that the ne	w setting is safe.		

Event name	Negative Software Limit Exceeded			Event code	64460000 hex		
Meaning	The position excee	eded the negative se	oftware limit while th	e axis is in motion.			
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruc- tion execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation Follows the setting of the Software Limit Functi tion.		nit Function Selec-		
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaultLvl.Active		BOOL	BOOL		Dccurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	The position exceeded the negative software limit.			Find the reason that the software limit was exceeded and make suitable corrections.		(
Attached information	None	None					
Precautions/ Remarks	Whenever you cha	ange negative softw	are limit settings, ma	ake sure that the new	setting is safe.		

Event name	In-position Check Time Exceeded			Event code	64470000 hex	
Meaning	The in-position cl	neck was not complet	ed within the monito	oring time.	•	
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruc- tion execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation Operation is not possible for relevant ax decelerates to a stop if it is in motion.		axis. Relevant axis	
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFaultLvI.Active		BOOL		Axis Minor Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention	
correction	Time is required to complete position- ing.		tioning and remover error. Or, adjust the adjust the In-positi In-position Range. gain if you adjust the However, make su the loop gain low of	etermine the cause of the slow posi- ning and remove the cause of the ror. Or, adjust the Servo Drive or just the In-position Check Time or position Range. Increase the loop in if you adjust the Servo Drive. wever, make sure that you keep e loop gain low enough so that the ntrol does not oscillate.		
Attached information	None					
Precautions/ Remarks	None					

Event name	Following Error Lir	nit Exceeded		Event code	64480000 hex			
Meaning	The error between Value.	The error between the command current position and actual current value exceeded the Following Error Over Limit Value.						
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruc- tion execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation Operation is not po decelerates to a sto			ssible for relevant axis. Relevant axis op if it is in motion.		
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence			
Cause and	Assumed cause	Assumed cause		Correction				
correction	The positioning operation has poor following performance and the actual motion is slower than the command.		Remove the cause of poor following performance in the positioning opera- tion. Or increase the Following Error Over Limit Value within the range that will not create problems.		Remove the cause of poor following performance in the positioning opera- tion as best you can.			
Attached information	None	None						
Precautions/ Remarks	None							

Event name	Immediate Stop Ir	iput		Event code	64490000 hex	
Meaning	The immediate sto	op input turned ON.				
Source	Motion Control Function Module		Source details	Axis	Detection timing	Continuously
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	According to the Ir	nmediate Stop Input	Stop Method.
System-defined	Variable		Data type	•	Name	
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault O	ccurrence
Cause and	Assumed cause		Correction		Prevention	
correction	An immediate stop input signal was detected.		Turn OFF the immediate stop input signal.		(The goal is to detect the immediate stop input. Preventative measures are not required.)	
	The immediate stop input signal is not connected correctly or the logic set- ting for the immediate stop input is wrong.		If the error occurs even when the immediate stop input signal is OFF, correct the immediate stop signal connection and logic setting for the immediate stop input. Check the logic settings both in the axis parameters and in the slave settings.		Make sure that the immediate stop signal connection and logic setting for the immediate stop input are correct. Check the logic settings both in the axis parameters and in the slave set- tings.	
Attached information	None					
Precautions/ Remarks	You must turn OF	F the immediate stop	input signal before	you reset the error.		

11-2-2 Error Descriptions

Event name	Positive Limit Inpu	t Detected		Event code	644A0000 hex		
Meaning	The positive limit in	nput turned ON.					
Source	Motion Control Fu	nction Module			Detection timing	Continuously	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	According to the L	imit Input Stop Meth	iod.	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaultLvI.Active		BOOL		Axis Minor Fault C	Occurrence	
Cause and correction	Assumed cause		Correction		Prevention		
	A positive limit input signal was detected.		back in the negati exceeds the limit tion. If the error o axes group motio tion, disable the a perform the above reason the limit w	Reset the error and move the axis back in the negative direction before it exceeds the limit in the positive direc- tion. If the error occurred during an axes group motion control instruc- tion, disable the axes group and then perform the above operation. Find the reason the limit was exceeded and make suitable corrections.		The goal is to detect the positive limit input. Preventative measures are not required. However, be sure not to exceed the positive limit input when making programs.	
	The positive limit input signal is not connected correctly or the logic set- ting for the positive limit input is wrong.		If a positive limit input signal does not occur, correct the connection of the positive limit signal and the logic set- ting for the positive limit input. Check the logic settings both in the axis parameters and in the slave settings.		Make sure that the positive limit signal connection and logic setting for the positive limit input are correct. Check the logic settings both in the axis parameters and in the slave settings.		
Attached information	None						
Precautions/ Remarks	None						

Event name	Negative Limit Inp	ut Detected		Event code	644B0000 hex		
Meaning	The negative limit	input turned ON.					
Source	Motion Control Function Module		Source details	Source details Axis		Continuously	
Error attributes	Level	Minor fault	Recovery	Recovery Error reset		System	
Effects	User program	Continues.	Operation	According to the L	imit Input Stop Meth	od.	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaultLvI.Active		BOOL		Axis Minor Fault C	Occurrence	
Cause and correction	Assumed cause		Correction		Prevention		
	A negative limit in detected.	A negative limit input signal was detected.		Reset the error and move the axis back in the positive direction before it exceeds the limit in the negative direction. If the error occurred during an axes group motion control instruc- tion, disable the axes group and then perform the above operation. Find the reason the limit was exceeded and make suitable corrections.		The goal is to detect the negative limit input. Preventative measures are not required. However, be sure not to exceed the negative limit input when making programs.	
	The negative limit input signal is not connected correctly or the logic set- ting for the negative limit input is wrong.		If a negative limit input signal does not occur, correct the connection of the negative limit signal and the logic setting for the negative limit input. Check the logic settings both in the axis parameters and in the slave set- tings.		Make sure that the negative limit sig- nal connection and logic setting for the negative limit input are correct. Check the logic settings both in the axis parameters and in the slave set- tings.		
Attached information	None						
Precautions/ Remarks	None						

Event name	Illegal Following Error			Event code	64560000 hex			
Meaning		The difference between the command position and the actual current position exceeds the range of 30-bit data when converted to pulses.						
Source	Motion Control Function Module		Source details	Axis	Detection timing	Continuously		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation	The Servo for the	axis turns OFF.			
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence			
Cause and	Assumed cause		Correction		Prevention			
correction	restricted so that the the slave axis woul axis maximum velo	The command current position was restricted so that the axis velocity of the slave axis would not exceed the axis maximum velocity for the speci- fied travel distance.		Correct the program or correct the electronic gear ratio so that the slave axis does not exceed the maximum velocity.		Write the program or set the elec- tronic gear ratio so that the slave axis does not exceed the maximum veloc- ity.		
	Performance of slave axis positioning operation is poor and the actual motion is slower than the command.		Remove the cause of poor slave axis following performance in the position-ing operation.		Remove the cause of poor slave axis following performance in the position- ing operation as best you can.			
Attached information	None							
Precautions/ Remarks	None							

Event name	Servo OFF Error	Servo OFF Error			64570000 hex		
Meaning	The Servo was tur	ned OFF for an axi	is due to an axes gro	oup error.			
Source	Motion Control Function Module Se		Source details	Axis	Detection timing	Continuously	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	Operation The Servo for the axis turns OFF.		•	
System-defined variables	Variable		Data type		Name		
	_MC_AX[*].MFaultLvI.Active		BOOL	BOOL		Occurrence	
Cause and	Assumed cause		Correction	Correction			
correction	The Servo was turned OFF for an axis due to an axes group error.			Find the cause of the error and take suitable measures.		None	
Attached information	None		·		·		
Precautions/ Remarks	Servos cannot be	This error occurs for axes for which the Servos are turned OFF for an axes group error to interlock the axes so that the Servos cannot be turned ON with the MC_Power (Power Servo) instruction. This error occurs only when an immediate stop of the command value and turning OFF Servo at same time (free-run stop) is specified for the Axes Group Stop Method Selection					

11-2 Troubleshooting

Event name	Absolute Encoder	Current Position Ca	Iculation Failed	Event code	64580000 hex	
Meaning	It was not possible power was interrup		the current position 1	from the absolute en	coder information th	nat was saved when
Source	Motion Control Function Module		Source details	Axis	Detection timing	At power ON, at Controller reset, when download- ing, when starting Servo ON status, or when changing an unused axis to a used axis
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	Operation is not pe	ossible for relevant	axes.
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFault	Lvl.Active	BOOL		Axis Minor Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention	
correction	 The ring counter setting in the Controller or the ring counter setting in the Servo Drive settings was changed. The position to restore when converted to pulses exceeded the range of signed 40-bit data. 		Perform homing new where the absolute so that the position	rform homing near the position ere the absolute encoder is set up that the position to restore does t exceed the range of signed 40-bit ta.		lo maximum posi- Perform homing where the absolute so that the position of exceed the range
Attached information	None					
Precautions/ Remarks	None					

Event name	Home Undefined d	luring Coordinated N	lotion	Event code	64590000 hex	
Meaning	Home of the logica	I axis became unde	fined during axes gro	oup motion or while	decelerating to a sto	ıp.
Source	Motion Control Fur	nction Module	Source details	Axes group	Detection timing	During instruc- tion execution
Error attributes	Level	Minor fault	Recovery Error reset I		Log category	System
Effects	User program	Continues.	Operation	The axes group de	celerates to a stop.	
System-defined	Variable		Data type		Name	
variables	_MC_GRP[*].MFai	ultLvI.Active	BOOL		Axes Group Minor	Fault Occurrence
Cause and correction	Assumed cause		Correction		Prevention	
	tion overflowed or logical axis in an a or a logical axis tha	The command position or actual posi- tion overflowed or underflowed for a logical axis in an axes group motion or a logical axis that was decelerating to a stop and the home definition was lost.		Correct the program so that the axis operates within ranges that do not cause overflows or underflows in the command position or actual position.		Write the program so that the axis operates within ranges that do not cause overflows or underflows in the command position or actual position.
	A slave communications error occurred for a logical axis and home became undefined during axes group motion or while decelerating to a stop.		Correct the slave communications error and define home.		None	
	A slave for a logical axis left the net- work or was disabled and home became undefined during axes group motion or while decelerating to a stop.		Connect the disconnected or disabled Slave to the network again and define home.		Do not disconnect or disable the slave of a logical axis during axes group motion or while decelerating to a stop.	
Attached information	None					
Precautions/ Remarks	None					

Event name	Servo Main Circui	t Power OFF		Event code	74210000 hex			
Meaning	The main circuit p	The main circuit power of the Servo Drive turned OFF while the Servo was ON.						
Source	Motion Control Function Module		Source details	Axis	Detection timing	Whenever Servo is ON		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation	The Servo for the	Servo for the axis turns OFF.			
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFaultLvI.Active		BOOL		Axis Minor Fault Occurrence			
Cause and	Assumed cause		Correction		Prevention			
correction	The main circuit power of the Servo Drive was interrupted while the Servo was ON.		Turn ON the main circuit power of the Servo Drive for the axis where the error occurred, reset the error, and then turn ON the Servo.		Turn OFF the Servo, then turn OFF the main circuit power of the Servo Drive.			
Attached information	None							
Precautions/ Remarks	None							

Event name	Interrupt Feeding	Interrupt Signal Miss	ing	Event code	74230000 hex	
Meaning	An interrupt input	was not received dur	ing execution of an	MC_MoveFeed (Inte	errupt Feeding) instr	uction.
Source	Motion Control Fu	nction Module	Module Source details Axis		Detection timing	During instruc- tion execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The axis decelerat	tes to a stop.	•
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault C	Occurrence
Cause and	Assumed cause		Correction		Prevention	
correction	The latch enabled range specification is invalid.		If an invalid latch enabled range is specified to the instruction, correct it.		Specify a correct latch enabled range based on the relationship between the motion and sensor position.	
	There is a problem with the wiring of the interrupt signal.		Correct any problems with the wiring for the interrupt signal for the instruction.		Make sure that the wiring of the inter- rupt signal is correct.	
	The sensor that outputs the interrupt signal has failed.		If neither of the two causes listed above are applicable, the sensor that outputs the interrupt signal has failed. Replace the sensor that outputs the interrupt signal for the instruction where this error occurred.		None	
Attached information	None		1		1	
Precautions/ Remarks	None					

Event name	Homing Opposite Direction Limit Input Detected Event code				74240000 hex		
Meaning	The limit signal ir	the direction opposit	te to the homing dir	ection was detected c	luring a homing ope	eration.	
Source	Motion Control Function Module Sour		Source details	Axis	Detection timing	During instruc- tion execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	The axis stops with cution status.	the stop method for the homing exe		
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaultLvI.Active		BOOL		Axis Minor Fault	Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	The Operation Selection at Negative Limit Input or Operation Selection at Positive Limit Input parameter is set to <i>No reverse turn</i> .		set the Operation tive Limit Input a	To prevent errors at the limit inputs, set the Operation Selection at Nega- tive Limit Input and Operation Selec- tion at Positive Limit Input parameters to <i>Reverse turn</i> .		Check to see if any of the conditions that are given as causes exist in advance.	
	The location of the homing input sig- nal sensors, homing settings, and homing start position cause a limit input to be reached.		sensors, homing	Correct the location of the input signal sensors, homing settings, and hom- ing start position so that a limit input is not reached.			
	The input signal sensor wiring is incorrect or the sensor is faulty.			Correct the wiring of the input signal sensor or replace the sensor.			
Attached information	None						
Precautions/ Remarks	None						

Event name	Homing Direction Limit Input Detected			Event code	Event code 74250000 hex	
Meaning	The limit signal in	the homing direction	was detected duri	ng a homing operatior	1.	
Source	Motion Control Fu	nction Module	Source details	Source details Axis I t		During instruc- tion execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The axis stops with cution status.	n the stop method fo	or the homing exe-
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault C	Occurrence
Cause and correction	Assumed cause		Correction		Prevention	
	Limit Input or Ope Positive Limit Inpu	The Operation Selection at Negative Limit Input or Operation Selection at Positive Limit Input parameter is set to <i>No reverse turn</i> .		To prevent errors at the limit inputs, set the Operation Selection at Nega- tive Limit Input and Operation Selec- tion at Positive Limit Input parameters to <i>Reverse turn</i> .		Check to see if any of the conditions that are given as causes exist in advance.
	The location of the homing input sig- nal sensors, homing settings, and homing start position cause a limit input to be reached.		Correct the location of the input signal sensors, homing settings, and hom- ing start position so that a limit input is not reached.			
	The input signal sensor wiring is incorrect or the sensor is faulty.			Correct the wiring of the input signal sensor or replace the sensor.		
Attached information	None					
Precautions/ Remarks	None					

Event name	Homing Limit Inpu	its Detected in Both I	Directions	Event code	74260000 hex	
Meaning	The limit signals in	n both directions wer	e detected during a	homing operation.	- -	
Source	Motion Control Fu	nction Module	Source details	Axis	Detection timing	During instruc- tion execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation The axis stops with the stop method for the ho cution status.		r the homing exe-	
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence	
Cause and	Assumed cause		Correction		Prevention	
correction	The wiring of the limit signal is incor- rect.		Correct the wiring of the limit signal.		Check to see if any of the conditions that are given as causes exist in advance.	
	The limit sensor is installed in the wrong location.		Correct the installation locations of the limit sensors so that they do not turn ON at the same time.			
	The contact logic not correct.	of the limit signal is	Correct the contact logic (N.C./N.O.) of the limit signal.		1	
	The limit sensor fa	The limit sensor failed.		Replace the limit sensor.		
Attached information	None					
Precautions/ Remarks	None					

Event name	Home Proximity/H Detected	loming Opposite Dire	ction Limit Input	Event code	74270000 hex		
Meaning	The home proximity input and the limit signal in the direction opposite to the homing direction were detected during homing operation.						
Source	Motion Control Fu	Inction Module			Detection timing	During instruc- tion execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	The axis stops wit cution status.	h the stop method f	or the homing exe-	
System-defined	efined Variable		Data type		Name		
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence		
Cause and	Assumed cause		Correction		Prevention		
correction	The wiring of the home proximity sig- nal or limit signal is incorrect.		Correct the wiring of the home prox- imity signal or limit signal.		Check to see if any of the conditions that are given as causes exist in		
	The home proximity sensor or limit sensor is installed in the wrong location.		home proximity s	Correct the installation location of the home proximity sensor or limit sensor so that they do not turn ON at the same time.		advance.	
	The contact logic of the home proxim- ity signal or limit signal is not correct.		Correct the contact logic (N.C./N.O.) of the home proximity sensor or limit sensor.				
	The home proximity sensor or limit sensor failed.		Replace the home proximity sensor or limit sensor.				
Attached information	None						
Precautions/ Remarks	None						

Event name	Home Proximity/Homing Direction Limit Input Detected Event code				74280000 hex			
Meaning	The home proxim operation.	The home proximity input and the limit signal in the homing direction were detected at the same time during a homing operation.						
Source	Motion Control Fu	unction Module			Detection timing	During instruc- tion execution		
Error attributes	Level	Minor fault	Recovery Error reset		Log category	System		
Effects	User program	Continues.	Operation	The axis stops with cution status.	with the stop method for the homing exe			
System-defined	Variable		Data type		Name			
variables	s _MC_AX[*].MFaultLvl.Active BOOL			Axis Minor Fault Occurrence				
Cause and	Assumed cause		Correction		Prevention			
correction	The wiring of the home proximity sig- nal or limit signal is incorrect.		Correct the wiring of the home prox- imity signal or limit signal.		Check to see if any of the conditions that are given as causes exist in			
		The home proximity sensor or limit sensor is installed in the wrong loca- tion.		Correct the installation location of the home proximity sensor or limit sensor so that they do not turn ON at the same time.		advance.		
	U U	The contact logic of the home proxim- ity signal or limit signal is not correct.		Correct the contact logic (N.C./N.O.) of the home proximity sensor or limit sensor.				
	The home proximity sensor or limit sensor failed.		Replace the home proximity sensor or limit sensor.					
Attached information	None							
Precautions/ Remarks	None							

Event name	Home Input/Homir Detected	ng Opposite Direction	n Limit Input	Event code	74290000 hex			
Meaning		The home input and the limit signal in the direction opposite to the homing direction were detected at the same time during a homing operation.						
Source	Motion Control Function Module S		Source details	Axis	Detection timing	During instruc- tion execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation	The axis stops with cution status.	the stop method fo	r the homing exe-		
System-defined	d Variable		Data type		Name			
variables	_MC_AX[*].MFaul	tLvl.Active	BOOL		Axis Minor Fault Occurrence			
Cause and	Assumed cause		Correction		Prevention			
correction	The wiring of the home input signal or limit signal is incorrect.		Correct the wiring of the home input signal or limit signal.		Check to see if any of the conditions that are given as causes exist in advance.			
	The home input sensor or limit sensor is installed in the wrong location.		home input sensor	Correct the installation location of the home input sensor or limit sensor so that they do not turn ON at the same time.				
	v v	The contact logic of the home input signal or limit signal is not correct.		Correct the contact logic (N.C./N.O.) of the home input signal or limit sensor.				
	The home input signal output device or limit sensor failed.		Replace the home input signal output device or limit sensor.]			
Attached information	None							
Precautions/ Remarks	None							

Event name	Home Input/Homing Direction Limit Input Detected Event code			Event code	742A0000 hex	
Meaning	The home input a	nd the limit signal in t	the homing directio	n were detected at the	e same time during	a homing operation.
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruc- tion execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The axis stops with cution status.	the stop method for the homing exe	
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault C	Occurrence
Cause and correction	Assumed cause		Correction		Prevention	
	The wiring of the home input signal or limit signal is incorrect.		Correct the wiring of the home input signal or limit signal.		Check to see if any of the conditions that are given as causes exist in advance.	
	The home input sensor or limit sensor is installed in the wrong location.		home input sense	Correct the installation location of the home input sensor or limit sensor so that they do not turn ON at the same time.		
	The contact logic of the home input signal or limit signal is not correct.		Correct the contact logic (N.C./N.O.) of the home input signal or limit sensor.			
	The home input signal output device or limit sensor failed.		Replace the home input signal output device or limit sensor.			
Attached information	None					
Precautions/ Remarks	None					

Event name	Invalid Home Input	Mask Distance		Event code	742B0000 hex		
Meaning	The setting of the	The setting of the home input mask distance is not suitable for the MC_Home or MC_HomeWithParameter instruction					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruc- tion execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	The axis stops with cution status.	n the stop method fo	or the homing exe-	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence		
Cause and	Assumed cause		Correction		Prevention		
correction	The set value of the home input mask distance when the operating mode of the MC_Home instruction is set to <i>Proximity Reverse Turn/Home Input Mask Distance</i> is insufficient to decelerate from the homing velocity to the homing approach velocity.		Check the home input mask distance, homing velocity, and homing approach velocity. Change the set- tings so that they provide sufficient travel distance to decelerate based on the operating specifications of the MC_Home or MC_HomeWithParameter instruction.		Check the operating specifications for the MC_Home or MC_HomeWithParameter instruc- tion, then set the home input mask distance, homing velocity, and hom- ing approach velocity so that they pro- vide sufficient travel distance to decelerate.		
Attached information	None						
Precautions/ Remarks	None						

Event name	No Home Input			Event code	742C0000 hex			
Meaning	There was no hom input.	There was no home signal input during the homing operation. Or, a limit signal was detected before there was a home input.						
Source	Motion Control Function Module Source details		Source details	Axis	Detection timing	During instruc- tion execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation	Operation The axis stops with the stop method for the hor cution status.		or the homing exe-		
System-defined	Variable		Data type	Data type				
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence			
Cause and	Assumed cause		Correction		Prevention			
correction	 There was no home signal input during the homing operation. A limit signal was detected before there was a home input. 		Check the home input settings and wiring and correct them so that the home signal is input during homing based on the operation specifications of the MC_Home or MC_HomeWithParameter instruc- tion. Also, set the system so that the home signal is detected before the limit signals.		nal is input during tion. Make sure th is detected before	that the home sig- the homing opera- tat the home signal a limit signal. Also re there are no wir- the home input.		
Attached information	None		·					
Precautions/ Remarks	None							

Event name	No Home Proximity Input			Event code	742D0000 hex		
Meaning	There was no hom	e proximity signal ir	put during the homi	ng operation.			
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruc- tion execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	The axis stops with cution status.	the stop method for the homing exe-		
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence		
Cause and	Assumed cause		Correction		Prevention		
correction	There was no home proximity signal input during the homing operation when a home proximity input signal was specified.		Check the home proximity input set- tings and wiring and correct them so that the home proximity signal is input during homing based on the operation specifications of the MC_Home or MC_HomeWithParameter instruction.		imity signal is input operation. Also ch	g problems with the	
Attached information	None	None					
Precautions/ Remarks	None						

Event name	Slave Error Detect	Slave Error Detected			742F0000 hex		
Meaning	An error was detec	An error was detected for the EtherCAT slave or NX Unit that is allocated to an axis.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	Continuously	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	The Servo for the a	axis turns OFF.		
System-defined	Variable		Data type	•	Name		
variables	_MC_AX[*].MFault	Lvl.Active	BOOL		Axis Minor Fault Occurrence		
Cause and	Assumed cause		Correction		Prevention		
correction	An error was detected for the Ether- CAT slave or NX Unit that is allocated to an axis.		Check the error at the slave and check the slave error code reported in Slave Error Code Report (94220000 hex) and perform the required correc- tions.		None		
Attached information	None						
Precautions/ Remarks	None	None					

Event name	Axes Group Composition Axis Error			Event code	74300000 hex			
Meaning	An error occurred	An error occurred for an axis in an axes group.						
Source	Motion Control Function Module		Source details	Axes group	Detection timing	Continuously		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation	If an immediate stop is performed for one of the compo- tion axes, operation will follow the setting of the Axes Group Stop Method Selection. Otherwise, an interpolat path stop is performed.				
System-defined	Variable		Data type	Data type				
variables	_MC_GRP[*].MFaultLvl.Active		BOOL	BOOL		Axes Group Minor Fault Occurrence		
Cause and	Assumed cause		Correction	Correction		Prevention		
correction	An error occurred for an axis in an axes group that was in motion.			Check the error code of the axes in the axes group and remove the cause of the error.		None		
Attached information	None							
Precautions/ Remarks	When an axis error occurs, any axes group that contains that axis will not operate.							

Event name	MC Common Error Occurrence			Event code	74330000 hex			
Meaning	An MC common er	An MC common error occurred.						
Source	Motion Control Function Module		Source details	Axis	Detection timing	Continuously		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation	Operation is not po	ossible for relevant	ossible for relevant axis.		
System-defined variables	Variable		Data type		Name			
	_MC_AX[*].MFaultLvI.Active		BOOL		Axis Minor Fault Occurrence			
Cause and	Assumed cause		Correction		Prevention			
correction	Partial fault level MC common error occurred.		Check the MC common error that occurred and remove the cause of the error.		None			
Attached information	None		·					
Precautions/ Remarks	When a partial fau	When a partial fault level MC common error occurs, the axis and axis group do not operate.						

Event name	Latch Position Ove	Latch Position Overflow			74340000 hex			
Meaning	An overflow occur	An overflow occurred for the latched position for the MC_TouchProbe (Enable External Latch) instruction.						
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruc- tion execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation	The axis decelerates to a stop. The Enable External L instruction cannot retrieve the latch position.				
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence			
Cause and	Assumed cause	Assumed cause		Correction		Prevention		
correction	An overflow occurred for the latched position for the MC_TouchProbe (Enable External Latch) instruction.		Correct the program so that the axis position does not overflow.		Write the program so that the axis position does not overflow.			
Attached information	None							
Precautions/ Remarks	None							

Event name	Latch Position Underflow			Event code	74350000 hex			
Meaning	An underflow occu	An underflow occurred for the latched position for the MC_TouchProbe (Enable External Latch) instruction.						
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruc- tion execution		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation	The axis decelerates to a stop. The Enable External instruction cannot retrieve the latch position.				
System-defined variables	Variable		Data type		Name			
	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence			
Cause and	Assumed cause	Assumed cause		Correction		Prevention		
correction	An underflow occurred for the latched position for the MC_TouchProbe (Enable External Latch) instruction.		Correct the program so that the axis position does not underflow.		Write the program so that the axis position does not underflow.			
Attached information	None							
Precautions/ Remarks	None							

Event name	Master Sync Direct	tion Error		Event code	74360000 hex		
Meaning	The master axis co	The master axis continued to move in the direction opposite to the sync direction.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruc- tion execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	The axis decelerat	es to a stop.		
System-defined	Variable	•	Data type		Name		
variables	_MC_AX[*].MFaultLvI.Active		BOOL		Axis Minor Fault Occurrence		
Cause and	Assumed cause		Correction		Prevention		
correction	The master axis continued to move in the direction opposite to the sync direction of the master and slave axes, resulting in an overflow.		Correct the program so that the movement direction and travel dis- tance of the master axis are in the sync direction after the start of syn- chronization.			•	
Attached information	None						
Precautions/ Remarks	None						

Event name	Slave Disconnection	on during Servo ON		Event code	74370000 hex			
Meaning	An EtherCAT slave ON.	n EtherCAT slave or NX Unit that is allocated to an axis was disconnected, replaced, or disabled while the Servo was N.						
Source	Motion Control Function Module		Source details	Axis	Detection timing	Whenever Servo is ON		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation	eration The Servo for the axis turns OFF.				
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence			
Cause and	Assumed cause	Assumed cause		Correction		Prevention		
correction	An EtherCAT slave or NX Unit that is allocated to an axis was discon- nected, replaced, or disabled while the Servo was ON.		Reconnect the EtherCAT slave or NX Unit that is allocated to the axis to the network.		Turn OFF the Servo before you dis- connect, replace, or disable a slave.			
Attached information	None		•		·			
Precautions/ Remarks	None							

Event name	Feed Distance Ove	erflow		Event code	74380000 hex		
Meaning	U 1	The target position after the interrupt input was received for the MC_MoveFeed (Interrupt Feeding) instruction over- lowed or underflowed.					
Source	Motion Control Function Module		Source details	Axis	Detection timing	During instruc- tion execution	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	The axis decelerat	es to a stop.	-	
System-defined	Variable		Data type	•	Name		
variables	_MC_AX[*].MFault	Lvl.Active	BOOL		Axis Minor Fault Occurrence		
Cause and	Assumed cause		Correction		Prevention		
correction	The target position after the interrupt input was received for the MC_MoveFeed (Interrupt Feeding) instruction exceeded the range of signed 40-bit data when converted to pulses.		Correct the input value for the com- mand position in the program. The target value after the interrupt input is received must not exceed the valid range for the number of pulses when it is converted to pulses.		Write the program correctly. The input value for the command position must not cause the target value after the interrupt input is received to exceed the valid range. The valid range is signed 40-bit data for the number of pulses when the target value is con- verted to pulses.		
Attached information	None	None					
Precautions/ Remarks	None	None					

Event name	Error in Changing Servo Drive Control Mode			Event code	74390000 hex	
Meaning	Changing the Cont	trol Mode was not co	ompleted within the s	pecified time.		
Source	Motion Control Fur	ntrol Function Module Source details Axis		Axis	Detection timing	During instruc- tion execution
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	The Servo for the	axis turns OFF.	
System-defined	fined Variable		Data type	•	Name	
variables	_MC_AX[*].MFault	Lvl.Active	BOOL		Axis Minor Fault C	ccurrence
Cause and correction	Assumed cause		Correction		Prevention	
	of 0 was output. For an OMRON G Drive, the actual of not reduced to 109 maximum velocity for three consecuti the MC_TorqueCo was stopped.	pped, the actual is not reduced to maximum velocity for three consecu- command velocity 5-series Servo urrent velocity was 6 or less of the within 10 seconds ve periods when ntrol instruction	Adjust the commar that an error does	not occur.	Adjust the comma that an error does	not occur.
	Changing the Control Mode of the Servo Drive between CSP, CSV, and CST was not completed within one second after the command was exe- cuted.		Check to see if there is an error in the Servo Drive and to see if settings are correct. Correct any problems that are found. When changing the control mode to perform control operations, set the PDO map to reference positions for CSP.		the Servo Drives and make sure that	
Attached information	None					
Precautions/ Remarks	None					

Event name	Master Axis Position Read Error Ev			Event code	743A0000 hex		
Meaning	The synchronized the synchronized c		as not executed bec	ause an error occuri	red in the position of	the master axis of	
Source	Motion Control Function Module		Source details	Axis	Detection timing	At or during instruction execu- tion	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation		ossible for relevant s ates to a stop if it is i		
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].MFault	Lvl.Active	BOOL		Axis Minor Fault O	occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	EtherCAT process data communica- tions are not established for the mas- ter axis of the synchronized control instruction or the I/O data of the NX Unit cannot be used for control.		Communicating Sla defined variable fo master of the mast investigate the error axis and remove the master axis is assig perform the same	If the <i>_EC_PDSlavTbl</i> (Process Data Communicating Slave Table) system- defined variable for the EtherCAT master of the master axis is FALSE, investigate the error in the master axis and remove the cause. If the master axis is assigned to an NX Unit, perform the same correction for the process data communicating status of the NX Unit.		If you execute synchronized control instructions after you turn ON the power supply, download data, or reset slave communications error, make sure that the _ <i>EC_PDSlavTbl</i> (Process Data Communicating Slave Table) system-defined variable for the EtherCAT master is TRUE for the node of the master axis before you execute the synchronized control instruction. If the master axis is assigned to an NX Unit, perform the same correction for the process data communicating status of the NX Unit.	
	The slave of the master axis for the synchronized control instruction was disconnected or disabled.		Check the slave of the master axis and reconnect if it was disconnected or enable it if it was disabled.		Make sure that the slave of the mas- ter axis is not disconnected or dis- abled during execution of the synchronized control instruction.		
	An Absolute Encoder Current Position Calculation Failed error (64580000 hex) was detected for the master axis of the synchronized control instruc- tion.		See if an Absolute Encoder Current Position Calculation Failed error (64580000 hex) occurred for the mas- ter axis and make suitable corrections to restore operation.		Do not use an axis with an Absolute Encoder Current Position Calculation Failed error (64580000 hex) as the master axis in the synchronized con- trol instruction.		
		axis for the synchronized Set the master axis to a Used Axis.		s to a Used Axis.	Do not change the master axis to an unused axis when executing synchro- nized control instructions.		
Attached information	None		·		·		
Precautions/ Remarks	None						

Event name	Auxiliary Axis Position Read Error			Event code	743B0000 hex		
Meaning		l control instruction wa control instruction.	as not executed bec	ause an error occurr	ed in the position of	the auxiliary axis of	
Source	Motion Control Fu	unction Module	Ile Source details Axis		Detection timing	At or during instruction execu- tion	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	- · · · ·	ossible for relevant s ates to a stop if it is		
System-defined	ed Variable _MC_AX[*].MFaultLvI.Active		Data type		Name		
variables			BOOL		Axis Minor Fault C	Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	EtherCAT process data communica- tions are not established for the auxil- iary axis of the synchronized control instruction or the I/O data of the NX Unit cannot be used for control.		Communicating SI defined variable for master of the auxil investigate the err axis and remove the auxiliary axis is as Unit, perform the sist the process data of	If the <i>_EC_PDSlavTbl</i> (Process Data Communicating Slave Table) system- defined variable for the EtherCAT master of the auxiliary axis is FALSE, investigate the error in the auxiliary axis and remove the cause. If the auxiliary axis is assigned to an NX Unit, perform the same correction for the process data communicating sta- tus of the NX Unit.		If you execute synchronized control instructions after you turn ON the power supply, download data, or reset slave communications error, make sure that the <i>_EC_PDSlavTbl</i> (Process Data Communicating Slave Table) system-defined variable for the EtherCAT master is TRUE for the node of the auxiliary axis before you execute the synchronized control instruction. If the auxiliary axis is assigned to an NX Unit, perform the same correction for the process data communicating status of the NX Unit.	
	The slave of the auxiliary axis for the synchronized control instruction was disconnected or disabled.		Check the slave of the auxiliary axis and reconnect if it was disconnected or enable it if it was disabled.		Make sure that the slave of the auxil- iary axis is not disconnected or dis- abled during execution of the synchronized control instruction.		
	Calculation Failed hex) was detected	An Absolute Encoder Current Position Calculation Failed error (64580000 hex) was detected for the auxiliary axis of the synchronized control instruction		See if an Absolute Encoder Current Position Calculation Failed error (64580000 hex) occurred for the aux- iliary axis and make suitable correc- tions to restore operation.		Do not use an axis with a Absolute Encoder Current Position Calculation Failed error (64580000 hex) as the auxiliary axis in a synchronized con- trol instruction.	
		The auxiliary axis for the synchro- nized control instruction is an unused axis.		Set the auxiliary axis to a Used Axis.		Do not change the auxiliary axis to an unused axis when executing synchro nized control instructions.	
Attached information	None						
Precautions/ Remarks	None						

Event name	EtherCAT Slave C	ommunications Erro	r	Event code	84400000 hex			
Meaning	A communications	A communications error occurred for the EtherCAT slave or NX Unit that is allocated to an axis.						
Source	Motion Control Function Module		Source details	Axis	Detection timing	Continuously		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation	Operation The Servo for the axis turns OFF.				
System-defined	stem-defined Variable		Data type		Name			
variables	_MC_AX[*].MFaultLvl.Active		BOOL		Axis Minor Fault Occurrence			
Cause and	Assumed cause	Assumed cause		Correction		Prevention		
correction	A communications error occurred for the EtherCAT slave or NX Unit that is allocated to an axis.		Check the event log for the EtherCAT error that occurred. Remove the cause of the error and clear the rele- vant error.		None			
Attached information	None							
Precautions/ Remarks		,		Function Module is n axis will still be disa		can be reset withou		

Event name	Too Many Reset	Motion Control Error	Instructions	Event code	571D0000 hex*		
Meaning	There are more t	han 100 instances of	he ResetMCError (Reset Motion Control Error) instruction.				
Source	Motion Control Function Module		Source details	MC Common	Detection timing	At power ON, Controller reset, download, or online editing	
Error attributes	Level	Observation	Recovery		Log category	System	
Effects	User program	Continues.	Operation	Not affected.			
System-defined	Variable		Data type		Name		
variables	_MC_COM.Obsr	Active	BOOL		MC Common Observation Active		
Cause and	Assumed cause		Correction		Prevention		
correction	There are more than 100 instances of the ResetMCError (Reset Motion Control Error) instruction declared in the user program. Instances inside function blocks are included.		Correct the user program so that there are not more than 100 instances of the ResetMCError (Reset Motion Control Error) instruction. Use the same instances, or use the MC_Reset (Reset Axis Error) instruc- tion or the MC_GroupReset (Group Reset) instruction depending on the error.			`	
Attached information	None						
Precautions/ Remarks	None						

* This event code occurs for unit versions 1.02 to 1.09 of the CPU Unit.

Event name	Following Error W	arning		Event code	644C0000 hex			
Meaning	The following erro	r exceeded the Follo	wing Error Warning	wing Error Warning Value.				
Source	Motion Control Fu	nction Module			Detection timing	During instruc- tion execution		
Error attributes	Level	Observation	Recovery		Log category	System		
Effects	User program	Continues.	Operation	Not affected.				
System-defined	ined Variable		Data type	Data type		Name		
variables	_MC_AX[*].Obsr.Active		BOOL		Axis Observation Occurrence			
Cause and	Assumed cause		Correction		Prevention			
correction	Performance of positioning operation is poor and the actual motion is slower than the command.		performance in th tion. Or increase Warning Value w	Remove the cause of poor following performance in the positioning opera- tion. Or increase the Following Error Warning Value within the range that will not create problems.		Remove the cause of poor following performance in the positioning opera- tion much as possible.		
Attached information	None							
Precautions/ Remarks	None							

Event name	Velocity Warning			Event code	644D0000 hex		
Meaning	The command velo	ocity exceeded the v	elocity warning valu	ie.			
Source	Motion Control Fur	nction Module	Source details	Source details Axis/axes group		During instruc- tion execution	
Error attributes	Level	Observation	Recovery		Log category	System	
Effects	User program	Continues.	Operation	Not affected.		•	
System-defined	Variable	•	Data type		Name		
variables	_MC_AX[*].Obsr.Active		BOOL		Axis Observation Occurrence		
	_MC_GRP[*].Obsr.Active		BOOL		Axes Group Observation Occurrence		
Cause and	Assumed cause		Correction		Prevention		
correction	velocity warning value.		value was exceed able corrections. Velocity Warning	Find the reason the velocity warning value was exceeded and make suit- able corrections. Or increase the Velocity Warning Value within the range that will not create problems.		(The goal is to enable detecting when the velocity warning value is exceeded. Preventative measures are not required.)	
Attached information	None						
Precautions/ Remarks	v v			you change the level eration column will be			

Event name	Acceleration Warn	ing		Event code	644E0000 hex		
Meaning	The command acc	eleration exceeded	I the acceleration war	he acceleration warning value.			
Source	Motion Control Function Module		Source details	Axis/axes group	Detection timing	During instruc- tion execution	
Error attributes	Level	Observation	Recovery		Log category	System	
Effects	User program	Continues.	Operation	Not affected.			
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].Obsr.Active		BOOL		Axis Observation Occurrence		
	_MC_GRP[*].Obsr.Active		BOOL	BOOL		Axes Group Observation Occurrence	
Cause and	Assumed cause		Correction	Correction			
correction	The command acceleration rate exceeded the acceleration warning value.		warning value was make suitable corr increase the Accel	Find the reason the acceleration warning value was exceeded and make suitable corrections. Or increase the Acceleration Warning Value within the range that will not create problems.		(The goal is to enable detecting when the acceleration warning value is exceeded. Preventative measures are not required.)	
Attached information	None				·		
Precautions/ Remarks	-		e minor fault level. If y or reset" and the Ope	-		· · · ·	

Event name	Deceleration Warr	ing		Event code	644F0000 hex		
Meaning	The command dec	eleration exceeded	the deceleration wa	rning value.			
Source	Motion Control Fu	nction Module	on Module Source details Axis/axes group		Detection timing	During instruc- tion execution	
Error attributes	Level	Observation	Recovery		Log category	System	
Effects	User program	Continues.	Operation	Not affected.	-	-	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].Obsr.Active		BOOL		Axis Observation Occurrence		
	_MC_GRP[*].Obsr.Active		BOOL	BOOL		Axes Group Observation Occurrence	
Cause and	Assumed cause		Correction	Correction			
correction	The command deceleration rate exceeded the deceleration warning value.		Find the reason th warning value was make suitable corn increase the Dece Value within the ra create problems.	s exceeded and rections. Or leration Warning	(The goal is to enable detecting when the deceleration warning value is exceeded. Preventative measures are not required.)		
Attached information	None						
Precautions/ Remarks	-		minor fault level. If y or reset" and the Ope	-			

Event name	Positive Torque Warning			Event code	64500000 hex		
Meaning	The torque comma	and value exceeded	the positive torque	warning value.			
Source	Motion Control Fu	nction Module	Source details	Source details Axis I		During instruc- tion execution	
Error attributes	Level	Observation	Recovery		Log category	System	
Effects	User program	Continues.	Operation	Not affected.			
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].Obsr.A	ctive	BOOL		Axis Observation Occurrence		
Cause and	Assumed cause		Correction		Prevention		
correction	The torque command value exceeded the positive torque warning value.		value was exceed able corrections. itive Torque Warr	Find the reason the torque warning value was exceeded and make suit- able corrections. Or increase the Pos- itive Torque Warning Value within the range that will not create problems.		(The goal is to enable detecting when the torque warning value is exceeded. Preventative measures are not required.)	
Attached information	None						
Precautions/ Remarks	U U			you change the level eration column will be		· ·	

Event name	Negative Torque V	Varning		Event code	64510000 hex		
Meaning	The torque comma	and value exceeded	the negative torque	warning value.			
Source	Motion Control Fur	Motion Control Function Module Source details Axis		Axis	Detection timing	During instruc- tion execution	
Error attributes	Level	Observation	Recovery		Log category	System	
Effects	User program	Continues.	Operation	Not affected.		·	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].Obsr.A	_MC_AX[*].Obsr.Active		BOOL		Axis Observation Occurrence	
Cause and	Assumed cause		Correction		Prevention		
correction	The torque command value exceeded the negative torque warning value.		value was exceed able corrections. C Negative Torque V	Find the reason the torque warning value was exceeded and make suit- able corrections. Or increase the Negative Torque Warning Value within the range that will not create problems.		(The goal is to enable detecting when the torque warning value is exceeded. Preventative measures are not required.)	
Attached information	None						
Precautions/ Remarks		e event level to the be changed to "Erro					

Event name	Command Position	n Overflow		Event code	64520000 hex			
Meaning	The number of pul	ses for the comman	d position overflowed	d position overflowed.				
Source	Motion Control Function Module		Source details	Axis	Detection timing	Continuously		
Error attributes	Level	Observation	Recovery		Log category	System		
Effects	User program	Continues.	Operation	The position is not	updated, but motion	n continues.		
System-defined	Variable		Data type		Name			
variables	_MC_AX[*].Obsr.Active		BOOL	BOOL		Occurrence		
Cause and	Assumed cause		Correction		Prevention			
correction	In Linear Mode, the command posi- tion when converted to pulses exceeded the upper limit of signed 40-bit data.		value for the common not exceed the ran of pulses for the in change the electro tings. To recover frichange the current	Correct the program so that the input value for the command position does not exceed the range for the number of pulses for the instruction. Or, change the electronic gear ratio set- tings. To recover from the overflow, change the current position or per- form the homing operation.		tio setting and the ting value, and converted number exceed the range tta.		
Attached information	None							
Precautions/ Remarks			minor fault level. If yor reset" and the Ope	-				

Event name	Command Positio	n Underflow		Event code	64530000 hex		
Meaning	The number of pu	lses for the comman	d position exceeded the valid range. (It underflowed.)				
Source	Motion Control Function Module		Source details	Axis	Detection timing	Continuously	
Error attributes	Level	Observation	Recovery		Log category	System	
Effects	User program	Continues.	Operation	The position is not	updated, but motic	on continues.	
System-defined	Variable		Data type		Name		
variables	_MC_AX[*].Obsr./	Active	BOOL		Axis Observation Occurrence		
Cause and	Assumed cause		Correction		Prevention		
correction	In Linear Mode, the command posi- tion when converted to pulses exceeded the lower limit of signed 40- bit data.		value for the common of exceed the pull the instruction. Or, tronic gear ratio see from the underflow	Correct the program so that the input value for the command position does not exceed the pulse number limit for the instruction. Or, change the elec- tronic gear ratio settings. To recover from the underflow, change the cur- rent position or perform the homing operation.		atio setting and the tting value, and e converted number ot exceed the range ata.	
Attached information	None						
Precautions/ Remarks	-	ne event level to the be changed to "Erro					

11-2-2 Error Descriptions

Event name	Actual Position O	verflow		Event code	64540000 hex	
Meaning	The number of pu	lses for the actual po	sition overflowed.			
Source	Motion Control Function Module		Source details	Axis	Detection timing	Continuously
Error attributes	Level	Observation	Recovery		Log category	System
Effects	User program	Continues.	Operation	The position is not	updated, but motion	on continues.
System-defined	Variable	-	Data type		Name	
variables	_MC_AX[*].Obsr.Active		BOOL		Axis Observation	Occurrence
Cause and			Correction		Prevention	
correction			Correct the program so that the target position is well within the pulse num- ber limit so that the actual position does not exceed the pulse number limit for the instruction. Or, change the electronic gear ratio settings. To recover from the overflow, change the current position or perform the hom- ing operation.		target position se make sure that th of pulses does no	atio setting and the etting value, and he converted number of exceed the range data. Allow some lee-
Attached information	None					
Precautions/ Remarks		he event level to the I be changed to "Erro				

Event name	Actual Position U	nderflow		Event code	64550000 hex	
Meaning	The number of pu	lses for the actual po	sition underflowed.		-	
Source	Motion Control FL	Inction Module			Detection timing	Continuously
Error attributes	Level	Observation	Recovery		Log category	System
Effects	User program	Continues.	Operation	The position is not	updated, but motio	n continues.
System-defined	Variable		Data type	•	Name	
variables	_MC_AX[*].Obsr.	Active	BOOL		Axis Observation	Occurrence
Cause and	Assumed cause		Correction		Prevention	
correction	The actual position when converted to pulses exceeded the lower limit of signed 40-bit data.		position is well with ber limit so that the does not exceed th limit for the instruct electronic gear rati recover from the u	Correct the program so that the target position is well within the pulse num- ber limit so that the actual position does not exceed the pulse number limit for the instruction. Or, change the electronic gear ratio settings. To recover from the underflow, change the current position or perform the homing operation.		ting value, and e converted number t exceed the range
Attached information	None					
Precautions/ Remarks	-	he event level to the I be changed to "Erro		-		

Event name	Slave Observation	Detected		Event code	74320000 hex	
Meaning	A warning was det	•				
Source	Motion Control Function Module		Source details	Axis	Detection timing	Continuously
Error attributes	Level	Observation	Recovery		Log category	System
Effects	User program	Continues.	Operation	Not affected.		•
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].Obsr.Active		BOOL		Axis Observation Occurrence	
Cause and	Assumed cause		Correction		Prevention	
correction	Ŭ Ŭ	ected for the Ether- Init that is allocated	Check the warning code for the Ether- CAT slave and remove the cause of the warning.		None	
Attached information	Attached information 1: Drive warning code					
Precautions/ Remarks				you change the level eration column will be		

Event name	Cannot Execute Sa	ave Cam Table Instr	uction	Event code	743C0000 hex	
Meaning	You cannot save a cam table to a file when non-volatile memory is being accessed by another operation.					
Source	Motion Control Function Module		Source details	MC Common	Detection timing	At instruction execution
Error attributes	Level	Observation	Recovery		Log category	System
Effects	User program	Continues.	Operation	Not affected.	t affected.	
System-defined variables	Variable		Data type		Name	
	_MC_COM.Obsr.Active		BOOL		MC Common Observation Active	
Cause and	Assumed cause		Correction		Prevention	
correction	An attempt was made to execute the MC_SaveCamTable instruction when another operation was accessing the non-volatile memory (e.g., transfer or data trace operation from the Sysmac Studio).		Execute the MC_s instruction again.	SaveCamTable	None	
Attached information	None					
Precautions/ Remarks	None					

Event name	Notice of Insufficient Travel Distance to Achieve Blendin Transit Velocity			Event code	94200000 hex	
Meaning	There is not sufficient travel distance to accelerate or decelerate to the transit velocity during blending operation.					
Source	Motion Control Function Module		Source details	Axis/axes group	Detection timing	At multi-execu- tion of instruc- tions
Error attributes	Level	Observation	Recovery		Log category	System
Effects	User program	Continues.	Operation	Not affected.		
System-defined	Variable		Data type		Name	
variables	_MC_AX[*].Obsr.Active		BOOL		Axis Observation Occurrence	
	_MC_GRP[*].Obsr.Active		BOOL		Axes Group Observation Occurrence	
Cause and	Assumed cause		Correction		Prevention	
correction	When the Acceleration/Deceleration Over parameter was set to Use rapid acceleration/deceleration (Blending is changed to Buffered), the results of profile creation caused the accelera- tion/deceleration rate to be exceeded when blending was specified, so buff- ered was used.		Set the Acceleration/Deceleration Over parameter to a value other than Use rapid acceleration/deceleration (Blending is changed to Buffered) if you do not want to change to Buffered operation.		Set the Acceleration/Deceleration Over parameter to a value other than Use rapid acceleration/deceleration (Blending is changed to Buffered) if you do not want to change to Buffered operation.	
	Blending was specified, but the target position was already reached, so it was changed to Buffered because the profile could not be created.		If unanticipated operation occurs from the switch to <i>Buffered</i> operation, cor- rect the program so that the causes given at the left do not occur.		If unanticipated operation would occur from the switch to <i>Buffered</i> operation, write the program so that the causes given at the left do not occur.	
Attached information	None					
Precautions/ Remarks	You can change the event level to the minor fault level. If you change the level to the minor fault level, the Recovery column above will be changed to "Error reset" and the Operation column will be "The axis/axes group decelerates to a stop."					

Event name	Error Clear from MC Test Run Tab Page			Event code	94210000 hex	
Meaning	An error was cleared from the MC Test Run Pane of the Sysmac Studio.					
Source	Motion Control Function Module		Source details	MC common	Detection timing	When MC Test Run error is reset
Error attributes	Level	Information	Recovery		Log category	System
Effects	User program	Continues.	Operation	Not affected.		
System-defined variables	Variable		Data type		Name	
	None					
Cause and	Assumed cause		Correction		Prevention	
correction		ared from the MC f the Sysmac Studio.				
Attached information	Attached information 1: Execution results (0000_0000 hex: All errors reset, 0000_0001 hex: Resetting all errors failed)					
Precautions/ Remarks	None					

Event name	Slave Error Code Report			Event code	94220000 hex		
Meaning	The error code was reported by the slave when a Slave Error Detected error occurred.						
Source	Motion Control Function Module		Source details	Axis	Detection timing	After Slave Error Detected error (742F0000 hex)	
Error attributes	Level	Information	Recovery		Log category	System	
Effects	User program	Continues.	Operation	Operation Not affected.			
System-defined	Variable		Data type		Name		
variables	None						
Cause and	Assumed cause		Correction		Prevention		
correction	The error code was reported by the slave when a Slave Error Detected error (742F0000 hex) occurred.		Detected error (74 Check the slave er	rror accompanies a Slave Error ted error (742F0000 hex). the slave error code in the ed information and make the ed corrections.			
Attached information	Attached information 1: Slave error code						
Precautions/ Remarks		For an OMRON G5-series Servo Drive, the error code (the main part of the error display number) from the Servo Drive is included in the lower two digits of the attached information.					
	For example, if the attached information is displayed as FF13, the error with display number 13 (Main Circuit Power Supply Undervoltage) occurred in the Servo Drive.						

11-2-3 Error Causes and Remedies

This section describes remedial actions to take when problems occur the first time you use the MC Function Module or after starting operation.

Preliminary Check Items

If an error occurs, check the items below to investigate the problem.

Category	Item to check			
Installation conditions	Is there dust in the ambient environment?			
	Are there conductive foreign matters (metal, carbon, etc.) in the ambient environment that might enter the Controller?			
	Is the ambient temperature higher than the ambient operating temperature in the specifications?			
	Is the ambient area humid (due to moisture in the air, use of water, etc.)?			
	Does the ambient air contain corrosive gases (acid, salt, sulfur, etc.)?			
	Are there sources of noise around the Controller (welders, inverters, etc.)?			
Wiring	Are power supply lines wired in the same duct as the signal lines?			
	Is the Controller grounded properly?			
	Is there a noise filter in the power supply?			
Changes	Was any extension work (welding work) done lately?			
	Was any power supply facility added lately?			
	Was the system (including its program) modified in any way (including addi- tions)?			
Accidents	Was there a lightning strike nearby?			
	Was there a ground-fault accident or was the earth leakage breaker tripped?			
	Was there a power outage?			

Problems and Countermeasures

This section describes troubleshooting when the MC Function Module is used in combination with an OMRON G5-series Servo Drive. If an unexpected operation is performed, data such as parameter settings or cam data may not have been transferred properly to the CPU Unit from the Sysmac Studio. Furthermore, variables may not be working properly between the user program and the MC Function Module. Use the data tracing function of Sysmac Studio to check if variables are exchanged at the correct timings.

Problem	Cause	Item to check	Countermeasure
Motor does not lock.	The MC Function Module does not output operation commands to the Servo Drive.	Make sure that you exe- cute the MC_Power instruction.	Correct the program.
	Servo Drive setting error	Check the Servo Drive settings.	Set the Servo Drives cor- rectly.
Motor does not run.	The drive prohibit input of the Servo Drive is enabled.	Use the Servo Drive soft- ware to check the drive prohibit input.	Cancel the drive prohibit input of the Servo Drive. Change the setting so that you do not use the drive prohibit input of the Servo Drive.
	Servo Drive error	Check for a Servo Drive error.	If there is an error, follow troubleshooting proce- dures for it.
	Mechanical axis is locked.	Check for contact with mechanical limits and check to see if mechanical parts are caught on some- thing.	Manually release the locked mechanical axis.
	CPU Unit failure		Replace the CPU Unit.

Problem	Cause	Item to check	Countermeasure
Homing cannot be per- formed.	Error	Check the nature of the error.	If there is an error, follow troubleshooting proce- dures for it.
	Incorrect wiring of the home proximity input.	Check the axis input infor- mation in the Axis Vari- ables to see if the home proximity input sensor turns ON/OFF.	Wire all connections cor- rectly.
	Incorrect wiring of the home input.	Check the wiring of the home input.	Wire all connections cor- rectly.
	The rotation direction and limit input direction are inconsistent.	If the axis moves to the mechanical limit without reversing at the limit, check the axis input infor- mation in the Axis Vari- ables to see if the limit input turns ON and OFF.	Wire the limit inputs cor- rectly.
	Incorrect wiring of the limit input	Check the wiring of the limit inputs.	Wire all connections cor- rectly.
	<i>InPosWaiting</i> does not change to FALSE	Check to see if the Servo Drive gain is too low. Check to see if the in-posi- tion range is too narrow.	Increase the Servo Drive gain. Increase the in-position range.
	Homing approach velocity is too high.	Check the homing approach velocity.	Lower the homing approach velocity of the MC Function Module.
	Axis parameters are not set correctly.	Check the axis parame- ters in the Sysmac Studio.	After setting the axis parameters correctly, download them to the MC Function Module.
	CPU Unit failure		Replace the CPU Unit.
The position of home defined with homing changes occasionally.	Loose mechanical parts, such as couplings	Use a marker pen to mark the motor shafts, cou- plings, and other mechani- cal connections to check for shifting.	Securely tighten the con- nections that shifted.
	Insufficient leeway for Z phase Insufficient leeway for home input signal	If the value is close to the setting per Servomotor rotation (number of pulses per encoder rotation) or near zero, the home may be shifted by one motor rotation due to slight changes in the timing of reading the sensor input.	Remove the motor cou- pling and shift the position by around one-quarter of a turn so that the Z phase pulse occurs at around one half of a Servomotor rotation (number of pulses per encoder rotation), and then perform homing again.

Problem	Cause	Item to check	Countermeasure
Unstable motor rotation	Incorrect wiring of Servo- motor power line/encoder line, missing phase, etc.	Check the wiring of the motor power line and encoder line.	Wire all connections cor- rectly.
	Load torque variation due to gear meshing or not tightening the coupling eccentric screw connect- ing the motor axis with the mechanical system	Check the machine. Turn the coupling under a no- load condition (with the mechanical part after the coupling removed).	Review and adjust the machine.
	Insufficient gain adjust- ment		Perform auto-tuning of the Servomotor. Manually adjust the Servomotor gain.
	Incorrect Servomotor selection (adjustment not possible)	Select another motor (check the torque and inertia ratio).	Change to an optimal motor.
	Damaged Servomotor bearings	Turn OFF the Servo Drive power supply, and also turn ON the brake power supply and release the brake if the motor comes with a brake. Then manu- ally turn the motor output shaft with the motor power line disconnected (because the dynamic brake may be applied).	Replace the Servomotor.
	Broken Servomotor wind- ing	Use a tester to check the resistance between phases U, V, and W of the motor power line. If the balance is off, there is a problem.	Replace the Servomotor.
Rotation direction is reversed.	The Servo Drive is set to the opposite rotation direc- tion.	Jog the machine. If the rotation direction of the Servo Drive is opposite the jogging direction, the rotation direction of the Servo Drive is reversed. Also check for reversed feedback signals (phases A and B) and reverse rota- tion setting of the parame- ter.	Set the rotation direction of the Servo Drive cor- rectly.
	(During homing) The axis parameters that set the polarity of the home proximity sensor and the polarity of the home proximity input do not match.	Check the axis parame- ters and sensor polarity again.	Set the correct axis parameters.
	(During homing) Incorrect wiring of the home proximity input	Check the axis input infor- mation in the Axis Vari- ables to see if the home proximity input sensor turns ON/OFF.	Wire the home proximity input correctly.

Problem	Cause	Item to check	Countermeasure
Operation cannot be started, positioning is not completed, or positioning takes too much time to complete.	The in-position range of the Servo Drive is too nar- row, and thus the current position does not enter the in-position range. (The current operation does not complete until the current position enters the in-posi- tion range, so you cannot start the next motion.)		Increase the in-position range.
	Servo Drive gain is low.		Adjust the Servo Drive gain.
	The axis does not remain in the in-position range due to an external force.	Check the axis input infor- mation for the Axis Vari- ables to see if the difference between the command current position and the actual current position is within the in- position range.	If you stop the axis so that a position inside the in- position range is not achieved, such as holding control, you can use the following error reset output to forcibly achieve the in- position range.
Abnormal noise	Mechanical vibration	Check the moving parts of the machine for intrusion of foreign matter, damage, deformation, and loosen- ing.	Correct the problem.
	Insufficient adjustment of the Servo Drive gain (high gain)		Perform auto-tuning. Man- ually lower the gain.
	Incorrect Servomotor selection (adjustment not possible).	Select another motor (check the torque and inertia ratio).	Change to an optimal motor.
	Misalignment of the cou- pling that connects the motor shaft and machine		Adjust the motor and machine installation.
Motor shaft shakes.	Insufficient adjustment of the gain (low gain)		Perform auto-tuning. Man- ually increase the gain.
	Gain cannot be adjusted due to low machine rigid- ity.	In particular, this condi- tion occurs on vertical axes, SCARA robots, pal- letizers, and other sys- tems whose axes are subject to bending or ten- sional loads.	Increase the machine rigidity. Readjust the gain.
	Mechanical configuration prone to stick slip (highly sticky static friction)		Perform auto-tuning. Man- ually adjust the gain.
	Incorrect Servomotor selection (adjustment not possible)	Select an appropriate motor (check the torque and inertia ratio).	Change to an optimal motor.
	Failure		Replace the Servo Drive. Replace the Servomotor.

Problem	Cause	Item to check	Countermeasure	
Position shift	The home position was already shifted before positioning.	Refer to The position of home defined with hom- ing changes occasionally.	Refer to The position of home defined with hom- ing changes occasionally.	
from a welder, inverter,		Check if a welder, inverter, or other similar device is located nearby.	Isolate the Controller from any nearby welders, inverters, etc.	
	Mechanical shift	Check if dimensional shifts accumulated. (Mark the mechanical connections to check for shifting.)	Securely tighten the mechanical tightening points.	
An MC Test Run is not possible from the Sysmac Studio.	An MC Test Run is being executed from another installation of the Sysmac Studio	Check to see if there is another installation of the Sysmac Studio connected to the same CPU Unit.	End all MC Test Run oper- ation for other installa- tions of the Sysmac Studio.	

11 Troubleshooting

A

Appendices

This section describes settings and connection methods for OMRON G5-series Servo Drive objects.

A-1	Connec	cting the Servo Drive	A-2		
	A-1-1	Wiring the Servo Drive	A-2		
	A-1-2	Servo Drive Settings	A-2		
A-2	Connec	cting to Encoder Input Terminals A	-12		
	A-2-1	Wiring to Encoder Input Terminals	- 12		
	A-2-2	Settings for Encoder Input Terminals	A-12		
A-3	3 Connecting to NX Units A				
A- 4	PDS St	ate TransitionA	-19		
	A-4-1	PDS State Control Method	۹-20		
	A-4-2	Main Circuit Power Supply OFF Detection	\-21		
A-5	Termin	ology A	-22		
	A-5-1	NJ/NX-series Controller			
	A-5-2	Motion Control	۹-23		
	A-5-3	EtherCAT Communications	۹-25		
A-6	Versior	۱ Information	-26		

A-1 Connecting the Servo Drive

This appendix describes connections to an OMRON G5-series Servo Drive with Built-in EtherCAT Communications.

A-1-1 Wiring the Servo Drive

Servo Drives are connected using EtherCAT communications. Refer to the *NJ/NX-series CPU Unit Built-in EtherCAT Port User's Manual* (Cat. No. W505) for information on the connection methods.

A-1-2 Servo Drive Settings

This section outlines the Servo Drive settings that are used when connected to OMRON G5-series Servo Drives with Built-in EtherCAT Communications (i.e., the applicable Servo Drives for the MC Function Module). For details on the Servo Drives, refer to the *G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications User's Manual* (Cat. No. 1576) or the *G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications Linear Motor Type User's Manual* (Cat. No. 1577).

Recommended Servo Drives

All of the functions of the MC Function Module can be used for Servo Drives with the unit versions that are given in the following table.

Manufacturer	Compatible models	Applicable unit versions
OMRON	R88D-KN 🗆 🗆 - ECT	Unit version 2.1 or later
	R88D-KN 🗆 🗆 - ECT-L	Unit version 1.1 or later

Additional Information

- You can also use unit versions of the OMRON G5-series Servo Drives with Built-in EtherCAT Communications other than the recommended unit versions. The functions that you can use depend on the specifications of the Servo Drive. Set the functions to use and the object dictionary on Sysmac Studio.
- The R88D-KN□□□-ECT-R (unit version 1.0) Servo Drives support only position control (Cyclic Synchronous Position Control Mode). You can use them for applications that do not require velocity control (Cyclic Synchronous Velocity Control Mode) or torque control (Cyclic Synchronous Torque Control Mode).

Refer to the *G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications User's Manual* (Cat. No. 1573) for details on functions.

- When you use unit version 2.0 or earlier of an OMRON G5-series Cylinder-type Servo Drive, do not set the node address switches to 00. If you set them to 00, a network configuration error occurs.
- Refer to the G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications User's Manual (Cat. No. 1576) for details on the differences between the unit versions of the OMRON G5-series Servo Drives.

Assigning External Input Signals

The MC Function Module uses the following input signals of the Servo Drives.

- Immediate stop input
- Positive limit input
- Negative limit input
- Home proximity input
- External latch trigger signals (latch input 1 and latch input 2)

• Assigning Positive Limit Inputs, Negative Limit Inputs, and Home Proximity Input

The default settings of the input signals of a G5-series Servo Drive are listed in the following table.

Signal name	Input signal
Immediate stop input	Servo Drive general-purpose input 1 (IN1: pin 5 on connector CN1, NC)
Positive limit input	Servo Drive general-purpose input 2 (IN2: pin 7 on connector CN1, NC) ^{*1}
Negative limit input	Servo Drive general-purpose input 3 (IN3: pin 8 on connector CN1, NC) ^{*2}
Home proximity input	General-purpose input 4 (IN4: pin 9 on connector CN1, NO)

*1 The signal name for the Servo Drive is the positive drive prohibit input.

*2 The signal name for the Servo Drive is the negative drive prohibit input.

• Trigger Signal Assignments for External Latches

The input signals in the following table are assigned to external latch trigger signals by default for the G5-series Servo Drive.

Settings for the <i>TriggerInput</i> (Trigger Input Condition) input variable of the MC_TouchProbe instruction			External latch trigger signal	
Mode	Mode InputDrive LatchID			
0:mcDrive	0:mcEncoderMark		Encoder Z phase	
	1:mcEXT	1:mcLatch1	Servo Drive general-purpose input 7 (IN7: pin 12 on connector CN1, NO) ^{*1}	
		2:mcLatch2	Servo Drive general-purpose input 6 (IN6: pin 11 on connector CN1, NO) ^{*2}	
1:mcController			Variable specified by TriggerVariable	

*1 The signal name for the Servo Drive is the external latch input 1.

*2 The signal name for the Servo Drive is the external latch input 2.

Backlash Compensation

The MC Function Module does not perform backlash compensation. If you require backlash compensation, use the compensation function of the Servo Drive. The objects that must be set on the Servo Drive are listed in the following table.

Index	Name	Description
3704 hex	Backlash Compensation Selection	This object is used to select whether to enable or disable back- lash compensation during position control, and to set the com- pensation direction. The default value is to disable compensation.
3705 hex	Backlash Compensation Amount	Set the backlash compensation amount during position control.
3706 hex	Backlash Compensation Time Constant	Set the backlash compensation time constant during position control.

For details on the backlash function, refer to the *G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications User's Manual* (Cat. No. 1576) or the *G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications Linear Motor Type User's Manual* (Cat. No. 1577).

PDO Mapping

This section describes mapping PDOs to control servo axes from the MC Function Module.

To use motion control functions, you must map the objects that are required for those functions to PDOs.

The PDO map is a list of required objects that is prepared in advance.

You select the PDOs to use in the Edit PDO Map Settings Window of the EtherCAT Tab Page in the Sysmac Studio.

lew Project	Configurations and Setup	All vendors
new_N0501_0	EtherCAT ×	Groups All croups
	Node Address Network configuration	Servo Drives
 Configurations and Setup 	Master Tem name Value	 Frequency Inverter Digital IO
Bit CPU/Expansion Racks	Device name E001	Analog 10
J at I/O Map	R88D-KN01L-ECT Rev:2.1 Model R88D-KN01L-ECT	Encoder Input
Controller Setup	9 Product name R88D-KN01L-ECT Rev:2.1 Revision 2.1	Vision Sensor
▶ 倍 Motion Control Setup	E Edit PDO Map Settings	
► & Cam Data Settings . ► Event Settings		-
 P Event Settings Task Settings 	PDO Map PDO entries included in 512th transmit PDO Mapping Process Data Size : Input 208 (bit) / 240 (bit) Index Size Data type PDO entry name Comment	
 Data Trace Settings 	Output 184 (bit) / 192 (bit) 0x2002:01 (8 fbit) BYTE System First Status, System error statu	B Show hidden slav
Programming	Selection Input/Output Name Flag	R88D-KN01H-ECT Rev:2.1
▼ ill POUs	No option Output 1st receive PDO Mapping Editable	RBBD-KN01H-ECT G5 Series ServeD0
▼ (if) Programs	Output 258th receive PDO Mapping	R88D-KN01L-ECT G5 Series ServeDriv
V 🖂 Program0	Output 259th receive PDO Mapping Output 250th receive PDO Mapping	R88D-KN02H-ECT Rev:2.1 R88D-KN02H-ECT G5 Series ServoDri
Section0	O Output 261th receive PDO Mapping	R88D-KN021-ECT Rev:2.1
. (0) Function Blocks		
▶ 🎞 Data	No option Inout 1st transmit PDO Mapping Editable	R88D-KN04H-ECT Rev:2.1 R88D-KN04H-ECT G5 Series ServoDri
🕨 🖽 Tasks	Irout Ist transmit POO Hosping Edibble Inout 258th baremit POO Hosping Inout 258th baremit POO Hosping	R88D-KN04L-ECT Rev:2.1 R88D-KN04L-ECT G5 Series ServoDriv
	Input 259th transmit PDO Mapping	R88D-KN06F-ECT Rev:2.1
	Input 260th transmit PDO Mapping Input 261th transmit PDO Mapping	RBID-KN06F-ECT GS Series ServoDriv R88D-KN08H-ECT Rev:2.1
	No option	R88D-KN08H-ECT G5 Series ServoDri
	Input S12th transmit PDO Mapping	R88D-KN10F-ECT Rev:2.1 R88D-KN10F-ECT G5 Series ServoDriv
		R88D-KN10H-ECT Rev:2.1 R88D-KN10H-ECT G5 Series ServoDri
		R88D-KN150F-ECT Rev:2.1
		R88D-KN150F-ECT G5 Series ServoDr
		R88D-KN150H-ECT Revr.2.1 R88D-KN150H-ECT GS Series ServeD
	Add PDO Entry Delete PDO Ent	RB8D-KN15F-ECT Rev:2.1 RB8D-KN15F-ECT G5 Series ServeDriv
	OK Cancel App	B88D-KN15H-ECT Rev:2.1
		REED-KN15H-ECT G5 Series ServoDri REED-KN20F-ECT Rev:2.1
		R88D-KN20F-ECT G5 Series ServeDriv
		R88D-KN20H-ECT Rev=2.1 R88D-40/20H-ECT G5 Series ServoDri
		Model : R88D-KN01H-ECT
		Product name : R88D-KN01H-E Revision : 2.1
		Vendor : OMRON Corporation Comment : 200V/100W ServoD
	- PDO Map Settings	URL : Open on a krowser
	The data are input/output periodically by the process data (PDO) communications.	
	process data (PDO) communications.	

The following PDOs are mapped by default in the Sysmac Studio.

RxPDO (1704 hex)	Controlword (6040 hex), Target Position (607A hex), Target Velocity (60FF hex), Target Torque (6071 hex), Modes of Operation (6060 hex), Touch Probe Function (60B8 hex), Max Profile Velocity (607F hex), Positive Torque Limit Value (60E0 hex), and Negative Torque Limit Value (60E1 hex)		
TxPDO (1B02 hex)	Error Code(603F hex), Status Word (6041 hex), Position Actual Value (6064 hex), Torque Actual Value (6077 hex), Modes of Operation Display (6061 hex), Touch Probe Status (60B9 hex), Touch Probe Pos1 Pos Value (60BA hex), Touch Probe Pos2 Pos Value (60BC hex), and Digital Inputs (60FD hex)		

Additional Information

- If you use the recommended OMRON Servo Drives (R88D-KN□□-ECT, version 2.1 or later, or R88D-KN□□-ECT-L, unit version 1.1 or later), then it is not necessary to change the default PDO map on the Sysmac Studio.
- To perform fully-closed control with OMRON R88D-KN□□□-ECT, select 1701 hex or 1600 hex for RxPDO. For 1600 hex, the total size of objects must be set to 12 bytes or less (for version 2.1 or later).

Relationships between MC Function Module and Process Data

The functions of the MC Function Module are related to the information in the process data objects. Depending on the EtherCAT slave configuration and functions that are used by the MC Function Module, you sometimes must change the relationships between the MC Function Module and the PDOs.

To access the settings, click the **Detailed Settings** Button on the Axis Basic Settings Display in the Sysmac Studio.

Edit View Insert Project Controller				
ាត់បែ១៤ថា គឺ		A 🛛 🤻 🔺 🔌 🖉 🖡 👘 O		
lew Project	<u>ا ا ا</u>	ations and Setup		неен
new_N3501_0	MIC_ACIS			
 Configurations and Setup 	100	Axis Basic Settings		
EtherCAT	25			
CPU/Expansion Racks		Axis number 0		
L 🚓 I/O Map	14444	Axis use Used axis 🔻		
Controller Setup		Axis type Servo axis 🔻		
▼ ⊕ Motion Control Setup		Feedback control No control loop 🔻		
Axis Settings MC_Axis000 (0)		Input device Node: 10 Device: R88D-KN01L-E	ECT Channel	H1.
_ @ MC Axis001 (1)		Output device	Channel	*
Aves Group Settings		Detailed Settings		
► & Cam Data Settings		Reset to Defaul		
💷 🗈 Event Settings		Function Name	Device	Process Data
L 🛤 Task Settings	(–)	Output (Controller to Drive) 1, Controlword		cotob op o(carbohured)
🗆 🖂 Data Trace Settings		3. Target position	Node:10, Device:R88D-KN01L-ECT CH1 V Node:10, Device:R88D-KN01L-ECT CH1 V	
Programming		5. Target velocity	Node:10, Device:R88D-KN01L-ECT CH1 V	
V 🛃 POUs		7. Target torgue	Node:10, Device:R88D-KN01L-ECT CH1 -	
▼ (#) Programs		9. Max profile Velocity	Node:10, Device:R88D-KN01L-ECT CH1 V	
🔻 🖂 Program0		11. Modes of operation	Node:10, Device:R88D-KN01L-ECT CH1 🔻	6060h-00.0(Modes of operation)
Section0		15. Positive torque limit value	Node:10, Device:R88D-KN01L-ECT CH1 🔻	
 30 Functions 30 Function Blocks 	-	16. Negative torque limit value	Node:10, Device:R88D-KN01L-ECT CH1 🔻	
E gata		21. Touch probe function	Node:10, Device:R88D-KN01L-ECT CH1 V	60B8h-00.0(Touch probe function)
► Tasks	123	44. Software Switch of Encoder's Input Slave Input (Drive to Controller)	K NOL JOSIG DEU 2	is not assigned >
		22. Status word	Node:10, Device:R88D-KN01L-ECT CH1 🔻	6041h-00.0/Status word)
		23. Position actual value	Node:10, Device:R88D-KN01L-ECT CH1 -	
		24. Velocity actual value	Node:10, Device:R88D-KN01L-ECT CH1 🔻	<not assigned=""></not>
	Ō	25. Torque actual value	Node:10, Device:R88D-KN01L-ECT CH1 🔻	
		27. Modes of operation display	Node:10, Device:R88D-KN01L-ECT CH1 🔻	
		40. Touch probe status	Node:10, Device:R88D-KN01L-ECT CH1 🔻	
		41. Touch probe pos1 pos value		60BAh-00.0(Touch probe position 1 positive va 60BCh-00.0(Touch probe position 2 positive va
		42. Touch probe pos2 pos value 43. Error code	Node:10, Device:R88D-KN01L-ECT CH1 V	
		45. Status of Encoder's Input Slave	KNot assigned >	such a second a
		46. Reference Position for csp	Node:10, Device:R88D-KN01L-ECT CH1 🔻	<not assigned=""></not>
		- Digital inputs		
		28. Positive limit switch	Node:10, Device:R88D-KN01L-ECT CH1 🔻	
		29. Negative limit switch	Node:10, Device:R88D-KN01L-ECT CH1 🔻	
		30. Immediate Stop Input	Node:10, Device:R88D-KN01L-ECT CH1 🔻	
		32. Encoder Phase Z Detection	Node:10, Device:R88D-KN01L-ECT CH1 •	
		33. Home switch 37. External Latch Input 1	Node:10, Device:R88D-KN01L-ECT CH1 ▼ Node:10, Device:R88D-KN01L-ECT CH1 ▼	
		37. External Latch Input 1 38. External Latch Input 2	Node:10, Device:R88D-KN01L-ECT CH1 V Node:10, Device:R88D-KN01L-ECT CH1 V	
		50. Externar Earch Triput 2	HOUSING DERCENDED KNOLL-ECT CHT +	don on cost of organi in puts)
Filter	a	2		

Additional Information

If you use the recommended OMRON Servo Drives (R88D-KNDD-ECT, version 2.1 or later, or R88D-KNDD-ECT-L, unit version 1.1 or later), then it is not necessary to change the default relationships between MC Function Module functions and the PDOs on the Sysmac Studio.

• Output Settings (Controller to Servo Drive)

The input settings apply to the command data that is sent from the MC Function Module to the Servo Drive. The default settings in the Sysmac Studio are listed in the following table. (Required objects are marked with a star.)

	Function name	Process data	Description
*	Control word	6040 hex-00.0 (Controlword)	This data is used to control the status of the Servo Drive. Set 6040 hex: Controlword.
*	Target position	607A hex-00.0 (Target posi- tion)	The target position for position control. Set 607A hex: Target position.
	Target velocity	60FF hex-00.0 (Target veloc- ity)	The target velocity for velocity control. This object is necessary to output to the Servo Drive in Cyclic Synchronous Velocity Control Mode by the MC_SyncMoveVelocity (Cyclic Syn- chronous Velocity Control) and other instructions. Normally set <i>60FF hex: Target velocity</i> .

Function name	Process data	Description
Target torque	6071 hex-00.0 (Target torque)	The target torque for torque control. This object is necessary to output to the Servo Drive in Cyclic Synchronous Torque Control Mode by the MC_TorqueControl (Torque Control) and other instructions. Normally set <i>6071 hex</i> : <i>Target torque</i> .
Maximum profile velocity	607F hex-00.0 (Max profile velocity)	The velocity limit value for torque control. This object is necessary for velocity control in Cyclic Synchronous Torque Control Mode by the MC_TorqueControl (Torque Control) and other instructions. Normally set <i>607F hex: Max profile velocity</i> .
Modes of operation	6060 hex-00.0 (Modes of operation)	This data is required to change the control mode. This object is necessary to change to a control mode other than Cyclic Synchronous Position Control Mode for the MC_SyncMoveVelocity (Cyclic Synchronous Velocity Control), MC_TorqueControl, and other instructions. Normally set <i>6060 hex: Modes of operation.</i> *
Positive torque limit value	60E0 hex-00.0 (Positive torque limit value)	This is the torque limit value in the positive direc- tion. This object is necessary to control the output torque of the Servo Drive by the MC_SetTorqueLimit and other instructions. Normally set 60E0 hex: Positive torque limit value.
Negative torque limit value	60E1 hex-00.0 (Negative torque limit value)	This is the torque limit value in the negative direc- tion. This object is necessary to control the output torque of the Servo Drive by the MC_SetTorqueLimit and other instructions. Normally set 60E1 hex: Negative torque limit value.
Touch probe function	60B8 hex-00.0 (Touch probe function)	This data is used to control the touch probe func- tion. It is required for the touch probe function for the MC_Home, MC_HomeWithParameter, MC_MoveFeed (Interrupt Feeding), MC_TouchProbe (Enable External Latch), MC_MoveLink (Synchronous Positioning), and other instructions. Normally set <i>60B8 hex</i> : <i>Touch probe function</i> .

* If you set 6060 hex (Modes of Operation), also set 6061 hex (Modes of Operation Display). Normal operation is not possible if only one of these two are set.



Precautions for Correct Use

- Some functions may not be supported if you a connect unit versions of the OMRON G5-series Servo Drives with Built-in EtherCAT Communications other than the recommended unit versions. Refer to the manual for the connected servo drive for details.
- If you change the settings, make sure that the desired operations are performed for the MC Function Module and process data settings.
- If you are not using an OMRON G5-series Servo Drive with Built-in EtherCAT Communications, always set the Modes of Operation (6060 hex).
- To perform fully-closed control with OMRON G5-series Servo Drives with Built-in EtherCAT Communications, make settings so that the size of objects totals 12 bytes or less.

• Input Settings (Servo Drive to Controller)

This is the status data from the Servo Drive to the MC Function Module. The default settings in the Sysmac Studio are listed in the following table. (Required objects are marked with a star.)

	Function name	Process data	Description
*	Status word	6041 hex-00.0 (Statusword)	The status of the Servo Drive.
			Set 6041 hex: Statusword.
*	Position actual value	6064 hex-00.0 (Position actual	Shows the actual position.
		value)	Set 6064 hex: Position actual value.
	Velocity actual value	Not set. ^{*1}	Shows the actual velocity.
			Normally set 606C hex: Velocity actual value.
	Torque actual value	6077 hex (Torque actual value)	Shows the actual torque.
			This object is necessary to output to the Servo Drive in Cyclic Synchronous Torque Control Mode by the MC_TorqueControl (Torque Control) and other instructions.
			Normally set 6077 hex: Torque actual value.
	Modes of operation display	6061 hex-00.0 (Modes of oper-	Shows the operation mode.
		ation display)	This object is necessary to change to a control mode other than Cyclic Synchro- nous Position Control Mode for the MC_SyncMoveVelocity (Cyclic Synchro- nous Velocity Control), MC_TorqueControl, and other instructions.
			Normally set <i>6061 hex</i> : <i>Modes of operation display</i> . ^{*2}
	Touch probe status	60B9 hex-00.0 (Touch probe status)	Shows the status of the touch probe func- tion.
			It is required for the touch probe function for the MC_Home, MC_HomeWithParameter, MC_MoveFeed (Interrupt Feeding), MC_TouchProbe (Enable External Latch), MC_MoveLink (Synchronous Positioning), and other instructions.
			Normally set 60B9 hex: Touch probe sta- tus.
	Touch probe position 1 posi-	60BA hex-00.0 (Touch probe	The latched position for touch probe 1.
	tion value	pos1 pos value)	It is required for the touch probe function for the MC_Home, MC_HomeWithParameter, MC_MoveFeed (Interrupt Feeding), MC_TouchProbe (Enable External Latch), MC_MoveLink (Synchronous Positioning), and other instructions.
			Normally set 60BA hex: Touch probe pos1 pos value.

Function name	Process data	Description
Touch probe position 2 posi-	60BC hex-00.0 (Touch probe	The latched position for touch probe 2.
tion value	pos2 pos value)	It is required for the touch probe function for the MC_Home, MC_HomeWithParameter, MC_MoveFeed (Interrupt Feeding), MC_TouchProbe (Enable External Latch), MC_MoveLink (Synchronous Positioning), and other instructions.
		Normally set 60BC hex: Touchprobe pos2 pos value.
Error code	603F hex-00.0 (Error code)	The error code in the Servo Drive.
		Normally set 603F hex: Error code.
Reference position for csp	Not set. ^{*3}	The reference position for changing the csp mode. This object is supported for OMRON G5-series Cylinder-type Servo Drives with unit version 2.1 or later. Set 4020 hex: Ref- erence Position for csp when required. ^{*4}
		G5-series Linear Motor Type do not support this object.

- *1 If required, map the selected process data to a PDO before setting it. The standard setting is 606Ch-00.0 (Velocity actual value).
- *2 If you set 6061 hex (Modes of Operation Display), also set 6060 hex (Modes of Operation). Normal operation is not possible if only one of these two are set.
- *3 This data is accessed by instructions that are used in Velocity Control Mode (CSV) or Torque Control Mode (CST). If it is required, set 4020 hex-00.0 (Reference position for csp). However, an error occurs in the Servo Drive if it is mapped to a PDO when the process data communications cycle for EtherCAT communications is 250 µs or 500 µs or when the electronic gear ratio at the Servo Drive (6091 hex) is not 1:1. For details, refer to the NJ/NX-series Motion Control Instructions Reference Manual (Cat. No. W508).
- *4 Refer to the *G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications User's Manual* (Cat. No. I576) if you use 4020 hex (Reference position for csp) and check the process data communications cycles that can be set for EtherCAT communications.

Precautions for Correct Use

- Some functions may not be supported if you a connect unit versions of the OMRON G5-series Servo Drives with Built-in EtherCAT Communications other than the recommended unit versions. Refer to the manual for the connected servo drive for details.
- If you change the settings, make sure that the desired operations are performed for the MC Function Module and process data settings.
- If you are not using an OMRON G5-series Servo Drive with Built-in EtherCAT Communications, always set the Modes of Operation Display (6061 hex).
- To use the MC_SyncMoveVelocity (Cyclic Synchronous Velocity Control) instruction to change the control mode of an OMRON G5-series Servo Drive, you need to map Reference Position for CSP. Set the primary period to 1 ms when you use Reference Position for CSP. Also, set the electronic gear ratio to 1:1 for the OMRON G5-series Servo Drive. For details, refer to the G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications User's Manual (Cat. No. 1576) or the G5-series AC Servomotors/Servo Drives with Built-in EtherCAT Communications Linear Motor Type User's Manual (Cat. No. 1577).

Digital Input Settings

Function name	Process data	Description
Positive limit switch (positive drive prohibit input)	60FD hex-00.1 (Digital inputs)	This signal is used for the positive limit input. Normally set <i>Bit 1: Positive limit switch of 60FD</i> <i>hex-00: Digital inputs.</i>
Negative limit switch (negative drive prohibit input)	60FD hex-00.0 (Digital inputs)	This signal is used for the negative limit input. Normally set <i>Bit 0</i> : <i>Negative limit switch of 60FD</i> <i>hex-00: Digital inputs.</i>
Immediate stop input	60FD hex-00.25 (Digital inputs)	This signal is used for the immediate stop input. Set <i>Bit 25</i> : <i>Immediate Stop Input of 60FD hex-00:</i> <i>Digital inputs</i> for an OMRON G5-series Servo Drive.
Encoder Phase Z Detection (encoder Z- phase detection)	60FD hex-00.16 (Digital inputs)	Shows the status of detecting the Z-phase input. For OMRON G5-series Cylinder-type Servo Drives with unit version 2.1 or later, set bit 16 (Encoder Phase Z Detection) of 60FD hex-00 (Digital Inputs). G5-series Linear Motor Type do not support this object.
Home switch (home proximity input)	60FD hex-00.2 (Digital inputs)	This signal is used for the home proximity input. Normally set <i>Bit 2</i> : <i>Home switch of 60FD hex-00:</i> <i>Digital inputs</i> .
External Latch Input 1	60FD hex-00.17 (Digital inputs)	Shows the status of the signal that is used for external latch input 1. Set <i>Bit 17: External Latch Input 1 of 60FD hex-00:</i> <i>Digital inputs</i> for an OMRON G5-series Servo Drive.
External Latch Input 2	60FD hex-00.18 (Digital inputs)	Shows the status of the signal that is used for external latch input 2. Set <i>Bit 18: External Latch Input 2 of 60FD hex-00:</i> <i>Digital inputs</i> for an OMRON G5-series Servo Drive.

The MC Function Module uses the following input signals of the Servo Drive.



Precautions for Correct Use

- Some functions may not be supported if you a connect unit versions of the G5-series Servo Drives with Built-in EtherCAT Communications other than the recommended unit versions. Refer to the manual for the connected servo drive for details.
- If you change the settings, make sure that the desired operations are performed for the MC Function Module and process data settings.

Version Information

- If you are using a CPU Unit with version 1.09 or earlier and you are not using an OMRON G5series Servo Drive with Built-in EtherCAT Communications for the servo axis, Modes of Operation (6060 hex) and Modes of Operation Display (6061 hex) are required.
- If you are using a CPU Unit with version 1.10 or later, operation is as described in the following table depending on whether Modes of Operation (6060 hex) and Modes of Operation Display (6061 hex) are mapped.

	Modes of Operation Display (6061 hex) mapped	Modes of Operation Display (6061 hex) not mapped
Modes of Operation (6060 hex) mapped	 You can execute instructions that use CSP,^{*1} CSV,^{*2} or CST.^{*3} The servo is OFF in any control mode other than CSP, CSV, or CST. 	 You can execute instructions that use CSP. If you execute any instruction that uses any other control mode, a Process Data Object Setting Missing error (error code 3461 hex) occurs. The MC Function Module assumes that the CSP Servo Drive control mode is used. Command the Servo Drive to use CSP.
Modes of Operation (6060 hex) not mapped	 You can execute instructions that use CSP. If you execute any instruction that uses any other control mode, a Process Data Object Setting Missing error (error code 3461 hex) occurs. The servo is OFF in any control mode other than CSP. 	• You can execute instructions that use CSP. If you execute any instruction that uses any other control mode, a Process Data Object Setting Missing error (error code 3461 hex) occurs.

*2 CSV is the Cyclic Synchronous Velocity Control Mode of the Servo Drive.

*3 CST is the Cyclic Synchronous Torque Control Mode of the Servo Drive.

Object Settings

The G5-series Servo Drive settings required to use the control functions of the MC Function Module are listed in the following table.

Consult the manual for your Servo Drive and set all related objects for the Servo Drive functions that you are going to use.

Index	Subindex	Name	Recom- mended setting	Description
3013 hex	00 hex	No. 1 External Torque Limit ^{*1}	1388 hex	Default setting = 500.0%
3015 hex ^{*2}	00 hex	Operation Switch for Using Absolute Encoder	0002 hex	Use absolute values and ignore multi-rotation counter overflow.
3317 hex	00 hex	Speed Limit Selec- tion	0001 hex	The velocity limit method used during torque control is either 607F: Max profile velocity or 3321h: Velocity limit value setting, whichever value is smaller.
3323 hex	00 hex	External Feedback Pulse Type Selec- tion	0000, 0001, or 0002 hex ^{*3}	Set the type of external scale to use. The default value is 0000 hex (90° Phase Difference Output).

Index	Subindex	Name	Recom- mended setting	Description
3324 hex ^{*2}	00 hex	External Feedback Pulse Dividing Numerator	00000000 hex	Set the encoder resolution per motor rotation [pulses]. Set to 0 for automatic setting.
3401 hex	00 hex	Input Signal Selec- tion 2	00818181 hex	Positive Drive Prohibit Input (NC)
3402 hex	00 hex	Input Signal Selec- tion 3	00828282 hex	Negative Drive Prohibit Input (NC)
3403 hex	00 hex	Input Signal Selec- tion 4	00222222 hex	Home proximity input (NO)
3404 hex	00 hex	Input Signal Selec- tion 5	002B2B2B hex	External Latch Signal 3 (NO)
3405 hex	00 hex	Input Signal Selec- tion 6	00212121 hex	External Latch Signal 2 (NO)
3406 hex	00 hex	Input Signal Selec- tion 7	00202020 hex	External Latch Signal 1 (NO)
3504 hex	00 hex	Drive Prohibit Input Selection	0001 hex	The drive prohibit input is disabled at the Servo. This is performed by the MC Function Module instead.
3508 hex	00 hex	Undervoltage Error Selection	0001 hex	Operation is stopped for an insufficient main power voltage.
3521 hex	00 hex	Torque Limit Selec- tion ^{*1}	0006 hex	There are two limit values, one for positive and one for negative. Switch between them by using PCL and NCL.
3522 hex	00 hex	No. 2 External Torque Limit ^{*1}	1388 hex	Default setting = 500.0%
3703 hex	00 hex	Torque Limit Output Setting ^{*1}	0001h hex	Output turns ON for the torque limit value excluding the torque command value.
3801 hex	00 hex	Software Limit Function	0003 hex	Disable the software limits in both directions.
3758 hex	00 hex	Latch Trigger Selection	0100 hex	Touch probe1 = External latch signal 1 Touch probe2 = External latch signal 2
3759 hex	00 hex	Warning Hold Selection	0000 hex	The warnings are automatically cleared when the cause of the warning is eliminated.
607C hex	00 hex	Encoder Home Off- set	00000000 hex	An offset value of 0 is used by the Servo Drive.
6091 hex	01 hex	Electronic Gear Ratio Numerator	00000001 hex	The gear ratio on the Servo Drive is 1:1. A simi- lar function is set in the MC Function Module.
	02 hex	Electronic Gear Ratio Denominator	00000001 hex]

*1 For G5-series Linear Motor Type, "force" applies instead of "torque."

*2 G5-series Linear Motor Type do not support this object.

*3 Set the type of external scale to use when you use an OMRON G5-series Servomotor with fully-closed control, or an OMRON G5-series Linear Motor Type.

A-2 Connecting to Encoder Input Terminals

This appendix describes connections to an OMRON GX-series EtherCAT Slave Encoder Input Terminals.

A-2-1 Wiring to Encoder Input Terminals

Encoder Input Terminals are connected using EtherCAT communications. Refer to the *NJ/NX-series CPU Unit Built-in EtherCAT Port User's Manual* (Cat. No. W505) for information on the connection methods.

A-2-2 Settings for Encoder Input Terminals

This section outlines the Encoder Input Terminal settings that are used when connected to OMRON GX-series GX-EC0211/EC0241 Encoder Input Terminals (i.e., the applicable Encoder Input Terminals for the MC Function Module). Refer to the *GX-series EtherCAT Slave User's Manual* (Cat. No. W488) for detailed information on the Encoder Input Terminals.

Recommended Encoder Input Terminals

All of the functions of an encoder axis of the MC Function Module can be used for Encoder Input Terminals with the unit versions that are given in the following table.

Manufacturer	Compatible models	Applicable unit versions		
OMRON	GX-EC0211	Unit version 1.1 or later		
OMRON	GX-EC0241	Unit version 1.1 or later		

Additional Information

- Only the OMRON GX-EC0211/EC0241 can be used for encoder axes of EtherCAT slaves.
- Unit version 1.0 of the GX-EC0211/EC0241 can also be used for encoder axes, but they do
 not support the Sysmac device functions. When you use unit version 1.0, do not set the node
 address switches to 00. If you set them to 00, a network configuration error occurs. Refer to
 the *GX-series EtherCAT Slave User's Manual* (Cat. No. W488) for detailed information on
 functions

External Input Signals

When all of the functions of an encoder axis are used for an Encoder Input Terminal, the following input signals are used at the Encoder Input Terminal.

- Counter A phase
- Counter B phase
- · Counter Z phase
- Latch Inputs (A/B)

There are two counter channels, and there are two external latches for each channel. Wire the input signals that are required for your application.

Refer to the GX-series EtherCAT Slave User's Manual (Cat. No. W488) for input signal wiring methods.

Α

PDO Mapping

This section describes mapping PDOs to control encoder axes from the MC Function Module.

You must map the objects that are required for the motion control functions that you will use to process data communications. The PDO map is a list of required objects that is prepared in advance.

You select the PDOs to use in the Edit PDO Map Settings Window of the EtherCAT Tab Page in the Sysmac Studio.

X 単価 自 ち さ 2	ð 1		A 🖲 🥅 🔺						
New Project	🖻 Edit	PDO Map Se	ttings					_ 🗆 🛛 🗖	
rew_N301_0	2	IInput/Output Output Output Output			/ 240 (bit)] / 192 (bit]	PDO entries included in 512th transm Index See Data type PDO 0x2002:01 8 (bt) BYTE Sysmat			Value 261th receive PDO Mappin 261th receive PDO Mappin 261th receive PDO Mappin
* # 1/0 Map * @ Controller Setup * @ Controller Setup * # Motion Control Setup * # ' Cam Data Settings * # Setup * # Task Settings * @ Data Trace Settings	••••	Output Output Output Input Input Input Input	260th receive PDO Mapping 261th receive PDO Mapping 252th receive PDO Mapping 252th receive PDO Mapping 15t transmit PDO Mapping 259th transmit PDO Mapping 259th transmit PDO Mapping	 Editable 					61th receive PDO Mappin 261th receive PDO Mappin 259th receive PDO Mappin 259th transmit PDO Mappi 259th transmit PDO Mappi 259th transmit PDO Mappi 259th transmit PDO Mappi 259th transmit PDO Mappi
Programming If POUs If POUs If POus If Poyrams If Poyrams If Inthone If Functions If Surticion Blocks		Input Input	261th transmit PDO Mapping No option 512th transmit PDO Mapping						259th transmit PDO Mappi 259th transmit PDO Mappi 259th transmit PDO Mappi 512th transmit PDO Mappi Edit PDO Map Settings
► I Tasks							d PDO Entry Delete OK Cancel Immunications.	Annta	Edit Setting Parameters

The following PDOs are mapped by default in the Sysmac Studio.

RxPDO (1700 hex)	Channel 1 Instruction Bits (4020 hex-01 hex) and Channel 2 Instruction Bits (4020 hex-02 hex)		
RxPDO (1701 hex)	Channel 1 Preset Value (4011 hex-01 hex) and Channel 2 Preset Value (4011 hex-02 hex)		
TxPDO (1B00 hex)	Channel 1 Position Value (4010 hex-01 hex) and Channel 2 Position Value (4010 hex-02 hex)		
TxPDO (1B01 hex)	Channel 1 Latch Value A (4012 hex-01 hex) and Channel 2 Latch Value A (4012 hex-02 hex)		
TxPDO (1B02 hex)	Channel 1 Latch Value B (4013 hex-01 hex) and Channel 2 Latch Value B (4013 hex-02 hex)		
TxPDO (1B03 hex)	Channel 1 Status Bits (4030 hex-01 hex) and Channel 2 Status Bits (4030 hex- 02 hex)		
TxPDO (1BFF hex)	Sysmac Error Status (2002 hex -01 hex)		


Additional Information

If you use the recommended Encoder Input Terminals (GX-EC0211/EC0241, version 1.1 or later), then it is not necessary to change the default PDO map on the Sysmac Studio.

Relationships between MC Function Module and Process Data

The functions of the MC Function Module are related to the information in the process data objects. Depending on the EtherCAT slave configuration and functions that are used by the MC Function Module, you sometimes must change the relationships between the MC Function Module and the PDOs.

To access the settings, click the **Detailed Settings** Button on the Axis Basic Settings Display in the Sysmac Studio.



Additional Information

If you use the recommended Encoder Input Terminals (GX-EC0211/EC0241, version 1.1 or later), then it is not necessary to change the default relationships between the functions and process data on the Sysmac Studio.

• Output Settings (Controller to Servo Drive)

The input settings apply to the command data that is sent from the MC Function Module to the Encoder Input Terminal. The default settings in the Sysmac Studio are listed in the following table. (Required objects are marked with a star.)

	Function name	Proces	ss data	Description	
	Function name	Channel 1	Channel 2	Description	
*	Software Switch of Encoder's Input Slave	4020 hex-01.0 (Instruction Bits)	4020 hex-02.0 (Instruction Bits)	Set the instruction bits. Set the objects given at the left for each channel.	

Precautions for Correct Use

• If you change the settings, make sure that the desired operations are performed for the MC Function Module and process data settings.

• Input Settings (Servo Drive to Controller)

This is the status data from the Encoder Input Terminal to the MC Function Module. The default settings in the Sysmac Studio are listed in the following table. (Required objects are marked with a star.)

	Function name	Proces	ss data	Description
	Function name	Channel 1	Channel 2	Description
*	Position actual value	4010 hex-01.0 (Position Value)	4010 hex-02.0 (Position Value)	Store the current values from the counters. Set the objects given at the left for each channel.
	Touch probe posi- tion 1 position value	4012 hex-01.0 (Latch Value A)	4012 hex-02.0 (Latch Value A)	This is the latched position for latch 1. Store the values of latch positions A. You must map these objects to use the touch probe function, i.e., to use the MC_TouchProbe (Enable External Latch) instruction. Set the objects given at the left for each channel.
	Touch probe posi- tion 2 position value	4013 hex-01.0 (Latch Value B)	4013 hex-02.0 (Latch Value B)	This is the latched position for latch 2. Store the values of latch positions B. You must map these objects to use the touch probe function, i.e., to use the MC_TouchProbe (Enable External Latch) instruction. Set the objects given at the left for each channel.
	Status of Encoder's Input Slave	4030 hex-01.0 (Status Bits)	4030 hex-02.0 (Status Bits)	Store the status bits. You must map these objects to use the touch probe function, i.e., to use the MC_TouchProbe (Enable External Latch) instruction. Set the objects given at the left for each channel.



Precautions for Correct Use

• If you change the settings, make sure that the desired operations are performed for the MC Function Module and process data settings.

Digital Input Settings

Settings are not required to use an encoder axis.

Object Settings in the Encoder Input Terminals

There are no objects that you must set at the Encoder Input Terminal.

Relationship between the MC Function Module and the Ring Counter of an Encoder Input Terminal

The Modulo Minimum Position Setting Value and Modulo Maximum Position Setting Value in the Servo Drive Settings in the axis parameters of the MC Function Module must agree with the maximum value setting of the ring counter in the Encoder Input Terminal.

The Modulo Minimum Position Setting Value and Modulo Maximum Position Setting Value are set on the Servo Drive Settings View on the Sysmac Studio.

The settings are as follows:


Parameter	Meaning	Set value
Modulo Maximum Posi- tion Setting Value	Set the modulo maximum position that is set on the Servo Drive or the Encoder Input Ter- minal.	This setting must agree with the maxi- mum value that is set for the ring coun- ter in the Encoder Input Terminal.
Modulo Minimum Posi- tion Setting Value	Set the modulo minimum position that is set on the Servo Drive or the Encoder Input Ter- minal.	Set this parameter to 0.

📓 New Project - new_Controller_0 - Sysmac Studio		
File Edit View Insert Project Co	ontroller Simulation Tools Help	
X 通 値 立 c 図	「 く な ほ 派 本 回 本 英 な ぶ ぶ ぶ き も む む け の の 点	
Multiview Explorer 🗸 🗸	contended Conte	Toolbox 🗸 🖡
new_Controller_0	Servo Drive Settings	<search></search>
Configurations and Setup	Modulo Position Settings	
► -□ Node1 : GX-EC0211 (E001)		
CPU/Expansion Racks I/O Map	Modulo minimum position setting value 0 pulse	
Controller Setup	Detailed Settings PDS state control method Switched on by Servo OFF	
▼ ⊕ Motion Control Setup ▼ ⊕ Axis Settings	Main signification of the state	
MC_Axis000 (0,MC1)	Main circuit power supply OFF detection C Detect	
∟ line Axes Group Settings L line Cam Data Settings		
Event Settings	中	
Image:		
Programming	CCT	
	123	
	\odot	
	Output • 7 X	
< > Filter	📑 Output 🔥 Build 🚓 Watch (Project)	
	Cabler 1 Course (Finders)	

The maximum value of the ring counter for the Encoder Input Terminal is set on the EtherCAT Tab Page in the Sysmac Studio.

The setting is as follows:

Index	Object name	Set value
0x4003	Max Count Setting (maxi- mum value of the ring coun- ter)	Set this parameter to the same value as the Modulo Maximum Position Setting Value in the Servo Drive Settings of the axis parameters of the MC Function Module.




A-3 Connecting to NX Units

Refer to the *NX-series Position Interface Units User's Manual* (Cat. No. W524) for information on connecting to the NX-series Position Interface Units.

A-4 PDS State Transition

The PDS state transition is defined in CiA402 drive profile. Use the Controlword (6040 hex) process data to command PDS state transitions. To check actual PDS states, use the Statusword (6041 hex) process data.

The following diagram shows the state transition defined in CiA402 drive profile. Each box indicates a state, while numbers indicate the state control commands.



A-4-1 PDS State Control Method

This section describes the relationship between the setting values of the **PDS State Control Method** axis parameter and the PDS states.

When PDS State Control Method Is Set to 0

The following operation is performed when **PDS State Control Method** is set to 0: Switched on by Servo OFF.

- After communications with the Servo Drive is established, MC Function Module automatically changes the PDS state to Servo Ready (Switched on).
- If *Enable* of the MC_Power (Power Servo) instruction changes to TRUE in the Servo Ready (Switched on) state, the PDS state changes to Servo ON (Operation enabled). This operation corresponds to *4: Enable operation* in the state transition diagram.
- If *Enable* of the MC_Power (Power Servo) instruction changes to FALSE in the Servo ON (Operation enabled) state, the PDS state changes to Servo Ready (Switched on). This operation corresponds to *5: Disable operation* in the state transition diagram.

When PDS State Control Method Is Set to 1

The following operation is performed when **PDS State Control Method** is set to 1: Ready to switched on by Servo OFF.

- After communications with the Servo Drive is established, MC Function Module automatically changes the PDS state to Main Power OFF (Ready to switch on).
- If *Enable* of the MC_Power (Power Servo) instruction changes to TRUE in the Main Power OFF (Ready to switch on) state, the PDS state changes to Servo ON (Operation enabled). This operation corresponds to *3: Switch on* and *4: Enable operation* in the state transition diagram. The steps 3 and 4 are performed simultaneously.
- If *Enable* of the MC_Power (Power Servo) instruction changes to FALSE in the Servo ON (Operation enabled) state, the PDS state changes to Main Power OFF (Ready to switch on). This operation corresponds to *5: Disable operation* and *6: Shutdown* in the state transition diagram. The steps 5 and 6 are performed simultaneously.

Version Information

- For a CPU Unit with unit version 1.09 or earlier, **PDS State Control Method** is set to *0*. For a CPU Unit with unit version 1.10 or later, **PDS State Control Method** is selectable.
- For a CPU Unit with unit version 1.10 or later, **PDS State Control Method** is set to *0* by default.

A-4-2 Main Circuit Power Supply OFF Detection

You can select whether to detect the OFF state of the main circuit power supply while the Servo is ON.

Select the *Do not detect* option if a *Servo Main Circuit Power OFF* error occurs even after the MC_Power (Power Servo) instruction is executed.



Precautions for Correct Use

You cannot select the *Do not detect* option when you use an OMRON G5-series Servo Drive. A *Servo Main Circuit Power OFF* error will occur if you select the *Do not detect* option and turn off the main power supply to Servo Drive when the Servo is ON.



Version Information

- For a CPU Unit with unit version 1.09 or earlier, **Main circuit power supply OFF detection** is set to *Detect*. For a CPU Unit with unit version 1.10 or later, **Main circuit power supply OFF detection** is selectable.
- For a CPU Unit with unit version 1.10 or later, **Main circuit power supply OFF detection** is set to *Detect* by default.

A-5 Terminology

This appendix provides definitions of terms related to motion control.

A-5-1 NJ/NX-series Controller

Term	Description
main memory	The memory inside the CPU Unit that is used by the CPU Unit to execute the OS and user program.
periodic task	Tasks for which user program execution and I/O refreshing are performed each period.
primary periodic task	The task with the highest priority.
task period	The interval at which the primary periodic task or a periodic task is executed.
I/O refreshing	Cyclic data exchange with external devices that is performed with predetermined memory addresses.
program	One of three POUs. The others are functions and function blocks. Programs are assigned to tasks to execute them.
user program	All of the programs in one project.
Inline ST	ST programming that is included within a ladder diagram program.
system-defined variable	A variable for which all attributes are defined by the system and cannot be changed by the user.
global variable	Reading and writing global variables are possible from all POUs (programs, functions, and function blocks).
local variable	A variable that can be accessed only from the POU in which it is defined. Local variables include internal variables, input variables, output variables, in-out variables, and external variables.
download	To transfer data from the Sysmac Studio to the Controller with the synchroniza- tion operation of the Sysmac Studio.
upload	To transfer data from the Controller to the Sysmac Studio with the synchroniza- tion operation of the Sysmac Studio.
major fault level Control error	An error for which all control operations from the NJ/NX-series Controller are not possible. The CPU Unit stops user program execution immediately and turns OFF the loads for all slaves and Units (including remote I/O).
partial fault level Controller error	An error for which all control operations for one of the function modules in the NJ/NX-series Controller are stopped.
	The NJ/NX-series CPU Unit continues operation even after a partial fault level Controller error occurs.
minor fault level Controller error	An error for which some of the control operations for one of the function modules in the NJ/NX-series Controller are stopped.
	The NJ/NX-series CPU Unit continues operation even after a minor fault level Controller error occurs.
observation	One of the event levels for Controller information and user-defined information. Observations represent minor errors that do not affect control operations. They are recorded in an event log to inform the user.

A-5-2 Motion Control

Term	Description
used real axis	Axis of which axis type is set to Servo Axis or Encoder Axis and axis use is set to Used Axis.
used virtual axis	Axis of which axis type is set to Virtual Servo Axis or Virtual Encoder Axis and axis use is set to Used Axis.
Motion Control Function Module	A software component that executes motion control. It performs motion control based on commands from the motion control instructions that are executed in the user program. (Abbreviation: MC Function Module)
motion control instruction	An instruction that is defined as a function block to execute a motion control function. The MC Function Module supports instructions that are based on function blocks for PLCopen [®] motion control as well as instructions developed specifically for the MC Function Module.
single-axis position control	Controlling the position of one axis.
single-axis velocity control	Controlling the velocity of one axis.
	For single-axis velocity control, the MC Function Module sometimes outputs velocity commands to the Servo Drive and sometimes outputs position commands to the Servo Drive.
single-axis torque control	Controlling the torque of one axis.
single-axis synchronized control	Synchronizing the control of one slave axis with one master axis.
	There are two types of single-axis synchronized control: gear operation, in which the axes are synchronized with a gear ratio, and cam operation, in which the axes are synchronized according to the relationship between phases and displacements in a cam table.
single-axis manual operation	Controlling an axis with manual operation, such as jogging.
auxiliary functions for single-axis control	Functions that aid in controlling an axis, such as override factor settings and reset- ting errors.
multi-axes coordinated control	Controlling the motion of more than one axis, such as linear interpolation and circular interpolation.
	You specify an axes group to specify the axes to coordinate.
auxiliary functions for multi-axes coordinated control	Functions that aid in controlling an axes group, such as override factor settings and resetting errors.
motion control parameters	Parameters that define the operation of the MC Function Module.
	The motion control parameters include the MC common parameters, axis parameters, and axes group parameters.
axis parameters	Parameters that apply to a single axis.
axes group parameters	Parameters that apply to an axes group.
system-defined variables for motion control	System-defined variables that provide status information for the MC Function Mod- ule.
	The system-defined variables for motion control include the MC Common Variable, Axis Variables, and Axes Group Variables.
MC common variable	A system-defined variable that is defined as a structure and provides status informa- tion for the overall operation of the MC Function Module.
axis variables	System-defined variables that are defined as structures and provide status informa- tion and some of the axis parameters for individual axes.
axes group variables	System-defined variables that are defined as structures and provide status informa- tion and some of the axes group parameters for individual axes groups.
homing	The process of defining home.
	Homing is also called home positioning, home searching, calibration, and datum.
home	The zero position of the mechanical system.
	Home is determined by the home input signal during the homing operation.

A

Term	Description
zero position	The position that is based on home and is treated as the zero position in the user program.
	This is the same position as home if the home position is not changed.
following error	The difference between the command current position and actual current position.
	There is a following error only in position control mode. (Other modes do not have a command current position.)
	The following error is also called the following error counter value and the remaining pulses.
following error reset	Setting the following error to zero.
cam profile curve	A curve that shows the relationship between phases and displacements in a cam operation.
	The cam profile curve is created on the Sysmac Studio.
cam data	Data made up of phases (master axis) and displacements (slave axis) for cam oper- ation.
cam data variable	A structure array variable for cam data. It contains phases and displacements and is defined as a structure array.
cam table	A data table that contains cam data.
	Use the Sysmac Studio to download the cam profile curves that you created with the Cam Editor to the CPU Unit to save them as cam tables in the non-volatile memory in the CPU Unit.
override	A function that allows the operator to temporarily change programmed values during operation.
jerk	The rate of change in the acceleration or deceleration rate.
	If you specify the jerk, the velocity graph will form an S-curve for acceleration and deceleration.
	Jerk is also called jolt, surge, and lurch.
Multi-motion	Performing the motion controls in parallel using both of the primary periodic task and the priority-5 periodic task.

A-5-3 EtherCAT Communications

Term	Description
CAN application protocol over Ether- CAT(CoE)	A CAN application protocol service implemented on EtherCAT.
CAN in Automation(CiA)	CiA is the international users' and manufacturers' group that develops and supports higher-layer protocols.
EtherCAT Technology Group	The ETG is a global organization in which OEM, End Users and Technology Providers join forces to support and promote the further technology development.
Object	An abstract representation of a particular component within a device, which consists of data, parameters, and methods.
Object Dictionary	A data structure addressed by Index and Subindex that contains description of data type objects, communications objects and application objects.
Process Data	Collection of application objects designated to be transferred cyclically or acyclically for the purpose of measurement and control.
Process Data Object	A process data (I/O data) object that exchanges data at regular periods with CoE.
Service Data Object	CoE asynchronous mailbox communications where all objects in the object dictionary can be read and written.
Receive PDO	A process data object received by an EtherCAT slave.
Transmit PDO	A process data object sent from an EtherCAT slave.
Device Profile	A collection of device dependent information and functionality providing consistency between similar devices of the same device type.

A-6 Version Information

This section describes the functions that are supported for each unit version. Refer to the *NJ/NX-series CPU Unit Software User's Manual* (Cat. No. W501) for the relationship between the unit versions of CPU Units and the Sysmac Studio versions. Refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508) for version information on the motion control instructions.

Motion Control Functions That Were Added for Unit Version 1.01

Version 1.02 or higher of the Sysmac Studio is required to use the functions that were added for unit version 1.01 of the CPU Unit.

Function	Outline
Changing the axes in an axes group	You can use the MC_ChangeAxesInGroup (Change Axes in Group) instruction to temporarily change the Composition Axes axes group parameter for an axes group.
Reading axes group positions	You can use the MC_GroupReadPosition (Read Axes Group Position) instruction to read the command current positions and the actual current positions of an axes group.
Axes group cyclic synchronous abso- lute positioning	You can use the MC_GroupSyncMoveAboslute (Axes Group Cyclic Synchronous Absolute Positioning) instruction to cyclically output the specified target positions for the axes.
Controllable Servo Drives	Support was added for OMRON G5-series Linear Motors/Drives with Built-in EtherCAT Communications Linear Motor Types.

Motion Control Functions That Were Added for Unit Version 1.02

Version 1.03 or higher of the Sysmac Studio is required to use the functions that were added for unit version 1.02 of the CPU Unit.

No motion control functions were added for unit version 1.02, but the specifications of some instructions were improved. Refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508) for version information on the motion control instructions.

Motion Control Functions That Were Added for Unit Version 1.03

Version 1.04 or higher of the Sysmac Studio is required to use the functions that were added for unit version 1.03 of the CPU Unit.

Function	Overview
Cyclic synchronous absolute positioning	The MC_SyncMoveAbsolute (Cyclic Synchronous Absolute Posi- tioning) instruction can be used to output a command position each control period in Position Control Mode.
Homing with parameters	The MC_HomeWithParameter (Home with Parameters) instruction can be used to specify the homing parameters and operate the motor to determine home. It uses the limit signals, home proximity signal, and home signal.

Motion Control Functions That Were Added for Unit Version 1.04

Version 1.05 or higher of the Sysmac Studio is required to use the functions that were added for unit version 1.04 of the CPU Unit.

Function	Overview
Changing axis use	You can use the MC_ChangeAxisUse (Change Axis Use) instruc- tion to temporarily change the setting of the Axis Use axis parame- ter.

Motion Control Functions That Were Added for Unit Version 1.05

Version 1.06 or higher of the Sysmac Studio is required to use the functions that were added for unit version 1.05 of the CPU Unit.

Function	Overview
Start velocity	You can set the initial velocity when axis motion starts.
Input signal logic inversion	You can inverse the logic of immediate stop input signal, positive limit input signal, negative limit input signal, or home proximity input signal.

Note With a CPU Unit with unit version 1.05 or later, you can perform motion control by assigning axes to NXseries Position Interface Units.

Motion Control Specifications That Were Added or Changed for Unit Version 1.06

Version 1.07 or higher of the Sysmac Studio is required to use the performance specifications and function specifications that were added or changed for unit version 1.06 of the CPU Unit.

Item	Overview
Maximum number of controlled axes	The maximum number of controlled axes for NJ301-
	(No change in maximum number of used real axes.)
Maximum number of axes for single-axis control	The maximum number of axes for single-axis control for NJ301-
	(No change in maximum number of used real axes.)
Enable digital cam switch	You can use the MC_DigitalCamSwitch (Enable Digital Cam Switch) instruction to turn the digital outputs ON or OFF according to the axis position.
Time stamp to axis position calculation	You can use the MC_TimeStampToPos (Time Stamp to Axis Posi- tion Calculation) instruction to calculate the position of the axis for the specified time stamp.
Adding blending options to Start Cam Operation	The blending options were added to Buffer Mode Selection for the MC_CamIn (Start Cam Operation) instruction.
_sMC_POSITION_REF	You can use this data type to display the path of user coordinate systems in 3D Motion Monitor Display Mode.

Α

Motion Control Functions That Were Added or Changed for Unit Version 1.08

Use Sysmac Studio version 1.09 or higher when you use the functions that were added or changed for the CPU Unit with unit version 1.08.

Function	Overview
Generating cam tables	You can use the MC_GenerateCamTable (Generate Cam Table) instruction and generate the cam table according to the cam property and cam node specified for the input parameters.
Changing axis parameters	You can access and change the axis parameters from the MC_WriteAxisParameter (Write Axis Parameters) instruction and the MC_ReadAxisParameter (Read Axis Parameters) instruction in the user program.
Assigning device variables	You can assign the device variables to the I/O ports of slaves and Units that are assigned to the Axis Variables. ^{*1} Refer to <i>2-4-2 Relationship between EtherCAT Master Function Module and MC Function Module</i> for details.

*1 This function is independent of the version of the CPU Unit. Using the Sysmac Studio version 1.09 or higher allows you use this assignment function.

Motion Control Functions That Were Added or Changed for Unit Version 1.09

Version 1.10 or higher of the Sysmac Studio is required to use the functions that were added for unit version 1.09 of the CPU Unit.

No motion control functions were added for unit version 1.09, but the specifications of some instructions were improved. Refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508) for version information on the motion control instructions.

Motion Control Functions That Were Added or Changed for Unit Version 1.10

Version 1.12 or higher of the Sysmac Studio is required to use the following functions that were added for unit version 1.10 of the CPU Unit.

Function	Overview
Slave axis position compensation	This function compensates the position of the slave axis currently in synchronized control.
Change in the blending operation	The maximum acceleration/deceleration rate is used and the blending operation is continued even if you set the Accelera- tion/Deceleration Over parameter to <i>Use rapid acceleration/decel-</i> <i>eration. (Blending is changed to Buffered.)</i> or <i>Minor fault stop.</i>
Home definition timing for absolute encoders	In addition to the existing home definition timing, home is also defined when EtherCAT slave process data communications change from a non-established to an established state.
Current position when process data com- munications are in a non-established state	The actual current position and the command current position axis variables will contain the actual current position output that is just before process data communications change to a non-established state.
With or without Modes of Operation (6060 hex) and Modes of Operation Display (6061 hex) mapping	The operation depends on whether Modes of Operation (6060 hex) and Modes of Operation Display (6061 hex) are mapped.
PDS state control method	You can set the state to which PDS state changes when Servo is turned OFF by the MC_Power instruction.

Function	Overview
Main circuit power supply OFF detection	You can select whether to detect the OFF state of the main circuit power supply while the Servo is ON or when the Servo ON com- mand is sent.

Version 1.13 or higher of the Sysmac Studio is required to use the following functions that were added for unit version 1.10 of the CPU Unit.

Function	Overview
Synchronized control in multi-motion	You can execute the synchronized control instructions between axes assigned to different tasks in the multi-motion.



Index

Index

Α

aborting	. 9-48.	9-65
absolute encoder	,	
Absolute Encoder Origin Position Offset		8-15
applicable Servomotors		
homing		
Rotary Mode		
setup		
absolute positioning		
acceleration and deceleration		
acceleration and deceleration rates	•••••	0.00
unit		9-35
acceleration rate		
changing		9-44
Acceleration Warning Value		
Acceleration/Deceleration Over		
Actual Current Position		
Actual Current Torque		
Actual Current Velocity		
actual position		
actual velocity		
Actual Velocity Filter Time Constant		
assumed causes		
axes		
specifying in user program		
Axes Group Basic Settings		
Axes Group Command Values		
Axes Group Control Status		
Axes Group Disabled		
Axes Group Error Status		
Axes Group Errors		11-8
axes group errors		
resetting		
Axes Group Minor Fault		
Axes Group Minor Fault Code		
Axes Group Minor Fault Occurrence		
Axes Group Number		
Axes Group Observation		
Axes Group Observation Code		6-33
Axes Group Observation Occurrence		6-33
Axes Group Operation Settings		5-28
axes group parameters	. 3-19,	5-25
list		
axes group states		6-8
Deceleration Stopping		6-9
Error Deceleration Stopping		
Moving		
Standby		
Axes Group Status		
Axes Group Stop Method		
Axes Group Use		
Axes Group Variable Names		
Axes Group Variables		
introduction		

axes groups	3-18
enabling and disabling	9-54
introduction	3-18
specifying in user program	3-18, 3-22
Axis Basic Settings	5-6, 6-28
Axis Command Values	
Axis Current Value	6-27
Axis Disabled	6-25
Axis Error	11-8
Axis Error Status	
axis following error monitoring	
Axis Minor Fault	
Axis Minor Fault Code	
Axis Minor Fault Occurrence	
Axis Number	
Axis Numbers	
Axis Observation	
Axis Observation Code	6-28
Axis Observation Occurrence	
axis parameters	3-3, 5-4
introduction	
list	
Axis Ready-to-execute	
axis states	
Axis Disabled	6-6
Continuous Motion	
Coordinated Motion	
Deceleration Stopping	
Discrete Motion	
Error Deceleration Stopping	
Homing	
Stopped	
Synchronized Motion	
Axis Status	6-25
axis types	
Axis Use	
Axis Variables	
names	3-6
relationship to axis types	
В	
basic data types	6-21

С

cam block		9-16
	end point	
cam block	start point	9-16
cam curve)	9-16
cam data		9-16
loading	g and saving	9-20

cam data index9-17
cam data variables
cam end point9-16
cam operation9-15, 9-16
cam profile curves6-35, 9-16
names6-37
cam start point9-16
Cam table
Generate Cam Table9-22
cam table9-16
Cam Table File Save Busy6-24
cam table start position9-17
cam tables6-35, 9-18
data type9-19
names
saving9-20
specifications9-19
specifying in user program6-37
switching
updating properties
CAN application protocol over EtherCAT (CoE)2-18
circular interpolation
combining axes
Command Current Acceleration/Deceleration
Command Current Jerk
Command Current Position
Command Current Torque
Command Current Velocity
Command Direction
Command Interpolation Acceleration/ Deceleration6-33
Command Interpolation Velocity6-33
command position6-17, 9-32
command position6-17, 9-32 Command Pulse Count Per Motor Rotation5-10, 6-28
Command Pulse Count Per Motor Rotation5-10, 6-28 command velocity9-34
Command Pulse Count Per Motor Rotation5-10, 6-28
Command Pulse Count Per Motor Rotation5-10, 6-28 command velocity9-34
Command Pulse Count Per Motor Rotation5-10, 6-28 command velocity
Command Pulse Count Per Motor Rotation5-10, 6-28 command velocity
Command Pulse Count Per Motor Rotation5-10, 6-28command velocity9-34Command Velocity Saturation6-26Composition5-26, 6-34Composition Axes5-26
Command Pulse Count Per Motor Rotation5-10, 6-28command velocity9-34Command Velocity Saturation6-26Composition5-26, 6-34Composition Axes5-26Composition Axis for Axis A06-34
Command Pulse Count Per Motor Rotation5-10, 6-28command velocity9-34Command Velocity Saturation6-26Composition5-26, 6-34Composition Axes5-26Composition Axis for Axis A06-34Composition Axis for Axis A16-34Composition Axis for Axis A26-34
Command Pulse Count Per Motor Rotation5-10, 6-28command velocity9-34Command Velocity Saturation6-26Composition5-26, 6-34Composition Axes5-26Composition Axis for Axis A06-34Composition Axis for Axis A16-34Composition Axis for Axis A26-34Composition Axis for Axis A36-34
Command Pulse Count Per Motor Rotation5-10, 6-28command velocity9-34Command Velocity Saturation6-26Composition5-26, 6-34Composition Axes5-26Composition Axis for Axis A06-34Composition Axis for Axis A16-34Composition Axis for Axis A26-34Composition Axis for Axis A36-34Composition Axis for Axis A36-34Composition Axis for Axis A36-34Composition Axis for Axis A36-34Composition Axis for Axis A36-34Connecting acceleration9-17
Command Pulse Count Per Motor Rotation5-10, 6-28command velocity9-34Command Velocity Saturation6-26Composition5-26, 6-34Composition Axes5-26Composition Axis for Axis A06-34Composition Axis for Axis A16-34Composition Axis for Axis A26-34Composition Axis for Axis A36-34Composition Axis for Axis A16-34Composition Axis for Axis A26-34Composition Axis for Axis A36-34Connecting acceleration9-17connecting velocity9-17
Command Pulse Count Per Motor Rotation5-10, 6-28command velocity9-34Command Velocity Saturation6-26Composition5-26, 6-34Composition Axes5-26Composition Axis for Axis A06-34Composition Axis for Axis A16-34Composition Axis for Axis A26-34Composition Axis for Axis A36-34Composition Axis for Axis A36-34Composition Axis for Axis A36-34Connecting acceleration9-17connecting velocity9-17Continuous Motion6-25
Command Pulse Count Per Motor Rotation5-10, 6-28command velocity9-34Command Velocity Saturation6-26Composition5-26, 6-34Composition Axes5-26Composition Axis for Axis A06-34Composition Axis for Axis A16-34Composition Axis for Axis A26-34Composition Axis for Axis A36-34Composition Axis for Axis A36-34Composition Axis for Axis A36-34Connecting acceleration9-17connecting velocity9-17Continuous Motion6-25Coordinated Motion6-25
Command Pulse Count Per Motor Rotation5-10, 6-28command velocity9-34Command Velocity Saturation6-26Composition5-26, 6-34Composition Axes5-26Composition Axis for Axis A06-34Composition Axis for Axis A16-34Composition Axis for Axis A26-34Composition Axis for Axis A36-34Composition Axis for Axis A36-34Connecting acceleration9-17connecting velocity9-17Continuous Motion6-25Coordinated Motion6-25Correction Allowance Ratio5-29
Command Pulse Count Per Motor Rotation5-10, 6-28command velocity9-34Command Velocity Saturation6-26Composition5-26, 6-34Composition Axes5-26Composition Axis for Axis A06-34Composition Axis for Axis A16-34Composition Axis for Axis A26-34Composition Axis for Axis A36-34Composition Axis for Axis A36-34Composition Axis for Axis A36-34Connecting acceleration9-17connecting velocity9-17Continuous Motion6-25Coordinated Motion6-25Correction Allowance Ratio5-29Count Mode5-18
Command Pulse Count Per Motor Rotation
Command Pulse Count Per Motor Rotation5-10, 6-28command velocity9-34Command Velocity Saturation6-26Composition5-26, 6-34Composition Axes5-26Composition Axis for Axis A06-34Composition Axis for Axis A16-34Composition Axis for Axis A26-34Composition Axis for Axis A36-34Composition Axis for Axis A36-34Composition Axis for Axis A36-34Connecting acceleration9-17connecting velocity9-17Continuous Motion6-25Correction Allowance Ratio5-29Count Mode5-18Count mode6-28current position6-28
Command Pulse Count Per Motor Rotation5-10, 6-28command velocity9-34Command Velocity Saturation6-26Composition5-26, 6-34Composition Axes5-26Composition Axis for Axis A06-34Composition Axis for Axis A16-34Composition Axis for Axis A26-34Composition Axis for Axis A36-34Composition Axis for Axis A26-34Composition Axis for Axis A36-34Connecting acceleration9-17connecting velocity9-17Continuous Motion6-25Correction Allowance Ratio5-29Count Mode5-18Count mode6-28current position9-73
Command Pulse Count Per Motor Rotation5-10, 6-28command velocity9-34Command Velocity Saturation6-26Composition5-26, 6-34Composition Axes5-26Composition Axis for Axis A06-34Composition Axis for Axis A16-34Composition Axis for Axis A26-34Composition Axis for Axis A36-34Composition Axis for Axis A36-34Composition Axis for Axis A36-34Connecting acceleration9-17connecting velocity9-17Continuous Motion6-25Coordinated Motion6-25Count Mode5-18Count Mode5-18Count mode6-28current position9-73Cyclic Synchronous Position (CSP) Control Mode6-26
Command Pulse Count Per Motor Rotation5-10, 6-28command velocity9-34Command Velocity Saturation6-26Composition5-26, 6-34Composition Axes5-26Composition Axis for Axis A06-34Composition Axis for Axis A16-34Composition Axis for Axis A26-34Composition Axis for Axis A36-34Composition Axis for Axis A36-34Connecting acceleration9-17connecting velocity9-17Continuous Motion6-25Coordinated Motion5-29Count Mode5-18Count mode6-28current position9-73Cyclic Synchronous Position (CSP) Control Mode6-26cyclic synchronous positioning9-6
Command Pulse Count Per Motor Rotation5-10, 6-28command velocity9-34Command Velocity Saturation6-26Composition5-26, 6-34Composition Axes5-26Composition Axis for Axis A06-34Composition Axis for Axis A16-34Composition Axis for Axis A26-34Composition Axis for Axis A36-34Composition Axis for Axis A36-34Composition Axis for Axis A36-34Connecting acceleration9-17connecting velocity9-17Continuous Motion6-25Correction Allowance Ratio5-29Count Mode5-18Count mode6-28current position9-73Cyclic Synchronous Position (CSP) Control Mode6-26cyclic Synchronous positioning9-6Cyclic Synchronous Torque (CST) Control Mode6-26
Command Pulse Count Per Motor Rotation5-10, 6-28 command velocity
Command Pulse Count Per Motor Rotation5-10, 6-28command velocity9-34Command Velocity Saturation6-26Composition5-26, 6-34Composition Axes5-26Composition Axis for Axis A06-34Composition Axis for Axis A16-34Composition Axis for Axis A26-34Composition Axis for Axis A36-34Composition Axis for Axis A36-34Composition Axis for Axis A36-34Connecting acceleration9-17connecting velocity9-17Continuous Motion6-25Correction Allowance Ratio5-29Count Mode5-18Count mode6-28current position9-73Cyclic Synchronous Position (CSP) Control Mode6-26cyclic Synchronous positioning9-6Cyclic Synchronous Torque (CST) Control Mode6-26

D

data types6-21

Ε

electronic gear ratio (unit conversion formula)	5-11
Enabling Digital Cam Switch	
encoder axis	3-2, 5-8
Encoder Type	5-18, 5-20
enumerated data types	6-22
error confirmation	11-4
Error Deceleration Stopping	6-25, 6-32
error status variables	11-6
EtherCAT	1-2
EtherCAT communications and motion control	
EtherCAT Master Function Module	2-2
event codes	11-13
event levels	11-8
event names	
events	11-2, 11-13
Execution ID	6-28, 6-33
External Latch Input 1	6-26
External Latch Input 2	6-26

F

finite length axis	5-18
following error counter reset	
following error monitoring	9-77
Following Error Over Value	5-18
Following Error Warning Value	5-18
function blocks for PLCopen® motion control	6-4
function specifications	1-9

G

gear operation	
Generating Cam Table	6-24
Get Motion Control Error Status instruction	11-6
GetMCError (Get Motion Control Error Status)	11-6

Η

high-speed homing	8-17
home	8-2

Home Defined	6-26
Home Input	6-26
Home Input Detection Direction	5-21, 8-8
Home Input Mask Distance	. 5-22, 8-10
Home Input Signal	5-21, 8-7
Home Offset	. 5-22, 8-10
Home Proximity Input	6-26
Homing	6-25
homing	8-2
Homing Acceleration	5-21, 8-9
Homing Approach Velocity	5-21, 8-9
Homing Compensation Value	. 5-22, 8-11
Homing Compensation Velocity	. 5-22, 8-11
Homing Deceleration	5-22, 8-9
Homing Holding Time	. 5-22, 8-11
Homing Jerk	. 5-22, 8-10
Homing Method	5-21, 8-6
homing parameters	8-5
Homing Settings	5-21
Homing Start Direction	5-21, 8-8
Homing Velocity	5-21, 8-9

I

Idle	6-32
Immediate Stop Input	6-26
Immediate Stop Input Stop Method	5-17
immediate stop of command value	9-10
immediate stop of command value and error reset	9-10
immediate stop of command value and servo OFF	9-10
In Home Position	6-26
indicators	11-4
infinite length axis	5-18
information	11-8
in-position check	9-79
In-position Check Time	5-14
In-position Range	5-14
In-position Waiting6-26,	6-32
Interpolation Acceleration Warning Value	5-28
Interpolation Acceleration/Deceleration Over	5-28
Interpolation Deceleration Warning Value	5-29
Interpolation Velocity Warning Value	5-28
interrupt feeding	9-5
invalid cam data	

J

jerk jerk unit jogging	
jogging	

Κ

L

latching	
Limit Input Stop Method	

Μ

Main Power	
major fault	
manual operation	
master axis	
master axis phase shift	
master following distance	
Maximum Acceleration	
Maximum Deceleration	
Maximum Interpolation Acceleration	
Maximum Interpolation Deceleration	
Maximum Interpolation Velocity	5-28
Maximum Jog Velocity	
Maximum Negative Torque Limit	
maximum number of cam data	9-16
Maximum Positive Torque Limit	5-17
Maximum Velocity	
MC Common Error Status	11-6
MC Common Errors	
MC Common Minor Fault	6-24
MC Common Minor Fault Code	6-24
MC Common Minor Fault Occurrence	6-24
MC Common Observation	6-24
MC Common Observation Code	6-24
MC Common Observation Occurrence	6-24
MC Common Partial Fault	6-24
MC Common Partial Fault Code	6-24
MC Common Partial Fault Occurrence	6-24
MC Common Status	6-24
MC Common Variable	6-24
MC Error Status	11-6
MC Run	6-24
MC Test Run4-	2, 6-24
MC Test Run functions	
_MC_AX[*].Scale.CountMode	
MC_AX[*].Scale.MaxPos	
MC_AX[*].Scale.MinPos	
MC_AX[0-63].Act.Pos (Actual Current Position)	
MC_AX[0-63].Act.TimeStamp (Time Stamp)	
_MC_AX[0-63].Act.Trq (Actual Current Torque)	
_MC_AX[0-63].Act.Vel (Actual Current Velocity)	
MC_AX[0-63].Cfg.AxEnable (Axis Use)	
_MC_AX[0-63].Cfg.AxNo (Axis Number)	
_MC_AX[0-63].Cfg.AxType (Axis Type)	
_MC_AX[0-63].Cfg.NodeAddress (Node Address)	
_MC_AX[0-63].Cmd.AccDec	
(Command Current Acceleration/Deceleration)	6-27
_MC_AX[0-63].Cmd.Jerk (Command Current Jerk)	
_MC_AX[0-63].Cmd.Pos	
(Command Current Position)	6-27
_MC_AX[0-63].Cmd.Trq	
(Command Current Torque)	6-27
_MC_AX[0-63].Cmd.Vel	
(Command Current Velocity)	6-27

_MC_AX[0-63].Details.Homed (Home Defined)
_MC_AX[0-63].Details.Idle (Idle)6-26 _MC_AX[0-63].Details.InHome (In Home Position)6-26
_MC_AX[0-63].Details.InPosWaiting
(In-position Waiting)
_MC_AX[0-63].Details.VelLimit
(Command Velocity Saturation)
_MC_AX[0-63].Dir.Nega (Negative Direction)
_MC_AX[0-63].Dir.Posi (Positive Direction)6-26
_MC_AX[0-63].DrvStatus.CSP
(Cyclic Synchronous Position (CSP)
Control Mode)
_MC_AX[0-63].DrvStatus.CST
(Cyclic Synchronous Torque (CST)
Control Mode)
_MC_AX[0-63].DrvStatus.CSV
(Cyclic Synchronous Velocity (CSV)
Control Mode)
_MC_AX[0-63].DrvStatus.DrvAlarm
(Drive Error Input)
_MC_AX[0-63].DrvStatus.DrvWarning
(Drive Warning Input)
_MC_AX[0-63].DrvStatus.Home (Home Input)6-26
_MC_AX[0-63].DrvStatus.HomeSw
(Home Proximity Input)6-26
_MC_AX[0-63].DrvStatus.ILA
(Drive Internal Limiting)6-26
_MC_AX[0-63].DrvStatus.ImdStop
(Immediate Stop Input)6-26
_MC_AX[0-63].DrvStatus.Latch1
(External Latch Input 1)6-26
_MC_AX[0-63].DrvStatus.Latch2
(External Latch Input 2)6-26
_MC_AX[0-63].DrvStatus.MainPower (Main Power)6-26
_MC_AX[0-63].DrvStatus.N_OT
(Negative Limit Input)6-26
_MC_AX[0-63].DrvStatus.P_OT
(Positive Limit Input)
(Positive Limit Input)6-26
(Positive Limit Input)
(Positive Limit Input) 6-26 _MC_AX[0-63].DrvStatus.Ready (Servo Ready) 6-26 _MC_AX[0-63].DrvStatus.ServoOn (Servo ON) 6-26 _MC_AX[0-63].DrvStatus.ServoOn (Servo ON) 6-26 _MC_AX[0-63].MFaultLvl.Active 6-28 _MC_AX[0-63].MFaultLvl.Code 6-28 _MC_AX[0-63].MFaultLvl.Code 6-28 _MC_AX[0-63].Obsr.Active 6-28 _MC_AX[0-63].Obsr.Active 6-28
(Positive Limit Input)
(Positive Limit Input) 6-26 _MC_AX[0-63].DrvStatus.Ready (Servo Ready) 6-26 _MC_AX[0-63].DrvStatus.ServoOn (Servo ON) 6-26 _MC_AX[0-63].DrvStatus.ServoOn (Servo ON) 6-26 _MC_AX[0-63].MFaultLvl.Active 6-28 _MC_AX[0-63].MFaultLvl.Code 6-28 _MC_AX[0-63].Obsr.Active 6-28 _MC_AX[0-63].Obsr.Active 6-28 _MC_AX[0-63].Obsr.Active 6-28 _MC_AX[0-63].Obsr.Code (Axis Observation Code) 6-28 _MC_AX[0-63].Obsr.Code (Axis Observation Code) 6-28
(Positive Limit Input)
(Positive Limit Input)6-26_MC_AX[0-63].DrvStatus.Ready (Servo Ready)6-26_MC_AX[0-63].DrvStatus.ServoOn (Servo ON)6-26_MC_AX[0-63].MFaultLvl.Active6-28_MC_AX[0-63].MFaultLvl.Active6-28_MC_AX[0-63].MFaultLvl.Code6-28_MC_AX[0-63].Obsr.Active6-28_MC_AX[0-63].Obsr.Active6-28_MC_AX[0-63].Obsr.Active6-28_MC_AX[0-63].Obsr.Code (Axis Observation Code)6-28_MC_AX[0-63].Scale.Den(Work Travel Distance Per Motor Rotation)6-28_MC_AX[0-63].Scale.Num(Command Pulse Count Per Motor Rotation)6-28_MC_AX[0-63].Scale.Units (Unit of Display)6-28_MC_AX[0-63].Status.Continuous6-25_MC_AX[0-63].Status.Coordinated6-25
(Positive Limit Input)6-26_MC_AX[0-63].DrvStatus.Ready (Servo Ready)6-26_MC_AX[0-63].DrvStatus.ServoOn (Servo ON)6-26_MC_AX[0-63].MFaultLvl.Active6-28_MC_AX[0-63].MFaultLvl.Active6-28_MC_AX[0-63].MFaultLvl.Code6-28_MC_AX[0-63].Obsr.Active6-28_MC_AX[0-63].Obsr.Active6-28_MC_AX[0-63].Obsr.Active6-28_MC_AX[0-63].Obsr.Code (Axis Observation Code)6-28_MC_AX[0-63].Scale.Den6-28_MC_AX[0-63].Scale.Den6-28_MC_AX[0-63].Scale.Num6-28_MC_AX[0-63].Scale.Num6-28_MC_AX[0-63].Scale.Num6-28_MC_AX[0-63].Scale.Units (Unit of Display)6-28_MC_AX[0-63].Status.Continuous6-25_MC_AX[0-63].Status.Coordinated6-25_MC_AX[0-63].Status.Disabled (Axis Disabled)6-25
(Positive Limit Input)6-26_MC_AX[0-63].DrvStatus.Ready (Servo Ready)6-26_MC_AX[0-63].DrvStatus.ServoOn (Servo ON)6-26_MC_AX[0-63].MFaultLvl.Active6-28_MC_AX[0-63].MFaultLvl.Active6-28_MC_AX[0-63].MFaultLvl.Code6-28_MC_AX[0-63].Obsr.Active6-28_MC_AX[0-63].Obsr.Active6-28_MC_AX[0-63].Obsr.Active6-28_MC_AX[0-63].Obsr.Code (Axis Observation Code)6-28_MC_AX[0-63].Scale.Den(Work Travel Distance Per Motor Rotation)6-28_MC_AX[0-63].Scale.Num(Command Pulse Count Per Motor Rotation)6-28_MC_AX[0-63].Scale.Units (Unit of Display)6-28_MC_AX[0-63].Status.Continuous6-25_MC_AX[0-63].Status.Coordinated6-25

_MC_AX[0-63].Status.ErrorStop	
(Error Deceleration Stopping)	6-25
_MC_AX[0-63].Status.Homing (Homing)	
	0-25
_MC_AX[0-63].Status.Ready	0.05
(Axis Ready-to-execute)	
_MC_AX[0-63].Status.Standstill (Standstill)	6-25
_MC_AX[0-63].Status.Stopping	
(Deceleration Stopping)	6-25
_MC_AX[0-63].Status.Synchronized	
(Synchronized Motion)	6-25
_MC_AX_ErrSta (MC Error Status)	11-6
_MC_COM (MC Common Variable)	6-24
MC_COM.MFaultLvl.Active	
(MC Common Minor Fault Occurrence)	6-24
MC COM.MFaultLvI.Code	
(MC Common Minor Fault Code)	6-24
MC COM.Obsr.Active	0-24
	0.04
(MC Common Observation Occurrence)	6-24
_MC_COM.Obsr.Code	
(MC Common Observation Code)	6-24
_MC_COM.PFaultLvI.Active	
(MC Common Partial Fault Occurrence)	6-24
_MC_COM.PFaultLvI.Code	
(MC Common Partial Fault Code)	6-24
_MC_COM.Status.CamTableBusy	
(Cam Table Busy)	6-24
_MC_COM.Status.RunMode (MC Run)	
_MC_COM.Status.TestMode (MC Test Run)	
_MC_ComErrSta (MC Common Error Status)	
_MC_ErrSta (Axis Error Status)	
	11-0
	<u> </u>
_MC_GRP[0-31] (Axes Group Variable)	
_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) .	6-33
_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number)	6-33
_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec	6-33
_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number)	6-33
_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec	6-33 6-33
_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation	6-33 6-33
_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel	6-33 6-33 6-33
_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity)	6-33 6-33 6-33 6-33
_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity) _MC_GRP[0-31].Details.Idle (Idle)	6-33 6-33 6-33 6-33
_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity) _MC_GRP[0-31].Details.Idle (Idle) _MC_GRP[0-31].Details.InPosWaiting	6-33 6-33 6-33 6-33 6-32
_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity) _MC_GRP[0-31].Details.Idle (Idle) _MC_GRP[0-31].Details.InPosWaiting (In-Position Waiting)	6-33 6-33 6-33 6-33 6-32
_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity) _MC_GRP[0-31].Details.Idle (Idle) _MC_GRP[0-31].Details.InPosWaiting (In-Position Waiting) _MC_GRP[0-31].Kinematics.Axis[0]	6-33 6-33 6-33 6-33 6-32 6-32
_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity) _MC_GRP[0-31].Details.Idle (Idle) _MC_GRP[0-31].Details.InPosWaiting (In-Position Waiting) _MC_GRP[0-31].Kinematics.Axis[0] (Composition Axis for Axis A0)	6-33 6-33 6-33 6-33 6-32 6-32
<pre>_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity) _MC_GRP[0-31].Details.Idle (Idle) _MC_GRP[0-31].Details.Idle (Idle) _MC_GRP[0-31].Details.InPosWaiting (In-Position Waiting) _MC_GRP[0-31].Kinematics.Axis[0] (Composition Axis for Axis A0) _MC_GRP[0-31].Kinematics.Axis[1]</pre>	6-33 6-33 6-33 6-33 6-32 6-32 6-34
<pre>_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity) _MC_GRP[0-31].Details.Idle (Idle) _MC_GRP[0-31].Details.InPosWaiting (In-Position Waiting) _MC_GRP[0-31].Kinematics.Axis[0] (Composition Axis for Axis A0) _MC_GRP[0-31].Kinematics.Axis[1] (Composition Axis for Axis A1)</pre>	6-33 6-33 6-33 6-33 6-32 6-32 6-34
<pre>_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity) _MC_GRP[0-31].Details.Idle (Idle) _MC_GRP[0-31].Details.InPosWaiting (In-Position Waiting) _MC_GRP[0-31].Kinematics.Axis[0] (Composition Axis for Axis A0) _MC_GRP[0-31].Kinematics.Axis[1] (Composition Axis for Axis A1) _MC_GRP[0-31].Kinematics.Axis[2]</pre>	6-33 6-33 6-33 6-33 6-32 6-34 6-34
<pre>_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity) _MC_GRP[0-31].Details.Idle (Idle) _MC_GRP[0-31].Details.InPosWaiting (In-Position Waiting) _MC_GRP[0-31].Kinematics.Axis[0] (Composition Axis for Axis A0) _MC_GRP[0-31].Kinematics.Axis[1] (Composition Axis for Axis A1) _MC_GRP[0-31].Kinematics.Axis[2] (Composition Axis for Axis A2)</pre>	6-33 6-33 6-33 6-33 6-32 6-34 6-34
<pre>_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity) _MC_GRP[0-31].Details.Idle (Idle) _MC_GRP[0-31].Details.InPosWaiting (In-Position Waiting) _MC_GRP[0-31].Kinematics.Axis[0] (Composition Axis for Axis A0) _MC_GRP[0-31].Kinematics.Axis[1] (Composition Axis for Axis A1) _MC_GRP[0-31].Kinematics.Axis[2]</pre>	6-33 6-33 6-33 6-33 6-32 6-34 6-34
<pre>_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity) _MC_GRP[0-31].Details.Idle (Idle) _MC_GRP[0-31].Details.InPosWaiting (In-Position Waiting) _MC_GRP[0-31].Kinematics.Axis[0] (Composition Axis for Axis A0) _MC_GRP[0-31].Kinematics.Axis[1] (Composition Axis for Axis A1) _MC_GRP[0-31].Kinematics.Axis[2] (Composition Axis for Axis A2)</pre>	6-33 6-33 6-33 6-32 6-32 6-34 6-34 6-34
<pre>_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity) _MC_GRP[0-31].Details.Idle (Idle) _MC_GRP[0-31].Details.InPosWaiting (In-Position Waiting) _MC_GRP[0-31].Kinematics.Axis[0] (Composition Axis for Axis A0) _MC_GRP[0-31].Kinematics.Axis[1] (Composition Axis for Axis A1) _MC_GRP[0-31].Kinematics.Axis[2] (Composition Axis for Axis A2) _MC_GRP[0-31].Kinematics.Axis[3]</pre>	6-33 6-33 6-33 6-32 6-32 6-34 6-34 6-34
 _MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity) _MC_GRP[0-31].Details.Idle (Idle) _MC_GRP[0-31].Details.InPosWaiting (In-Position Waiting) _MC_GRP[0-31].Kinematics.Axis[0] (Composition Axis for Axis A0) _MC_GRP[0-31].Kinematics.Axis[1] (Composition Axis for Axis A1) _MC_GRP[0-31].Kinematics.Axis[2] (Composition Axis for Axis A2) _MC_GRP[0-31].Kinematics.Axis[3] (Composition Axis for Axis A3) _MC_GRP[0-31].Kinematics.Axis[3] 	6-33 6-33 6-33 6-32 6-32 6-34 6-34 6-34 6-34
<pre>_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity) _MC_GRP[0-31].Details.Idle (Idle) _MC_GRP[0-31].Details.InPosWaiting (In-Position Waiting) _MC_GRP[0-31].Kinematics.Axis[0] (Composition Axis for Axis A0) _MC_GRP[0-31].Kinematics.Axis[1] (Composition Axis for Axis A1) _MC_GRP[0-31].Kinematics.Axis[2] (Composition Axis for Axis A2) _MC_GRP[0-31].Kinematics.Axis[3] (Composition Axis for Axis A3) _MC_GRP[0-31].Kinematics.GrpType (Composition)</pre>	6-33 6-33 6-33 6-32 6-32 6-34 6-34 6-34 6-34
<pre>_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity) _MC_GRP[0-31].Details.Idle (Idle) _MC_GRP[0-31].Details.InPosWaiting (In-Position Waiting) _MC_GRP[0-31].Kinematics.Axis[0] (Composition Axis for Axis A0) _MC_GRP[0-31].Kinematics.Axis[1] (Composition Axis for Axis A1) _MC_GRP[0-31].Kinematics.Axis[2] (Composition Axis for Axis A2) _MC_GRP[0-31].Kinematics.Axis[3] (Composition Axis for Axis A3) _MC_GRP[0-31].Kinematics.GrpType (Composition) _MC_GRP[0-31].MFaultLvI.Active</pre>	6-33 6-33 6-33 6-33 6-32 6-34 6-34 6-34 6-34 6-34
<pre>_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity) _MC_GRP[0-31].Details.Idle (Idle) _MC_GRP[0-31].Details.InPosWaiting (In-Position Waiting) _MC_GRP[0-31].Kinematics.Axis[0] (Composition Axis for Axis A0) _MC_GRP[0-31].Kinematics.Axis[1] (Composition Axis for Axis A1) _MC_GRP[0-31].Kinematics.Axis[2] (Composition Axis for Axis A2) _MC_GRP[0-31].Kinematics.Axis[3] (Composition Axis for Axis A3) _MC_GRP[0-31].Kinematics.GrpType (Composition) _MC_GRP[0-31].MFaultLvI.Active (Axes Group Minor Fault Occurrence)</pre>	6-33 6-33 6-33 6-33 6-32 6-34 6-34 6-34 6-34 6-34
<pre>_MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity) _MC_GRP[0-31].Details.Idle (Idle) _MC_GRP[0-31].Details.InPosWaiting (In-Position Waiting) _MC_GRP[0-31].Kinematics.Axis[0] (Composition Axis for Axis A0) _MC_GRP[0-31].Kinematics.Axis[1] (Composition Axis for Axis A1) _MC_GRP[0-31].Kinematics.Axis[2] (Composition Axis for Axis A2) _MC_GRP[0-31].Kinematics.Axis[3] (Composition Axis for Axis A3) _MC_GRP[0-31].Kinematics.GrpType (Composition) _MC_GRP[0-31].MFaultLvI.Active (Axes Group Minor Fault Occurrence) _MC_GRP[0-31].MFaultLvI.Code</pre>	6-33 6-33 6-33 6-32 6-32 6-34 6-34 6-34 6-34 6-34
 _MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity) _MC_GRP[0-31].Details.Idle (Idle) _MC_GRP[0-31].Details.InPosWaiting (In-Position Waiting) _MC_GRP[0-31].Kinematics.Axis[0] (Composition Axis for Axis A0) _MC_GRP[0-31].Kinematics.Axis[1] (Composition Axis for Axis A1) _MC_GRP[0-31].Kinematics.Axis[2] (Composition Axis for Axis A2) _MC_GRP[0-31].Kinematics.Axis[3] (Composition Axis for Axis A3) _MC_GRP[0-31].Kinematics.GrpType (Composition) _MC_GRP[0-31].MFaultLvI.Active (Axes Group Minor Fault Occurrence) _MC_GRP[0-31].MFaultLvI.Code (Axes Group Minor Fault Code) 	6-33 6-33 6-33 6-32 6-32 6-34 6-34 6-34 6-34 6-34
 _MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity) _MC_GRP[0-31].Details.Idle (Idle) _MC_GRP[0-31].Details.InPosWaiting (In-Position Waiting) _MC_GRP[0-31].Kinematics.Axis[0] (Composition Axis for Axis A0) _MC_GRP[0-31].Kinematics.Axis[1] (Composition Axis for Axis A1) _MC_GRP[0-31].Kinematics.Axis[2] (Composition Axis for Axis A2) _MC_GRP[0-31].Kinematics.Axis[3] (Composition Axis for Axis A3)	6-33 6-33 6-33 6-32 6-32 6-34 6-34 6-34 6-34 6-34 6-33
 _MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity) _MC_GRP[0-31].Details.Idle (Idle) _MC_GRP[0-31].Details.InPosWaiting (In-Position Waiting) _MC_GRP[0-31].Kinematics.Axis[0] (Composition Axis for Axis A0) _MC_GRP[0-31].Kinematics.Axis[1] (Composition Axis for Axis A1) _MC_GRP[0-31].Kinematics.Axis[2] (Composition Axis for Axis A2) _MC_GRP[0-31].Kinematics.Axis[3] (Composition Axis for Axis A3) _MC_GRP[0-31].Kinematics.GrpType (Composition) _MC_GRP[0-31].MFaultLvI.Active (Axes Group Minor Fault Occurrence)	6-33 6-33 6-33 6-32 6-32 6-34 6-34 6-34 6-34 6-34 6-33
 _MC_GRP[0-31].Cfg.GrpEnable (Axes Group Use) . _MC_GRP[0-31].Cfg.GrpNo (Axes Group Number) _MC_GRP[0-31].Cmd.AccDec (Command Interpolation Acceleration/Deceleration) _MC_GRP[0-31].Cmd.Vel (Command Interpolation Velocity) _MC_GRP[0-31].Details.Idle (Idle) _MC_GRP[0-31].Details.InPosWaiting (In-Position Waiting) _MC_GRP[0-31].Kinematics.Axis[0] (Composition Axis for Axis A0) _MC_GRP[0-31].Kinematics.Axis[1] (Composition Axis for Axis A1) _MC_GRP[0-31].Kinematics.Axis[2] (Composition Axis for Axis A2) _MC_GRP[0-31].Kinematics.Axis[3] (Composition Axis for Axis A3)	6-33 6-33 6-33 6-32 6-32 6-34 6-34 6-34 6-34 6-34 6-33 6-33

_MC_GRP[0-31].Status.Disabled	
(Axes Group Disabled)6-3	2
_MC_GRP[0-31].Status.ErrorStop	
(Error Deceleration Stopping)6-3	32
_MC_GRP[0-31].Status.Moving (Moving)	2
_MC_GRP[0-31].Status.Ready (Ready to Execute) 6-3	2
_MC_GRP[0-31].Status.Standby (Standby) 6-3	2
_MC_GRP[0-31].Status.Stopping	
(Deceleration Stopping) 6-3	32
_MC_GRP_ErrSta (Axes Group Error Status) 11-	-6
minor fault 11-	-8
Modulo Maximum Position Setting Value 5-18, 5-2	20
Modulo Minimum Position Setting Value 5-18, 5-2	20
Motion Control Function Module2-	·2
motion control instructions	-4
Enable variable 6-1	2
exclusiveness of outputs 6-1	0
Execute variable 6-1	2
execution and status 6-1	0
input parameters6-1	0
multi-execution9-47, 9-6	5
operation of output variable Busy	1
operation of output variable CommandAborted 6-1	
operation of output variable Done	1
output status 6-1	
output variable Active6-1	
re-executing9-42, 9-6	
timing chart for multi-execution 6-1	
timing chart for re-execution6-1	
timing charts for enable-type instructions	
timing charts for execute-type instructions6-1	
motion control period 2-2	
motion control programs	
writing6-3	
Moving	
multi-axes coordinated control	
multi-execution of instructions9-47, 9-6	5

Ν

Negative Direction	6-26
Negative Limit Input	6-26
Negative Software Limit	5-18
Negative Torque Warning Value	5-14
Node Address	6-28
node addresses	5-9
null cam data	9-17
number of valid cam data	9-16

0

object dictionary	
operation direction	
specifying	9-38
current direction	9-39
negative direction	9-39
no direction specified	9-39
positive direction	9-38

shortest way	9-38
Operation Selection at Negative Limit Input	
Operation Selection at Positive Limit Input	5-21, 8-8
Operation Selection at Reversing	5-13
Operation Settings	5-13
original cam data	9-16
Other Operation Settings	5-17
overrides	9-12, 9-59

Ρ

partial fault	
performance specifications	1-6
Periodic task	2-4
periodic tasks	2-4
phase	9-16
phase pitch	
PLC Function Module	
PLCopen®	
Position Count Settings	
positioning gear operation	
positions	
types	
Positive Direction	
Positive Limit Input	6-26
Positive Software Limit	
Positive Torque Warning Value	
Primary period	
primary period	
primary periodic task	
process data communications cycle	
process data objects (PDOs) program-modified cam data	

R

Ready to Execute	6-32
re-executing instructions	9-42
re-execution of instructions	9-64
relative positioning	9-4
Rotary Mode	5-19

S

9-37
2-18
3-2, 5-8
5-20
6-26
6-26, 7-3
6-26
9-32
9-3
9-13
9-31
9-29
9-16
5-18

software limits9-76
sources11-8
Standby6-32
Standstill6-25
start mode9-17
stop priorities9-11
Stopping
stopping
due to errors or other problems
immediate stop input
limit inputs
MC_GroupImmediateStop instruction
MC_GroupStop instruction
MC_ImmediateStop instruction
MC_Stop instruction
Servo Drive input signals
stop method
stopping under multi-axes coordinated control
structure data types
superimpose corners
Synchronized Motion6-25
synchronous positioning9-24
system configuration1-3
system-defined variables6-19, 11-6
motion control6-19, 11-7
attributes6-22
tables6-24

Т

target position	
changing	9-42
excessive deceleration patterns	9-43
triangular control patterns	9-43
when a reverse turn occurs for	
the new command value	9-42
target velocity	
changing	9-44
task period	2-6
tasks	2-4
torque command	
changing	9-45
torque limit	9-74
transition disabled	
Transition Modes	9-68
travel distance	
changing	
trial operation	4-2
Troubleshooter	
troubleshooting	

U

Unit Conversion Settings	.5-10,	6-28
Unit of Display	.5-10,	6-28

V

valid cam data9-16

W

Work Travel Distance Per Motor Rotation5-10, 6-28

Ζ

Zero Position Range	5	-14
zones	9	-75

Index

OMRON Corporation Industrial Automation Company Tokyo, JAPAN

Contact: www.ia.omron.com

Regional Headquarters OMRON EUROPE B.V.

OMRON EUROPE B.V. Wegalaan 67-69, 2132 JD Hoofddorp The Netherlands Tel: (31)2356-81-300/Fax: (31)2356-81-388

OMRON ASIA PACIFIC PTE. LTD. No. 438A Alexandra Road # 05-05/08 (Lobby 2), Alexandra Technopark, Singapore 119967 Tel: (65) 6835-3011/Fax: (65) 6835-2711

OMRON ELECTRONICS LLC 2895 Greenspoint Parkway, Suite 200 Hoffman Estates, IL 60169 U.S.A Tel: (1) 847-843-7900/Fax: (1) 847-843-7787

OMRON (CHINA) CO., LTD. Room 2211, Bank of China Tower, 200 Yin Cheng Zhong Road, PuDong New Area, Shanghai, 200120, China Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200

Authorized Distributor:

© OMRON Corporation 2011 All Rights Reserved. In the interest of product improvement, specifications are subject to change without notice.

Cat. No. W507-E1-11