

Command List

Header code	RUN mode		Test mode	Setting mode	Name
	RUN	During change of setting			
KR	Yes	Yes	Yes	---	Reset control (maximum/minimum value resetting)
W%	Yes	Yes	Yes	---	Set value write (See Note 1)
W#	Yes	Yes	Yes	---	Set value write (only with bank) (See Note 2)
R%	Yes	Yes	Yes	---	Set value read (See Note 1)
R#	Yes	Yes	Yes	---	Set value read (only with bank) (See Note 2)
RH	Yes	Yes	---	---	Hold data read (See Note 3)
RX	Yes	Yes	Yes	---	Display value (PV) read
RU	Yes	Yes	Yes	---	Model data read
TS	Yes	Yes	Yes	Yes	Test

- Note**
1. Effective only in communication plus comparative output type.
 2. Effective only in K3NR, K3NP, and K3NC communication plus comparative output type.
 3. Not effective in K3NC.