

# Before Applying Power

## Terminator Designation

For the RS-422 and RS-485 Models, designate the Intelligent Signal Processor located at the right end of the transmission line as an end station by setting the terminator switch of that unit to ON. (End-station designation is not required for the RS-232C Model.)

