

About the Communications Function

The E5AK-T can be provided with a communications function that allows you to check and set controller parameters from a host computer. If the communications function is required, add on the communications unit.

For details on the communications function, refer to Chapter 6 Using the Communications Function

RS-232C

When using the communications function on the RS-232C interface, add on the communications unit (E53-AK01).

RS-422

When using the communications function on the RS-422 interface, add on the communications unit (E53-AK02).

RS-485

When using the communications function on the RS-485 interface, add on the communications unit (E53-AK03).