

Items to Be Checked First

First, check the following three items if the K3NV has any problems during operation.

1, 2, 3...

Power Supply

Be sure that power supplied to the K3NV is within the rated voltage range.

Wiring

Be sure that the K3NV is wired correctly.

Communications Conditions

If the model is a K3NV with the Communications Output Board, be sure that the baud rate and unit numbers are correct.

After checking and remedying the above items, if the K3NV still has problems during operation, check the error message.