

End Code List

End code		Contents
x 16 ¹	x 16 ⁰	
0	0	Normal completion
0	4	Address over (data overflow)
0	B	Not executable because of setting mode
0	C	Not executable because of test mode
1	0	Parity error
1	1	Framing error
1	2	Overflow error
1	3	FCS error
1	4	Format error (parameter length error, parameter error, data code error, data length error)
1	6	No corresponding command
2	0	Not executable due to sensor failure (K3NH), not executable due to startup compensation time function (K3NX)
2	1	Not executable due to Processor failure
2	2	No corresponding memory