

## **6-3 Maintenance Mode**

The set values of the K3NR can be initialized in maintenance mode. The operations of the K3NR in this mode are described below.