

HOLD

- The K3NV will stop the measurement if the HOLD input is ON.
- When the HOLD input is ON, the K3NV will retain the process value, output, and BCD data effective immediately before the HOLD input.
- The HOLD indicator is lit while HOLD input is ON.

