

## 4-1-2 Setting Procedures

- The K3NR has four modes: RUN mode for normal operations, Setting mode for initial parameter input, Protect mode for lock-out configuration, and Maintenance mode for initializing set values. The parameters that are accessible on any individual K3NR will vary depending on the Output Board installed. Refer to *Appendix D Available Parameters*.
- The K3NR is in RUN mode when the K3NR is turned on. Parameter settings in protect or setting mode are described below on the basis that the parameters are set for the first time.

For the operation in RUN mode, refer to *Section 5 Operations in RUN Mode*.

- The setting examples are provided on condition that the factory-set values of the K3NR have not been changed.