


4-2-3 Setting Value Menu (sUset)

s.bank	<u>Bank No. of Set Value</u>
sU*.hh	<u>HH Set Value</u>
sU*.h	<u>H Set Value</u>
sU*.l	<u>L Set Value</u>
sU*.ll	<u>LL Set Value</u>




FUNCTION



SETTING



REFERENCE



MODELS

- There are two basic methods for setting HH, H, L, and LL set values: by entering during RUN mode via the front-panel buttons, setting in Setting mode, or by the teaching function.

Setting	Setting range	Default
Set value bank	1 to 4	1
HH set value	-19,999 to 99999	99,999
H set value		99,999
L set value		-19999
LL set value		-19999

Set the decimal point position in the prescaling menu.

Refer to 6-1 Teaching Function.

- The menu is only available for the K3NR with Comparative Output Board.

SETTING EXAMPLE

Follow the steps described below to input the following.

Setting value bank = 2


HH setting value = "8000"

H setting value = "6000"


L setting value = "4000"

LL setting value = "2000"

Set Value LED Display Model




Basic Model




- 1, 2, 3...**
1. Press the Mode Key for more than one second while the sUset setting value menu is displayed. The s.bank setting value bank setting will be displayed.

Set Value LED Display Model




Basic Model




2. Press the Shift Key to display the set value 1 for changing. The PROG indicator will flash.

Set Value LED Display Model




Basic Model




3. Press the Up Key to set the value to 2. The input will be validated automatically if no change is made for five seconds. The s.bank setting value bank setting will be displayed again.

Note Press the Mode Key to enter the set value immediately. The sU2.hh HH setting value of bank 2 setting will be displayed for setting the next parameter.

Set Value LED Display Model




Basic Model




4. Press the Mode Key to display the sU2.hh HH setting value of bank 2 setting.

Set Value LED Display Model




Basic Model



5. Press the Shift Key to display the set value 99999 for changing. The PROG indicator will flash.

Set Value LED Display Model Basic Model



6. Press the Up and Shift Keys to set the value to 8000. The input will be validated automatically if no change is made for five seconds. The sU2.hh HH setting value of bank 2 setting will be displayed again.

Note Press the Mode Key to enter the set value immediately. The sU2.h H setting value of bank 2 setting will be displayed for setting the next parameter.

Set Value LED Display Model Basic Model



7. Press the Mode Key to display the sU2.h H setting value of bank 2 setting.

Set Value LED Display Model Basic Model



8. Press the Shift Key to display the set value 99999 for changing. The PROG indicator will flash.

Set Value LED Display Model Basic Model



9. Press the Up and Shift Keys to set the value to 6000. The input will be validated automatically if no change is made for five seconds. The sU2. h H setting value of bank 2 setting will be displayed again.

Note Press the Mode Key to enter the set value immediately. The sU2. 1 L setting value of bank 2 setting will be displayed for setting the next parameter.

Set Value LED Display Model Basic Model




10. Press the Mode Key to display the sU2.1 L setting value of bank 2 setting.

Set Value LED Display Model Basic Model



11. Press the Shift Key to display the set value -19999 for changing. The PROG indicator will flash.


Set Value LED Display Model Basic Model



12. Press the Up and Shift Keys to set the value to 4000. The input will be validated automatically if no change is made for five seconds. The sU2.1 L setting value of bank 2 setting will be displayed again.

Note Press the Mode Key to enter the input immediately. The sU2.1L LL setting value setting will be displayed for setting the next parameter.

Set Value LED Display Model Basic Model



13. Press the Mode Key to display the sU2.1L LL setting value of bank 2 setting.

Set Value LED Display Model Basic Model




14. Press the Mode Key to display the set value -19999 for changing. The PROG indicator will flash.

Set Value LED Display Model Basic Model



15. Press the Up and Shift Keys to set the value to 2000. The input will be validated automatically if no change is made for five seconds. The sU2.1L LL setting value setting will be displayed again.

Note Press the Mode Key to enter the set value immediately. The s.bank setting value bank setting will be displayed for setting the next parameter.



16. Press the Escape Key to display the sUset setting value menu.

