


Set Value Read (K3NR/K3NP/K3NC Communication/Comparative Output)

This set value read is effective only in models with RS-422/485 capability, T_R comparative output, and bank function, and special models with K3TR communication and comparative output. The set values (HH, H, L, and LL) of the banks not in use are read individually.


Refer to the following Note 2 for K3NC operands.

Command Format




Response Format

Response at normal end. End code: "00"



Response format when an error occurs:



End code when error occurs:

- In non-comparative output type: End code is "16" (without corresponding command).
- In comparative output type without corresponding set value: End code is "22" (without corresponding memory).

Note

1. Set value is expressed in five figures of ASCII. Negative sign is represented by "F" at the position of the X10⁴ digit.

2. The comparative operands for the K3TC are as follows:



- 0 5 ... Comparative set value data for OUT5
- 0 4 ... Comparative set value data for OUT4
- 0 3 ... Comparative set value data for OUT3
- 0 2 ... Comparative set value data for OUT2
- 0 1 ... Comparative set value data for OUT1