

SECTION 5

Operations in RUN Mode

This section provides instructions for operating the K3NR in RUN mode.

5-1	Displaying and Changing Setting Values	100
5-1-1	Displaying Setting Values	100
5-1-2	Changing Setting Values	100
5-2	Displaying and Resetting of Maximum and Minimum Values (Operating Modes F1 to F6)	103
5-2-1	Displaying Maximum and Minimum Values	103
5-2-2	Resetting Maximum and Minimum Values	103
5-3	External Input Signals	104
5-3-1	Bank Selection	104
5-3-2	RESET (Operating Modes F1 to F6)	104
5-3-3	RESET (Operating Mode F7)	105
5-3-4	HOLD (Operating Modes F1 to F6)	105
5-3-5	HOLD (Operating Mode F7)	106