

## Summary of Response Codes

Response code	Name	Meaning
"0000"	Normal completion	The command was completed properly.
"0401"	Undefined command	The command was incorrect.
"1002"	Command too short	Some required data was missing from the command.
"1003"	Number of elements/Data mismatch	An error occurred while writing data. The specified number of elements and amount of data didn't agree.
"1100"	Parameter error	The specified parameters(s) were incorrect.
"1101"	Area type error	The area type (memory/parameter) specification was incorrect.
"1103"	Starting address out-of-range error	The specified starting address was outside of the allowed range.
"1104"	End address out-of range error	The specified end address (starting address + number of elements) was outside of the allowed range.
"110B"	Response too long	The response exceeded the maximum response length (37 bytes).
"2203"	Operating error	Attempted to change a set value while in local mode. Attempted to change a setting other than a set value while in RUN mode. Execution wasn't possible because the startup compensation time function was being executed. (K3NX)
"3003"	Read-only data	Couldn't write data because the specified area is read-only.