

Operating Command

Text within the Command Frame

MRC	SRC	Command	
"30"	"05"	code	Sub-code
2 bytes	2 bytes	2 bytes	2 bytes

The following table shows the four command codes and the sub-codes for commands that require them.

Code	Command	Sub-code	
"10"	Reset maximum and minimum values.	None	
"11"	Forced-zero	"00": Clear forced-zero setting. "01": Execute (Invalid for the K3NR, K3NP, K3NC, and K3NH.)	
"12"	Remote/local programming	"00": Local Remote	"01":
"13"	Switch mode.	"00": RUN mode	"01": Setting mode

Response Text within the Response Frame

MRC	SRC	Response code	Command
"30"	"05"		code
2 bytes	2 bytes	4 bytes	2 bytes

1, 2, 3...

Response code

Response code	Meaning
"0000"	Normal completion
"1001"	Command too long
"1002"	Command too short
"1100"	Parameter error
"2203"	Operating error

Command code

The command code sent by the command is returned unchanged when the command was completed normally or an operating error occurred.