

5-2 Displaying and Resetting of Maximum and Minimum Values (Operating Modes F1 to F6)

The maximum and minimum values are refreshed automatically while the K3NR is in measurement operation.