


Set Value Read (K3NX/K3NV/K3NH Communication/Comparative Output)


This set value read is effective only in models with communication and comparative output. The set values (HH, H, L, and LL) are read individually.

Command Format




Response Format

Response at normal end. End code: "00"



Response format when an error occurs:



End code when error occurs:

- In non-comparative output type: End code is "16" (without corresponding command).
- In comparative output type without corresponding set value: End code is "22" (without corresponding memory).
- When set value is changed in RUN mode: End code is "0D" (not executable due to change of setting in RUN mode).

Note

Set value is expressed in five figures of ASCII. Negative sign is represented by "F" at the position of the X10⁴ digit.