

## BCD Programs

With the BCD output type, only the PV value (display value), maximum value, and minimum value can be read. The marks (+) and (–) correspond respectively to L polarity and H polarity. Read the read data after the DATA VALID signal rises.

Data cannot be written from the PC to the Processor.