

5-3-5 HOLD (Operating Mode F7)

- If HOLD input is ON, the counting value is on hold.
- The K3NR is in counting operation continuously while HOLD input is ON and comparative output and BCD data are available regardless of the HOLD input.
- The HOLD indicator is lit while HOLD input is ON.

