

## Displaying and Resetting of Maximum and Minimum Values

The maximum and minimum values are refreshed automatically while the K3NV is in measurement operation.