


## Changing Setting Values

- Setting values can be prohibited against change when key protect or setting value change prohibit is ON in protect mode.
- Select the setting value to be changed with the Mode Key.
- All digits will be displayed and ready for changing if the Shift Key is pressed.
- Press the Up and Shift Keys to change the displayed setting value. The input will be entered if nothing else is input within two seconds. The input is entered immediately by pressing the Mode Key.
- The next setting value will be displayed and ready for changing if the Mode Key is pressed. If nothing else is input within two seconds, the setting value will be entered and the previous setting value will be displayed.
- The setting value can be changed through communications if the K3NV is a model with a communications function.

## SETTING EXAMPLE

### Basic Model

Follow the steps below to change the H setting value from 600 to 700 while the process value is displayed in RUN mode.



1, 2, 3...

Press the Mode Key to display the HH setting value and to light the HH indicator of the SV display status indicators.



Press the Mode Key again to display the H setting value H and light the H indicator.



Press the Shift Key to display all the digits of the prior setting value 600 for changing.



Press the Up and Shift Keys to set the value to 00700.



The input will be entered if nothing else is input within five seconds.

or Press the Mode Key to display the L setting value for changing. The H setting value will appear again if nothing else is input within five seconds.



To return to the process value display, perform one of the following.

- Repeatedly press the Mode Key until the process value appears.
- Leave the K3NV with no key input for five seconds.



## SETTING EXAMPLE

### Set Value LED Display Model

Follow the steps below to change the H setting value from 600 to 700 while the process value is displayed in RUN mode, provided that the HH setting value is already displayed on the SV display.



1, 2, 3...

Press the Mode Key to display the H setting value and to light the H indicator of the SV display status indicators.



Press the Shift Key to display all the digits of the setting value 600 for changing.



Press the Up and Shift Keys to set the value to 00700.



The input will be entered if nothing else is input within five seconds.

or Press the Mode Key to display the L setting value for changing. The H setting value will appear again if nothing else is input within five seconds.

