

8-2 Display

8-2-1 Flashing

The display will flash in the following cases.

- The input or process value is not within the display range.

If the display flashes the output status will be as follows:

Models with BCD Output Board: The OVER signal will be ON.

Models with Communications Output Board: The OVER or UNDER signal will be ON and other output signals will be retained.

- The display will flash for three seconds if an attempt is made to change a setting on the K3NR. Set to remote programming to accept key input.