

TABLE OF CONTENTS

PRECAUTIONS
1 Intended Audience
2 General Precautions
3 Operating Environment Precautions
4 Application Precautions
SECTION 1	
Features and Ordering Information
1-1 Features
1-2 Ordering Information
SECTION 2	
Dimensions
2-1 ES1A-A
2-2 ES1A-B
2-3 ES1A-C
2-4 ES1A-J
SECTION 3	
Specifications
3-1 Ratings
3-2 Field-of-vision
3-3 Accuracy
SECTION 4	
Operation Principle
4-1 Operation Principle
4-2 Causes of Errors
SECTION 5	
Input Shift for Temperature Controller
5-1 Connection to E5CN or E5GN
5-2 Connection to Temperature Controller other than E5CN and E5GN
SECTION 6	
Mounting and Wiring
6-1 Mounting
6-2 Connections
6-3 Adjustments
6-4 Cleaning
6-5 Mounting the ES1A-J
SECTION 7	
Application Examples
7-1 Detection of Workpieces Conveyed Intermittently
7-2 Continuous Furnace (Thermal Treatment of Sheets)
7-3 Air Purge
7-4 Monitoring Hot-melt Adhesive Application
SECTION 8	
Troubleshooting
Appendix	
Radiation Rates
Revision History