

Maintenance Mode

- The K3NV will be in maintenance mode if the Mode and Shift Keys are pressed simultaneously while the K3NV is turned on.
- The K3NV in maintenance mode will go into RUN mode if the Escape Key is pressed.

