

SECTION 6

Useful Functions

This section provides information on the output test and maintenance mode functions of the K3NR.

6-1	Teaching Function	108
6-1-1	Set Value	108
6-1-2	Prescaling Value	109
6-1-3	Linear Output Range	111
6-2	Output Test	112
6-3	Maintenance Mode	113
6-3-1	Maintenance Mode	113
6-3-2	Initialization	113