

6-3-1 Maintenance Mode

- The K3NR will be in maintenance mode if the Mode and Shift Keys are pressed simultaneously while the K3NR is turned on.
- The K3NR in maintenance mode will go into RUN mode if the Escape Key is pressed.

