

Internode Echo Test

Text within the Command Frame

MRC	SRC	Test data
"08"	"01"	
2 bytes	2 bytes	20 bytes max.

The test data can be any arbitrary data (1 to 20 bytes), although the bytes of data must be within the following ranges:

20 to FF hexadecimal when the number of data bits is set to 8.

20 to 7F hexadecimal when the number of data bits is set to 7.

Note The test data isn't checked for out-of range values.

Response Text within the Response Frame

MRC	SRC	Response code	Test data
"08"	"01"		
2 bytes	2 bytes	4 bytes	20 bytes max.

1, 2, 3...

Response codes

Response code	Meaning
"0000"	Normal completion
"1001"	Command too long
"2203"	Operating error

Test data

The test data sent by the command is returned unchanged.