

5-3-4 HOLD (Operating Modes F1 to F6)

- The K3NR will stop the measurement if the HOLD input is ON.
- When the HOLD input is ON, the K3NR will retain the process value, output, and BCD data effective immediately before the HOLD input.
- The HOLD indicator is lit while HOLD input is ON.

