

# **Transparent Object Detection Sensor**

E3S-R

- Ideal for transparent bottle sensing.
- Senses glass wafers and LCD glass circuit boards.
- With a stability indicator for the highly sensitive sensing of plastic bottles and other transparent bottles.





# **Ordering Information**

# **Plastic-housing Compact Models**

Connection	Appearance	Sensing method	Sensing distance	Light source color	Operating modes	Model		Recommended application (see note 1)	
								Flat object	Cylindrical object
						NPN	PNP	Sensing of glass wafers and LCD glass circuit boards	Sensing of plastic bottles and other transparent bottles
Pre-wired Horizontal  Vertical	Horizontal	Retrore- flective 10 to 30 cm 0.1 to 1 m 10 to 30 cm		Infrared	Light-ON Dark-ON (selectable)	E3S-R12	E3S-R32	Ideal	Ideal
			0.1 to 1 m	Red		E3S-R11	E3S-R31	Ideal	
			Infrared		E3S-R62	E3S-R82	Ideal	Ideal	
			0.1 to 1 m	Red		E3S-R61	E3S-R81	Ideal	
Plug-in connector	Horizontal		10 to 30 cm	Infrared	Light-ON Dark-ON	E3S-R17	E3S-R37	Ideal	Ideal
(see note 2)			0.1 to 1 m	Red	(selectable)	E3S-R16	E3S-R36	Ideal	
	Vertical		10 to 30 cm	Infrared		E3S-R67	E3S-R87	Ideal	Ideal
			0.1 to 1 m	Red	1	E3S-R66	E3S-R86	Ideal	

Note: 1. The E3S-R may not easily sense some glass wafers due to their materials or plastic bottles due to their shapes. Before using the E3S-R for the sensing of glass wafers or plastic bottles, be sure to use test examples of the glass wafers or plastic bottles to check if the E3S-R senses the examples easily.

- 2. Refer to page 2 for the connection plugs used for the plug-in connector-type models.
- 3. Before using the product under conditions not described in the manual or applying the product to nuclear control systems, railroad systems, aviation systems, vehicles, combustion systems, medical equipment, amusement machines, safety equipment, and other systems, machines, and equipment that may have a serious influence on lives and property if used improperly, consult your OMRON representative. Make sure that the ratings and performance characteristics of the product are good enough for the systems, machines, and equipment, and be sure to provide the systems, machines, and equipment with double safety mechanisms.

# **Metal-housing Models**

Connection	Appearance	Sensing method	Sensing distance	Light source color	Operating modes	Model		ed application note 1)		
							Flat object	Cylindrical object		
							Sensing of glass wafers and LCD glass circuit boards	Sensing of plastic bottles and other transparent bottles		
Pre-wired	Horizontal	Retroreflec-	30 cm	Infrared	Light-ON	E3S-RS30E4		Ideal		
		tive	1 m				Dark-ON (selectable by wiring)	E3S-R1E4 E3S-R1B4		Applicable
	Vertical		30 cm			by willing)	E3S-RS30E42		Ideal	
			1 m			E3S-R1E42 E3S-R1B42		Applicable		

Note: The E3S-R may not easily sense some glass wafers due to their materials or plastic bottles due to their shapes. Before using the E3S-R for the sensing of glass wafers or plastic bottles, be sure to use test examples of the glass wafers or plastic bottles to check if the E3S-R senses the examples easily.


# ■ Accessories (Order Separately)

**Plugs (for Sensors with Connector Terminals)** 


Cord	Cord Appearance		Cord length	Model
Standard	Straight (3 conductor)		2 m	XS2F-D421-DC0-A
			5 m	XS2F-D421-GC0-A
	L-shape (3 conductor)		2 m	XS2F-D422-DC0-A
			5 m	XS2F-D422-GC0-A
Robot (vibration-proof)	Straight (4 conductor)		2 m	XS2F-D421-D80-R
			5 m	XS2F-D421-G80-R
	L-shape (4 conductor)		2 m	XS2F-D422-D80-R
			5 m	XS2F-D422-G80-R

# **Application Examples**

Sensing of Glass Wafers and LCD Glass Circuit Bottles



Sensing of Plastic Bottles and Other Transparent Bottles



# Specifications

Item	E3S-R12/-R62/ -R17/-R67/-R32/-R82/ -R37/-R87	E3S-R11/-R61/ -R16/-R66/-R31/-R81/ -R36/-R86	E3S-RS30E4/ -RS30E42	E3S-R1j 4/-R1j 42	
LED for emitter	Infrared LED	Red LED	Infrared LED		
Indicator	Light indicator (red), exce	ess gain indicator (green)	Light indicator (red)	Light indicator (red), sta- bility indicator (green)	
Sensitivity adjustment	Two-turn adjustor with an	indicator	One-turn adjustor		
Connection method	See note.		Pre-wired		
Materials	Case: Polybutylene terep Lens: Denatured polyally		Case: Zinc die-cast Lens: Polycarbonate		

Note: The E3S-R11/-R12/-R61/-R62/-R31/-R32/-R81/-R82 each have a pre-wired cord. The E3S-R16/-R17/-R66/-R67/-R36/-R37/-R86/-R87 each have a plug-in connector.

# ■ Ratings/Characteristics

lte	em	E3S-R12/-R62/ -R17/-R67	E3S-R11/-R61/ -R16/-R66	E3S-R32/-R82/ -R37/-R87	E3S-R31/-R81/ -R36/-R86	E3S-RS30E4/ -RS30E42	E3S-R1j 4/ -R1j 42		
Power sup	oply volt-	10 to 30 VDC; ripple:		12 to 24 VDC±10	,				
age			max.						
Current consump- tion		30 mA max.	40 mA max.						
Sensing d	listance	10 to 30 cm	0.1 to 1 m	10 to 30 cm	0.1 to 1 m	30 cm	1 m		
Sensing n	nethod	Retroreflective with polarized function Retroreflective with polarized function			Retroreflective				
Standard sensing object		0.7-mm-thick LCD glass boards; 10-mm-dia., 1.0-mm-thick, 30-mm-long cylindrical glass objects	0.7-mm-thick LCD glass boards	0.7-mm-thick LCD glass boards; 10-mm-dia., 1.0-mm-thick, 30-mm-long cy- lindrical glass objects	0.7-mm-thick LCD glass boards	10-mm-dia., 1.0-mm-thick, 30-mm-long cylindrical glass of jects			
Response	time	1 ms max. for both op							
Control output (no- contact output)		NPN open collector, 3 max.	0 VDC, 100 mA	PNP open collector, 30 VDC, 100 mA max.		Output current: 1.5 to 4 mA at 24 VDC; NPN output (with suffix -E): 80 mA PNP output (with suffix -B): 100 mA			
Ambi- ent illu- mina- tion	Incandes- cent lamp	5,000 ℓx max.				Illumination on o 3,000 ℓx max.	otical spot:		
	Sunlight	10,000 ℓx max.				Illumination on o 10,000 ℓx max.	otical spot:		
Ambient t	empera-	Operating: 0°C to 40°C		Operating: -25°C to 55°C (with no icing)					
Ambient h	numidity	Operating: 35% to 85%							
Insulation tance	resis-	20 M $Ω$ min. (at 500 VDC)							
Dielectric	strength	1,000 VAC, 50/60 Hz	for 1 min						
Vibration	resistance	Destruction: 10 to 55 Hz, 1.5-mm double amplitude for 2 h each in X, Y, and Z directions							
Shock res	istance	Destruction: 500 m/s <sup>2</sup> (approx. 50G) for 3 times each in X, Y, and Z directions							
Protection	1	Load short-circuit protence prevention	ection, reverse po	larity protection, m	nutual interfer-	Load short-circui mutual interferen			
Enclosure	rating	IEC: IP67							

Note: 1. The above sensing distances are possible when the E39-R1 Reflector is used. The E39-R1 Reflector is provided with the E3S-R.

2. Even though the excess gain indicator of the E3S-R is dimly lit during sensitivity adjustment of the E3S-R, the E3S-R will provide stable operation if the ambient temperature does not rise or fall by more than 5°C while the E3S-R is operating.

# ■ Characteristic Data (Reference Values)

# **Light Level Change Rates with Various Transparent Objects (See Note 1)**

The following are the permeation rates of a various transparent objects on condition that a permeation rate of 100 means that there is no object within the sensing distance of the E3S-R. The permeation rate of any type of object sensed by the E3S-R must be as low as possible for the stable sensing of the object. Before using the E3S-R to sense objects, use samples of the objects to check if the E3S-R can sense the samples easily.


Sensi	Sensing object		E3S-R11/-R61/-R16/ -R66/-R31/-R81/ -R36/-R86	<b>E3S-RS30</b> j j	E3S-R1j j
		Center	Center	Center	Center
Cylindrical glass	10-dia. x 30, t = 1.0	27		20	33
object	15-dia. x 30, t = 1.25	27		20	13
	20-dia. x 30, t = 1.7	22		28	13
	30-dia. x 30, t = 1.9	41		43	23
	100-dia. x 30, t = 2.5	58		55	50
	200-dia. x 30, t = 5.0	55		58	58
Glass plate	50 x 50, t = 0.5	82	91.5	78	
	50 x 50, t = 1	74	82.5	70	75
	50 x 50, t = 2	73	81	70	75
	50 x 50, t = 3	62	69	58	65
	50 x 50, t = 5	53	59	50	55
	50 x 50, t = 10	38	42	35	40
Liquid crystal glass	t = 0.5 (permeability of 98%) (see note 2)	86	96		
	t = 0.7 (permeability of 95%) (see note 2)	81	90		
	t = 1.1 (permeability of 91%) (see note 2)	75	83		
Operating range		95 max.	95 max.	90 max.	80 max.
Stable operating r	ange	90 max.	90 max.	70 max.	60 max.

Note: 1. The sensing distance of each model was set to the rated sensing distance.


2. The permeability values were checked with light with a wavelength of 700  $\mu m$ .

# **Engineering Data**


# Reflector Operating Range (Typical) E3S-R11/-R61/-R16/-R66/-R31/-R81/-R36/-R86




# E3S-R12/-R62/-R17/-R67/-R32/-R82/-R37/-R87



Excess Gain vs. Set Distance (Typical)
E3S-R11/-R61 /-R16/-R66/-R31/-R81/-R36/-R86 with E39-R1



E3S-R12/-R62/-R17/-R67/-R32/-R82/-R37/-R87




# Operation

# ■ Output Circuits E3S-R11/-R12/-R61/-R62/-R16/-R17/-R66/-R67

# Light indicator (Red) Stability indicator (Green) Main circuit Stability indicator (Felay) Black 10 to 30 VDC

# E3S-R31/-R32/-R81/-R82/-R36/-R37/-R86/-R87




# E3S-RS30E4/-RS30E42/-R1E4/-R1E42

Color of code	Polarity of power supply	Output configuration	Output circuit
Brown (see note 1)	+	Light-ON	Light in- Stability in- dicator (see note 1) 24 VDC (see note 1) 24 VDC
Blue (see note 1)	0 V		(Red) (Green) Load 1
Brown (see note 1)	0 V	Dark-ON	Main circuit Load 2 (See note 3)
Blue (see note 1)	+	1	Blue 1.5 to 4 mA (see note 1)

Note: 1. Reverse the polarity of the power supply to change the output mode.

- 2. The E3S-RS30E and E3S-RS30E42 do not have a stability indicator.
- 3. This load is needed when voltage output to connect a transistor circuit is required.

# E3S-Rj B4 (PNP Output)



# **■ Timing Charts**

# E3S-R11/-R12/-R61/-R62/-R16/-R17/-R66/-R67/-R31/-R32/-R81/-R82/-R36/-R37/-R86/-R87

Output transistor	Timing Charts
ON when light is received.	Light received Light not received  Light indicator ON (red) OFF  Output ON transistor OFF
	Load Operate (Between brown and black)
ON when light is not received.	Light received Light not received  Light indicator ON (Orange) OFF  Output ON transistor OFF
	Load Operate (Between brown and black)

# E3S-RS30E4/-RS30E42/-R1E4/-R1E42

Color of code	Polarity of power supply	Output transistor	Timing Charts
Brown (see note)	+	ON when light is received.	Light received Light not received Light indicator ON
			(red) OFF ——————————————————————————————————
Blue (see note)	0 V		transistor OFF
Dide (See Hote)	O V		Load Operate (Between brown and black)
			Output voltage H (Between blue and black)
Brown (see note)	0 V	ON when light is not received.	Light received Light not received
			Light indicator ON (red) OFF
			Output ON transistor OFF
Blue (see note)	+		Load Operate (Retween blue and black)
			Output voltage H (Between brown and black)


**Note:** Reverse the polarity of the power supply to change the output mode of the E3S-R.

# E3S-Rj B4 (PNP Output)

Output transistor	Timing Charts			
ON when light is received.	Light received Light not received  Light indicator ON (Orange) OFF  Output ON transistor OFF			
	Load Operate (Between brown and black)			
	Output voltage H (Between blue and black)			
ON when light is not received.	Light received Light not received			
	Light indicator ON (Orange) OFF			
	Output ON transistor OFF			
	Load Operate (Between blue and black)			
	Output voltage H (Between brown and black)			


# **Dimensions**

Note: All units are in millimeters unless otherwise indicated.




Type NPN output		E3S-R11	E3S-R12
	PNP output	E3S-R31	E3S-R32
Size	Α	42.3	40
	В	15.2	12.9

# E3S-R61/-R62/-R81/-R82




Туре	/pe NPN output		E3S-R62
	PNP output	E3S-R81	E3S-R82
Size	Α	23.3	21
	В	5.9	3.6
	С	31.5	29.2



Туре	NPN output E3S-R16		E3S-R17
	PNP output	E3S-R36	E3S-R37
Size	Α	42.3	40
	В	15.2	12.9

# E3S-R66/-R67/-R86/-R87



Туре	NPN output	E3S-R66	E3S-R67
	PNP output	E3S-R86	E3S-R87
Size	Α	23.3	21
	В	5.9	3.6
	С	31.5	29.2


# E3S-RS30E4/-R1j 4

Cord: Vinyl-insulated cord (4-mm dia.,

0.12-mm x 18, 3 cores) Standard length: 2 m

Weight: Approx. 165 g





---21.5-

# **Mounting Holes**

**Note:** The E3S-RS30E4 does not have a green stability indicator




# E3S-RS30E42/-R1j 42

Cord: Vinyl-insulated cord (4-mm dia.,

0.12-mm x 18, 3 cores) Standard length: 2 m

Weight: Approx. 165 g





Lens (10 x 15)

# **Mounting Holes**




Note: The E3S-RS30E42 does not have a green stability indicator.


# **■** Accessories

# E39-R1 Retroreflector (Attachment)






E39-G1 Sensitivity Adjustor Knob for the E3S-RS30Ej j and E3S-R1Ej j /-R1Bj j (Attachment)



E39-G2 Sensitivity Adjustor Knob for E3S-Rj j



# Connecting Method of the Sensitivity Adjustor Knob


Press the sensitivity adjusting knob so that the pointer of the sensitivity adjusting knob is in the direction shown in the illustration to connect the sensitivity adjusting knob to the E3S-R.


Make sure to connect the sensitivity adjusting knob correctly. It is impossible to remove the sensitivity adjusting knob from the E3S-R after it is connected to the E3S-R.



E39-L2 Special Mounting Bracket for the E3S-RS30Ej j and E3S-R1Ej j /-R1Bj j (Order Separately)








Mounting Holes



# E39-L69 Mounting Bracket for E3S-Rj $\,$ j Horizontal Type (Attachment)


# 


# E39-L70 Mounting Bracket for E3S-Rj j Vertical Type (Attachment)



E39-L60 Contact Mounting Plate for E3S-Rj j Plug-in Connector Type (Order Separately)










# ■ Accessories (Order Separately)










# Installation


# **■** Connections

If the brown and blue lead wires are connected in reverse, the output mode can be changed for the E3S-RS30Ej  $\,j$  and E3S-R1Ej  $\,j$  /-R1Bj  $\,j$  (Light-ON, Dark-ON).




# With S3D2 Sensor Controller

The E3S-R will operate in reverse using the signal input selector of the S3D2.




# ■ Plug (for E3S-R with Connector)

# **Internal Connection**



Item	Color of cord	Coonection pin No.	Application
For DC	Brown	1	Power supply (+V)
	Black	4	Output
	Blue	3	Power supply (0 V)
		2	No connection

# **External Connections**



# **Precautions**

# **Definitions of Precautionary Information**

• DANGER! Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury. Limited to most extreme situa-



<u>∕!</u> WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



/ Caution

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. May also be used to alert against unsafe practices and property damage-only accidents.




# /!\ WARNING

Item	Examples
Power supply  Do not impose an excessive voltage on the E3S-R, otherwise it may explode or burn. Do not impose 100 VAC on any E3S-R DC model, otherwise it may explode or burn.	Sensor Black Incorrect
Load short-circuit  Do not short-circuit the load, or the E3S-R may explode or burn.  The E3S-R's short-circuit protection function is valid if the polarity of the supply voltage imposed is correct and within the rated voltage range.	Sensor Black Incorrect
Wiring  Be sure to wire the E3S-R and load correctly, otherwise it may explode or burn.	Sensor Black Incorrect
Connection with no load  Make sure to connect a proper load to the E3S-R in operation, otherwise it may explode or burn.	Brown 12 to 24 VDC Load Incorrect Black 0 V

# Adjustment

When the E3S-R senses a cylindrical object, the amount of light received varies with the direction of the cylindrical object. To prevent this, locate the E3S-R as shown in the following illustration.



When the E3S-R senses an uneven plastic container or glass bottle, the amount of light received varies with the direction and sensing part of the plastic container or glass bottle. To prevent this, turn a sample of the plastic container or glass bottle to the best sensing position of the E3S-R to find and decide the optimum direction and sensing part, and then make the sensitivity adjustment.

In principle, sensing objects must pass through the center between the E3S-R and the reflector. Sensing objects must not be too close to the reflector, otherwise sensing errors may result.

### Installation

### **Power Reset Time**

The Photoelectric Sensor is ready to operate within 100 ms after power is supplied. If power supplies are connected to the Photoelectric Sensor and load respectively, be sure to supply power to the Photoelectric Sensor before supplying power to the load.

### **Power OFF**

The Photoelectric Sensor may output a pulse signal when it is turned off. Therefore, it is recommended to turn off the load before turning off the Photoelectric Sensor.

### **Types of Power Supplies**

The Photoelectric Sensor must not be connected to a non-smoothed, all-wave or half-wave rectified power supply.

# Wiring

### Cord

The cord can be extended up to  $100\,\mathrm{m}$  provided that the thickness of the cord is  $0.3\,\mathrm{mm}^2$  maximum.

### Repeated Bending

The cable must not be bent repeatedly.

### **High-tension Lines**

The power supply lines of the Photoelectric Sensor must not be wired alongside power lines or high-tension lines in the same conduit, otherwise the Photoelectric Sensor may become damaged or malfunction due to induction noise that may be generated from the power lines or high-tension lines.

### **Cord Tractive Force**

Do not pull cords with the tractive forces exceeding the following.

Diameter	Tractive force	
4 dia. max.	30 N max.	
4 dia. min.	50 N max.	

**Note:** Do not impose tensile stress on any shielded wire or coaxial cable.

### **Unused Lead Wired**

Cut any unused lead wire of the Photoelectric Sensor, such as a lead wire for self-diagnostic output, and insulate the lead wire with insulating tape so that the wire will not touch any terminal of the Photoelectric Sensor.

E3S-R ————	OMRON	EAC D
L33-N -		

# ALL DIMENSIONS SHOWN ARE IN MILLIMETERS.

To convert millimeters into inches, multiply by 0.03937. To convert grams into ounces, multiply by 0.03527.

Cat. No. E009-E1-7 In the interest of product improvement, specifications are subject to change without notice.

OMRON Corporation
Systems Components Division H.Q.
28th Fl., Crystal Tower Bldg.
1-2-27, Shiromi, Chuo-ku, Osaka 540 Japan

Phone: 06-949-6012 Fax: 06-949-6021

Printed in Japan 0696-2M (0795) a